



Service Manual

(Serial No. 290000001 and Above)

Groundsmaster[®] 4000-D

Preface

The purpose of this publication is to provide the service technician with information for troubleshooting, testing and repair of major systems and components on the Groundsmaster 4000-D.

REFER TO THE TRACTION UNIT AND CUTTING UNIT OPERATOR'S MANUALS FOR OPERATING, MAINTENANCE AND ADJUSTMENT INSTRUCTIONS. Space is provided in Chapter 2 of this book to insert the Operator's Manuals and Parts Catalogs for your machine. Replacement Operator's Manuals and Parts Catalogs are available on the internet at www.Toro.com or by sending complete Model and Serial Number to:

The Toro Company
Attn. Technical Publications
8111 Lyndale Avenue South
Bloomington, MN 55420-1196

The Toro Company reserves the right to change product specifications or this publication without notice.



This safety symbol means DANGER, WARNING, or CAUTION, PERSONAL SAFETY INSTRUCTION. When you see this symbol, carefully read the instructions that follow. Failure to obey the instructions may result in personal injury.

NOTE: A **NOTE** will give general information about the correct operation, maintenance, service, testing or repair of the machine.

IMPORTANT: The **IMPORTANT** notice will give important instructions which must be followed to prevent damage to systems or components on the machine.



This page is intentionally blank.

Table Of Contents

Chapter 1 – Safety

General Safety Instructions 1 – 2
Jacking Instructions 1 – 4
Safety and Instruction Decals 1 – 5

Chapter 2 – Product Records and Maintenance

Product Records 2 – 1
Maintenance 2 – 1
Equivalents and Conversions 2 – 2
Torque Specifications 2 – 3

Chapter 3 – Kubota Diesel Engine

General Information 3 – 2
Specifications 3 – 3
Service and Repairs 3 – 4
KUBOTA WORKSHOP MANUAL, DIESEL ENGINE,
V2403–M–T–E3B SERIES

Chapter 4 – Hydraulic System

Specifications 4 – 2
General Information 4 – 3
Hydraulic Schematic 4 – 8
Hydraulic Flow Diagrams 4 – 9
Special Tools 4 – 19
Troubleshooting 4 – 21
Testing 4 – 24
Adjustments 4 – 49
Service and Repairs 4 – 51

Chapter 5 – Electrical System

Electrical Drawings 5 – 2
Special Tools 5 – 3
Troubleshooting 5 – 5
Electrical System Quick Checks 5 – 8
Component Testing 5 – 9
Service and Repairs 5 – 30

Chapter 6 – Axles, Planetaries and Brakes

Specifications 6 – 2
Adjustments 6 – 3
Service and Repairs 6 – 4

Chapter 7 – Chassis

Service and Repairs 7 – 2

Chapter 8 – Cutting Units

Specifications 8 – 2
Troubleshooting 8 – 3
Adjustments 8 – 4
Service and Repairs 8 – 6

Chapter 9 – Foldout Drawings

Hydraulic Schematic 9 – 3
Electrical Schematic 9 – 4
Wire Harness Drawings 9 – 6

Safety
Product Records and Maintenance
Kubota Diesel Engine
Hydraulic System
Electrical System
Axles, Planetaries and Brakes
Chassis
Cutting Units
Foldout Drawings

This page is intentionally blank.



Chapter 1

Safety

Safety

Table of Contents

GENERAL SAFETY INSTRUCTIONS 2

 Before Operating 2

 While Operating 2

 Maintenance and Service 3

JACKING INSTRUCTIONS 4

SAFETY AND INSTRUCTION DECALS 5

General Safety Instructions

The GROUNDSMASTER 4000-D was tested and certified by TORO for compliance with the B71.4-1999 specifications of the American National Standards Institute. Although hazard control and accident prevention partially are dependent upon the design and configuration of the machine, these factors are also dependent upon the awareness, concern, and proper training of the personnel involved in the operation, transport, maintenance, and storage of the machine. Improper use or maintenance of the machine can result in injury or

death. To reduce the potential for injury or death, comply with the following safety instructions.



WARNING

To reduce the potential for injury or death, comply with the following safety instructions.

Before Operating

1. Read and understand the contents of the Operator's Manual before starting and operating the machine. Become familiar with the controls and know how to stop the machine and engine quickly. A replacement Operator's Manual is available on the Internet at www.Toro.com or by sending the complete model and serial number to:

The Toro Company
Attn. Technical Publications
8111 Lyndale Avenue South
Bloomington, Minnesota 55420-1196

2. Keep all shields, safety devices, and decals in place. If a shield, safety device, or decal is defective, illegible or damaged, repair or replace it before operating the machine. Also tighten any loose nuts, bolts or screws to ensure machine is in safe operating condition.

3. Assure interlock switches are adjusted correctly so engine cannot be started unless traction pedal is in NEUTRAL and cutting units are DISENGAGED.

4. Since diesel fuel is highly flammable, handle it carefully:

- A. Use an approved fuel container.
- B. Do not remove fuel tank cap while engine is hot or running.
- C. Do not smoke while handling fuel.
- D. Fill fuel tank outdoors and only to within an inch of the top of the tank, not the filler neck. Do not overfill.
- E. Wipe up any spilled fuel.

While Operating

1. Sit on the seat when starting and operating the machine.

2. Before starting the engine:

- A. Engage the parking brake.
- B. Make sure traction pedal is in neutral and the PTO switch is OFF (disengaged).
- C. After engine is started, release parking brake and keep foot off traction pedal. Machine must not move. If movement is evident, the traction pedal linkage is adjusted incorrectly; therefore, shut engine off and adjust until machine does not move when traction pedal is released.

3. Do not run engine in a confined area without adequate ventilation. Exhaust fumes are hazardous and could possibly be deadly.

4. Do not touch engine, muffler or exhaust pipe while engine is running or soon after it is stopped. These areas could be hot enough to cause burns.

5. Before getting off the seat:

- A. Ensure that traction pedal is in neutral.
- B. Set parking brake.
- C. Disengage cutting units and wait for blades to stop.
- D. Stop engine and remove key from switch.
- E. Toro recommends that anytime the machine is parked (short or long term), the cutting units should be lowered to the ground. This relieves pressure from the lift circuit and eliminates the risk of cutting units accidentally lowering to the ground.
- F. Do not park on slopes unless wheels are chocked or blocked.

Maintenance and Service

1. Before servicing or making adjustments, lower decks, stop engine, set parking brake, and remove key from the switch.
2. Make sure machine is in safe operating condition by keeping all nuts, bolts and screws tight.
3. Never store the machine or fuel container inside where there is an open flame, such as near a water heater or furnace.
4. Make sure all hydraulic line connectors are tight, and all hydraulic hoses and lines are in good condition before applying pressure to the system.
5. Keep body and hands away from pin hole leaks in hydraulic lines that eject high pressure hydraulic fluid. Use cardboard or paper to find hydraulic leaks. Hydraulic fluid escaping under pressure can penetrate skin and cause injury. Fluid accidentally injected into the skin must be surgically removed within a few hours by a doctor familiar with this form of injury or gangrene may result.
6. Before disconnecting or performing any work on the hydraulic system, all pressure in system must be relieved by stopping engine and lowering cutting units to the ground.
7. If major repairs are ever needed or assistance is desired, contact an Authorized Toro Distributor.
8. To reduce potential fire hazard, keep engine area free of excessive grease, grass, leaves and dirt. Clean protective screen on machine frequently.
9. If engine must be running to perform maintenance or an adjustment, keep hands, feet, clothing and other parts of the body away from cutting units and other moving parts. Keep bystanders away.
10. Do not overspeed the engine by changing governor setting. To assure safety and accuracy, check maximum engine speed.
11. Shut engine off before checking or adding oil to the crankcase.
12. Disconnect battery before servicing the machine. Disconnect negative cable first and positive cable last. If battery voltage is required for troubleshooting or test procedures, temporarily connect the battery. Reconnect positive cable first and negative cable last.
13. Battery acid is poisonous and can cause burns. Avoid contact with skin, eyes, and clothing. Protect your face, eyes, and clothing when working with a battery.
14. Battery gases can explode. Keep cigarettes, sparks, and flames away from the battery.
15. At the time of manufacture, the machine conformed to the safety standards for riding mowers. To assure optimum performance and continued safety certification of the machine, use genuine Toro replacement parts and accessories. Replacement parts and accessories made by other manufacturers may result in non-conformance with the safety standards, and the warranty may be voided.
16. When changing attachments, tires, or performing other service, use correct blocks, hoists, and jacks. Make sure machine is parked on a solid level surface such as a concrete floor. Prior to raising the machine, remove any attachments that may interfere with the safe and proper raising of the machine. Always chock or block wheels. Use jack stands or solid wood blocks to support the raised machine. If the machine is not properly supported by blocks or jack stands, the machine may move or fall, which may result in personal injury (see Jacking Instructions).

Jacking Instructions



CAUTION

When changing attachments, tires or performing other service, use correct jacks and supports. Make sure machine is parked on a solid, level surface such as a concrete floor. Prior to raising machine, remove any attachments that may interfere with the safe and proper raising of the machine. Always chock or block wheels. Use jack stands to support the raised machine. If the machine is not properly supported by jack stands, the machine may move or fall, which may result in personal injury.

Jacking the Front End (Fig. 1)

1. Set parking brake and chock both rear tires to prevent the machine from moving.
2. Position jack securely under the frame, just to the inside of the front tire.
3. Position jack stands or hardwood blocks under the frame as close to the wheels as possible to support the machine.

Jacking the Rear End (Fig. 2)

1. Place jack securely under the center of rear axle.
2. Chock both front tires. Jack rear of machine off the ground.
3. Use jack stands or blocks under the axle to support the machine.




Figure 1

1. Frame jacking point 2. Front tire




Figure 2

1. Rear axle jacking point 2. Rear tire

Safety and Instruction Decals

Numerous safety and instruction decals are affixed to the Groundsmaster 4000–D. If any decal becomes illegible or damaged, install a new decal. Part numbers are listed in your Parts Catalog.

This page is intentionally blank.



Product Records and Maintenance

Table of Contents

PRODUCT RECORDS 1

MAINTENANCE 1

EQUIVALENTS AND CONVERSIONS 2

 Decimal and Millimeter Equivalents 2

 U.S. to Metric Conversions 2

TORQUE SPECIFICATIONS 3

 Fastener Identification 3

 Standard Torque for Dry, Zinc Plated, and
 Steel Fasteners (Inch Series) 4

 Standard Torque for Dry, Zinc Plated, and
 Steel Fasteners (Metric) 5

 Other Torque Specifications 6

 Conversion Factors 6

Product Records

Insert Operator’s Manuals and Parts Catalogs for your Groundsmaster at the end of this chapter. Additionally, if any optional equipment or accessories have been installed to your machine, insert the Installation Instructions, Operator’s Manuals and Parts Catalogs for those options at the end of this chapter.

Maintenance

Maintenance procedures and recommended service intervals for your Groundsmaster are covered in the Traction Unit and Cutting Unit Operator’s Manuals. Refer to those publications when performing regular equipment maintenance.

Product Records
and Maintenance

PRELIMINARY – For Toro Distributor and Toro Company use only.

Equivalents and Conversions

Decimal and Millimeter Equivalents

Fractions	Decimals	mm	Fractions	Decimals	mm		
	1/64	0.015625	— 0.397	33/64	0.515625	— 13.097	
	1/32	0.03125	— 0.794	17/32	0.53125	— 13.494	
	3/64	0.046875	— 1.191	35/64	0.546875	— 13.891	
1/16	—	0.0625	— 1.588	9/16	—	0.5625	— 14.288
	5/64	0.078125	— 1.984	37/64	0.578125	— 14.684	
	3/32	0.09375	— 2.381	19/32	—	0.59375	— 15.081
	7/64	0.109275	— 2.778	39/64	0.609375	— 15.478	
1/8	—	0.1250	— 3.175	5/8	—	0.6250	— 15.875
	9/64	0.140625	— 3.572	41/64	0.640625	— 16.272	
	5/32	0.15625	— 3.969	21/32	—	0.65625	— 16.669
	11/64	0.171875	— 4.366	43/64	0.671875	— 17.066	
3/16	—	0.1875	— 4.762	11/16	—	0.6875	— 17.462
	13/64	0.203125	— 5.159	45/64	0.703125	— 17.859	
	7/32	0.21875	— 5.556	23/32	—	0.71875	— 18.256
	15/64	0.234375	— 5.953	47/64	0.734375	— 18.653	
1/4	—	0.2500	— 6.350	3/4	—	0.7500	— 19.050
	17/64	0.265625	— 6.747	49/64	0.765625	— 19.447	
	9/32	0.28125	— 7.144	25/32	—	0.78125	— 19.844
	19/64	0.296875	— 7.541	51/64	0.796875	— 20.241	
5/16	—	0.3125	— 7.938	13/16	—	0.8125	— 20.638
	21/64	0.328125	— 8.334	53/64	0.828125	— 21.034	
	11/32	0.34375	— 8.731	27/32	—	0.84375	— 21.431
	23/64	0.359375	— 9.128	55/64	0.859375	— 21.828	
3/8	—	0.3750	— 9.525	7/8	—	0.8750	— 22.225
	25/64	0.390625	— 9.922	57/64	0.890625	— 22.622	
	13/32	0.40625	— 10.319	29/32	—	0.90625	— 23.019
	27/64	0.421875	— 10.716	59/64	0.921875	— 23.416	
7/16	—	0.4375	— 11.112	15/16	—	0.9375	— 23.812
	29/64	0.453125	— 11.509	61/64	0.953125	— 24.209	
	15/32	0.46875	— 11.906	31/32	—	0.96875	— 24.606
	31/64	0.484375	— 12.303	63/64	0.984375	— 25.003	
1/2	—	0.5000	— 12.700	1	—	1.000	— 25.400
1 mm = 0.03937 in.			0.001 in. = 0.0254 mm				

U.S.to Metric Conversions

	To Convert	Into	Multiply By
Linear Measurement	Miles	Kilometers	1.609
	Yards	Meters	0.9144
	Feet	Meters	0.3048
	Feet	Centimeters	30.48
	Inches	Meters	0.0254
	Inches	Centimeters	2.54
	Inches	Millimeters	25.4
Area	Square Miles	Square Kilometers	2.59
	Square Feet	Square Meters	0.0929
	Square Inches	Square Centimeters	6.452
	Acre	Hectare	0.4047
Volume	Cubic Yards	Cubic Meters	0.7646
	Cubic Feet	Cubic Meters	0.02832
	Cubic Inches	Cubic Centimeters	16.39
Weight	Tons (Short)	Metric Tons	0.9078
	Pounds	Kilograms	0.4536
	Ounces (Avdp.)	Grams	28.3495
Pressure	Pounds/Sq. In.	Kilopascal	6.895
	Pounds/Sq. In.	Bar	0.069
Work	Foot-pounds	Newton-Meters	1.356
	Foot-pounds	Kilogram-Meters	0.1383
	Inch-pounds	Kilogram-Centimeters	1.152144
Liquid Volume	Quarts	Liters	0.9463
	Gallons	Liters	3.785
Liquid Flow	Gallons/Minute	Liters/Minute	3.785
Temperature	Fahrenheit	Celsius	1. Subtract 32°
			2. Multiply by 5/9

Torque Specifications

Recommended fastener torque values are listed in the following tables. For critical applications, as determined by Toro, either the recommended torque or a torque that is unique to the application is clearly identified and specified in this Service Manual.

These Torque Specifications for the installation and tightening of fasteners shall apply to all fasteners which do not have a specific requirement identified in this Service Manual. The following factors shall be considered when applying torque: cleanliness of the fastener, use of a thread sealant (e.g. Loctite), degree of lubrication on the fastener, presence of a prevailing torque feature (e.g. Nylock nut), hardness of the surface underneath the fastener's head or similar condition which affects the installation.

As noted in the following tables, torque values should be **reduced by 25% for lubricated fasteners** to achieve the similar stress as a dry fastener. Torque values may also have to be reduced when the fastener is threaded into aluminum or brass. The specific torque value should be determined based on the aluminum or brass material strength, fastener size, length of thread engagement, etc.

The standard method of verifying torque shall be performed by marking a line on the fastener (head or nut) and mating part, then back off fastener 1/4 of a turn. Measure the torque required to tighten the fastener until the lines match up.

Product Records
and Maintenance

Fastener Identification




Figure 1




Figure 2

Standard Torque for Dry, Zinc Plated and Steel Fasteners (Inch Series)

Thread Size	Grade 1, 5 & 8 with Thin Height Nuts	SAE Grade 1 Bolts, Screws, Studs & Sems with Regular Height Nuts (SAE J995 Grade 2 or Stronger Nuts)		SAE Grade 5 Bolts, Screws, Studs & Sems with Regular Height Nuts (SAE J995 Grade 2 or Stronger Nuts)		SAE Grade 8 Bolts, Screws, Studs & Sems with Regular Height Nuts (SAE J995 Grade 5 or Stronger Nuts)	
	in-lb	in-lb	N-cm	in-lb	N-cm	in-lb	N-cm
# 6 – 32 UNC	10 ± 2	13 ± 2	147 ± 23	15 ± 2	169 ± 23	23 ± 3	262 ± 34
# 6 – 40 UNF				17 ± 2	192 ± 23	25 ± 3	282 ± 34
# 8 – 32 UNC	13 ± 2	25 ± 5	282 ± 56	29 ± 3	328 ± 34	41 ± 5	463 ± 56
# 8 – 36 UNF				31 ± 4	350 ± 45	43 ± 5	486 ± 56
# 10 – 24 UNC	18 ± 2	30 ± 5	339 ± 56	42 ± 5	475 ± 56	60 ± 6	678 ± 68
# 10 – 32 UNF				48 ± 5	542 ± 56	68 ± 7	768 ± 79
1/4 – 20 UNC	48 ± 7	53 ± 7	599 ± 79	100 ± 10	1130 ± 113	140 ± 15	1582 ± 169
1/4 – 28 UNF	53 ± 7	65 ± 10	734 ± 113	115 ± 12	1299 ± 136	160 ± 17	1808 ± 192
5/16 – 18 UNC	115 ± 15	105 ± 15	1186 ± 169	200 ± 25	2260 ± 282	300 ± 30	3390 ± 339
5/16 – 24 UNF	138 ± 17	128 ± 17	1446 ± 192	225 ± 25	2542 ± 282	325 ± 33	3672 ± 373
	ft-lb	ft-lb	N-m	ft-lb	N-m	ft-lb	N-m
3/8 – 16 UNC	16 ± 2	16 ± 2	22 ± 3	30 ± 3	41 ± 4	43 ± 5	58 ± 7
3/8 – 24 UNF	17 ± 2	18 ± 2	24 ± 3	35 ± 4	47 ± 5	50 ± 6	68 ± 8
7/16 – 14 UNC	27 ± 3	27 ± 3	37 ± 4	50 ± 5	68 ± 7	70 ± 7	95 ± 9
7/16 – 20 UNF	29 ± 3	29 ± 3	39 ± 4	55 ± 6	75 ± 8	77 ± 8	104 ± 11
1/2 – 13 UNC	30 ± 3	48 ± 7	65 ± 9	75 ± 8	102 ± 11	105 ± 11	142 ± 15
1/2 – 20 UNF	32 ± 4	53 ± 7	72 ± 9	85 ± 9	115 ± 12	120 ± 12	163 ± 16
5/8 – 11 UNC	65 ± 10	88 ± 12	119 ± 16	150 ± 15	203 ± 20	210 ± 21	285 ± 28
5/8 – 18 UNF	75 ± 10	95 ± 15	129 ± 20	170 ± 18	230 ± 24	240 ± 24	325 ± 33
3/4 – 10 UNC	93 ± 12	140 ± 20	190 ± 27	265 ± 27	359 ± 37	375 ± 38	508 ± 52
3/4 – 16 UNF	115 ± 15	165 ± 25	224 ± 34	300 ± 30	407 ± 41	420 ± 43	569 ± 58
7/8 – 9 UNC	140 ± 20	225 ± 25	305 ± 34	430 ± 45	583 ± 61	600 ± 60	813 ± 81
7/8 – 14 UNF	155 ± 25	260 ± 30	353 ± 41	475 ± 48	644 ± 65	667 ± 66	904 ± 89

NOTE: Reduce torque values listed in the table above by 25% for lubricated fasteners. Lubricated fasteners are defined as threads coated with a lubricant such as engine oil or thread sealant such as Loctite.

NOTE: Torque values may have to be reduced when installing fasteners into threaded aluminum or brass. The specific torque value should be determined based on the fastener size, the aluminum or base material strength, length of thread engagement, etc.

NOTE: The nominal torque values listed above for Grade 5 and 8 fasteners are based on 75% of the minimum proof load specified in SAE J429. The tolerance is approximately ± 10% of the nominal torque value. Thin height nuts include jam nuts.

Standard Torque for Dry, Zinc Plated and Steel Fasteners (Metric Series)

Thread Size	Class 8.8 Bolts, Screws and Studs with Regular Height Nuts (Class 8 or Stronger Nuts)		Class 10.9 Bolts, Screws and Studs with Regular Height Nuts (Class 10 or Stronger Nuts)	
M5 X 0.8	57 ± 6 in-lb	644 ± 68 N-cm	78 ± 8 in-lb	881 ± 90 N-cm
M6 X 1.0	96 ± 10 in-lb	1085 ± 113 N-cm	133 ± 14 in-lb	1503 ± 158 N-cm
M8 X 1.25	19 ± 2 ft-lb	26 ± 3 N-m	28 ± 3 ft-lb	38 ± 4 N-m
M10 X 1.5	38 ± 4 ft-lb	52 ± 5 N-m	54 ± 6 ft-lb	73 ± 8 N-m
M12 X 1.75	66 ± 7 ft-lb	90 ± 10 N-m	93 ± 10 ft-lb	126 ± 14 N-m
M16 X 2.0	166 ± 17 ft-lb	225 ± 23 N-m	229 ± 23 ft-lb	310 ± 31 N-m
M20 X 2.5	325 ± 33 ft-lb	440 ± 45 N-m	450 ± 46 ft-lb	610 ± 62 N-m

Product Records
and Maintenance

NOTE: Reduce torque values listed in the table above by 25% for lubricated fasteners. Lubricated fasteners are defined as threads coated with a lubricant such as engine oil or thread sealant such as Loctite.

NOTE: The nominal torque values listed above are based on 75% of the minimum proof load specified in SAE J1199. The tolerance is approximately ± 10% of the nominal torque value.

NOTE: Torque values may have to be reduced when installing fasteners into threaded aluminum or brass. The specific torque value should be determined based on the fastener size, the aluminum or base material strength, length of thread engagement, etc.

Other Torque Specifications

SAE Grade 8 Steel Set Screws

Thread Size	Recommended Torque	
	Square Head	Hex Socket
1/4 – 20 UNC	140 ± 20 in-lb	73 ± 12 in-lb
5/16 – 18 UNC	215 ± 35 in-lb	145 ± 20 in-lb
3/8 – 16 UNC	35 ± 10 ft-lb	18 ± 3 ft-lb
1/2 – 13 UNC	75 ± 15 ft-lb	50 ± 10 ft-lb

Wheel Bolts and Lug Nuts

Thread Size	Recommended Torque**	
7/16 – 20 UNF Grade 5	65 ± 10 ft-lb	88 ± 14 N-m
1/2 – 20 UNF Grade 5	80 ± 10 ft-lb	108 ± 14 N-m
M12 X 1.25 Class 8.8	80 ± 10 ft-lb	108 ± 14 N-m
M12 X 1.5 Class 8.8	80 ± 10 ft-lb	108 ± 14 N-m

** For steel wheels and non-lubricated fasteners.

Thread Cutting Screws (Zinc Plated Steel)

Type 1, Type 23 or Type F	
Thread Size	Baseline Torque*
No. 6 – 32 UNC	20 ± 5 in-lb
No. 8 – 32 UNC	30 ± 5 in-lb
No. 10 – 24 UNC	38 ± 7 in-lb
1/4 – 20 UNC	85 ± 15 in-lb
5/16 – 18 UNC	110 ± 20 in-lb
3/8 – 16 UNC	200 ± 100 in-lb

Thread Cutting Screws (Zinc Plated Steel)

Thread Size	Threads per Inch		Baseline Torque*
	Type A	Type B	
No. 6	18	20	20 ± 5 in-lb
No. 8	15	18	30 ± 5 in-lb
No. 10	12	16	38 ± 7 in-lb
No. 12	11	14	85 ± 15 in-lb

* Hole size, material strength, material thickness and finish must be considered when determining specific torque values. All torque values are based on non-lubricated fasteners.

Conversion Factors

$$\text{in-lb} \times 11.2985 = \text{N-cm}$$

$$\text{ft-lb} \times 1.3558 = \text{N-m}$$

$$\text{N-cm} \times 0.08851 = \text{in-lb}$$

$$\text{N-m} \times 0.7376 = \text{ft-lb}$$



Kubota Diesel Engine

Table of Contents

GENERAL INFORMATION 2

 Traction Unit Operator’s Manual 2

 Stopping the Engine 2

SPECIFICATIONS 3

SERVICE AND REPAIRS 4

 Air Filter System 4

 Exhaust System 6

 Fuel System 8

 Check Fuel Lines and Connections 9

 Drain and Clean Fuel Tank 9

 Fuel Tank Removal 9

 Fuel Tank Installation 9

 Radiator 10

 Engine 12

 Engine Removal 13

 Engine Installation 14

 Spring Coupler 16

KUBOTA WORKSHOP MANUAL, DIESEL ENGINE,
V2403–M–T–E3B SERIES

Kubota
Diesel Engine

General Information

This Chapter gives information about specifications and repair of the diesel engine used in the Groundsmaster 4000–D.

General maintenance procedures are described in your Operator's Manual. Information on engine troubleshooting, testing, disassembly and reassembly is identified in the Kubota Workshop Manual, Diesel Engine, V2403–M–T–E3B that is included at the end of this section.

Most repairs and adjustments require tools which are commonly available in many service shops. Special

tools are described in the Kubota Workshop Manual, Diesel Engine, V2403–M–T–E3B. The use of some specialized test equipment is explained. However, the cost of the test equipment and the specialized nature of some repairs may dictate that the work be done at an engine repair facility.

Service and repair parts for Kubota engines are supplied through your Authorized Toro Distributor. If no parts list is available, be prepared to provide your distributor with the Toro model and serial number.

Operator's Manual

The Operator's Manual provides information regarding the operation, general maintenance and maintenance intervals for your Groundsmaster machine. Refer to that publication for additional information when servicing the machine.

Stopping the Engine

IMPORTANT: Before stopping the engine after mowing or full load operation, cool the turbo-charger by allowing the engine to run at low idle speed for 5 minutes. Failure to do so may lead to turbo-charger trouble.

Specifications

Item	Description
Make / Designation	Kubota Model V2403-M-T-E3B: 4-Cycle, 4 Cylinder, Water Cooled, Turbocharged, Diesel Engine
Bore	3.43" (87.0 mm)
Stroke	4.031" (102.4 mm)
Total Displacement	148.5 in ³ (2434 cc)
Firing Order	1-3-4-2
Combustion Chamber	Spherical Type (E-TVCS)
Fuel	Diesel or Biodiesel (up to B20) Fuel with Low or Ultra Low Sulfur Content
Fuel Capacity	19.0 U.S. Gallons (72 Liters)
Fuel Injection Pump	Denso PFR 4M Type Mini Pump
Governor	Centrifugal Mechanical
Low Idle (no load)	1425 ± 50 RPM
High Idle (no load)	2870 + 50/-120 RPM
Direction of Rotation	Counterclockwise (Viewed from Flywheel)
Compression Ratio	23.0:1
Injection Nozzle	Denso OPD Mini Nozzle
Engine Oil	API CH-4, CI-4 or higher
Engine Oil Viscosity	See Operator's Manual
Oil Pump	Trochoid Type
Crankcase Oil Capacity	10.0 U.S. Quarts (9.5 Liters) with Filter
Starter	12 VDC, 2.0 kW
Alternator/Regulator	12 VDC, 480 Watt
Coolant Capacity	13 U.S. Quarts (12.3 Liters)
Engine Dry Weight	419 U.S. Pounds (190 Kg)

Service and Repairs

Air Filter System




Figure 3

- 1. Air cleaner hose
- 2. Hose clamp
- 3. Air cleaner assembly
- 4. Indicator

- 5. Air cleaner strap
- 6. Lock nut
- 7. Hose clamp
- 8. Air cleaner hose

- 9. Hose clamp
- 10. Cap screw
- 11. Flat washer

PRELIMINARY – For Toro Distributor and Toro Company use only.

Removal

1. Remove air cleaner components as needed using Figure 3 as a guide.

Installation

IMPORTANT: Any leaks in the air filter system will cause serious engine damage. Make sure daily that all air cleaner components are in good condition and are properly secured during reassembly.

1. Reassemble air cleaner system using Figure 3 as a guide.
2. When installing air cleaner hose (8) between air cleaner and turbo-charger (Fig. 4):
 - A. Make sure that hose does not contact engine valve cover. To modify clearance, move and/or rotate air cleaner body in air cleaner strap. Verify that tabs in strap mesh fully with slots in air cleaner body.
 - B. Position hose to allow maximum clearance between air cleaner hose and muffler bracket.




Figure 4

- | | |
|-----------------------|----------------------|
| 1. Air cleaner hose | 4. Air cleaner slots |
| 2. Engine valve cover | 5. Muffler bracket |
| 3. Air cleaner strap | |

Exhaust System




Figure 5

- 1. Muffler
- 2. Muffler bracket
- 3. Exhaust pipe
- 4. Flange head screw
- 5. Exhaust gasket

- 6. Lock nut
- 7. Cap screw
- 8. Flat washer
- 9. Spacer
- 10. Rubber hanger

- 11. Flange nut
- 12. Flange head screw
- 13. Engine mount
- 14. Muffler clamp

Removal



CAUTION

The muffler and exhaust pipe may be hot. To avoid possible burns, allow the engine and exhaust system to cool before working on the muffler.

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Remove muffler and/or muffler bracket from the engine as necessary using Figure 5 as a guide.

Installation

Note: Make sure muffler flange and exhaust manifold sealing surfaces are free of debris or damage that may prevent a tight seal.

1. Install **new** gasket if original gasket is damaged or torn.

IMPORTANT: Failure to follow the suggested muffler fastener sequence may result in premature muffler failure.

2. Install muffler and/or muffler bracket to the engine using Figure 5 as a guide. Hand tighten and then torque the following fasteners from **16 to 22 ft-lb (21 to 29 N-m)** in the sequence listed (Fig. 6):

- A. Locknuts used on rubber hanger cap screws.
- B. Flange nuts that secure muffler to muffler bracket.
- C. Flange head screws that secure muffler flange to engine.
- D. Flange nuts that secure muffler bracket to engine.

3. Tailpipe should have equal clearance between frame and engine after installation.




Figure 6

Fuel System




Figure 7

- | | | |
|--------------------------|-------------------------|-------------------------|
| 1. Fuel tank | 15. Retaining ring | 29. Fuel hose |
| 2. Fuel tank bracket | 16. Battery cover | 30. Hose clamp |
| 3. Air breather | 17. Flat washer | 31. Elbow fitting |
| 4. Female hose barb | 18. Knob | 32. Fuel cap |
| 5. Tank support assembly | 19. Battery plate | 33. Locking flange nut |
| 6. Fuel hose | 20. Negative cable | 34. Speed nut |
| 7. Flange nut | 21. Positive cable | 35. Tank cover |
| 8. Cap screw | 22. Carriage screw | 36. Phillips head screw |
| 9. Flat washer | 23. Gasket | 37. Vent tube |
| 10. Cap screw | 24. Bushing | 38. Insulated clip |
| 11. Carriage screw | 25. Stand pipe | 39. Washer head screw |
| 12. Washer | 26. Fuel sender | 40. Hose clamp |
| 13. Battery strap | 27. Lock washer | 41. ROPS assembly |
| 14. Battery | 28. Phillips head screw | |



DANGER

Because diesel fuel is highly flammable, use caution when storing or handling it. Do not smoke while filling the fuel tank. Do not fill fuel tank while engine is running, hot or when machine is in an enclosed area. Always fill fuel tank outside and wipe up any spilled diesel fuel before starting the engine. Store fuel in a clean, safety-approved container and keep cap in place. Use diesel fuel for the engine only; not for any other purpose.

Check Fuel Lines and Connections

Check fuel lines and connections periodically as recommended in the Operator's Manual. Check lines for deterioration, damage, leaking or loose connections. Replace hoses, clamps and connections as necessary.

Drain and Clean Fuel Tank

Drain and clean the fuel tank periodically as recommended in the Operator's Manual. Also, drain and clean the fuel tank if the fuel system becomes contaminated or if the machine is to be stored for an extended period.

To clean fuel tank, flush tank out with clean diesel fuel. Make sure tank is free of contaminants and debris.

Fuel Tank Removal (Fig. 7)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Raise seat and hood.
3. Remove battery cover and strap. Disconnect negative battery cable first and then positive battery cable. Remove battery from machine.
4. Use a fuel transfer pump to remove fuel from the fuel tank and into a suitable container.
5. Disconnect electrical wiring from the sending unit.
6. Disconnect fuel hose from the standpipe and venting hoses from elbow fittings in top of tank.
7. Remove phillips head screws that secure two (2) tank covers to ROPS assembly. Remove tank covers.
8. Remove fuel tank using Figure 7 as a guide.

Fuel Tank Installation (Fig. 7)

1. Install fuel tank using Figure 7 as a guide.
 - A. Torque two (2) flange nuts (item 7) that secure the fuel tank to the frame from **60 to 80 in-lb (7 to 9 N-m)**.
2. Install two (2) tank covers to ROPS assembly.
3. Connect fuel hose to the standpipe and venting hoses to the elbow fittings.
4. Connect electrical wiring to the sending unit.
 - A. Connect white wire to the center terminal and black wire to any of the screws that secure the fuel sender to the fuel tank.
 - B. Apply skin-over grease to the wire terminal connections.



CAUTION

Connecting battery cables to the wrong battery post could result in personal injury and/or damage to the electrical system.

5. Position battery in machine. Connect positive battery cable first and then negative battery cable. Install battery strap and cover.
6. Lower seat and hood.
7. Fill fuel tank.

Radiator





Figure 8

- | | | |
|------------------------|-----------------------------------|-------------------------------|
| 1. Radiator cap | 17. Bulb seal | 33. Flange head screw |
| 2. Foam strip | 18. Radiator support assembly | 34. Bulb seal |
| 3. Foam strip | 19. Retaining ring | 35. Grommet |
| 4. Lower radiator hose | 20. Oil cooler bracket | 36. Frame cover |
| 5. Upper radiator hose | 21. Oil cooler | 37. Flange head screw |
| 6. Hose clamp | 22. Carriage screw | 38. Plate |
| 7. Radiator shroud | 23. Hydraulic fitting | 39. Flat washer |
| 8. Lock nut | 24. Flange head screw | 40. Knob |
| 9. Radiator | 25. Clamp | 41. Shoulder bolt |
| 10. Hose clamp | 26. Flange nut | 42. Flat washer |
| 11. Reservoir hose | 27. Oil cooler bracket (RH shown) | 43. Coolant reservoir |
| 12. Flange head screw | 28. Flat washer | 44. Coolant reservoir bracket |
| 13. Grommet | 29. Foam plug | 45. O-ring |
| 14. Flange nut | 30. Lock nut | 46. O-ring |
| 15. Retaining ring | 31. Foam strip | 47. Air cleaner hose |
| 16. Knob | 32. Lower radiator support | |

Removal

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Open engine hood on the machine.



3. Drain radiator into a suitable container using the radiator drain. The radiator drain hose is located near the engine oil filter.
4. Disconnect hoses (upper and lower) from the radiator.
5. Remove air cleaner hose.
6. Disconnect reservoir hose from the vent tube.
7. Detach radiator shroud from the radiator by removing four flange head screws and flat washers. Position shroud away from radiator.
8. Remove screws, flat washers and lock nuts securing the radiator to the support frame. Pull radiator from the machine.
9. Plug any radiator or hose openings to prevent contamination.

Installation

1. Remove any plugs used during the removal procedure.
2. Position radiator to the support frame. Secure radiator to the support frame with lock nuts, flat washers and screws.
3. Attach radiator shroud to the radiator with flange screws and flat washers. Make sure that clearance between shroud and fan is at least 0.180" (4.6 mm) at all points.
4. Connect reservoir hose to the vent tube.
5. Connect hoses (upper and lower) to the radiator.
6. Reinstall air cleaner hose.
7. Make sure radiator drain is closed. Fill radiator with coolant.
8. Close and secure engine hood on the machine.

Engine




Figure 9

- | | | |
|-------------------------------------|-----------------------------|--------------------------------|
| 1. Engine | 18. Cap screw | 34. Cap screw |
| 2. Engine mount bracket (RH shown) | 19. Lock washer | 35. Pump adapter plate |
| 3. Lock washer | 20. Cap screw | 36. Lock washer |
| 4. Cap screw | 21. Cap screw | 37. Cap screw |
| 5. Barb fitting | 22. Rubber engine mount | 38. Traction cylinder assembly |
| 6. Hose clamp | 23. Flange head locking nut | 39. Cap screw |
| 7. Hose | 24. Rebound washer | 40. O-ring |
| 8. Fuel line | 25. Hose clamp | 41. Cylinder piston |
| 9. Fuel filter | 26. Fuel line | 42. Back-up ring |
| 10. Fuel line | 27. Coupler spacer | 43. Retaining ring |
| 11. Coolant drain hose | 28. Dowel | 44. Seal |
| 12. Hose clamp | 29. Lock washer | 45. Hydraulic fitting |
| 13. Cap screw | 30. Shoulder bolt | 46. O-ring |
| 14. Barb fitting (female) | 31. Cap screw | 47. O-ring |
| 15. Coolant drain cock fitting | 32. Spring coupler | 48. Shim plate |
| 16. Engine mount bracket (RH shown) | 33. Plate pin | 49. Hydraulic hose |
| 17. Lock washer | | |

Engine Removal

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Remove battery cover and strap. Disconnect negative battery cable first and then positive battery cable. Remove battery from machine.
3. Open engine hood.



CAUTION

Do not open radiator cap or drain coolant if the radiator or engine is hot. Pressurized, hot coolant can escape and cause burns.

Ethylene-glycol antifreeze is poisonous. Dispose of coolant properly or store it in a properly labeled container away from children and pets.

4. Drain coolant from the radiator into a suitable container (see Radiator Removal). Disconnect coolant hoses from the radiator.



CAUTION

The muffler and exhaust pipe may be hot. To avoid possible burns, allow the exhaust system to cool before working on or near the muffler.

5. Remove exhaust system from engine (see Muffler Removal).
6. Remove air cleaner system from engine (see Air Cleaner Removal).
7. Note location of cable ties used to secure wires. Disconnect wires and/or electrical connections from the following electrical components:
 - A. The temperature sender and alternator (Fig 10). Note: the red wire attached to alternator with washer, nut and boot does not have to be removed.
 - B. The engine run solenoid and fuel pump (Fig. 12).
 - C. The high temperature shutdown switch and glow plug (Fig. 13).
 - D. Battery, frame and wire harness ground at the engine block (Fig. 14).
 - E. The electric starter (Fig. 14) and low oil pressure switch (near electric starter).




Figure 10

1. Temperature sender
2. Alternator
3. Coolant hose




Figure 11

1. Run solenoid
2. Fuel line
3. Throttle cable
4. Cable jam nut
5. Cable washer/lock nut




Figure 12

1. Run solenoid
2. Fuel pump
3. Fuel filter

PRELIMINARY – For Toro Distributor and Toro Company use only.

8. Disconnect fuel line from injection pump (Fig. 11).

9. Disconnect throttle cable from the speed control lever by removing the washer and lock nut. Loosen jam nut and take cable from mounting bracket (Fig. 11).

10. Remove coolant reservoir and bracket from fan shroud.

11. Remove four flange head screws and flat washers securing the fan shroud to the radiator.

12. Remove traction cylinder assembly from engine adapter plate. It is not necessary to remove the hydraulic hose from the cylinder. Locate and remove shim plate from between traction cylinder and adapter plate.

13. Disconnect two (2) wires from neutral switch on hydraulic traction pump.

IMPORTANT: Support hydraulic pump assembly to prevent it from falling and being damaged.

14. Remove hydraulic pump assembly from engine (see Pump Assembly in Chapter 4 – Hydraulic Systems).

15. Make sure all cable ties securing the wiring harness, fuel lines or hydraulic hoses to the engine are removed.

16. Connect hoist or lift to the front and rear lift tabs on engine.

17. Remove flange head locking nuts, rebound washers and cap screws securing the engine brackets to the engine mounts.




Figure 13

1. Glow plug wire

2. Engine lift tab




Figure 14

1. Battery cable (+)

2. Battery cable (-)

3. Engine to frame ground

4. Engine wire harness

5. Alternator wire

6. Fusible link harness

7. Cable tie



CAUTION

One person should operate lift or hoist while the other person guides the engine out of the machine.

IMPORTANT: Make sure not to damage the engine, fuel and hydraulic lines, electrical harness or other parts while removing the engine.

18. Slowly remove engine from the machine.

19. If necessary, remove engine mount brackets from the engine using Figure 9 as a guide.

Engine Installation

1. If removed, install engine mount brackets to the engine using Figure 9 as a guide.

2. Connect hoist or lift to the front and rear lift tabs on engine.

3. Position fan shroud around the engine fan.



CAUTION

One person should operate lift or hoist while the other person guides the engine into the machine.

IMPORTANT: Make sure not to damage the engine, fuel and hydraulic lines, electrical harness or other parts while installing the engine.

4. Slowly lower engine into the machine.

5. Align engine to the rubber engine mounts and secure with cap screws, rebound washers and flange head locking nuts.

6. Secure fan shroud to the radiator with four cap screws, flat washers and locknuts. Make sure that clearance between shroud and fan is at least 0.180" (4.6 mm) at all points.

7. Install coolant reservoir bracket and reservoir to fan

PRELIMINARY – For Toro Distributor and Toro Company use only.

shroud.

8. Connect throttle cable to the speed control lever with washer and lock nut. Install cable to mounting bracket (Fig. 11). Adjust throttle cable.

9. Connect fuel line to the injection pump (Fig. 11).

10. Install traction cylinder assembly to engine adapter plate.

IMPORTANT: Support hydraulic pump assembly to prevent it from falling and being damaged.

11. Install hydraulic pump assembly to engine (see Pump Assembly in Chapter 4 – Hydraulic Systems).

12. Connect two (2) wires to neutral switch on traction pump.

13. Connect wires and/or electrical connections to the following electrical components:

- A. The temperature sender and alternator (Fig 10).
- B. The engine run solenoid and fuel pump (Fig. 12).
- C. The high temperature shutdown switch and glow plug (Fig. 13).
- D. Battery, frame and wire harness ground to the engine block (Fig. 14).
- E. The starter (Fig. 14) and low oil pressure switch (near starter).

14. Install air cleaner assembly to the engine (see Air Cleaner Installation in this section).

15. Install exhaust system to machine (see Muffler Installation in this section).

16. Connect coolant hoses to the radiator. Make sure radiator drain is shut. Fill radiator and reservoir with coolant.

17. Check position of wires, fuel lines, hydraulic hoses and cables for proper clearance with rotating, high temperature and moving components.

18. Position battery to machine. Connect positive battery cable first and then negative battery cable. Secure battery to machine with strap and cover.

19. Check and adjust engine oil as needed.

20. Check and adjust hydraulic oil as needed.

21. Bleed fuel system.

22. Operate hydraulic controls to properly fill hydraulic system (see Charge Hydraulic System in Chapter 4 – Hydraulic Systems).

Spring Coupler




Figure 15

- | | | |
|-----------------------|----------------------------|-----------------------|
| 1. Spring coupler | 8. Carriage screw (2 used) | 15. Retaining ring |
| 2. Washer (14 used) | 9. Cylinder shim | 16. Seal |
| 3. Cap screw (6 used) | 10. Transport cylinder | 17. O-ring |
| 4. Flywheel plate | 11. Lock nut (2 used) | 18. Hydraulic fitting |
| 5. Cap screw (4 used) | 12. Cylinder piston | 19. O-ring |
| 6. LH engine mount | 13. O-ring (2 used) | 20. Hydraulic hose |
| 7. Cap screw (2 used) | 14. Backup ring (2 used) | 21. RH engine mount |

Coupler Removal (Fig. 15)

1. If engine is in machine:
 - A. The hydraulic pump assembly needs to be removed from engine before coupler can be removed (see Piston (Traction) Pump Removal in the Service and Repairs section of Chapter 4 – Hydraulic System).
 - B. Support engine from below to prevent it from shifting while removing flywheel plate, engine mounts and spring coupler.
2. Remove flywheel plate and spring coupler from engine using Figure 15 as a guide.

Coupler Installation (Fig. 15)

1. Position spring coupler to engine flywheel and align mounting holes. Make sure that coupling hub is away from engine flywheel (Fig. 16).
2. Apply Loctite #242 (or equivalent) to threads of cap screws (item 3). Secure coupler to flywheel with six (6) cap screws and washers. Torque cap screws in a crossing pattern from **29 to 33 ft-lb (40 to 44 N-m)**.
3. Position flywheel plate to engine and engine mounts. Secure flywheel plate and mounts with cap screws (items 5 and 7) and washers using a crossing pattern tightening procedure. Torque cap screws in a crossing pattern from **28 to 32 ft-lb (38 to 43 N-m)**.
4. If engine is in machine, install hydraulic pump assembly (see Piston (Traction) Pump Installation in the Service and Repairs section of Chapter 4 – Hydraulic System).




Figure 16

1. Coupler
2. Engine flywheel

This page is intentionally blank.



Hydraulic System

Table of Contents

SPECIFICATIONS	2	SERVICE AND REPAIRS	51
GENERAL INFORMATION	3	General Precautions for Removing and	
Traction Unit Operator's Manual	3	Installing Hydraulic System Components	51
Towing Traction Unit	3	Check Hydraulic Lines and Hoses	51
Check Hydraulic Fluid	3	Flush Hydraulic System	52
Hydraulic Hoses	4	Charge Hydraulic System	53
Hydraulic Hose and Tube Installation	5	Gear Pump	54
Hydraulic Fitting Installation	6	Gear Pump Service	56
HYDRAULIC SCHEMATIC	8	Piston (Traction) Pump	58
HYDRAULIC FLOW DIAGRAMS	9	Piston (Traction) Pump Service	60
Traction Circuit	9	Piston Pump Control Assembly	64
Lower Cutting Unit	11	Hydraulic Control Manifold: 4 Wheel Drive	66
Raise Cutting Unit	13	Hydraulic Control Manifold Service:	
Mow	15	4 Wheel Drive	68
Steering Circuit	17	Hydraulic Control Manifold: Deck Drive	70
SPECIAL TOOLS	19	Hydraulic Control Manifold Service: Deck Drive ..	71
Hydraulic Pressure Test Kit	19	Hydraulic Control Manifold: Cutting Deck	
Hydraulic Tester (Pressure and Flow)	19	Lift/Lower	72
Hydraulic Test Fitting Kit	20	Hydraulic Control Manifold Service: Cutting	
Measuring Container	20	Deck Lift/Lower	73
TROUBLESHOOTING	21	Hydraulic Control Manifold: Filter Manifold	74
TESTING	24	Hydraulic Control Manifold Service:	
Traction Circuit Charge Pressure	25	Filter Manifold	75
Traction Circuit Relief Pressure	27	Hydraulic Control Manifold: Flow Divider	76
Cutting Deck Circuit Pressure	29	Hydraulic Control Manifold Service:	
Cutting Deck Gear Pump Flow	31	Flow Divider	77
Cutting Deck Manifold Relief Pressure	33	Rear Axle Motor	78
Cutting Deck Motor Case Drain Leakage	35	Front Wheel Motors	80
Steering Circuit Relief Pressure	37	Rear Axle/Front Wheel Motor Service	82
Lift/Lower Circuit Relief Pressure	39	Cutting Deck Motor	85
Steering and Lift/Lower Gear Pump Flow	41	Cutting Deck Motor Service	86
Counterbalance Pressure	43	Lift/Lower Control Valve	90
Rear Traction Circuit (RV5) Relief Pressure	45	Lift/Lower Control Valve Service	92
Traction Circuit Reducing Valve (PR) Pressure .	47	Steering Valve	94
ADJUSTMENTS	49	Steering Valve Service	96
Adjust Front Cutting Unit Lift Flow Control	49	Engine Cooling Fan Motor Service	98
		Side Deck Lift Cylinder	102
		Front Deck Lift Cylinder	104
		Lift Cylinder Service	106
		Steering Cylinder	108
		Steering Cylinder Service	110
		Hydraulic Reservoir	112
		Hydraulic Oil Cooler	113

Specifications

Item	Description
Piston (Traction) Pump System Relief Pressure: Forward System Relief Pressure: Reverse Charge Pressure	Variable displacement piston pump 4000 PSI (274 bar) 5000 PSI (343 bar) 250 PSI (17 bar)
Gear Pump Section P1/P2 Displacement (per revolution) Section P3/P4 Displacement (per revolution)	Casappa 4 section, positive displacement gear type pump 1.16 Cubic Inches (19.09 cc) 0.56 Cubic Inches (9.16 cc)
Steering Relief Pressure	1350 PSI (93 bar)
Lift/Lower Relief Pressure	2525 PSI (174 bar)
Front Wheel Motors	Fixed displacement piston motors
Rear Axle Motor	Fixed displacement piston motor
Cutting Deck Motors Relief Pressure (front and left side) Relief Pressure (right side)	Gear motor 3000 PSI (207 bar) 2000 PSI (137 bar)
Engine Cooling Fan Motor Displacement (per revolution)	Casappa Gear Motor 0.50 Cubic Inches (8.258 cc)
Hydraulic Filters In-line Suction Strainer	10 Micron spin-on cartridge type 100 mesh (in reservoir)
Hydraulic Reservoir	8 U.S. Gallons (30.3 Liters)
Hydraulic Oil	See Operator's Manual

General Information

Traction Unit Operator's Manual

The Traction Unit Operator's Manual provides information regarding the operation, general maintenance and maintenance intervals for your Groundsmaster machine. Refer to that publication for additional information when servicing the machine.

Towing Traction Unit

IMPORTANT: If towing limits are exceeded, severe damage to the piston pump may occur.

If it becomes necessary to tow (or push) the machine, tow (or push) in a **forward direction only** and at a speed **below 3 mph**. The piston (traction) pump is equipped with a by-pass valve that needs to be turned 90° for towing. See Operator's Manual for Towing Procedures.




Figure 17

1. By-pass valve location

Check Hydraulic Fluid

The Groundsmaster 4000-D hydraulic system is designed to operate on anti-wear hydraulic fluid. The reservoir holds about 8 gallons (30.3 liters) of hydraulic fluid. **Check level of hydraulic fluid daily.** See Operator's Manual for fluid level checking procedure and oil recommendations.




Figure 18

1. Hydraulic reservoir cap

Hydraulic Hoses

Hydraulic hoses are subject to extreme conditions such as pressure differentials during operation and exposure to weather, sun, chemicals, very warm storage conditions or mishandling during operation and maintenance. These conditions can cause hose damage and deterioration. Some hoses are more susceptible to these conditions than others. Inspect all machine hydraulic hoses frequently for signs of deterioration or damage:

Hard, cracked, cut, abraded, charred, leaking or otherwise damaged hose.

Kinked, crushed, flattened or twisted hose.

Blistered, soft, degraded or loose hose cover.

Cracked, damaged or badly corroded hose fittings.

When replacing a hydraulic hose, be sure that the hose is straight (not twisted) before tightening the fittings. This can be done by observing the imprint (layline) on the hose. Use two wrenches; hold the hose straight with one wrench and tighten the hose swivel nut onto the fitting with the other wrench (See Hydraulic Hose and Tube Installation in this section). If the hose has an elbow at one end, tighten the swivel nut on that end before tightening the nut on the straight end of the hose.

For additional hydraulic hose information, refer to Toro Service Training Book, Hydraulic Hose Servicing (Part Number 94813SL).



WARNING

Before disconnecting or performing any work on hydraulic system, relieve all pressure in system (see Relieving Hydraulic System Pressure in this section).

Keep body and hands away from pin hole leaks or nozzles that eject hydraulic fluid under high pressure. Use paper or cardboard, not hands, to search for leaks. Hydraulic fluid escaping under pressure can have sufficient force to penetrate the skin and cause serious injury. If fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury. Gangrene may result from such an injury.

Hydraulic Hose and Tube Installation (O-Ring Face Seal Fitting)

1. Make sure threads and sealing surfaces of the hose/tube and the fitting are free of burrs, nicks, scratches or any foreign material.

2. As a preventative measure against leakage, it is recommended that the face seal O-ring be replaced any time the connection is opened. Make sure the O-ring is installed and properly seated in the fitting groove. Lightly lubricate the O-ring with clean hydraulic oil.

3. Place the hose/tube against the fitting body so that the flat face of the hose/tube sleeve fully contacts the O-ring in the fitting.

4. Thread the swivel nut onto the fitting by hand. While holding the hose/tube with a wrench, use a torque wrench to tighten the swivel nut to the recommended installation torque shown in Figure 3. This tightening process will require the use of an offset wrench (e.g. crowfoot wrench). Use of an offset wrench will affect torque wrench calibration due to the effective length change of the torque wrench. Tightening torque when using a torque wrench with an offset wrench will be lower than the listed installation torque (see Using a Torque Wrench with an Offset Wrench in the Torque Specifications section of Chapter 2 – Product Records and Maintenance).

5. If a torque wrench is not available or if space at the swivel nut prevents use of a torque wrench, an alternate method of assembly is the Flats From Wrench Resistance (F.F.W.R.) method (Fig. 2).

A. Using a wrench, tighten the swivel nut onto the fitting until light wrench resistance is reached (approximately 30 in-lb).

B. Mark the swivel nut and fitting body. Hold the hose/tube with a wrench to prevent it from turning.

C. Use a second wrench to tighten the nut to the correct Flats From Wrench Resistance (F.F.W.R.). The markings on the nut and fitting body will verify that the connection has been properly tightened.

Size	F.F.W.R.
4 (1/4 in. nominal hose or tubing)	1/2 to 3/4
6 (3/8 in.)	1/2 to 3/4
8 (1/2 in.)	1/2 to 3/4
10 (5/8 in.)	1/2 to 3/4
12 (3/4 in.)	1/3 to 1/2
16 (1 in.)	1/3 to 1/2




Figure 1




Figure 2

Fitting Dash Size	Hose/Tube Side Thread Size	Installation Torque
4	9/16 – 18	18 to 22 ft-lb (25 to 29 N-m)
6	11/16 – 16	27 to 33 ft-lb (37 to 44 N-m)
8	13/16 – 16	37 to 47 ft-lb (51 to 63 N-m)
10	1 – 14	60 to 74 ft-lb (82 to 100 N-m)
12	1 3/16 – 12	85 to 105 ft-lb (116 to 142 N-m)
16	1 7/16 – 12	110 to 136 ft-lb (150 to 184 N-m)
20	1 11/16 – 12	140 to 172 ft-lb (190 to 233 N-m)

Figure 3

Hydraulic Fitting Installation (SAE Straight Thread O-Ring Fitting into Component Port)

Non-Adjustable Fitting (Fig. 4)

1. Make sure all threads and sealing surfaces of fitting and component port are free of burrs, nicks, scratches or any foreign material.
2. As a preventative measure against leakage, it is recommended that the O-ring be replaced any time the connection is opened.
3. Lightly lubricate the O-ring with clean hydraulic oil. Fitting threads should be clean with no lubricant applied.

IMPORTANT: Before installing fitting into port, determine port material. If fitting is to be installed into an aluminum port, installation torque is reduced.

4. Install the fitting into the port. Then, use a torque wrench and socket to tighten the fitting to the recommended installation torque shown in Figure 5.

NOTE: Use of an offset wrench (e.g. crowfoot wrench) will affect torque wrench calibration due to the effective length change of the torque wrench. Tightening torque when using a torque wrench with an offset wrench will be less than the recommended installation torque. See Using a Torque Wrench with an Offset Wrench in the Torque Specifications section of Chapter 2 – Product Records and Maintenance to determine necessary conversion information.

5. If a torque wrench is not available, or if space at the port prevents use of a torque wrench, an alternate method of assembly is the Flats From Finger Tight (F.F.F.T.) method.

A. Install the fitting into the port and tighten it down full length until finger tight.

B. If port material is steel, tighten the fitting to the listed F.F.F.T. If port material is aluminum, tighten fitting to 60% of listed F.F.F.T.

Size	F.F.F.T.
4 (1/4 in. nominal hose or tubing)	1.00 ± 0.25
6 (3/8 in.)	1.50 ± 0.25
8 (1/2 in.)	1.50 ± 0.25
10 (5/8 in.)	1.50 ± 0.25
12 (3/4 in.)	1.50 ± 0.25
16 (1 in.)	1.50 ± 0.25




Figure 4

Fitting Dash Size	Fitting Port Side Thread Size	Installation Torque Into Steel Port	Installation Torque Into Aluminum Port
4	7/16 – 20	15 to 19 ft-lb (21 to 25 N-m)	9 to 11 ft-lb (13 to 15 N-m)
5	1/2 – 20	18 to 22 ft-lb (25 to 29 N-m)	11 to 15 ft-lb (15 to 20 N-m)
6	9/16 – 18	34 to 42 ft-lb (47 to 56 N-m)	20 to 26 ft-lb (28 to 35 N-m)
8	3/4 – 16	58 to 72 ft-lb (79 to 97 N-m)	35 to 43 ft-lb (48 to 58 N-m)
10	7/8 – 14	99 to 121 ft-lb (135 to 164 N-m)	60 to 74 ft-lb (82 to 100 N-m)
12	1 1/16 – 12	134 to 164 ft-lb (182 to 222 N-m)	81 to 99 ft-lb (110 to 134 N-m)
14	1 3/16 – 12	160 to 196 ft-lb (217 to 265 N-m)	96 to 118 ft-lb (131 to 160 N-m)
16	1 5/16 – 12	202 to 248 ft-lb (274 to 336 N-m)	121 to 149 ft-lb (165 to 202 N-m)
20	1 5/8 – 12	247 to 303 ft-lb (335 to 410 N-m)	149 to 183 ft-lb (202 to 248 N-m)

Figure 5

Adjustable Fitting (Fig. 6)

1. Make sure all threads and sealing surfaces of fitting and component port are free of burrs, nicks, scratches or any foreign material.
2. As a preventative measure against leakage, it is recommended that the O-ring be replaced any time the connection is opened.
3. Lightly lubricate the O-ring with clean hydraulic oil. Fitting threads should be clean with no lubricant applied.
4. Turn back the lock nut as far as possible. Make sure the back up washer is not loose and is pushed up as far as possible (Step 1 in Figure 7).

IMPORTANT: Before installing fitting into port, determine port material. If fitting is to be installed into an aluminum port, installation torque is reduced.

5. Install the fitting into the port and tighten finger tight until the washer contacts the face of the port (Step 2).
6. To put the fitting in the desired position, unscrew it by the required amount, but no more than one full turn (Step 3).
7. Hold the fitting in the desired position with a wrench and use a torque wrench to tighten the fitting to the recommended installation torque shown in Figure 5. This tightening process will require the use of an offset wrench (e.g. crowfoot wrench). Use of an offset wrench will affect torque wrench calibration due to the effective length change of the torque wrench. Tightening torque when using a torque wrench with an offset wrench will be lower than the listed installation torque (see Using a Torque Wrench with an Offset Wrench in the Torque Specifications section of Chapter 2 – Product Records and Maintenance).
8. If a torque wrench is not available, or if space at the port prevents use of a torque wrench, an alternate method of assembly is the Flats From Finger Tight (F.F.T.) method. Hold the fitting in the desired position with a wrench and, if port material is steel, tighten the lock nut with a second wrench to the listed F.F.T. (Step 4). If port material is aluminum, tighten fitting to 60% of listed F.F.T.




Figure 6




Figure 7

Size	F.F.T.
4 (1/4 in. nominal hose or tubing)	1.00 ± 0.25
6 (3/8 in.)	1.50 ± 0.25
8 (1/2 in.)	1.50 ± 0.25
10 (5/8 in.)	1.50 ± 0.25
12 (3/4 in.)	1.50 ± 0.25
16 (1 in.)	1.50 ± 0.25

Hydraulic Schematic

The hydraulic schematic for the Groundsmaster 4000–D is located in Chapter 9 – Foldout Drawings.

Hydraulic Flow Diagrams



Traction Circuit

The traction circuit piston pump is a variable displacement pump that is directly coupled to the engine flywheel. Pushing the top of the traction pedal engages a hydraulic servo valve which controls the variable displacement piston pump swash plate to create a flow of oil. This oil is directed to the front wheel and rear axle motors. Operating pressure on the high pressure side of the closed traction circuit loop is determined by the amount of load developed at the fixed displacement wheel and axle motors. As the load increases, circuit pressure can increase to relief valve settings: 4000 PSI in forward and 5000 PSI in reverse. If pressure exceeds the relief setting, oil flows through the relief valve to the low pressure side of the closed loop circuit. The traction circuit provides operation in either four wheel drive (mowing) or two wheel drive (transport).

Traction circuit pressure (forward and reverse) can be measured at test ports on the sides of the machine.


The traction pump uses a small amount of hydraulic fluid for internal lubrication. Fluid is designed to leak across pump parts into the case drain. This leakage results in the loss of hydraulic fluid from the closed loop traction circuit that must be replaced.

The gear pump that supplies oil to the steering and lift/lower circuits also provides charge oil for the traction circuit. This gear pump is driven directly off the traction pump. It provides a constant supply of charge oil to the traction circuit to make up for oil that is lost due to internal leakage in the traction pump and motors.

Charge pump flow is directed through the oil filter and to the low pressure side of the closed loop traction circuit. A filter bypass valve allows charge oil flow to the closed loop if the filter becomes plugged. Charge pressure is limited by a relief valve located in the oil filter manifold. Charge pressure can be measured at the charge circuit pressure test port on the oil filter manifold.

Two wheel drive (transport) operation is controlled by a solenoid valve. When in transport, hydraulic flow to the rear axle motor is blocked in both forward and reverse directions. A transport cylinder is included in the traction circuit to reduce control arm movement on the piston pump when operating in two wheel drive (transport). This reduced arm movement limits swash plate rotation to prevent excessive transport speed.

A flow divider is incorporated into the traction circuit. When in four wheel drive, the operator can momentarily engage the traction flow divider when low traction situations could lead to wheel spin. The engaged flow divider splits traction pump flow to the front wheel motors (approximately 45%) and rear axle motor (55%) to reduce the chance that excessive flow goes to a spinning wheel.



Lower Cutting Unit

A four section gear pump is coupled to the piston (traction) pump. The third gear pump section supplies hydraulic flow to both the lift/lower control valve and the steering control valve. Hydraulic flow from this pump section is delivered to the circuits through a proportional flow divider. This pump section takes its suction from the hydraulic reservoir.


When the cutting units are in a stationary position, flow from the gear pump is by-passed through the lift/lower control valve, counterbalance manifold, oil filter and traction charge circuit.

To lower a side cutting unit, the appropriate lift lever on the lift/lower control valve is pushed to allow valve shift in the lift/lower control. This valve change causes a valve shift in the counterbalance manifold and oil flow to the rod end of the lift cylinder. Higher hydraulic pressure against the rod end of the cylinder causes the shaft to retract, and lower the cutting unit. Oil from the piston end of the cylinder returns to the traction charge circuit. When the lift lever is released, the lift cylinder is held in position.

To lower the front cutting unit, the center lift lever on the lift/lower control valve is pushed to allow valve shift in the lift/lower control. This valve change allows a passage for oil flow from the rod end of the front deck lift cylinder. The weight of the cutting deck causes the lift cylinder to extend, and lower the cutting unit. Oil from the rod end of the cylinder is allowed to return to the traction charge circuit. When the lift lever is released, the lift cylinder is held in position.

The drop speed of the front cutting units is regulated by an adjustable flow control valve that is located in the hydraulic lines between the lift/lower control valve and the front deck lift cylinders.

An adjustable counterbalance valve maintains back pressure on the side deck lift cylinders. A relief valve located in the lift/lower control valve limits circuit pressure. Excess circuit flow is routed to the oil filter and then to the traction charge circuit.



Raise Cutting Unit


A four section gear pump is coupled to the piston (traction) pump. The third gear pump section supplies hydraulic flow to the lift/lower control valve and the steering control valve. Hydraulic flow from this pump section is delivered to the two circuits through a proportional flow divider. The gear pump takes its suction from the hydraulic reservoir.

When the cutting units are in a stationary position, flow from the gear pump is by-passed through the lift/lower control valve, counterbalance manifold, oil filter and traction charge circuit.

To raise a side cutting unit, the appropriate lift lever on the lift/lower control valve is pulled to allow valve shift in the lift/lower control. This valve change allows hydraulic pressure to the piston end of the lift cylinder and causes the shaft to extend, raising the cutting unit. Oil from the rod end of the cylinder flows to the traction charge circuit. When the lift lever is released, the lift cylinder is held in position.

To raise the front cutting unit, the center lift lever on the lift/lower control valve is pulled to allow valve shift in the lift/lower control. This valve change allows hydraulic pressure to the rod end of the front deck lift cylinders, causing the cylinders to retract. As the cylinders retract, the front deck raises. Oil from the piston end of the cylinder returns to the hydraulic reservoir. When the lift lever is released, the lift cylinder is held in position.

An adjustable counterbalance valve maintains back pressure on the lift cylinders. A relief valve located in the lift/lower control valve limits circuit pressure. Excess circuit flow is routed to the oil filter and then to the traction charge circuit.



Groundsmaster 4000-D
Mow (Front Deck Shown)
Working Pressure
Low Pressure (Charge)
Return or Suction
Flow

Mow


Hydraulic flow for the mow circuit is supplied by two sections of the gear pump. The gear pump section closest to the piston (traction) pump supplies hydraulic flow to the side cutting units, while the next gear pump section supplies the front cutting unit.

Each cutting deck is controlled by a hydraulic manifold equipped with a solenoid control valve (SV1), bypass cartridge (BY1), brake cartridge (BR1) and relief cartridge (R1BR). When the deck solenoid valve (SV1) is not energized (PTO switch OFF), hydraulic flow bypasses the deck motor through the bypass cartridge (BY1). When the PTO switch is turned ON, the solenoid valve (SV1) energizes, causing a shift of the by-pass cartridge (BY1) and allowing hydraulic flow to the deck motor. Brake cartridge (BR1) and relief cartridge (R1BR) control the stopping rate of the blade when the solenoid control valve is de-energized as the PTO switch is turned OFF.

Return oil from the deck motors is directed to the oil cooler and oil filter. Deck motor case drain leakage returns to the hydraulic reservoir.

Maximum mow circuit pressure is limited at each deck by a relief valve (R1BY) in the hydraulic manifold. The front and left deck relief valves are set at 3000 PSI and the right deck relief valve is set at 2000 PSI.

Circuit pressure can be measured at port (G) of the hydraulic manifold for each cutting deck.



Groundsmaster 4000-D
Steering Circuit (Left Turn Shown)
Working Pressure
Low Pressure (Charge)
Return or Suction
Flow

Steering Circuit

A four section gear pump is coupled to the piston (traction) pump. The third gear pump section supplies hydraulic flow to the steering control valve and the lift/lower control valve. Pump hydraulic flow is delivered to the two circuits through a proportional flow divider. The gear pump takes its suction from the hydraulic reservoir. Steering circuit pressure is limited by a relief valve located in the steering control.

With the steering wheel in the neutral position (rear wheels positioned straight ahead) and the engine running, flow enters the steering control valve at the P port and goes through the steering control spool valve, bypassing the rotary meter (V1) and steering cylinder. Flow leaves the control valve through the PB port to the oil filter and traction charge circuit.

Left Turn

When a left turn is made with the engine running, the turning of the steering wheel positions the spool valve so that flow goes through the top of the spool. Flow entering the steering control valve at the P port goes through the spool and is routed to two places. First, most of the flow through the valve is by-passed out the PB port back to the oil filter and traction charge circuit. Second, the remainder of the flow is drawn through the rotary meter (V1) and out the L port. Pressure contracts the piston for a left turn. The rotary meter ensures that the oil flow to

the cylinder is proportional to the amount of the turning on the steering wheel. Fluid leaving the cylinder flows back through the spool valve then through the T port and to the hydraulic reservoir.

The steering wheel and steering control valve return to the neutral position when turning is completed.

Right Turn

When a right turn is made with the engine running, the turning of the steering wheel positions the spool valve so that flow goes through the bottom of the spool. Flow entering the steering control valve at the P port goes through the spool and is routed to two places. As in a left turn, most of the flow through the valve is by-passed out the PB port back to the oil filter and traction charge circuit. Also like a left turn, the remainder of the flow is drawn through the rotary meter (V1) but goes out port R. Pressure extends the piston for a right turn. The rotary meter ensures that the oil flow to the cylinder is proportional to the amount of the turning on the steering wheel. Fluid leaving the cylinder flows back through the spool valve then through the T port and to the hydraulic reservoir.

The steering wheel and steering control valve return to the neutral position when turning is completed.




Figure 8

Special Tools

Order these tools from your Toro Distributor.

Hydraulic Pressure Test Kit

Use to take various pressure readings for diagnostic tests. Quick disconnect fittings provided attach directly to mating fittings on machine test ports without tools. A high pressure hose is provided for remote readings. Contains one each: 1000 PSI (70 Bar), 5000 PSI (350 Bar) and 10000 PSI (700 Bar) gauges. Use gauges as recommended in Testing section of this chapter.

Toro Part Number: **TOR47009**



Figure 9

Hydraulic Tester (Pressure and Flow)




Figure 10

This tester requires O-ring Face Seal (ORFS) adapter fittings for use on this machine.

1. **INLET HOSE:** Hose connected from the system circuit to the inlet side of the hydraulic tester.
2. **LOAD VALVE:** A simulated working load is created in the circuit by turning the valve to restrict flow.
3. **LOW PRESSURE GAUGE:** Low range gauge to provide accurate reading at low pressure: 0 to 1000 PSI.

A protector valve cuts out when pressure is about to exceed the normal range for the gauge. The cutout pressure is adjustable.

4. **HIGH PRESSURE GAUGE:** High range gauge which accommodates pressures beyond the capacity of the low pressure gauge: 0 to 5,000 PSI.
5. **FLOW METER:** This meter measures actual oil flow in the operating circuit with a gauge rated at 15 GPM.
6. **OUTLET HOSE:** A hose from the outlet side of the hydraulic tester connects to the hydraulic system circuit.

Toro Part Number: **TOR214678**

Hydraulic Test Fitting Kit

This kit includes a variety of O-ring Face Seal fittings to enable you to connect test gauges into the system.

The kit includes: tee's, unions, reducers, plugs, caps and male test fittings.

Toro Part Number: **TOR4079**









TORO TEST FITTING KIT (NO. TOR4079)			
FITTING	TOOL NUMBER	FITTING	TOOL NUMBER
	Swivel Nut Run Tee (2 ea.)		Union (1 ea.)
	Size Toro No.		Size Toro No.
	No. 4 TOR4079-3		No. 6 to No. 8 TOR4079-8
	No. 6 TOR4079-12		No. 10 to No. 8 TOR4079-2
	Plug (2 ea.)		Reducer (1 ea.)
	Size Toro No.		Size Toro No.
	No. 4 TOR4079-13		No. 10 to No. 8 TOR4079-7
	No. 6 TOR4079-14		No. 12 to No. 8 TOR4079-6
	Cap (2 ea.)		Test Cap Fitting (2 ea.)
	Size Toro No.		Size Toro No.
	No. 4 TOR4079-17		No. 4 TOR4079-10
	No. 6 TOR4079-18		No. 6 TOR4079-11
	Male Test Fitting (2 ea.)		Test Fitting (2 ea.)
	Size Toro No.		Size Toro No.
	No. 8 TOR4079-19		7/16-20 ORB TOR4079-22
	No. 10 TOR4079-20		1/8" Pipe Thd. TOR4079-23

Figure 11

Measuring Container

Use this container for doing hydraulic motor efficiency testing (motors with case drain lines only). Measure efficiency of a hydraulic motor by restricting the outlet flow from the motor and measuring leakage from the case drain line while the motor is pressurized by the hydraulic system.

The table in Figure 13 provides gallons per minute (GPM) conversion for measured milliliter or ounce motor case drain leakage.

Toro Part Number: **TOR4077**



Figure 12

GPM	Milliliters in 15 sec.	Ounces in 15 sec.
.1	95	3.2
.2	189	6.4
.3	284	9.6
.4	378	12.8
.5	473	16.0
.6	568	19.2
.7	662	22.4
.8	756	25.6
.9	852	28.8
1.0	946	32.0

Figure 13

Troubleshooting

The charts that follow contain information to assist in troubleshooting. There may possibly be more than one cause for a machine malfunction.

Refer to the Testing section of this Chapter for precautions and specific test procedures.

Problem	Possible Cause
Hydraulic system operates hot.	Engine RPM is too low. Hydraulic reservoir oil level is low. Hydraulic oil is contaminated or the wrong type. Brakes are engaged or sticking. Piston pump by-pass valve is open or damaged. Cooling system is not operating properly. Charge pressure is low. Traction circuit pressure is incorrect. Pump(s) or motor(s) are damaged.
Hydraulic oil in reservoir foams.	Hydraulic reservoir oil level is low. Wrong type of oil is in the hydraulic system. Air is leaking in suction line.
Machine operates in one direction only.	Traction control linkage is faulty. System charge check valve and/or system relief valve is defective. Pilot direction valve in 4WD manifold is damaged or sticking.
Traction pedal is sluggish.	Traction control linkage is stuck or binding. Piston pump servo control valve is damaged. Charge pressure is low.
Machine travels too far before stopping when the traction pedal is released.	Traction linkage is out of adjustment. Piston pump servo control valve is damaged. Traction pedal does not return to neutral.
Traction power is lost or unit will not operate in either direction.	Brakes are engaged or sticking. Traction control linkage is damaged or disconnected. Hydraulic reservoir oil level is low. Piston pump by-pass valve is open or damaged. Charge pressure is low. Traction circuit pressure is low. Front wheel motor couplers are damaged.

PRELIMINARY – For Toro Distributor and Toro Company use only.

Problem	Possible Causes
Four wheel drive will not engage.	Electrical problem exists (see Chapter 5 – Electrical System). Solenoid valve on 4WD hydraulic manifold is faulty. Cartridge valve in 4WD manifold is damaged or sticking. Rear axle motor is damaged.
Four wheel drive will not disengage.	Electrical problem exists (see Chapter 5 – Electrical System). Solenoid valve on 4WD hydraulic manifold is faulty. Cartridge valve in 4WD manifold is damaged or sticking.
No cutting units will operate.	Electrical problem exists (see Chapter 5 – Electrical System). Gear pump or its coupler is damaged.
One cutting unit will not operate.	Electrical problem exists (see Chapter 5 – Electrical System). System pressure to the affected deck is low. Key on affected deck motor is damaged. Solenoid valve in deck manifold is faulty. Cartridge valve in deck manifold is damaged or sticking. Deck motor or gear pump section is damaged.
All cutting decks operate slowly.	Engine RPM is low. Deck motor or gear pump section is damaged.
Cutting deck stops under load.	Relief valve in deck manifold is by-passing. Deck motor has internal leakage (by-passing oil). Cutting deck gear pump section is inefficient.
Cutting units will not raise.	Engine RPM is too low. Hydraulic oil level in reservoir is low. Lift cylinder(s) is (are) damaged. Lift arm pivots are binding. Relief valve in lift/lower control valve is stuck. Pilot valve in lift/lower manifold is damaged or sticking. Gear pump section for lift/lower control valve is inefficient.
Cutting units raise, but will not stay up.	Lift circuit lines or fittings are leaking. Lift cylinder is damaged. Detents in lift/lower control valve are worn.

PRELIMINARY – For Toro Distributor and Toro Company use only.

Problem	Possible Causes
Front cutting unit drops too fast or too slow.	Flow control valve is not adjusted properly.
Cutting units will not lower.	Lift arm pivots are binding. Lift cylinder is damaged. Counterbalance pressure is excessive. Lift/lower control valve is worn or damaged. Pilot valve in lift/lower manifold is damaged or sticking.

Testing

The most effective method for isolating problems in the hydraulic system is by using hydraulic test equipment such as pressure gauges and flow meters in the circuits during various operational checks (See the Special Tools section in this Chapter).

Before Performing Hydraulic Tests

IMPORTANT: All obvious areas such as oil supply, filter, binding linkages, loose fasteners or improper adjustments must be checked before assuming that a hydraulic component is the source of the problem.

Precautions for Hydraulic Testing



CAUTION

Failure to use gauges with recommended pressure (PSI) rating as listed in test procedures could result in damage to the gauge and possible personal injury from leaking hot oil.



CAUTION

All testing should be performed by two (2) people. One person should be in the seat to operate the machine, and the other should read and record test results.



CAUTION

Operate all hydraulic controls to relieve system pressure and avoid injury from pressurized hydraulic oil. Controls must be operated with the ignition switch in OFF. Remove key from the ignition switch.



WARNING

Keep body and hands away from pin hole leaks or nozzles that eject hydraulic fluid under high pressure. Do not use hands to search for leaks; use paper or cardboard. Hydraulic fluid escaping under pressure can have sufficient force to penetrate the skin and cause serious injury. If fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury. Gangrene may result from such an injury.




WARNING

Before disconnecting or performing any work on the hydraulic system, all pressure in the system must be relieved and all rotating machine parts must be stopped. Stop engine; lower or support attachments.

1. Clean machine thoroughly before disconnecting or disassembling any hydraulic components. Always keep in mind the need for cleanliness when working on hydraulic equipment. Contamination will cause excessive wear of components.
2. Put metal caps or plugs on any hydraulic lines left open or exposed during testing or removal of components.
3. The engine must be in good operating condition. Use a phototac when performing a hydraulic test. Engine speed can affect the accuracy of the tester readings. Check actual speed of the pump when performing flow testing.
4. When using the hydraulic tester with pressure and flow capabilities, the inlet and the outlet hoses must be properly connected and not reversed to prevent damage to the hydraulic tester or components.
5. When using the hydraulic tester with pressure and flow capabilities, open load valve completely in the tester to minimize the possibility of damaging components.
6. Install fittings finger tight and far enough to make sure that they are not cross-threaded before tightening them with a wrench.
7. Position tester hoses to prevent rotating machine parts from contacting and damaging the hoses or tester.
8. Check oil level in the hydraulic reservoir. After connecting test equipment, make sure tank is full.
9. Check control linkages for improper adjustment, binding or broken parts.
10. All hydraulic tests should be made with the hydraulic oil at normal operating temperature.
11. Before returning machine to use, make sure that hydraulic reservoir has correct fluid level.

Traction Circuit Charge Pressure (Using Pressure Gauge)



PRELIMINARY – For Toro Distributor and Toro Company use only.

Procedure for Traction Circuit Charge Pressure Test

1. Make sure hydraulic oil is at normal operating temperature by operating the machine for approximately 10 minutes. Make sure the hydraulic tank is full.
2. Park machine on a level surface with the cutting units lowered and off. Make sure engine is off and the parking brake is engaged.



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.




Figure 14

1. Charge pressure port 2. Hydraulic reservoir cap

3. Connect a 1000 PSI gauge onto charge pressure test port (Fig. 14) under operator seat.
4. Start the engine and put throttle at full engine speed (**2870 RPM**) with no load on the hydraulic system.


GAUGE READING TO BE 200 to 300 PSI.

5. If there is no pressure or pressure is low, check for restriction in pump intake line. Also, inspect charge relief valve located in filter manifold (see Hydraulic Manifold Service: Filter Manifold in the Service and Repairs section of this chapter). If necessary, check for internal damage or worn parts in gear pump.
6. Also, with the pressure gauge still connected to the charge pressure test port, take a gauge reading while operating the machine in forward and reverse. Start the engine and put throttle at full engine speed (**2870 RPM**). Apply the brakes and push the traction pedal forward, then reverse.

GAUGE READING TO BE 200 to 300 PSI.

7. If pressure is good under no load, but drops below specification when under traction load, the piston pump and/or traction motor(s) should be suspected of wear and inefficiency. When the pump and/or traction motor(s) are worn or damaged, the charge pump is not able to keep up with internal leakage in traction circuit components.

Traction Circuit Relief Pressure (Forward Shown) (Using Pressure Gauge)



PRELIMINARY – For Toro Distributor and Toro Company use only.

Procedure for Traction Circuit Relief Pressure Test

1. Make sure hydraulic oil is at normal operating temperature by operating the machine for approximately 10 minutes. Make sure the hydraulic tank is full.



CAUTION

Move machine to an open area, away from people and obstructions.

2. Drive machine to an open area, lower cutting units, turn the engine off and engage the parking brake.



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

3. Connect a 10,000 psi gauge to traction circuit test port for function to be checked (Fig. 16).
4. Start the engine and move throttle to full speed (**2870 RPM**). Release parking brake.
5. Sit on seat, apply brakes fully and slowly depress the traction pedal in the appropriate direction. While pushing traction pedal, look at pressure reading on gauge:

GAUGE READING TO BE:

Forward: **3750 to 4250 PSI**

Reverse: **4750 to 5250 PSI**

6. If traction pressure is too low, inspect traction pump relief valves (Fig. 17). Clean or replace valves as necessary. These cartridge type valves are factory set, and are not adjustable. If relief valves are in good condition, traction pump or wheel motors should be suspected of wear and inefficiency.




Figure 15

1. Forward traction port 2. Left front wheel




Figure 16

1. Reverse traction port 2. Right front wheel





Figure 17

1. Forward relief valve 3. Traction pump
2. Reverse relief valve

Cutting Deck Circuit Pressure (Front Deck Shown) (Using Pressure Gauge)



PRELIMINARY – For Toro Distributor and Toro Company use only.

Procedure for Cutting Deck Circuit Pressure Test

1. Make sure hydraulic oil is at normal operating temperature by operating the machine for approximately 10 minutes. Make sure the hydraulic tank is full.
2. Park machine on a level surface with the cutting units lowered and off. Make sure engine is off and the parking brake is engaged.



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

3. Install test gauge with hydraulic hose attached to manifold test port for the deck to be tested (Fig. 18, 19 and 20).



CAUTION

Keep away from decks during test to prevent personal injury from the cutting blades.

4. Start engine and move throttle to full speed (**2870 RPM**). Engage the cutting units.
5. Watch pressure gauge carefully while mowing with the machine.
6. Cutting deck circuit pressure should be from **1000 to 3000 PSI** and will vary depending on mowing conditions.
7. Disengage cutting units. Shut off engine.
8. Disconnect test gauge with hose from manifold test port.




Figure 18

1. Front deck circuit pressure test port




Figure 19

1. Right deck circuit pressure test port






Figure 20

1. Left deck circuit pressure test port

Cutting Deck Gear Pump Flow (Front Deck Shown) (Using Tester with Pressure Gauges and Flow Meter)



PRELIMINARY – For Toro Distributor and Toro Company use only.

Procedure for Cutting Deck Gear Pump Flow Test

NOTE: Over a period of time, the gears and wear plates in the pump can wear. A worn pump will by pass oil and make the pump less efficient. Eventually, enough oil loss will occur to cause the cutting unit motors to stall under heavy cutting conditions. Continued operation with a worn, inefficient pump can generate excessive heat and cause damage to the seals and other components in the hydraulic system.

1. Make sure hydraulic oil is at normal operating temperature by operating the machine for approximately 10 minutes. Make sure the hydraulic tank is full.
2. Park machine on a level surface with the cutting units lowered and off. Make sure engine is off and the parking brake is engaged.



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

3. Locate deck manifold for gear pump section to be tested. Disconnect hydraulic hose at deck manifold port (P1) (Fig. 21).
4. Install tester in series with the the disconnected hose and hydraulic manifold port (P1).
5. Make sure the flow control valve on the tester is fully open.

6. Start engine and move throttle to full speed (**2870 RPM**). Do not engage the cutting units.

IMPORTANT: Do not fully restrict oil flow through tester. In this test, the flow tester is positioned before the relief valve. Pump damage can occur if the oil flow is fully restricted.

7. Watch pressure gauge carefully while slowly closing the flow control valve until **2000 PSI** is obtained. Verify with a phototac that the **engine speed** is **2870 RPM**.
8. Flow indication should be approximately **14 GPM**.
9. Shut off engine.
10. Disconnect flow tester from hydraulic hose and manifold port. Reconnect hose to the manifold.
11. If flow was less than **14 GPM** or a pressure of **2000 PSI** cannot be obtained, check for restriction in the pump intake line. If line is not restricted, remove gear pump and repair or replace as necessary.





Figure 21

- | | |
|--------------------------|-------------------------|
| 1. Front deck manifold | 3. Side deck manifold |
| 2. Hyd. hose to front P1 | 4. Hyd. hose to side P1 |

Cutting Deck Manifold Relief Pressure (Front Deck Shown) (Using Tester with Pressure Gauges and Flow Meter)



- Working Pressure
- Low Pressure
- Return or Suction
- Flow

PRELIMINARY – For Toro Distributor and Toro Company use only.

Procedure for Cutting Deck Manifold Relief Pressure Test

1. Make sure hydraulic oil is at normal operating temperature by operating the machine for approximately 10 minutes. Make sure the hydraulic tank is full.
2. Park machine on a level surface with the cutting units lowered and off. Make sure engine is off and the parking brake is engaged.



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

3. Locate deck manifold to be tested (Fig. 22). Disconnect hydraulic hose at deck manifold port (MP).

NOTE: An alternative to using manifold port (MP) would be to disconnect the inlet hydraulic hose to the deck motor.

4. Install tester in series with the the disconnected hose and hydraulic manifold port (MP) (or motor inlet if hose was disconnected at deck motor).
5. Make sure the flow control valve on the tester is fully open.
6. Install tester in series with the hose and hydraulic fitting. Make sure the flow control valve on tester is fully open.



CAUTION

Keep away from decks during test to prevent personal injury from the cutting blades.

7. Start engine and move throttle to full speed (**2870 RPM**). Engage the cutting units.
8. Watch pressure gauge carefully while slowly closing the flow control valve to fully closed.
9. As the relief valve lifts, system pressure should be approximately:

2900 to 3100 PSI for the front and left decks
1900 to 2100 PSI for the right deck

10. Disengage cutting units. Shut off engine. If specification is **not** met, adjust or clean relief valve in deck manifold port (R1BY). Adjust relief valve as follows:

NOTE: Do not remove valve from the hydraulic manifold for adjustment.

- A. Remove cap on relief valve with an allen wrench.
- B. To **increase** pressure setting, turn the adjustment screw on the valve in a clockwise direction. A 1/8 turn on the screw will make a measurable change in relief pressure.
- C. To **decrease** pressure setting, turn the adjustment screw on the valve in a counterclockwise direction. A 1/8 turn on the screw will make a measurable change in relief pressure.
- D. Reinstall and tighten cap to secure adjustment. Recheck relief pressure and readjust as needed.

11. Disconnect tester from manifold and hose. Reconnect hydraulic hose that was disconnected for test procedure.




Figure 22

1. Front deck manifold
2. LH deck manifold
3. RH deck manifold





Figure 23

1. Deck manifold
2. Relief valve
3. Relief valve cap

Cutting Deck Motor Case Drain Leakage (Using Tester with Pressure Gauges and Flow Meter)



GPM	Milliliters in 15 sec.	Ounces in 15 sec.
.1	95	3.2
.2	189	6.4
.3	284	9.6
.4	378	12.8
.5	473	16.0
.6	568	19.2
.7	662	22.4
.8	756	25.6
.9	852	28.8
1.0	946	32.0

- Working Pressure
- Low Pressure
- Return or Suction
- Flow

PRELIMINARY – For Toro Distributor and Toro Company use only.

Procedure for Cutting Deck Motor Case Drain Leakage Test

NOTE: Over a period of time, a deck motor can wear internally. A worn motor may by-pass oil to its case drain causing the motor to be less efficient. Eventually, enough oil loss will cause the deck motor to stall under heavy cutting conditions. Continued operation with a worn, inefficient motor can generate excessive heat, cause damage to seals and other components in the hydraulic system and affect quality of cut.

NOTE: One method to find a failing or malfunctioning deck motor is to have another person observe the machine while mowing in dense turf. A bad motor will run slower, produce fewer clippings and may cause a different appearance on the turf.

1. Make sure hydraulic oil is at normal operating temperature by operating the machine for approximately 10 minutes. Make sure the hydraulic tank is full.

2. Park machine on a level surface with the cutting units lowered and off. Make sure engine is off and the parking brake is engaged.



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

NOTE: The side deck motors are connected in series. To isolate a faulty motor, both motors in the circuit may have to be tested by starting with the left side motor first.

3. Disconnect hose from return of the motor to be tested (Fig. 24). Install flow tester in series with the motor and disconnected return hose. Make sure the flow control valve on tester is fully open. (Fig. 25).

4. Disconnect the motor case drain hose (small diameter hose) where it connects to hydraulic manifold tee-fitting (not at the motor). Put a steel cap on the fitting at the tee-fitting; leave the case drain hose open (Fig. 25).



CAUTION

Cutting unit blades will rotate when lowered with PTO switch in ON position. Keep away from cutting units during test to prevent personal injury from rotating blades. Do not stand in front of the machine.

5. Sit on seat and start the engine. Move throttle to full speed (**2870 RPM**). Move PTO switch to ON.

6. While watching pressure gauge, slowly close flow control valve on tester until a pressure of **1200 PSI** is obtained.

NOTE: Use a graduated container, special tool TOR4077, to measure case drain leakage (Fig. 25).

7. Have another person measure flow from the case drain line for **15 seconds**, then move the PTO switch to OFF and stop the engine.

TEST RESULTS: Flow less than **0.5 GPM** (less than **16 ounces (473 ml)** of hydraulic fluid in 15 seconds).

8. Disconnect tester from motor and hose. Reconnect hose to the deck motor. Remove cap from tee-fitting and reconnect case drain hose.

9. If flow is more than **0.5 GPM**, the motor is worn or damaged and should be repaired or replaced.




Figure 24

1. Deck motor (RH shown) 3. Case drain hose
2. Return hose





Figure 25

Steering Circuit Relief Pressure (Using Pressure Gauge)



PRELIMINARY – For Toro Distributor and Toro Company use only.

Procedure for Steering Circuit Relief Pressure Test

1. Make sure hydraulic oil is at normal operating temperature by operating the machine for approximately 10 minutes. Make sure the hydraulic tank is full.
2. Park machine on a level surface with the cutting units lowered and off. Make sure engine is off and the parking brake is engaged.



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

3. Connect a 5000 PSI gauge onto steering pressure test port.
4. Start the engine and move throttle to full engine speed (**2870 RPM**).

IMPORTANT: Hold steering wheel at full lock only long enough to get a system pressure reading. Holding the steering wheel against the stop for an extended period will damage the steering motor.

5. Turn steering all the way in one direction and momentarily hold the steering wheel against resistance.

GAUGE READING TO BE 1300 to 1400 PSI.

6. Stop the engine.
7. If pressure is incorrect, inspect steering relief valve (Fig. 27). If relief valve is operating properly and if lift/lower problems also exist, gear pump should be suspected of wear and inefficiency. If steering wheel continues to turn at end of cylinder travel (with lower than normal effort), steering cylinder or steering valve should be suspected of wear or damage.




Figure 26

1. Steering circuit pressure test port





Figure 27

1. Steering tower
2. Steering relief valve

Lift/Lower Circuit Relief Pressure (Using Pressure Gauge)



PRELIMINARY – For Toro Distributor and Toro Company use only.

Procedure for Lift/Lower Circuit Relief Pressure Test

NOTE: Before attempting to check or adjust lift pressure, make sure that counterbalance pressure is correctly adjusted.

1. Make sure hydraulic oil is at normal operating temperature by operating the machine for approximately 10 minutes. Make sure the hydraulic tank is full.
2. Park machine on a level surface with the cutting units lowered and off. Make sure engine is off and the parking brake is engaged.



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

3. Raise seat to gain access to hydraulic test fitting. Connect a 5,000 psi gauge to lift circuit test port (Fig. 28). Route gauge hose to allow seat to be safely lowered.
4. Sit on the seat and start the engine. Move throttle to full speed (**2870 RPM**).
5. While sitting on the seat, pull lift lever back to raise the cutting units. Momentarily hold the lever with the lift cylinder at full extension while looking at the gauge.

GAUGE READING TO BE **1500 to 1600 PSI**.

6. Stop the engine. If pressure is too high, adjust relief valve in lift control valve by rotating counterclockwise (Figure 29). If pressure is too low, check for restriction in pump intake line. Check the lift cylinder for internal leakage. If cylinder is not leaking, adjust the relief valve by rotating clockwise. If pressure is still too low, pump or lift cylinder(s) should be suspected of wear, damage or inefficiency.




Figure 28

1. Lift circuit port
2. Hydraulic reservoir cap





Figure 29

1. Control valve assembly
2. Relief valve assembly
3. Washers
4. Spring
5. Poppet

Steering and Lift/Lower Gear Pump Flow (Using Tester with Pressure Gauges and Flow Meter)



- High Pressure
- Low Pressure
- - - Return or Suction
- Flow

PRELIMINARY – For Toro Distributor and Toro Company use only.

Procedure for Steering and Lift/Lower Gear Pump Flow Test

Output from the steering and lift/lower gear pump section is equally divided by a proportional valve to provide flow to the steering circuit and the lift circuit. To test gear pump flow, testing of both circuits is required. Total gear pump flow is the combined flow from the two circuits.

1. Make sure hydraulic oil is at normal operating temperature by operating the machine for approximately 10 minutes. Make sure the hydraulic tank is full.
2. Park machine on a level surface with the cutting units lowered and off. Make sure engine is off and the parking brake is engaged.



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

IMPORTANT: Make sure that the oil flow indicator arrow on the flow gauge is showing that the oil will flow from the pump, through the tester and into the hydraulic hose.

3. With the engine off and cutting units lowered, install tester in series between the last gear pump section and one of the circuit hoses. Make sure the tester flow control valve is OPEN.

IMPORTANT: The pump is a positive displacement type. If pump flow is completely restricted or stopped, damage to the pump, tester or other components could occur.

4. Start the engine and move throttle to full speed (**2870 RPM**). DO NOT engage the cutting units.
5. While watching pressure gauges, slowly close flow control valve until **1000 PSI** is obtained on gauge. Verify engine speed continues to be correct (**2870 RPM**).


GUAGE READING TO BE: Flow approximately **3.5 GPM** at **1000 PSI**.

6. Stop engine. Remove tester and reinstall hose. Complete steps 3 through 6 for other circuit hose.

7. If the **total** of the two flows is lower than **7 GPM** or a pressure of **1000 PSI** could not be obtained, check for restriction in pump intake line. If intake line is not restricted, remove gear pump and repair or replace as necessary.

If the **total** of the two flows is **7 GPM** but individual circuit flow is less than **3.5 GPM** (e.g. steering circuit has 2 GPM and lift circuit has 5 GPM), suspect a problem with the proportional valve in the gear pump.

Counterbalance Pressure (Using Pressure Gauge)



PRELIMINARY – For Toro Distributor and Toro Company use only.

Procedure for Counterbalance Pressure Test

1. Make sure hydraulic oil is at normal operating temperature by operating the machine for approximately 10 minutes. Make sure the hydraulic tank is full.
2. Park machine on a level surface with the cutting units lowered and off. Make sure engine is off and the parking brake is engaged.



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

3. Determine system charge pressure (see Traction Circuit Charge Pressure in this chapter).
4. Connect a 1000 PSI gauge to counterbalance test port on manifold under console (Fig. 30).
5. Start the engine and put throttle at full engine speed (2870 RPM) with no load on the system. **Do not engage the cutting units.**

GAUGE READING TO BE 220 PSI (15.2 bar) over system charge pressure (e.g. if charge pressure is 250 PSI, counterbalance pressure should be 470 PSI).

6. Adjustment of the counterbalance valve can be performed as follows:

NOTE: Do not remove the valve from the hydraulic manifold for adjustment.

- A. Loosen locknut on counterbalance valve (Fig. 30).
- B. To **increase** pressure setting, turn the adjustment screw on the valve in a clockwise direction. A 1/8 turn on the screw will make a measurable change in counterbalance pressure.
- C. To **decrease** pressure setting, turn the adjustment screw on the valve in a counterclockwise direction. A 1/8 turn on the screw will make a measurable change in counterbalance pressure.
- D. Tighten locknut to secure adjustment. Check counterbalance pressure and readjust as needed.





Figure 30

- | | |
|-----------------------------|--------------------|
| 1. Counterbalance test port | 3. Locknut |
| 2. Counterbalance valve | 4. Adjusting screw |

Rear Traction Circuit (RV5) Relief Pressure (Using Pressure Gauge)



PRELIMINARY – For Toro Distributor and Toro Company use only.

Procedure for Rear Traction Circuit (RV5) Relief Pressure Test

1. Make sure hydraulic oil is at normal operating temperature by operating the machine for approximately 10 minutes. Make sure the hydraulic tank is full.
2. Park machine on a level surface with the cutting units lowered and off. Make sure engine is off and the parking brake is engaged.



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

3. Connect a 1000 PSI gauge to test port on 2WD/4WD control manifold under radiator (Fig. 31).
4. Start the engine and put throttle at full engine speed (2870 RPM).
5. Operate the machine in 4WD with the cutting units lowered. Drive down a slope in a forward direction, decrease pressure on the traction pedal and monitor the pressure gauge. Pressure should increase until the relief valve lifts.

GUAGE READING TO BE **750 PSI** (approximate).

6. Relief valve (RV5) is located on the lower, front side of the 2WD/4WD control manifold (Fig. 32). Adjustment of the relief valve can be performed as follows:

NOTE: Do not remove the valve from the hydraulic manifold for adjustment.

- A. To **increase** relief pressure setting, remove cap on relief valve and turn the adjustment socket on the relief valve in a clockwise direction. A 1/8 turn on the socket will make a measurable change in relief pressure (Fig. 33).
- B. To **decrease** pressure setting, remove cap on relief valve and turn the adjustment socket on the relief valve in a counterclockwise direction. A 1/8 turn on the socket will make a measurable change in relief pressure (Fig. 33).
- C. Recheck relief pressure and readjust as needed.




Figure 31

1. 2WD/4WD control manifold
2. Relief valve test port




Figure 32

1. Manifold: lower side
2. Relief valve (RV5)





Figure 33

1. Relief valve cap
2. Adjustment socket

Traction Circuit Reducing Valve (PR) Pressure (Using Pressure Gauge)



—— Working Pressure
—— Low Pressure
..... Return or Suction
➤ Flow

PRELIMINARY – For Toro Distributor and Toro Company use only.

Procedure for Traction Circuit Reducing Valve (PR) Pressure Test

1. Make sure hydraulic oil is at normal operating temperature by operating the machine for approximately 10 minutes. Make sure the hydraulic tank is full.
2. Park machine on a level surface with the cutting units lowered and off. Make sure engine is off and the parking brake is engaged.



CAUTION

Prevent personal injury and/or damage to equipment. Read all WARNINGS, CAUTIONS and Precautions for Hydraulic Testing at the beginning of this section.

3. Connect a 1000 PSI gauge to test port on 2WD/4WD control manifold under radiator (Fig. 34).
4. Start the engine and put throttle at full engine speed (2870 RPM).
5. Sit on seat, apply brakes fully and slowly depress the traction pedal in the reverse direction. While pushing traction pedal, look at pressure reading on gauge:

GUAGE READING TO BE approximately **650 PSI**.

6. Pressure reducing valve (PR) is located on the lower, front side of the 2WD/4WD control manifold (Fig. 35). Adjustment of this valve can be performed as follows:

NOTE: Do not remove the valve from the hydraulic manifold for adjustment.

A. To **increase** pressure setting, remove cap on reducing valve and turn the adjustment socket on the valve in a clockwise direction. A 1/8 turn on the socket will make a measurable change in pressure setting.

B. To **decrease** pressure setting, remove cap on reducing valve and turn the adjustment socket on the valve in a counterclockwise direction. A 1/8 turn on the socket will make a measurable change in pressure setting.

C. Recheck pressure setting and readjust as needed.




Figure 34

1. 2WD/4WD control manifold
2. Pressure test port




Figure 35

1. Manifold: lower side
2. Reducing valve (PR)

Adjustments

Adjust Front Cutting Unit Lift Flow Control

The front cutting unit lift circuit is equipped with an adjustable flow control valve used to adjust the rate at which the front cutting deck lowers. Adjust flow control valve as follows:

1. Run machine to get hydraulic oil at operating temperatures. Park machine on a level surface, shut engine off and lower cutting units to the ground.
2. Locate flow control valve under front of machine (Fig. 36).
3. Loosen setscrew on valve and rotate valve clockwise to slow down drop rate of front cutting unit.
4. Verify adjustment by raising and lowering cutting unit several times. Readjust as required.
5. After desired drop rate is attained, tighten setscrew on flow control valve to lock adjustment.




Figure 36

1. Front cutting unit flow control valve

This page is intentionally blank.

Service and Repairs

General Precautions for Removing and Installing Hydraulic System Components

Before Repair or Replacement of Components

1. Before removing any parts from the hydraulic system, park machine on a level surface, engage parking brake, lower cutting units or attachments and stop engine. Remove key from the ignition switch.
2. Clean machine before disconnecting, removing or disassembling any hydraulic components. Make sure hydraulic components, hoses connections and fittings are cleaned thoroughly. Always keep in mind the need for cleanliness when working on hydraulic equipment.



CAUTION

Operate all hydraulic controls to relieve system pressure and avoid injury from pressurized hydraulic oil. Controls must be operated with the ignition switch in RUN and the engine OFF. Make sure all electrically operated control valves are actuated. Return ignition switch to OFF when pressure has been relieved. Remove key from the ignition switch.

3. Put caps or plugs on any hydraulic lines, hydraulic fittings and components left open or exposed to prevent contamination.
4. Put labels on disconnected hydraulic lines and hoses for proper installation after repairs are completed.
5. Note the position of hydraulic fittings (especially elbow fittings) on hydraulic components before removal. Mark parts if necessary to make sure they will be aligned properly when reinstalling hydraulic hoses and tubes.

After Repair or Replacement of Components

1. Check oil level in the hydraulic reservoir and add correct oil if necessary. Drain and refill hydraulic system reservoir and change oil filter if component failure was severe or system is contaminated (see Flush Hydraulic System).
2. Lubricate O-rings and seals with clean hydraulic oil before installing hydraulic components.
3. Make sure caps or plugs are removed from the hydraulic tubes, hydraulic fittings and components before reconnecting.
4. Use proper tightening methods when installing hydraulic hoses and fittings (see Hydraulic Fitting Installation in the General Information section of this chapter).
5. After repairs, check control linkages or cables for proper adjustment, binding or broken parts.
6. After disconnecting or replacing any hydraulic components, operate machine functions slowly until air is out of system (see Charge Hydraulic System in the Service and Repairs section of this Chapter).
7. Check for hydraulic oil leaks. Shut off engine and correct leaks if necessary. Check oil level in hydraulic reservoir and add correct oil if necessary.

Check Hydraulic Lines and Hoses



WARNING

Keep body and hands away from pin hole leaks or nozzles that eject hydraulic fluid under high pressure. Use paper or cardboard, not hands, to search for leaks. Hydraulic fluid escaping under pressure can have sufficient force to penetrate the skin and cause serious injury. If fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury. Gangrene may result from such an injury.

IMPORTANT: Check hydraulic lines and hoses daily for leaks, kinked lines, loose mounting supports, wear, loose fittings, weather deterioration and chemical deterioration. Make all necessary repairs before operating.

Flush Hydraulic System

IMPORTANT: Flush the hydraulic system any time there is a severe component failure or the system is contaminated (oil appears milky, black or contains metal particles).

IMPORTANT: Flush hydraulic system when changing from petroleum base hydraulic fluid to a biodegradable fluid such as Mobil EAL 224H. Operate machine under normal operating conditions for at least four (4) hours before draining.

1. Park machine on a level surface. Lower cutting units, stop engine and engage parking brake. Remove key from the ignition switch.



CAUTION

Operate all hydraulic controls to relieve system pressure and avoid injury from pressurized hydraulic oil. Controls must be operated with the ignition switch in OFF. Remove key from the ignition switch.

IMPORTANT: Make sure to clean around any hydraulic connections that will be disconnected for draining.

2. Drain hydraulic reservoir.
3. Drain hydraulic system. Drain all hoses, tubes and components while the system is warm.
4. Change and replace both hydraulic oil filters.
5. Inspect and clean hydraulic reservoir (see Hydraulic Reservoir Inspection).

6. Reconnect all hydraulic hoses, lines and components that were disconnected while draining system.

NOTE: Use only hydraulic fluids specified in the Operator's Manual. Other fluids may cause system damage.

7. Fill hydraulic reservoir with **new** hydraulic fluid.

8. Disconnect electrical connector from engine run solenoid.

9. Turn ignition key switch; engage starter for 10 seconds to prime pump. Repeat this step again.

10. Connect electrical connector to engine run solenoid.

11. Start engine and let it idle at low speed (**1450 RPM**) for a minimum of 2 minutes. Increase engine speed to high idle (**2870 RPM**) for minimum of 1 minute under no load.

12. Raise and lower cutting units several times. Turn steering wheel fully left and right several times.

13. Shut off engine and check for hydraulic oil leaks. Check oil level in hydraulic reservoir and add correct amount of oil if necessary.

14. Operate machine for 2 hours under normal operating conditions.

15. Check condition of hydraulic oil. If the new fluid shows any signs of contamination, repeat steps 1 through 14 again until oil is clean. If changing to biodegradable fluid, repeat steps 1 through 14 again at least once and until the oil is clean.

16. Assume normal operation and follow recommended maintenance intervals.

Charge Hydraulic System

NOTE: When initially starting the hydraulic system with new or rebuilt components such as motors, pumps or lift cylinders, it is important that the hydraulic system be charged properly. Air must be purged from the system and its components to reduce the chance of damage.

IMPORTANT: Change hydraulic oil filter whenever hydraulic components are repaired or replaced.

1. Park machine on a level surface. Lower cutting units, stop engine and engage parking brake. Remove key from the ignition switch.
2. Make sure all hydraulic connections, lines and components are secured tightly.
3. If component failure was severe or the system is contaminated, flush and refill hydraulic system and tank (see Flush Hydraulic System in this section).
4. Make sure hydraulic reservoir is full. Add correct hydraulic oil if necessary.
5. Disconnect engine run solenoid lead to prevent the engine from starting.
6. Check control rod to the piston (traction) pump for proper adjustment, binding or broken parts.
7. Make sure traction pedal and lift control lever are in the **neutral** position. Turn ignition key switch; engage starter for **fifteen (15) seconds** to prime the traction and gear pumps.
8. Reconnect engine run solenoid lead.



WARNING

Before jacking up the machine, review and follow Jacking Instructions in Chapter 1 – Safety.

9. Raise one front and one rear wheel off the ground and place support blocks under the frame. Chock remaining wheels to prevent movement of the machine.
10. Make sure traction pedal and lift control lever are in **neutral**. Start engine and run it at low idle (**1450 rpm**). The charge pump should pick up oil and fill the hydraulic system. If there is no indication of fill in **30 seconds**, stop the engine and determine the cause.

11. After the hydraulic system starts to show signs of fill, actuate lift control lever until the lift cylinder rod moves in and out several times. If the cylinder rod does not move after **10 to 15 seconds**, or the pump emits abnormal sounds, shut the engine off immediately and determine cause or problem. Inspect for the following:

- A. Loose filter or suction lines.
- B. Blocked suction line.
- C. Faulty charge relief valve.
- D. Faulty gear pump.

12. If cylinder does move in **10 to 15 seconds**, proceed to step 13.

13. Operate the traction pedal in the forward and reverse directions. The wheels off the ground should rotate in the proper direction.

- A. If the wheels rotate in the wrong direction, stop engine, remove lines from bottom of piston (traction) pump and reverse the connections.
- B. If the wheels rotate in the proper direction, stop engine.

14. Adjust traction pedal to the neutral position.

15. Check operation of the traction interlock switch (see Check Interlock System in Chapter 5 – Electrical System).

16. Remove blocks from frame and lower machine. Remove chocks from remaining wheels.

17. If the piston (traction) pump or a traction motor was replaced or rebuilt, run the machine so all wheels turn slowly for 10 minutes.

18. Operate machine by gradually increasing its work load to full over a 10 minute period.

19. Stop the machine. Check hydraulic reservoir and fill if necessary. Check hydraulic components for leaks and tighten any loose connections.

Gear Pump




Figure 37

- | | | |
|--------------------------|-------------------------|-----------------|
| 1. 90° hydraulic fitting | 10. O-ring | 19. Flat washer |
| 2. O-ring | 11. Clamp | 20. Engine |
| 3. O-ring | 12. Hydraulic T fitting | 21. Piston pump |
| 4. 90° hydraulic fitting | 13. O-ring | 22. O-ring |
| 5. O-ring | 14. Hydraulic fitting | 23. Coupler |
| 6. O-ring | 15. Fitting cap | 24. Gear pump |
| 7. Hydraulic fitting | 16. Hydraulic fitting | 25. Spacer |
| 8. O-ring | 17. O-ring | 26. Cap screw |
| 9. Hydraulic fitting | 18. Cap screw | 27. Washer |

Removal (Fig. 37)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Raise seat and secure it with prop rod to gain access to gear pump.
3. Drain the hydraulic reservoir.
4. To prevent contamination of hydraulic system during removal, thoroughly clean exterior of pump and fittings.
5. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
6. Disconnect hydraulic lines from pump and put caps or plugs on open hydraulic lines and fittings. Label disconnected hydraulic lines for proper installation.
7. Support gear pump assembly to prevent it from falling.
8. Remove two (2) cap screws and washers securing gear pump to piston pump. Remove gear pump, coupler, spacer and O-rings from machine.

Installation (Fig. 37)

1. Lubricate new O-rings with clean hydraulic oil and position on pump.
2. Slide coupler onto the piston pump output shaft.
3. Position O-rings and spacer to gear pump. Align gear teeth and slide gear pump input shaft into coupler. Secure gear pump to piston pump with two (2) cap screws and washers. Torque screws from **79 to 84 ft-lb (108 to 113 N-m)**.
4. Remove caps or plugs from hydraulic lines and fittings. Install lines to gear pump.
5. Replace hydraulic filter and fill hydraulic reservoir with new hydraulic oil.
6. Disconnect engine run solenoid electrical connector to prevent engine from starting. Prime the hydraulic pump by turning the ignition key switch to start and crank the engine for 10 seconds. Repeat cranking procedure again.
7. Connect engine run solenoid electrical connector, start the engine and check for proper operation.
8. Properly fill hydraulic system (see Charge Hydraulic System in this section).
9. Stop engine and check for hydraulic oil leaks. Check hydraulic reservoir oil level.

Gear Pump Service




Figure 38

- | | | |
|--------------------------|---------------------------------------|------------------------|
| 1. Dust seal | 10. Seal (8 used) | 19. Body |
| 2. Retaining ring | 11. Idler gear | 20. Body |
| 3. Flange washer | 12. Drive shaft | 21. Drive gear |
| 4. Shaft seal | 13. Back-up gasket | 22. Idler gear |
| 5. Front cover | 14. Pressure seal | 23. Rear body |
| 6. Dowel pin (16 used) | 15. Front body | 24. Rear cover |
| 7. Pressure seal | 16. Splined connecting shaft (3 used) | 25. Cap screw (4 used) |
| 8. Back-up gasket | 17. Flange | 26. Washer (4 used) |
| 9. Thrust plate (8 used) | 18. Drive gear | |

Disassembly (Fig. 38)

NOTE: The gear pump must be replaced as a complete assembly. Individual gears, housings and thrust plates are not available separately. Disassemble gear pump for cleaning, inspection and seal replacement only.

IMPORTANT: Keep bodies, gears, flanges and thrust plates for each pump section together; do not mix parts between pump sections.

1. Plug pump ports and thoroughly clean exterior of pump with cleaning solvent. Make sure work area is clean.

2. Use a marker to make a **diagonal** line across the gear pump for assembly purposes (Fig. 39).




Figure 39

PRELIMINARY – For Toro Distributor and Toro Company use only.

IMPORTANT: Use caution when clamping gear pump in a vise to avoid distorting any pump components.

3. Secure the front cover of the pump in a vise with the drive shaft pointing down.
4. Loosen the four (4) cap screws that secure pump assembly.
5. Remove pump from vise and remove fasteners.
6. Support the pump assembly and gently tap the pump case with a soft face hammer to loosen the pump sections. Be careful to not drop parts or disengage gear mesh.

IMPORTANT: Mark the relative positions of the gear teeth and the thrust plates so they can be reassembled in the same position. Do not touch the gear surfaces as residue on hands may be corrosive to gear finish.

7. Remove the thrust plates and seals from each pump section. Before removing each gear set, apply marking dye to mating teeth to retain "timing". Pump efficiency may be affected if the teeth are not installed in the same position during assembly. Keep the parts for each pump section together; do not mix parts between sections.

8. Clean all parts. Check all components for burrs, scoring, nicks and other damage.

9. Replace the entire pump assembly if parts are excessively worn or scored.

Assembly (Fig. 38)

1. Apply clean hydraulic oil to all parts before assembling.

NOTE: Pressure seals and back-up gaskets fit in grooves machined into thrust plates. Body seals fit in grooves machined in body faces.

2. Assemble pump sections starting at front cover end. Apply grease or petroleum jelly to new section seals to hold them in position during gear pump assembly.
3. After pump has been assembled, tighten cap screws and nuts by hand. Rotate the drive shaft to check for binding. Protect the shaft if using a pliers.
4. Tighten the four (4) cap screws evenly in a crossing pattern to a torque of **33 ft-lb (45 N-m)**.

Piston (Traction) Pump




Figure 40

- | | | |
|--------------------------|---------------------------|-----------------|
| 1. Hydraulic T fitting | 11. O-ring | 21. Clamp |
| 2. O-ring | 12. Hose connector | 22. Roll pin |
| 3. O-ring | 13. 90° hydraulic fitting | 23. Piston pump |
| 4. 90° hydraulic fitting | 14. O-ring | 24. Gear pump |
| 5. O-ring | 15. Hydraulic T fitting | 25. Coupler |
| 6. O-ring | 16. Hydraulic fitting | 26. O-ring |
| 7. Hydraulic fitting | 17. Fitting cap | 27. Spacer |
| 8. O-ring | 18. Hydraulic fitting | 28. Cap screw |
| 9. O-ring | 19. Cap screw | 29. Washer |
| 10. Hydraulic fitting | 20. Flat washer | |

Removal (Fig. 40)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. To prevent contamination of hydraulic system during removal, thoroughly clean exterior of pump assembly.
3. Remove traction rod from control arm on piston pump by removing lock nut, spacer and cap screw.
4. Disconnect two (2) wires from neutral switch on traction pump.
5. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
6. For installation purposes, label all hydraulic lines that connect to gear pump and piston pump.
7. Put a drain pan below the pump assembly. Remove hydraulic hoses and fittings connected to piston and gear pumps. Put plugs or caps on disconnected hydraulic hoses to prevent contamination of the system. Put plugs in open ports of pumps.
8. Remove gear pump from machine (see Gear Pump Removal in this section). Note: If fuel tank is loosened and raised from the machine, the gear pump and piston pump can be removed as a complete assembly.
9. Support the piston pump to prevent it from falling while removing two (2) cap screws and washers retaining pump assembly to engine flywheel plate. Carefully pull pump assembly from flywheel plate and raise it out of the machine.

Installation (Fig. 40)

1. Carefully lower piston pump into the machine, align pump input shaft to spring coupler on engine and position it to the engine flywheel plate. Support pump to prevent it from producing any side load into coupler and also to align pilot diameter of pump to flywheel plate bore.
2. While maintaining pump alignment with spring coupler and flywheel plate, install two (2) cap screws and washers to secure piston pump to engine flywheel plate. Torque screws from **79 to 84 ft-lb (108 to 113 N-m)**.
3. Install gear pump to piston pump (see Gear Pump Installation).
4. Position traction rod to control arm on piston pump by installing cap screw, spacer and lock nut.
5. Connect two (2) wires to neutral switch on traction pump.
6. Remove plugs or caps from disconnected hydraulic hoses and open ports of the pump assembly. Install fittings and hoses to correct location on gear and piston pumps.
7. Install new filter and fill hydraulic reservoir with correct oil.
8. Disconnect engine run solenoid electrical connector to prevent engine from starting. Prime pumps by turning ignition key switch to crank engine for 10 seconds. Repeat cranking procedure again.
9. Connect engine run solenoid electrical connector, start the engine and check for proper operation.
10. Properly fill hydraulic system (see Charge Hydraulic System in this section).
11. Stop engine and check for hydraulic oil leaks. Check hydraulic reservoir oil level.

Piston (Traction) Pump Service




Figure 41

- | | | |
|--------------------------|----------------------------|-----------------------------|
| 1. Jam nut | 16. Relief valve (Reverse) | 31. Flat washer |
| 2. Retaining ring | 17. Socket head screw | 32. Housing gasket |
| 3. Retaining ring | 18. Valve plate | 33. Cover plate gasket |
| 4. Seal washer | 19. Pump housing | 34. Control assembly gasket |
| 5. Socket head screw | 20. Backplate assembly | 35. Plug |
| 6. Rotating kit assembly | 21. Drive shaft | 36. O-ring |
| 7. Servo piston assembly | 22. Nut | 37. Seal sub-assembly |
| 8. Piston follower | 23. Lock washer | 38. Roll pin |
| 9. Cover plate | 24. Washer | 39. Bearing |
| 10. Cover plate | 25. Shaft seal | 40. Dowel bushing |
| 11. Camplate assembly | 26. Relief valve (Forward) | 41. Cradle sub-assembly |
| 12. Thrust race | 27. Control arm | 42. Cap screw |
| 13. Thrust bearing | 28. Servo control assembly | 43. Button head cap screw |
| 14. Bypass valve | 29. Washer | 44. Bushing |
| 15. Cap screw | 30. Orifice plate (3 used) | 45. Bearing |

Disassembly (Fig. 41)

1. Position the pump into a protected jaw vise, clamping onto the outer portion of the flange, with the cap screws up. Mark the relationship of the working ports (for reassembly identification) to the servo control assembly with a scribe. Remove the four cap screws (15) retaining backplate (20).
2. Lift backplate (20) straight up off drive shaft (21) and housing (19). Remove valve plate (18) from backplate (20) or from rotating kit assembly (6), still in housing (19).
3. From backplate (20), remove bypass valve (14), forward relief valve (26) and reverse relief valve (16). Note: Mark the valves in relationship to the cavity it was removed, for reassembly purposes.
4. Remove housing gasket (32) from housing (19) or backplate (20).
5. With pump still in vise, remove the six socket head screws (17) retaining the servo control assembly (28). Remove the control assembly and control housing gasket (34) from the housing. Remove orifice plates (30), noting location for reassembly. Remove nut (22), lock washer (23) and control arm (27) from servo control input shaft. Note position of control arm for reassembly.
6. To remove rotating kit assembly (6) from housing, first remove pump from vise holding the rotating kit assembly in position. Lower pump so that the shaft end (flange end) is up. Set the rear of housing onto table with housing flat and rotating kit assembly at rest on table. (Hole in table, for protruding shaft, is required.) Lift and remove the housing (19) and drive shaft (21) from rotating kit assembly (6) and camplate assembly(11).
7. Remove camplate (11) from rotating kit assembly (6) and servo piston follower (8) from camplate (11).
8. Remove the four socket head screws (5) and washers (31) retaining each cover plate (9 & 10).
9. Remove jam nut (1), washer (29) and seal washer (4). Hold the servo piston bolt with hex key and unscrew cover plate (10) from bolt.
10. Remove servo piston assembly (7) and seal sub-assemblies (two sets) (37) from housing. Note: Disassembly of servo piston assembly is not required.
11. Remove retaining ring (2) from the front of pump housing (19). Press the drive shaft (21), shaft seal (25) and washer (24) from housing. Remove retaining ring (3), thrust race (12), thrust bearing (13), second thrust race (12) and second retaining ring (3) from drive shaft (21).

12. Remove the two cap screws (42) that secure cradle sub-assembly inside housing. Move the cradle sub-assembly back-and-forth to release dowel bushings (40) and remove cradle sub-assembly from housing.

13. Remove button head cap screw (43) to remove bushing (44) from cradle.

14. Remove remaining plugs from housing.

15. Discard the shaft seal (25), gaskets (32, 33, 34) and O-rings from all assemblies. Replace with new seals upon reassembly.

Inspection

1. Inspect backplate assembly:

A. Check the bearing (45) (press fit) in backplate (20). If needles remain in cage, move freely and setting is at the dimension shown in Figure 42, bearing removal is not required.

B. Check roll pin (38) in backplate (20). If tight and set to the dimension shown in Figure 42, removal not required.




Figure 42

2. Check the bearing (39) (press fit) in pump housing (19). If needles remain in cage, move freely and setting at the dimension shown in Figure 43, bearing removal is not required.




Figure 43

PRELIMINARY – For Toro Distributor and Toro Company use only.

3. Inspect camplate assembly:

- A. The finish on the piston shoe surfaces of the camplate (11) should show no signs of scoring.
- B. Inspect camplate (11) bushing surface for wear. Also inspect surface for coating transfer from bushing.

4. Inspect bushing (44) for contamination embedment within coating of bushing surface coming in contact with camplate (11).

5. Inspect rotating kit (Fig. 44):

- A. The pistons should move freely in the rotating kit piston block bore. If they are sticky in the bore, examine the bore for scoring or contamination.
- B. Examine the O.D. of the pistons for finish condition. They should not show wear or deep scratches. Inspect the shoes for a snug fit on the ball end of the pistons and a flat smooth surface that comes in contact with the camplate. **Do not lap piston shoes.**
- C. Examine the spider for wear in the pivot area.
- D. Examine the spider pivot to insure smoothness and no signs of wear.

Assembly (Fig. 41)

1. All parts should be cleaned and internal pump parts lubricated with clean hydraulic oil before reassembly.
2. If necessary, press new bearing into pump housing to dimension shown in Figure 43 with the numbered end of bearing outward.
3. Install the two new seal sub-assemblies (37) into the servo piston cavity of pump housing (19).
4. Screw the cover plate (10) onto the servo piston assembly (7). Install new cover plate gasket (33) in place on pump housing. Install servo piston assembly (7) and cover plate (10) into servo piston bore in right side of housing (Fig. 45). Retain cover plate with four washers (31) and socket head screws (5). Torque screws from **40 to 48 in-lb (4.5 to 5.4 N-m)**. To obtain neutral, centering the servo piston assembly is required. Measure in from the left side and set servo piston 0.500 in. (12.7 mm) from surface of housing servo bore as shown in Figure 45.

NOTE: Re-adjustment may be required for neutral at unit start-up.




Figure 44

- | | |
|----------------------|-----------------|
| 1. Piston assemblies | 4. Piston block |
| 2. Spider | 5. Retainer |
| 3. Spider pivot | |




Figure 45

5. Install new seal washer (4), washer (29) and jam nut (1) to servo piston bolt. Holding servo piston bolt with hex key wrench, torque jam nut from **150 to 160 in-lb (17 to 18 N-m)**. Check the centering of servo piston assembly (7). Install new cover plate gasket (33) and cover plate (9) to open side of servo piston and retain with four washers (31) and socket head screws (5). Torque screws from **40 to 48 in-lb (4.5 to 5.4 N-m)**.
6. Press dowel bushings (40) into cradle and secure bushing (44) onto cradle with button head cap screw (43). Torque button head cap screw from **14 to 16 in-lb (1.6 to 1.8 N-m)**.
7. Place cradle sub-assembly (41) into housing (19) making sure dowel bushings (40) and cradle (41) are completely seated into housing. Retain cradle sub-assembly with two cap screws (42) after applying Loctite #277 (or equivalent) to the end of threads. Torque cap screws from **25 to 28 ft-lb (34 to 38 N-m)**.

PRELIMINARY – For Toro Distributor and Toro Company use only.

8. Place exterior retaining ring (3), thrust race (12), thrust bearing (13), second thrust race (12) and second retaining ring (3) onto drive shaft (21). Position washer (24) and shaft seal (25) onto shaft.
9. Install shaft assembly into front of housing. Seat seal (25) into position with seal driver and retain with interior retaining ring (2).
10. Install servo piston follower (8) onto camplate dowel pin. Install camplate (11) carefully onto bushing (44) (coat bushing surface with hydraulic oil), aligning servo piston follower (8) with slot in servo piston assembly (7).
11. Position housing in a horizontal position. Holding camplate (11) in position with screw driver through controller linkage passageway at the top of housing, place rotating kit assembly (6) over shaft and into housing until pistons are against camplate (11). Make sure all parts are in housing completely and are properly positioned. Return the pump to the vise with open end of housing up, clamping housing on the outer portion of the flange.
12. Install gasket (32) onto housing.
13. If necessary, press new bearing (45) and roll pin (38) in backplate (20) to dimension shown in Figure 42. Note: Bearing should be installed with the numbered end outward. Roll pin should be installed with split oriented away from bearing.
14. Install new O-ring on relief valves (16 & 26). Install relief valve in the cavity in backplate that it was removed and torque from **100 to 110 ft-lb (136 to 149 N-m)**.
15. Install new O-ring on bypass valve (14). Install bypass valve (14) into backplate (20). Note: Make sure paddle of bypass valve is perpendicular to relief valve axis prior to installing or damage could result.
16. Apply a small amount of petroleum jelly to the steel side of valve plate (18) to hold in place for installation. Aligning the index pin, place the valve plate (18) in position onto the backplate (20), with steel side against backplate.
17. Install backplate assembly (20) onto housing assembly (19). Make sure ports are positioned correctly and that valve plate (18) and gasket (32) stay in place.
18. Retain backplate (20) with four cap screws (15). Torque cap screws from **27 to 31 ft-lb (37 to 42 N-m)**.
19. Install control housing gasket (34) onto housing. Install orifices (30) into servo control assembly (28) and retain in position with petroleum jelly. Position the feedback link at 90 degrees from control housing. Install manual servo control assembly (28) onto housing making sure feedback link entered small groove in servo piston assembly (7).
20. Secure control assembly with six socket head screws (17). Torque screws from **40 to 48 in-lb (4.5 to 5.4 N-m)**.
21. Install control arm (27) onto control assembly input shaft. Retain with lock washer (23) and nut (22). Torque nut from **4 to 6 ft-lb (5 to 8 N-m)**.
22. Install remaining plugs that were removed from pump. Torque 3/4 in. plug from **21 to 24 ft-lb (28 to 32 N-m)**. Torque 1-1/4 in. plug from **40 to 45 ft-lb (54 to 61 N-m)**.

Piston Pump Control Assembly




Figure 46

- | | |
|--------------------|--------------------|
| 1. Plug | 9. O-ring |
| 2. O-ring | 10. Wiper seal |
| 3. Retaining ring | 11. O-ring |
| 4. Spring retainer | 12. Adaptor |
| 5. Spring | 13. Ball |
| 6. Spool valve | 14. Pin |
| 7. Control housing | 15. Neutral switch |
| 8. Input shaft | 16. O-ring |

- | |
|--------------------|
| 17. Set screw |
| 18. Set screw |
| 19. Pin |
| 20. Retaining ring |
| 21. Feedback link |
| 22. Dowel pin |
| 23. Bell crank |
| 24. Set screw |

Disassembly – Manual Servo Control Assembly

1. Remove wiper seal with screw driver. Remove set screw (18) that retains input shaft and remove input shaft from control housing. Remove O-ring from shaft.
2. Remove set screw (24) from plug that retains valve spool. Remove plug from control housing and O-ring from plug.
3. Remove retaining ring (20) from pin that retains feedback link and spool valve. Remove pin, feedback link, spool valve and bell crank from control housing.
4. Compress spring and remove retaining ring (3). Remove spring retainer, spring and second spring retainer from spool valve.
5. Clean all parts and lubricate in clean hydraulic oil for reassembly.

Assembly – Manual Servo Control Assembly

1. Install spring retainer, spring and second spring retainer onto spool valve. Compress spring to allow retaining ring (3) to be installed onto spool valve.
2. Install spool valve into control housing making sure that metering notches on spool valve can be seen in the metering ports.
3. Position bell crank in housing. Slide feedback link into position between clevis on valve spool, aligning holes and install dowel pin and retaining ring (20).
4. Install new O-ring (9) onto input shaft. Hold bell crank in position with feedback link slot and align splined hole of bell crank with input shaft cavity. Install input shaft into control housing and bell crank.

PRELIMINARY – For Toro Distributor and Toro Company use only.

5. Apply Loctite #242 or equivalent to set screw (18) and install into control housing. Adjust set screw until it bottoms out on input shaft and back out one-quarter turn.

6. Install wiper seal on input shaft.

7. Install new O-ring (2) onto plug and install plug. Adjust plug until there is no end play in the valve spool with input shaft held stationary. Secure plug in place with set screw (24). Torque set screw from **17 to 26 in-lb (2 to 3 N-m)**.

Disassembly – Neutral Switch

1. Loosen set screw (17) in adapter and remove neutral switch from adapter.

2. Remove adapter from control housing.

3. Remove pin, ball and O-rings (11 & 16) from adapter.

Assembly – Neutral Switch

1. Install new O-ring (11) onto adapter and new O-ring (16) onto pin.

2. Install ball and pin into adapter. Lubricate with petroleum jelly to hold in place during installation.

3. Install adapter into control housing. Torque from **44 to 52 ft-lb (60 to 70 N-m)**.

4. Apply Loctite #222 or equivalent to threads of neutral switch and install switch into adapter. The adjustment procedure for the switch are as follows.

A. Install switch, while moving link back and forth, until “detent” action is detected. Back out the switch until the “detent” action is very slight.

B. Attach the leads from a test light to the switch terminals. **Note:** A multimeter could be used instead of a test light.

C. Move the link out of the detent position. The test light will go on. Screw in the switch until the light goes off. Mark this as position “A” (Fig. 47). Move the link to the detent position and the test light should come back on.

D. Leaving the link in the detent position, the light will remain on. Screw in the switch until the light goes off. Mark this position “B”.

E. Unscrew the switch one third of the distance between “B” and “A”. Install and tighten the set screw (17) in one of the upper quadrants of the hex of the switch adapter (Fig. 47). Torque set screw from **28 to 34 in-lb (3.2 to 3.8 N-m)**.

5. Test the switch by moving the control arm to the det-

ent position, the light should be on. Move the control arm out of detent, the light should go off.

6. Remove test light and put servo control assembly into operation.




Figure 47

Hydraulic Control Manifold: 4 Wheel Drive




Figure 48

- | | | |
|--------------------------|---------------------------|-----------------------|
| 1. Frame assembly | 8. Fitting cap | 14. Hydraulic fitting |
| 2. Manifold | 9. Hydraulic fitting | 15. Adapter |
| 3. 90° hydraulic fitting | 10. O-ring | 16. Hydraulic fitting |
| 4. O-ring | 11. O-ring | 17. O-ring |
| 5. O-ring | 12. 90° hydraulic fitting | 18. Cap screw |
| 6. Quick fitting | 13. O-ring | 19. Flange nut |
| 7. O-ring | | |

Removal (Fig. 48)

NOTE: The ports on the manifold are marked for easy identification of components. Example: P1 is a piston pump connection port and 2 is the location for the solenoid valve (See Hydraulic Schematic in Chapter 9 – Foldout Drawings to identify the function of the hydraulic lines and cartridge valves at each port).

1. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
2. Disconnect electrical connector from the solenoid valve.
3. Disconnect hydraulic lines from manifold and put caps or plugs on open hydraulic lines and fittings. Label disconnected hydraulic lines for proper installation.
4. Remove hydraulic manifold from the frame using Figure 48 as guide.

Installation (Fig. 48)

1. Install hydraulic manifold to the frame using Figure 48 as guide.
2. Remove caps and plugs from fittings and hoses. Properly connect hydraulic lines to manifold.
3. Connect electrical connector to the solenoid valve.

Hydraulic Control Manifold Service: 4 Wheel Drive




Figure 49

1. Manifold body
2. Solenoid valve (port SV)
3. Solenoid coil
4. Check valve (port CV)
5. Nut

6. Directional valve (ports PD1 & PD2)
7. Pressure reducing valve (port PR)
8. Relief valve (port RV)
9. Orifice (.030)

10. #4 zero leak plug with O-ring
11. #6 zero leak plug with O-ring
12. Orifice (.050)
13. #8 zero leak plug with O-ring

NOTE: The ports on the manifold are marked for easy identification of components. Example: P1 is a piston pump connection port and 2 is the location for the solenoid valve (See Hydraulic Schematics to identify the function of the hydraulic lines and cartridge valves at each port).

Cartridge Valve Service

1. Make sure the manifold is clean before removing the valve.
2. If cartridge is solenoid operated, remove nut securing solenoid to the cartridge valve. Carefully slide solenoid off the valve.

IMPORTANT: Use care when handling the valve cartridge. Slight bending or distortion of the stem tube can cause binding and malfunction.

3. Remove cartridge valve with a deep socket wrench. Note correct location for O-rings, sealing rings and backup rings. Remove and discard seal kit.
4. Visually inspect the port in the manifold for damage to the sealing surfaces, damaged threads and contamination.
5. Visually inspect cartridge valve for damaged sealing surfaces and contamination.
 - A. Contamination may cause valves to stick or hang up. Contamination can become lodged in small valve orifices or seal areas causing malfunction.
 - B. If valve sealing surfaces appear pitted or damaged, the hydraulic system may be overheating or there may be water in the system.



6. Clean cartridge valve using clean mineral spirits. Submerge valve in clean mineral spirits to flush out contamination. Particles as fine as talcum powder can affect the operation of high pressure hydraulic valves. If cartridge design allows, use a wood or plastic probe to push the internal spool in and out 20 to 30 times to flush out contamination. Be extremely careful not to damage cartridge. Use compressed air for cleaning.

7. Reinstall the cartridge valve:

A. Lubricate new seal kit components with clean hydraulic oil and install on valve. The O-rings, sealing rings and backup rings must be arranged properly on the cartridge valve for proper operation and sealing.

IMPORTANT: Use care when handling the valve cartridge. Slight bending or distortion of the stem tube can cause binding and malfunction.

B. Thread cartridge valve carefully into manifold port. The valve should go in easily without binding.

C. Torque cartridge valve using a deep socket to value identified in manifold illustration.

D. If cartridge is solenoid operated, carefully install solenoid coil to the cartridge valve. Apply "Loctite 242" or equivalent to the threads of the valve. Torque nut to value identified in manifold illustration.

8. If problems still exist, remove valve and clean again or replace valve.

Hydraulic Control Manifold: Deck Drive




Figure 50

- | | | |
|------------------------------------|--------------------------------|----------------------------------|
| 1. Hydraulic manifold (front deck) | 10. O-ring | 19. Elbow (90°) |
| 2. Quick fitting | 11. Cap screw | 20. Hydraulic fitting |
| 3. Flange nut | 12. Fitting cap | 21. O-ring |
| 4. O-ring | 13. Adapter | 22. O-ring |
| 5. Hydraulic fitting | 14. Adapter | 23. Adapter |
| 6. O-ring | 15. Straight hydraulic fitting | 24. O-ring |
| 7. O-ring | 16. Adapter | 25. Hydraulic manifold (RH deck) |
| 8. 45° hydraulic fitting | 17. O-ring | 26. Hydraulic manifold (LH deck) |
| 9. Adapter | 18. Hydraulic fitting | |

Removal (Fig. 50)

NOTE: The ports on the manifold are marked for easy identification of components. Example: SV1 is the deck solenoid valve and P1 is a gear pump connection port. (See Hydraulic Schematics to identify the function of the hydraulic lines and cartridge valves at each port).

1. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
2. Disconnect electrical connector from the solenoid valve.

3. Disconnect hydraulic lines from manifold and put caps or plugs on open hydraulic lines and fittings. Label disconnected hydraulic lines for proper installation.

4. Remove hydraulic manifold from the frame using Figure 50 as guide.

Installation (Fig. 50)

1. Install hydraulic manifold to the frame using Figure 50 as guide.
2. Remove caps and plugs from fittings and hoses. Properly connect hydraulic lines to manifold.
3. Connect electrical connector to the solenoid valve.

Hydraulic Control Manifold Service: Deck Drive




Figure 51

- | | | |
|-------------------------------------|--|----------------------------|
| 1. Manifold body | 8. Solenoid valve (port SV1) | 15. O-ring |
| 2. Spool logic cartridge (port BY1) | 9. Seal kit | 16. Plug (SAE #4) |
| 3. Seal kit | 10. Solenoid coil | 17. O-ring |
| 4. Spool logic cartridge (port BR1) | 11. Nut | 18. Plug (SAE #8) |
| 5. Seal kit | 12. Relief pilot cartridge (port R1BR) | 19. O-ring |
| 6. Relief valve (port R1BY) | 13. Seal kit | 20. Orifice plug (port MR) |
| 7. Seal kit | 14. Plug (SAE #2) | |

NOTE: The ports on the manifold are marked for easy identification of components. Example: SV1 is the deck solenoid valve and P1 is the gear pump connection port. (See Hydraulic Schematics to identify the function of the hydraulic lines and cartridge valves at each port location).

For solenoid and control valve service procedures, see Hydraulic Control Manifold Service: 4 Wheel Drive in this section. Refer to Figure 51 for cartridge valve installation torque.

The control manifolds for the three cutting decks are very similar. **Note:** When servicing the deck control manifolds, **DO NOT** interchange parts from one control manifold to another.

Hydraulic Control Manifold: Cutting Deck Lift/Lower




Figure 52

- | | | |
|----------------------------------|---------------------------|---------------------------|
| 1. Lift/lower hydraulic manifold | 7. Lock nut | 12. Cap screw |
| 2. Valve plate | 8. Hydraulic fitting | 13. 90° hydraulic fitting |
| 3. Flat washer | 9. O-ring | 14. O-ring |
| 4. Cap screw | 10. O-ring | 15. Test nipple |
| 5. Grommet | 11. 90° hydraulic fitting | 16. Fitting cap |
| 6. Flat washer | | |

Removal (Fig. 52)

NOTE: The ports on the manifold are marked for easy identification of components. Example: C1 is the connection port from the LH deck lift cylinder and CHG is the charge circuit connection (See Hydraulic Schematics to identify the function of the hydraulic lines and cartridge valves at each port).

1. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
2. Disconnect hydraulic lines from manifold and put caps or plugs on open hydraulic lines and fittings. Label disconnected hydraulic lines for proper reassembly.
3. Remove hydraulic manifold from the frame using Figure 52 as guide.

Installation (Fig. 52)

1. Install hydraulic manifold to the frame using Figure 52 as guide.
2. Remove caps and plugs from fittings and hoses. Properly connect hydraulic lines to manifold.

Hydraulic Control Manifold Service: Cutting Deck Lift/Lower




Figure 53

- 1. Manifold body
- 2. Pilot valve
- 3. Seal kit

- 4. Relief valve (Counterbalance)
- 5. Seal kit

- 6. Plug (SAE #2)
- 7. O-ring

NOTE: The ports on the manifold are marked for easy identification of components. Example: C1 is the connection port from the LH deck lift cylinder and CHG is the charge circuit connection (See Hydraulic Schematics to identify the function of the hydraulic lines and cartridge valves at each port).

For cartridge valve service procedures, see Hydraulic Control Manifold Service: 4 Wheel Drive in this section. Refer to Figure 53 for cartridge valve installation torque.

Hydraulic Manifold: Filter Manifold




Figure 54

- | | | |
|------------------------|-----------------------|---------------------------|
| 1. Filter manifold | 9. Flat washer | 17. 90° hydraulic elbow |
| 2. 45° hydraulic elbow | 10. Hydraulic fitting | 18. Hydraulic hose |
| 3. Test nipple | 11. O-ring | 19. Hydraulic fitting |
| 4. Fitting cap | 12. O-ring | 20. 90° hydraulic fitting |
| 5. O-ring | 13. Hydraulic fitting | 21. O-ring |
| 6. O-ring | 14. Hydraulic hose | 22. Hose clamp |
| 7. O-ring | 15. O-ring | 23. Filter hose |
| 8. Cap screw | 16. O-ring | |

Removal (Fig. 54)

NOTE: The ports on the manifold are marked for easy identification of components. Example: P2 is the gear pump connection port and CD is the connection for the case drain from the deck motors (See Hydraulic Schematics to identify the function of the hydraulic lines and cartridge valves at each port).

1. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.

2. Disconnect hydraulic lines from manifold and put caps or plugs on open hydraulic lines and fittings. Label disconnected hydraulic lines for proper reassembly.

3. Remove hydraulic manifold from the frame using Figure 54 as guide.

Installation (Fig. 54)

1. Install hydraulic manifold to the frame using Figure 54 as guide.

2. Remove caps and plugs from fittings and hoses. Properly connect hydraulic lines to manifold.

Hydraulic Manifold Service: Filter Manifold




Figure 55

- | | | |
|-----------------------------------|-------------------|------------------------|
| 1. Filter manifold assembly | 7. Seal kit | 12. Plug (SAE #5) |
| 2. Check valve (Reservoir return) | 8. Plug (SAE #4) | 13. O-ring |
| 3. Seal kit | 9. O-ring | 14. Plug (SAE #10) |
| 4. Check valve (Filter bypass) | 10. Plug (SAE #6) | 15. O-ring |
| 5. Seal kit | 11. O-ring | 16. Oil filter element |
| 6. Check valve (Charge pressure) | | |

NOTE: The ports on the manifold are marked for easy identification of components. Example: P2 is the gear pump connection port and CD is the connection for the case drain from the deck motors (See Hydraulic Schematics to identify the function of the hydraulic lines and cartridge valves at each port).

For cartridge valve service procedures, see Hydraulic Control Manifold Service: 4 Wheel Drive in this section. Refer to Figure 55 for cartridge valve installation torque.



- | | | |
|-----------------------|------------------------|-------------------------|
| 1. Hydraulic manifold | 8. O-ring | 14. O-ring |
| 2. O-ring | 9. 90° hydraulic elbow | 15. 90° hydraulic elbow |
| 3. Hydraulic fitting | 10. O-ring | 16. O-ring |
| 4. Bracket | 11. Hydraulic hose | 17. Cap screw |
| 5. Flange nut | 12. Hydraulic fitting | 18. O-ring |
| 6. Cap screw (2 used) | 13. O-ring | 19. Hydraulic fitting |
| 7. Hydraulic hose | | |

NOTE: The ports on the manifold are marked for easy identification of hydraulic line connections. Example: P is the traction pump connection port and M1 is the connection for the front traction motors (See Hydraulic Schematics to identify the function of the hydraulic lines and cartridge valves at each port).

1. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.

2. Disconnect hydraulic lines from manifold and put caps or plugs on open hydraulic lines and fittings. Label disconnected hydraulic lines for proper reassembly.

3. Remove hydraulic manifold from the frame using Figure 56 as guide.

1. Install hydraulic manifold to the frame using Figure 56 as guide.

2. Remove caps and plugs from fittings and hoses. Properly connect hydraulic lines to manifold.

Hydraulic Manifold Service: Flow Divider




Figure 57

- | | | |
|------------------------------|-----------------------------|-------------------|
| 1. Flow divider valve | 7. Plug (not serviced) | 12. Plug (SAE #6) |
| 2. Piloted directional valve | 8. Seal kit | 13. O-ring |
| 3. Seal kit | 9. Solenoid cartridge valve | 14. Check valve |
| 4. Hydraulic manifold | 10. Solenoid coil | 15. Seal kit |
| 5. O-ring | 11. Nut | 16. Seal kit |
| 6. Plug (SAE #8) | | |

NOTE: The ports on the manifold are marked for easy identification of components. Example: P2 is the gear pump connection port and CD is the connection for the case drain from the deck motors (See Hydraulic Schematics to identify the function of the hydraulic lines and cartridge valves at each port).

For cartridge valve service procedures, see Hydraulic Control Manifold Service: 4 Wheel Drive in this section. Refer to Figure 57 for cartridge valve installation torque.

Rear Axle Motor




Figure 58

- | | | |
|--------------------------|-----------------------|-------------------------|
| 1. Wheel motor | 7. External snap ring | 12. O-ring |
| 2. 90° hydraulic fitting | 8. Pinion gear | 13. O-ring |
| 3. Hydraulic fitting | 9. External snap ring | 14. O-ring |
| 4. Cap screw | 10. Gear | 15. O-ring |
| 5. Flat washer | 11. Needle bearing | 16. Drive axle assembly |
| 6. O-ring | | |

Removal (Fig. 58)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.

2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.

NOTE: To ease installation, tag the hydraulic hoses to show their correct position on the axle motor.

3. Disconnect hydraulic hoses from motor. Put caps or plugs on ports to prevent contamination.

IMPORTANT: Support axle motor to prevent motor from falling during removal.

4. Remove motor using Figure 58 as a guide.

Installation (Fig. 58)

1. If removed, install pinion gear to axle motor.

2. Install O-ring onto motor. Position motor to rear axle assembly making sure that arrows on the side of motor case point upward. Align gear teeth and slide motor into place.

3. Secure motor to axle with cap screws and flat washers. Torque screws from **59 to 73 ft-lb (80 to 99 N-m)**.

4. Remove plugs from ports. Attach hydraulic hoses to axle motor.

5. Fill reservoir with hydraulic fluid as required.

6. After assembly is completed, verify that hydraulic hoses and fittings do not contact anything.

Front Wheel Motors




Figure 59

1. Front wheel motor
2. Internal retaining ring
3. Splined brake shaft
4. RH brake assembly
5. Planetary assembly
6. Cap screw
7. Flat washer
8. O-ring

9. Flange head screw
10. 90° hydraulic fitting
11. 90° hydraulic fitting
12. O-ring
13. O-ring
14. Hydraulic fitting
15. O-ring

16. O-ring
17. Hydraulic fitting
18. O-ring
19. O-ring
20. LH brake assembly
21. Flange head screw
22. Hex plug

Removal (Fig. 59)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.

2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.

NOTE: To ease installation, tag the hydraulic hoses to show their correct position on the wheel motor.

3. Disconnect hydraulic hoses and tubes from wheel motor. Put caps or plugs on ports to prevent contamination.

IMPORTANT: Before loosening fasteners, support wheel motor to prevent motor from falling during removal.

4. Remove wheel motor using Figure 59 as a guide.

Installation (Fig. 59)

1. Position wheel motor to brake assembly making sure that arrows on the side of motor case point upward.

2. Align splines on motor shaft and splined brake shaft. Slide motor into brake assembly.

3. Secure motor to brake assembly with cap screws and flat washers. Tighten cap screws from **75 to 85 ft-lb (101 to 115 N-m)**.

4. Remove plugs from ports. Attach hydraulic hoses and tubes to wheel motor.

5. Fill reservoir with hydraulic fluid as required.

Rear Axle/Front Wheel Motor Service




Figure 60

- | | | |
|----------------------------------|-------------------|--------------------|
| 1. Drive shaft | 7. Cap screw | 13. Thrust bearing |
| 2. Backplate (front motor shown) | 8. Shaft seal | 14. Roll pin |
| 3. Housing assembly | 9. Retaining ring | 15. Roll pin |
| 4. Rotating assembly | 10. Thrust race | 16. Bearing |
| 5. Cam plate insert | 11. O-ring | 17. Bearing |
| 6. Retaining ring | 12. Valve plate | 18. Washer |

NOTE: The front wheel motors are identical. The rear axle motor has some differences from the front motors. Service of the front and rear motors requires the same procedures.

Cleanliness is extremely important when repairing these motors. Work in a clean area. Before disconnecting the lines, clean port area of motor. Thoroughly clean the outside of the motor. After cleaning, remove port plugs and drain oil.

Disassembly (Fig. 60)

1. Clamp the drive shaft end of the piston motor in a protected jaw vise with the cap screws up. Remove the six cap screws (7) from the motor assembly.
2. Use a soft face hammer and tap the backplate (2) to loosen and remove from housing.
3. Remove valve plate (12) and O-ring (11) from backplate. It is not necessary to remove roll pins (14, 15) in backplate.

PRELIMINARY – For Toro Distributor and Toro Company use only.

4. Remove motor from vise and remove rotating assembly (4) from motor housing.
5. Remove the camplate insert (5) from housing. Use caution not to mar the finish that makes contact with pistons.
6. Remove retaining ring (6) from housing. Press shaft from housing and remove shaft seal (8) and washer (18).
7. Remove retaining rings (9) from shaft and remove thrust races (10) and thrust bearing (13).
8. Discard the shaft seal and O-ring, and replace with new items upon reassembly.

Inspection

1. Check the condition of the needle bearing (16) in backplate (2) and replace if necessary.
2. Inspect valve plate (12) on the bronze side next to the piston block for wear. A smooth surface is required. **Do not lap valve plate bronze surface.** Replace valve plate if any wear exists.
3. Inspect the piston block surface that makes contact with valve plate. This surface should be smooth and free of deep scratches. **Do not lap piston block.**
4. The pistons should move freely in the piston block bore. If they are sticky in the bore, examine the bore for scoring or contamination.
5. Examine the O.D. of the pistons for finish condition. They should not show wear or deep scratches. Inspect the shoes for a snug fit on the ball end of the pistons and a flat smooth surface that comes in contact with the camplate. **Do not lap piston shoes.**
6. Examine the spider for wear in the pivot area.
7. Examine the spider pivot to insure smoothness and no signs of wear.
8. The polished finish on the shoe surface of the camplate insert (5) should show no signs of scoring.
9. Inspect the shaft for wear in the seal, bearing and spline areas.
10. Inspect thrust bearing (13) and races (10) for wear.
11. Check the condition of the needle bearing (17) in housing and replace if necessary.

Assembly (Fig. 60)

1. Clean all parts in suitable solvent and lubricate all internal parts with clean hydraulic oil before reassembly.

2. If necessary, install new needle bearing (17) in housing (3) with numbered end of the bearing outward.
3. Install retaining ring (9) on shaft. Install thrust race (10), thrust bearing (13) and second thrust race (10). Secure with second retaining ring (9).
4. Install shaft in housing. Install washer (18), new shaft seal (8) and retaining ring (6).
5. Install camplate insert (5) with the lettering side of insert to the front of the housing. Use petroleum jelly to hold in place during assembly.
6. Install rotating assembly (4) into housing. Make sure that piston shoes make contact with the camplate insert.
7. Clamp motor assembly in a protected jaw vise with the open end of the housing up.
8. If roll pins were removed, install to dimension shown in Figure 61 and with opening of roll pin oriented away from bearing within 5 degrees of bearing center line.
9. To replace bearing (16) in backplate (2). Press bearing down to the dimension shown (Fig. 61) protruding from backplate with numbered end of bearing facing up next to valve plate.




Figure 61

10. Apply small amount of petroleum jelly to the steel side of valve plate (12) to hold in place for installation. Place the valve plate in position onto the backplate (2), with steel side against backplate, bronze colored side against piston block.
11. Placing new O-ring (11) onto backplate, install backplate assembly (2) onto housing assembly. Make sure valve plate stays in position.
12. Insert cap screws and torque from **15 to 18 ft-lb (20 to 24 N-m)** in a criss-cross pattern.
13. Fill case half full of new hydraulic oil.

This page is intentionally blank.

Cutting Deck Motor Service




Figure 64

- | | | |
|-----------------|------------------|------------------|
| 1. Rear cover | 7. Spider hub | 12. Idler gear |
| 2. Drive gear | 8. Pressure seal | 13. Cap screw |
| 3. Seal | 9. Back-up ring | 14. Front flange |
| 4. Woodruff key | 10. O-ring | 15. Dowel pin |
| 5. Nut | 11. Body | 16. Snap ring |
| 6. Tab washer | | |

Disassembly (Fig. 64)

1. Plug motor ports and clean the outside of the motor thoroughly. After cleaning, remove plugs and drain any oil out of the motor.

2. Use a marker or scribe to make a **diagonal** mark across the front flange, body and rear cover for reassembly purposes (Fig. 65).

IMPORTANT: Avoid using excessive clamping pressure on the motor flange to prevent distorting the casting.

3. Clamp mounting flange of motor in a vise with the shaft end down.

4. Loosen cap screws on the rear cover.

5. Take motor from the vise and remove cap screws.

6. Remove front flange from the body, then remove rear cover. Locate and remove dowel pins from body.




Figure 65

PRELIMINARY – For Toro Distributor and Toro Company use only.

IMPORTANT: Mark the relative positions of the gear teeth and the bearing blocks so they can be re-assembled in the same position. Do not touch the gear surfaces as residue on hands may be corrosive to gear finish.

7. Place the motor on its side and push on the rear bearing block to remove the bearing block and gear set (Fig. 66).

8. Carefully remove and discard O-rings, pressure seals and back-up rings (Fig. 67) from motor. Do not cause any damage to the machined grooves during the removal process.

IMPORTANT: Make sure not to damage the counter bore when removing the shaft seal from the front plate.

9. Position front flange with seal side up. Remove snap ring and shaft seal.

Inspection

1. Remove any nicks and burrs from all motor components with emery cloth.



2. Clean all motor components with solvent. Dry all parts with compressed air.

3. Inspect drive gear, idler gear and bearing blocks (Fig. 68) for the following:

A. Gear shafts should be free of rough surfaces and excessive wear at bushing points and sealing areas. Scoring, rough surfaces or wear on gear shafts indicates need for replacement.

B. Gear teeth should be free of excessive scoring and wear. Any broken or nicked gear teeth must be replaced.

C. Inspect gear face edge for sharpness. Sharp edges of gears will mill into bearing blocks and, thus, must be replaced.

D. Bearing areas of bearing blocks should not have excessive wear or scoring.

E. Face of bearing blocks that are in contact with gears should be free of wear, roughness or scoring.

4. Inspect front flange and rear cover for damage or wear.




Figure 66

1. Motor body

2. Bearing block & gear set




Figure 67




Figure 68

1. Drive gear
2. Idler gear

3. Bearing block

PRELIMINARY – For Toro Distributor and Toro Company use only.

Assembly (Fig. 64)

NOTE: When assembling the motor, check the identification marks made during disassembly to make sure the parts are properly aligned during assembly.

1. Lubricate O-rings, pressure seals, back-up gaskets and seal grooves with a thin coat of petroleum jelly. Lubricate all other internal parts freely with clean hydraulic oil.
2. Install new shaft seal into front flange. Install snap ring into front flange.
3. Install lubricated pressure seals into the grooves in the front flange and rear cover. Follow by carefully placing the back-up rings into the grooves.
4. Install new O-rings to the body.
5. Lubricate gear faces and bearing surfaces of drive gear, idler gear and bearing blocks. Carefully assemble bearing blocks and gears noting identification marks made during disassembly.
6. Position the motor body on its side. Carefully slide bearing block and gear assembly into the body cavity using identification marks made during disassembly.
7. Remove any excess lubrication from mating surfaces of body, rear cover and front flange. Make sure that these surfaces are clean and dry.

8. Install dowel pins in body.

IMPORTANT: Do not dislodge O-rings, pressure seals or back-up rings during final assembly.

9. Gently slide the rear cover onto the assembly using marker or scribe mark for proper location. Firm hand pressure should be sufficient to engage the dowel pins.

10. Position the motor with rear cover downwards. Carefully slide the front flange onto the assembly using marker or scribe mark for proper location.

11. Install the four (4) cap screws and hand tighten.

IMPORTANT: Avoid using excessive clamping pressure on the motor housing to prevent distorting the housing.

12. Place motor front flange in a vise and alternately torque the screws from **33 to 40 ft-lb (45 to 55 N-m)**.

13. Put a small amount of hydraulic oil in port on motor and rotate driveshaft one revolution. Protect the shaft if using a pliers. If drive shaft binds, disassemble motor and repeat assembly process.

14. Remove motor from vise.

This page is intentionally blank.

Lift/Lower Control Valve




Figure 69

- | | | |
|---------------------------|------------------------------------|--------------------------------|
| 1. Control valve assembly | 10. Cotter pin (6 used) | 18. O-ring |
| 2. Valve bracket | 11. RH lever assembly | 19. Cap screw (2 used) |
| 3. Grommet (6 used) | 12. Spacer | 20. Hydraulic fitting (4 used) |
| 4. Cap screw | 13. Cap screw (2 used) | 21. Hydraulic fitting |
| 5. Lock nut (2 used) | 14. Knob (3 used) | 22. O-ring |
| 6. Pivot bracket | 15. Lock nut (3 used) | 23. Flat washer (3 used) |
| 7. LH lever assembly | 16. 90° hydraulic fitting (2 used) | 24. Cap screw (3 used) |
| 8. Lever link (3 used) | 17. O-ring | 25. Control panel |
| 9. Center lever assembly | | |

PRELIMINARY – For Toro Distributor and Toro Company use only.

Removal (Fig. 69)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
3. Remove lift/lower control valve using Figure 69 as a guide.

Installation (Fig. 69)

1. Install control valve using Figure 69 as a guide.
 - A. If valve bracket (item 2) was removed, tighten cap screw (item 24) only until the washer (item 23) begins to seat against the isolator (item 3). The isolator should not be deformed.
2. Make sure hydraulic tank is full. Add correct oil if necessary before returning machine to service.

Lift/Lower Control Valve Service




Figure 70

- 1. Poppet
- 2. Spacer
- 3. Wiper
- 4. Seat
- 5. O-ring
- 6. Plug
- 7. Ring
- 8. Bushing
- 9. Cap
- 10. Relief valve poppet
- 11. O-ring
- 12. Retaining ring

- 13. Washer
- 14. Washer
- 15. Washer
- 16. Washer
- 17. Plug
- 18. O-ring
- 19. Spring
- 20. Backup washer
- 21. Detent spring
- 22. Plunger
- 23. Plug
- 24. O-ring

- 25. O-ring
- 26. Backup washer
- 27. Disc
- 28. Plunger
- 29. Plug assembly
- 30. Lockout spring
- 31. Spring
- 32. Relief plug assembly
- 33. Plunger
- 34. O-ring
- 35. Spool
- 36. Body

Disassembly (Fig. 70)

1. Plug all ports and thoroughly clean outside of control valve.
2. Remove caps (item 9). Do not remove retaining rings (item 12) from spools unless spring (item 19) is broken.

NOTE: Spools and spool bores are matched sets. Be sure each spool is identified with the correct body spool bore.

3. Remove spools (item 35) from body (item 36).
4. Remove bushings (item 8) and O-rings (item 11) from spools.
5. Remove plugs (item 6).

IMPORTANT: Check location and positioning of plungers when removing from body to assure proper assembly.

6. Remove plugs (item 29), springs (item 30), poppets (item 1), seats (item 4) and plungers (items 28 and 33).
7. Remove plug (item 17).
8. Remove plug (item 23), disc (item 27), spring (item 21) and detent plunger (item 22).
9. Remove relief plug assembly (item 32), washers (items 13, 14 and 15), spring (item 31) and poppet (item 10).
10. Remove all O-rings and back-up rings from all plugs and seats.

Inspection

1. Remove all nicks and burns from parts and inspect for excessive wear.
2. Inspect all plungers and poppet seats for burrs or roughness.
3. Inspect spool springs (item 19), relief valve spring (item 31), lockout springs (item 30) and detent spring (item 21) for breakage.
4. If spools (item 35) have excessive wear, the control valve becomes non-serviceable as the spools and spool bores are matched. Damaged spools cannot be replaced.
5. Inspect relief valve poppet (item 10) for breakage or wear.

Assembly (Fig. 70)

1. Thoroughly clean and dry all parts. Apply a light coating of clean hydraulic oil to parts prior to assembly.

NOTE: All O-rings, back-up washers, wiper seals and nylon poppets should be replaced with new items.

2. Install new O-rings (item 11) in proper grooves in spool bores.
3. Install relief valve components (items 13, 14, 15, 31 and 10) with new O-ring (item 34) on plug assembly (item 32).
4. Install plugs (item 6) with new back-up washers (item 20) and O-rings (item 7).
5. Install plungers (items 33 and 28).

IMPORTANT: Check location and positioning of plungers during installation.

6. Install new O-rings (item 5) on seats (item 4). Install new back-up washers (item 26) and O-rings (item 25) on plugs (item 29).
7. Install seats (item 4), new poppets (item 1) and plugs (item 29).
8. Install plug (item 17) with new O-ring (item 18).
9. Install detent plunger (item 22), spring (item 21), disc (item 27) and plug (item 23) with new O-ring (item 24).
10. If retaining ring (item 12) has been removed to replace spool spring (item 19), install washer (item 16), spring (item 19), spacer (item 2) and secure with retaining ring (item 12).
11. Slide bushings (item 8) over spools. Slide new O-rings (item 11) over spools and position next to bushings. Dip spools in clean hydraulic oil and install spool assemblies into proper location of body.
12. Install spool caps (item 9) and tighten from **20 to 25 ft-lb (27 to 33 N-m)**.
13. Install new wiper seals (item 3).

Steering Valve




Figure 71

- | | | |
|----------------------------|-----------------------------|------------------------------|
| 1. Hex nut | 11. O-ring | 21. Steering column assembly |
| 2. Flat washer | 12. Flange head screw | 22. Flange bushing |
| 3. Steering wheel | 13. Hydraulic adapter | 23. Thrust washer |
| 4. Foam collar | 14. Steering valve assembly | 24. Steering wheel cover |
| 5. Steering seal | 15. Nut insert | 25. In port (P) |
| 6. External snap ring | 16. Steering tower | 26. Right turn port (R) |
| 7. Steering shaft assembly | 17. Flange locking nut | 27. Load sensing port (PB) |
| 8. Steering tower cover | 18. Flange head screw | 28. Left turn port (L) |
| 9. O-ring | 19. Pivot hub | 29. Out port (T) |
| 10. 90° hydraulic fitting | 20. Cap screw | |

PRELIMINARY – For Toro Distributor and Toro Company use only.

Removal (Fig. 71)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
3. Remove steering valve from machine using Figure 71 as a guide.

Installation (Fig. 71)

1. Install steering valve using Figure 71 as a guide.
2. Make sure hydraulic tank is full. Add correct oil if necessary before returning machine to service.

Steering Valve Service




Figure 72

- | | | |
|------------------------------|---------------|--------------------|
| 1. Steering valve housing | 9. Cap screw | 17. Geroter drive |
| 2. Dust seal | 10. End cap | 18. Wear plate |
| 3. O-ring | 11. O-ring | 19. Bearing race |
| 4. Spool | 12. Seal ring | 20. Thrust bearing |
| 5. Spring retaining ring | 13. O-ring | 21. Plug |
| 6. Pin | 14. Geroter | 22. O-ring |
| 7. Sleeve | 15. O-ring | 23. Relief valve |
| 8. Centering springs/spacers | 16. Spacer | 24. Quad seal |

Disassembly (Fig. 72)

NOTE: Cleanliness is extremely important when repairing steering control units. Work in a clean area. Before disconnecting the hydraulic lines, clean the port area of the steering valve assembly. Before disassembly, drain the oil, then plug the ports and thoroughly clean the exterior. During repairs, always protect machined surfaces.

1. Remove the seven cap screws from the steering valve assembly.
2. Remove end cap, geroter, spacer, geroter drive, wear plate, seal ring and O-rings from housing (Fig. 72).
3. Remove the plug and relief valve.
4. Slide the spool and sleeve assembly from the housing.
5. Remove the thrust bearing and bearing races (2).
6. Remove the quad seal.
7. Use a small blade screwdriver to carefully pry the dust seal from the housing. Be careful to not damage the dust seal seat in the housing.
8. Remove the pin that holds the spool and sleeve together.
9. Carefully slide the spool out of the sleeve. The centering springs and spring retaining ring will stay with the spool as it is removed.



CAUTION

The centering springs are under tension. Remove the retaining ring carefully.

10. Remove the spring retaining ring and centering springs from the spool.

Assembly (Fig. 72)

Check all mating surfaces. Replace any parts with scratches or burrs that could cause leakage. Wash all metal parts in clean solvent. Blow them dry with pressurized air. Do not wipe parts dry with paper towels or cloth. Lint in a hydraulic system will cause damage.

NOTE: Always use new seals and O-rings when assembling the steering control unit.

IMPORTANT: During assembly, lubricate the new seals with petroleum jelly. Also, lubricate machined surfaces and bearings with clean hydraulic fluid.

1. Install the quad seal:
 - A. Put one of the bearing races and sleeve into the housing.
 - B. Together, the housing and bearing race create a groove into which the quad seal will be installed.
 - C. Hold the bearing race tightly against the input end of the housing by pushing on the gerotor end of the sleeve.
 - D. Fit the quad seal into its seat through the input end of the housing. Be sure the seal is not twisted.
 - E. Remove the sleeve and bearing race.
2. Lubricate and install the dust seal.
3. Install the centering springs in the spool. It is best to install the two flat pieces first. Next, install the curved pieces, three at a time.
4. Fit the retaining ring over the centering springs.
5. Apply a light coating of clean hydraulic fluid to the spool and slide it into the sleeve. Be sure the centering springs fit into the notches in the sleeve.
6. Install the pin.
7. Apply a light coating of petroleum jelly to the inner edge of the dust and quad seals.

8. Put the thrust bearing and races into the housing. The thrust bearing goes between the two races (Fig. 73).

IMPORTANT: Do not damage the dust or quad seals when installing the spool and sleeve assembly.

9. Apply a light coating of clean hydraulic fluid to the spool and sleeve assembly and slide carefully the assembly into the housing.
 10. Clamp the housing in a vise. Use only enough clamping force to hold the housing securely.
 11. Lubricate and install a new o-ring seal in the groove in the housing.
 12. Install the wear plate and align screw holes in the wear plate with threaded holes in the housing.
- NOTE:** The holes in the wear plate are symmetrical.
13. Install the gerotor drive, making sure the slot in the drive engages the pin.
 14. Lubricate and install new o-ring in wear plate groove.
 15. Install the gerotor and align the screw holes.
 16. Lubricate and install new o-ring in gerotor ring groove.
 17. Lubricate and install new o-ring and seal ring in gerotor star groove.
 18. Install the spacer.
 19. Install the end cap and seven cap screws. Tighten the cap screws, in a crossing pattern, from **140 to 160 in-lb (16 to 18 N-m)**.
 20. Remove the steering control unit from the vise.
 21. Install the relief valve and plug. Tighten the plug to **150 in-lb (17 N-m)**.




Figure 73

Engine Cooling Fan Motor Service




Figure 74

- | | | |
|---------------------|---------------------|------------------------|
| 1. Flange washer | 7. Shaft seal | 12. Idler gear |
| 2. O-ring | 8. Backup gasket | 13. Cap screw (4 used) |
| 3. Front flange | 9. Pressure seal | 14. Dowel (2 used) |
| 4. Dust seal | 10. Rear wear plate | 15. Drive gear |
| 5. Retaining ring | 11. Body | 16. Washer (4 used) |
| 6. Front wear plate | | |

Disassembly (Fig. 74)

1. Plug motor ports and clean the outside of the motor thoroughly. After cleaning, remove plugs and drain any oil out of the motor.

2. Use a marker to make a **diagonal** line across the front flange and body for assembly purposes (Fig. 75).

IMPORTANT: Avoid using excessive clamping pressure on the motor housing to prevent distorting the housing.

3. Clamp front flange of motor in a vise with soft jaws with the shaft end down.

4. Loosen cap screws from the rear cover.

5. Remove motor from the vise. Turn motor so that the shaft end is facing down. Remove cap screws.

6. Carefully remove body. Lift body straight up to remove. Make sure the rear wear plate remains on the drive and idler gear shafts. Remove and discard O-rings from the body. Locate and retrieve dowel pins.




Figure 75

IMPORTANT: Note position of the open and closed side of the wear plates before removing. Also, identify wear plates (front and rear) with a marker for proper assembly.

7. Carefully remove rear wear plate, idler gear, drive gear and front wear plate from the front flange.

PRELIMINARY – For Toro Distributor and Toro Company use only.

8. Remove and discard back-up gaskets and pressure seals from wear plates.

9. Turn front flange over, with seal side up.

IMPORTANT: Make sure not to damage the front flange counter bore when removing the seals from the front flange.

10. Carefully remove dust seal, retaining ring, flange washer and shaft seal from the front flange (Fig. 76). Discard seals.

Inspection

1. Remove any nicks and burrs from all parts with emery cloth.



2. Clean all parts with solvent. Dry all parts with compressed air.

3. Inspect drive gears and idler gears for the following (Fig. 77):

A. Gear shafts should be free of rough surfaces and excessive wear at bushing points and sealing areas. Scoring, rough surfaces or wear on gear shafts indicates need for replacement.

B. Gear teeth should be free of excessive scoring and wear. Any broken or nicked gear teeth must be replaced.

C. Inspect gear face edge for sharpness. Sharp edges of gears will mill into wear plates and, thus, must be replaced.

4. Inspect wear plates for the following:

A. Bearing areas should not have excessive wear or scoring.

B. Face of wear plates that are in contact with gears should be free of wear, roughness or scoring.

C. Thickness of wear plates should be equal.

5. Inspect front flange and rear cover for damage or wear.




Figure 76

- | | |
|-------------------|------------------|
| 1. Dust seal | 3. Flange washer |
| 2. Retaining ring | 4. Shaft seal |




Figure 77

- | | |
|----------------------|-------------------|
| 1. Gear shaft spline | 3. Gear teeth |
| 2. Gear shaft | 4. Gear face edge |

Assembly (Fig. 74)

NOTE: When assembling the motor, check the marker line on each part to make sure the parts are properly aligned during assembly.

1. Lubricate O-rings, pressure seals, back-up gaskets and wear plate grooves with a thin coat of petroleum jelly. Lubricate all other internal parts freely with clean hydraulic oil.

2. Install new seals into front flange (Fig. 76):

A. Press shaft seal into front flange until it reaches the bottom of the bore.

B. Install flange washer into front flange and then install retaining ring into the groove of the front flange.

C. Install new dust seal into front flange.

3. Place front flange, seal side down, on a flat surface.

PRELIMINARY – For Toro Distributor and Toro Company use only.

4. Install the pressure seals, flat side outward, into the grooves in the wear plates. Follow by carefully placing the backup gaskets, flat side outward, between the pressure seals and the grooves in the wear plate.

5. Apply a light coating of petroleum jelly to the exposed side of the front flange.

6. Lubricate the drive gear shaft with clean hydraulic oil. Insert the drive end of the drive shaft through the wear plate with the pressure seal side down and the open side of the pressure seal pointing to the inlet side of the motor. Carefully install shaft into front flange.

7. Lubricate the idler gear shaft with clean hydraulic oil. Install idler gear shaft into the remaining position in the front wear plate. Apply a light coating of clean hydraulic oil to gear faces.

8. Install rear wear plate with pressure seal side up and open side of the pressure seal pointing to the inlet side of the motor.

9. Apply a light coating of petroleum jelly to new O-rings and O-ring grooves in the body. Install new O-rings to the body.

10. Install locating dowels in body. Align marker line on the body and front flange.

IMPORTANT: Do not dislodge seals during installation.

11. Gently slide the body onto the assembly. Firm hand pressure should be sufficient to engage the dowels.

12. Install the four (4) cap screws with washers and hand tighten.

IMPORTANT: Avoid using excessive clamping pressure on the motor housing to prevent distorting the housing.

13. Place front flange of the motor into a vise with soft jaws and alternately torque the cap screws **33 ft-lb (45 N-m)**.

14. Remove motor from vise.

15. Place a small amount of clean hydraulic oil in the inlet of the motor and rotate the drive shaft away from the inlet one revolution. If any binding is noted, disassemble the motor and check for assembly problems.

This page is intentionally blank.

Side Deck Lift Cylinder




Figure 78

- 1. Lift arm assembly (LH shown)
- 2. Shoulder screw
- 3. Pin assembly
- 4. Lift cylinder

- 5. Flange locking nut
- 6. 90° hydraulic fitting (2 used)
- 7. O-ring
- 8. O-ring

- 9. Cylinder pin
- 10. Spring pin
- 11. Lock nut
- 12. Flat washer

Removal (Fig. 78)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.

2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.

NOTE: To ease installation, tag the hydraulic hoses to show their correct position on the lift cylinder.

3. Disconnect hydraulic hoses from lift cylinder.

4. Remove shoulder screw and flange locking nut that secure the pin assembly to the lift arm. Remove pin assembly from lift arm and cylinder shaft clevis.

5. Remove lock nut and flat washer from the cylinder pin. Remove cylinder pin with spring pin from the frame and cylinder barrel clevis.

6. Remove lift cylinder from machine.

Installation (Fig. 78)

1. Position cylinder barrel clevis to frame and insert cylinder pin through the frame and cylinder clevis. Secure pin with flat washer and lock nut.

2. Insert pin assembly through the lift arm and cylinder shaft clevis. Secure pin assembly to lift arm with shoulder screw and flange locking nut.

3. Attach hydraulic hoses to lift cylinder.

4. Fill reservoir with hydraulic fluid as required.

5. After installation is completed, operate lift cylinder to verify that hydraulic hoses and fittings are not contacted by anything.

Front Deck Lift Cylinder




Figure 79

- | | | |
|-------------------|---------------------------------|--------------------------------|
| 1. Lift cylinder | 5. Cap screw | 9. O-ring |
| 2. Upper lift pin | 6. Flat washer | 10. Straight hydraulic fitting |
| 3. Cotter pin | 7. Lock nut | 11. O-ring |
| 4. Pin assembly | 8. Lift arm assembly (LH shown) | 12. 90° hydraulic fitting |

Removal (Fig. 79)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.

2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.

NOTE: To ease installation, tag the hydraulic hoses to show their correct position on the lift cylinder.

3. Disconnect hydraulic hoses from lift cylinder.

4. Remove lock nut, flat washers and cap screw that secure the pin assembly to the lift arm. Remove pin assembly from lift arm and cylinder shaft clevis which will free lift cylinder from lift arm.

5. Remove one cotter pin from upper lift pin. Pull upper lift pin from frame and cylinder barrel clevis.

6. Remove lift cylinder from machine.

Installation (Fig. 79)

1. Position cylinder barrel clevis to frame and insert upper lift pin into frame and clevis. Secure lift pin with cotter pin.

2. Insert pin assembly through lift arm and cylinder shaft clevis. Secure pin to lift arm with cap screw, flat washers and lock nut.

3. Attach hydraulic hoses to lift cylinder.

4. Fill reservoir with hydraulic fluid as required.

5. After assembly is completed, operate lift cylinder to verify that hydraulic hoses and fittings are not contacted by anything.

Lift Cylinder Service




Figure 80

- | | | |
|-----------------------|-----------------|--------------------|
| 1. Barrel with clevis | 7. Back-up ring | 12. Lock nut |
| 2. Retaining ring | 8. Head | 13. Grease fitting |
| 3. Shaft with clevis | 9. O-ring | 14. Bushing |
| 4. Dust seal | 10. Wear ring | 15. O-ring |
| 5. Rod seal | 11. Piston | 16. Seal |
| 6. O-ring | | |




Figure 81

- | | | |
|-----------------------|-----------------|--------------------|
| 1. Barrel with clevis | 6. O-ring | 10. Wear ring |
| 2. Seal | 7. Back-up ring | 11. Piston |
| 3. Shaft with clevis | 8. Head | 12. Lock nut |
| 4. Dust seal | 9. O-ring | 13. Retaining ring |
| 5. Rod seal | | |

PRELIMINARY – For Toro Distributor and Toro Company use only.

Disassembly (Figs. 80 and 81)

1. Remove oil from lift cylinder into a drain pan by slowly pumping the cylinder shaft. Plug both ports and clean the outside of the cylinder.

IMPORTANT: Prevent damage when clamping the cylinder in a vise; clamp on the clevis only. Do not close vise enough to distort the barrel.

2. Mount lift cylinder securely in a vise by clamping on the clevis end of the barrel. Use of a vise with soft jaws is recommended.

3. Loosen head from barrel:

A. Use a spanner wrench to rotate head clockwise until the edge of the retaining ring appears in the barrel opening.

B. Insert a screwdriver under the beveled edge of the retaining ring to start the retaining ring through the opening.

C. Rotate the head counter-clockwise to remove retaining ring from barrel and head.

4. Extract shaft with head and piston by carefully twisting and pulling on the shaft.

IMPORTANT: Do not clamp vise jaws against the shaft surface. Protect shaft surface before mounting in a vise.

5. Mount shaft securely in a vise by clamping on the clevis of the shaft. Remove lock nut and piston from the shaft. Slide head off the shaft.

6. Remove and discard all seals and O-rings from the piston and the head.

7. Wash parts in clean solvent. Dry parts with compressed air. Do not wipe parts dry with paper towels or cloth. Lint in a hydraulic system will cause damage.

8. Carefully inspect internal surface of barrel for damage (deep scratches, out-of-round, etc.). Replace entire cylinder if barrel is damaged. Inspect piston rod and piston for evidence of excessive scoring, pitting or wear. Replace any damaged parts.

Assembly (Figs. 80 and 81)

1. Make sure all cylinder components are clean before assembly.

2. Coat new seal kit components with clean hydraulic oil.

A. Install new seals and O-rings to the piston.

B. Install new seals, O-ring and back-up ring to the head.

IMPORTANT: Do not clamp vise jaws against the shaft surface. Protect shaft surface before mounting in a vise.

3. Mount shaft securely in a vise by clamping on the clevis of the shaft.

A. Coat shaft with clean hydraulic oil.

B. Carefully slide head and piston onto the shaft. Secure piston to shaft with lock nut.

C. Torque lock nut to specification in Figure 80 (side deck cylinder) or 81 (front deck cylinder).

4. Lubricate head and piston with hydraulic oil. Carefully slide shaft assembly into cylinder barrel.

IMPORTANT: Prevent damage when clamping the cylinder's barrel into a vise; clamp on the clevis only. Do not close vise enough to distort the barrel.

5. Mount lift cylinder in a vise with soft jaws. Secure head in barrel:

A. Align retaining ring hole in the head with the access slot in the barrel.

B. Insert the retaining ring hook into the hole and rotate head clockwise until the retaining ring is completely pulled into the barrel and the ring ends are covered.

C. Apply silicone sealer to barrel access slot.

Steering Cylinder




Figure 82

- 1. Steering cylinder
- 2. Ball joint
- 3. Ball joint
- 4. Retaining ring
- 5. Grease fitting

- 6. Grease fitting
- 7. 90° hydraulic fitting
- 8. O-ring
- 9. O-ring
- 10. Drive axle assembly

- 11. Ball joint spacer
- 12. Axle washer
- 13. Slotted hex nut
- 14. Cotter pin

Removal (Fig. 82)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.

2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.

NOTE: To ease installation, tag the hydraulic hoses to show their correct position on the steering cylinder.

3. Remove hydraulic hoses from steering cylinder.

4. Remove cotter pins, slotted hex nuts, axle washer and ball joint spacer from the threaded ends of ball joints (Fig. 82). Remove steering cylinder with ball joints from machine.

5. If needed, remove ball joints from steering cylinder.

Installation (Fig. 82)

1. If removed, install ball joints into steering cylinder.

2. Slide ram end ball joint through hole on steering arm. Secure with axle washer and hex slotted nut. Slide fixed end of cylinder through hole on axle. Secure with slotted hex nut. Torque slotted hex nuts to **100 ft-lbs (135 N-m)** and then continue tightening the nut until hex nut groove aligns with cotter pin hole in ball joint. Install cotter pin to nut and ball joint.

3. Install hydraulic hoses to steering cylinder.

4. Fill reservoir with hydraulic fluid as required.

5. After assembly is completed, operate steering cylinder to verify that hydraulic hoses and fittings are not contacted by anything.

Steering Cylinder Service




Figure 83

- 1. Tube assembly
- 2. Rod
- 3. Piston assembly
- 4. Head

- 5. Retaining ring
- 6. Backup ring
- 7. O-ring
- 8. Cap seal

- 9. Rod seal
- 10. O-ring
- 11. O-ring
- 12. Wiper

PRELIMINARY – For Toro Distributor and Toro Company use only.

Disassembly (Fig. 83)

1. Pump oil out of cylinder into a drain pan by SLOWLY moving rod and piston in and out of cylinder bore. Plug ports and clean outside of cylinder.

IMPORTANT: To prevent damage when clamping cylinder in a vise, clamp only on pivotal ends. Use of a vise with soft jaws is recommended.

2. Mount cylinder in a vise so rod end of cylinder is tilted up slightly. Do not close vise so firmly that cylinder tube could become distorted.

3. Loosen head from tube:

A. Use a spanner wrench to rotate head clockwise until the edge of the retaining ring appears in the tube opening.

B. Insert a screwdriver under the beveled edge of the retaining ring to start the retaining ring through the opening.

C. Rotate the head counter-clockwise to remove retaining ring from tube and head.

4. Grasp end of piston rod and use a twisting and pulling motion to carefully extract piston, piston rod and head from cylinder tube.

IMPORTANT: Do not clamp vise jaws against piston rod surface; the piston rod will become damaged.

5. Securely mount piston, piston rod and head into vise and remove piston. Remove head from rod.

6. Remove and discard all seals and O-rings from head and piston.

7. Wash parts in clean solvent. Dry parts with compressed air. Do not wipe parts dry with paper towels or cloth. Lint in a hydraulic system will cause damage.

8. Carefully inspect internal surface of barrel for damage (deep scratches, out-of-round, etc.). Replace entire cylinder if barrel is damaged. Inspect rod and piston for evidence of excessive scoring, pitting or wear. Replace any damaged parts.

Assembly (Fig. 83)

1. Use a complete repair kit when rebuilding the cylinder. Put a coating of clean hydraulic oil on all new seals and O-rings.

2. Install new O-rings and seals to the piston and head.

3. Lubricate shaft with clean hydraulic oil. Slide head onto shaft. Install and tighten head. Torque head from **45 to 55 ft-lb (62 to 74 N-m)**.

4. Put a coating of clean hydraulic oil on all cylinder parts to ease assembly.

5. Slide rod assembly into cylinder tube.

6. Mount steering cylinder in a vise with soft jaws. Secure head in barrel:

A. Align retaining ring hole in the head with the access slot in the tube.

B. Insert the retaining ring hook into the hole and rotate head clockwise until the retaining ring is completely pulled into the tube and the ring ends are covered.

C. Apply silicone sealer to tube access slot.

Hydraulic Reservoir




Figure 84

- 1. Hydraulic reservoir
- 2. Petcock
- 3. O-ring
- 4. Strap
- 5. Felt strap
- 6. Bushing
- 7. Bushing
- 8. Hydraulic fitting

- 9. Stand pipe
- 10. Hose clamp
- 11. Screen filter
- 12. Dipstick
- 13. O-ring
- 14. Reservoir cap
- 15. Suction hose
- 16. Tank strainer w/O-ring

- 17. Hose clamp
- 18. Hose
- 19. Hose clamp
- 20. Cap screw
- 21. Cap screw
- 22. Lock nut
- 23. Hose
- 24. Hose

Removal

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
3. Drain reservoir into a suitable container.
4. Disconnect hydraulic hoses from reservoir.
5. Remove hydraulic reservoir using Figure 84 as a guide.

Hydraulic System

Inspection

1. Clean hydraulic reservoir and suction strainer with solvent.
2. Inspect for leaks, cracks or other damage.

Installation

1. Install reservoir using Figure 84 as a guide.
2. Using a wrench, turn strainer into port at least 1-1/2 to 2 full turns beyond finger tight.
3. Reconnect hydraulic hoses.
4. Fill reservoir with hydraulic fluid as required.

Hydraulic Oil Cooler

Removal



CAUTION

The radiator and oil cooler may be hot. To avoid possible burns, allow the engine and cooling systems to cool before working on the oil cooler.

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Read the General Precautions for Removing and Installing Hydraulic System Components at the beginning of the Service and Repairs section of this chapter.
3. Remove oil cooler using Figures 85 and 86 as guides.

Inspection

1. Back flush oil cooler with cleaning solvent. After cooler is clean, make sure all solvent is drained from the cooler.



CAUTION

Use eye protection such as goggles when using compressed air.

2. Dry inside of oil cooler using compressed air in the opposite direction of the oil flow.
3. Plug both ends of oil cooler. Clean exterior of cooler. Make sure fins are clear of dirt and debris.
4. The oil cooler should be free of corrosion, cracked tubes and excessive pitting of tubes.

Installation

1. Install oil cooler using Figures 85 and 86 as guides.
2. Fill reservoir with hydraulic fluid as required.




Figure 85

1. Oil cooler

2. Radiator assembly




Figure 86

1. Oil cooler
2. 90° hydraulic fitting
3. O-ring
4. O-ring
5. Knob
6. Retaining ring

7. Carriage screw
8. Clamp
9. Oil cooler bracket (RH)
10. Flange screw
11. Flange locking nut
12. Radiator support



Electrical System

Table of Contents

ELECTRICAL DRAWINGS	2	Audio Alarm	15
SPECIAL TOOLS	3	Glow Relay	16
TROUBLESHOOTING	5	Start, Engine Shutdown, Seat, PTO, Alarm, and Over Temperature Relays	17
Starting Problems	5	Hydraulic Valve Solenoids	18
General Run & Transport Problems	6	Fuel Sender	19
Cutting Unit Operating Problems	7	Fuel Gauge	20
ELECTRICAL SYSTEM QUICK CHECKS	8	Fuel Pump	21
Battery Test (Open Circuit)	8	Glow Controller	22
Charging System Test	8	Temperature Sender	23
Check Operation of Interlock Switches	8	Dual Temperature Switch	24
COMPONENT TESTING	9	Temperature Gauge	25
Ignition Switch	9	Traction Neutral Switch	26
Fuses	10	Diode Assemblies	26
Warning Lights	11	Diode Circuit Board	27
PTO Switch	12	Cutting Deck Position Switch	28
Transport, Alarm Silence and Temperature Override Switches	13	SERVICE AND REPAIRS	30
Seat Switch	14	Battery Storage	30
Parking Brake Switch	14	Battery Care	30
Hour Meter	15	Battery Service	30

Electrical
System

Electrical Drawings

The electrical schematic, circuit diagrams and wire harness drawings for the Groundsmaster 4000-D are located in Chapter 9 – Foldout Drawings.

Special Tools

Order special tools from your Toro Distributor. Some tools may also be available from a local supplier.

Multimeter

The meter can test electrical components and circuits for current, resistance or voltage.

NOTE: Toro recommends the use of a DIGITAL Volt–Ohm–Amp multimeter when testing electrical circuits. The high impedance (internal resistance) of a digital meter in the voltage mode will make sure that excess current is not allowed through the meter. This excess current can cause damage to circuits not designed to carry it.




Figure 1

Skin–Over Grease

Special non–conductive grease which forms a light protective skin which helps waterproof electrical switches and contacts.

Toro Part Number: **505–165**



Figure 2

Dielectric Gel

Dielectric gel should be used to prevent corrosion of connection terminals. To ensure complete coating of terminals, liberally apply gel to both component and wire harness connector, plug connector to component, unplug connector, reapply gel to both surfaces and reconnect harness connector to component. Connectors should be thoroughly packed with gel for effective results.

Toro Part Number: **107–0342**



Figure 3

Battery Terminal Protector

Aerosol spray that should be used on battery terminals to reduce corrosion problems. Apply terminal protector after the battery cable has been secured to the battery terminal.

Toro Part Number: **107-0392**



Figure 4

Battery Hydrometer

Use the Battery Hydrometer when measuring specific gravity of battery electrolyte. Obtain this tool locally.



Figure 5

Deck Proximity Switch Adjustment Tool

The Deck Proximity Switch Adjustment Tool is designed to assist in the adjustment of the cutting deck position switches for cutting blade shutdown during deck lift.

Toro Part Number: **TOR4095**



Figure 6

Troubleshooting



CAUTION

Remove all jewelry, especially rings and watches, before doing any electrical troubleshooting or testing. Disconnect the battery cables unless the test requires battery voltage.

For effective troubleshooting and repairs, you must have a good understanding of the electrical circuits and components used on this machine (see Chapter 9 – Foldout Drawings).

If the machine has any interlock switches by-passed, reconnect the switches for proper troubleshooting and safety.

Starting Problems

Problem	Possible Causes
All electrical power is dead, including gauges.	<p>The battery charge is low.</p> <p>The 10 amp fuse to the ignition switch is open.</p> <p>Bad ground connection on machine.</p> <p>The ignition switch or circuit wiring is faulty.</p> <p>The fusible link from the battery is faulty.</p>
<p>Starter solenoid clicks, but starter will not crank.</p> <p>NOTE: If the solenoid clicks, the problem is not in the interlock circuit wiring.</p>	<p>Low battery charge.</p> <p>Loose or corroded battery cables.</p> <p>Loose or corroded ground.</p> <p>Faulty wiring at the starter.</p> <p>Faulty starter solenoid.</p> <p>Faulty starter.</p>
Nothing happens when start attempt is made. Control panel lights and gauges operate with the ignition switch in ON.	<p>The traction pedal is not in neutral position or the neutral switch or circuit wiring is faulty.</p> <p>The cutting units are engaged.</p> <p>Faulty ignition switch or circuit wiring.</p> <p>Start relay or circuit wiring is faulty.</p> <p>Starter solenoid or starter is faulty.</p>
Engine starts, but stops when the ignition switch is released from the START position.	<p>The fuel run solenoid is out of adjustment or circuit wiring is faulty.</p> <p>High temperature shutdown switch or circuit wiring is faulty.</p>

PRELIMINARY – For Toro Distributor and Toro Company use only.

Problem	Possible Causes
Engine cranks, but does not start.	Engine is not cranking fast enough. Engine fuel stop solenoid, circuit wiring or fuel pump is faulty. The problem is not electrical (see Chapter 3 – Kubota Engine).
Starter cranks, but should not when the traction pedal is depressed.	The traction neutral switch is out of adjustment. The traction neutral switch or circuit wiring is faulty.

General Run and Transport Problems

Engine continues to run, but should not, when the ignition switch is turned off.	The engine fuel stop solenoid is stuck open. Ignition switch or circuit wiring is faulty.
Engine continues to run, but should not, when the traction pedal is engaged with no operator in the seat.	The seat sensor or circuit wiring is faulty. Traction neutral switch or circuit wiring is faulty.
The engine stops during operation, but is able to restart.	The operator is lifting off the seat switch. The seat switch or circuit wiring is faulty. The engine shutdown delay is faulty. The ignition switch or circuit wiring is faulty.
The engine kills when the traction pedal is depressed.	The operator is lifting off the seat switch. The seat switch or circuit wiring is faulty.
Battery does not charge.	Loose, corroded or broken wire(s). The fusible link to the battery is faulty. Faulty alternator or dead battery. Charge indicator lamp is faulty or burned out. Charge indicator lamp wiring loose, corroded or damaged.

Cutting Unit Operating Problems

The cutting units remain engaged, but should not, with no operator in the seat.	The seat switch or circuit wiring is faulty.
Cutting units run, but should not, when raised. Units shut off with PTO switch.	The deck position switch or circuit wiring is faulty.
Cutting units run, but should not, when raised. Units do not shut off with the PTO switch.	The deck position switch or circuit wiring and PTO switch or circuit wiring are faulty. A hydraulic problem exists (see Troubleshooting section of Chapter 4 – Hydraulic System).
Cutting units run, but should not, when lowered with PTO switch in the OFF (disengage) position.	The PTO switch or circuit wiring is faulty.
Cutting deck(s) do not operate.	The operator is lifting off the seat switch. The seat switch or circuit wiring is faulty. The PTO switch or circuit wiring is faulty. The deck position switch or circuit wiring is faulty. Hydraulic valve solenoid(s) or circuit wiring is faulty. A hydraulic problem exists (see Troubleshooting section of Chapter 4 – Hydraulic System).
PTO fuse blows when engaging cutting deck	Hydraulic valve solenoid coil is shorted. Cutting deck position switch is faulty.

Electrical System Quick Checks

Battery Test (Open Circuit Test)

Use a multimeter to measure the voltage between the battery terminals.

Set multimeter to the DC volts setting. The battery should be at a temperature of 60 to 100°F (16 to 38°C). The ignition key should be off and all accessories turned off. Connect the positive (+) meter lead to the positive battery post and the negative (–) meter lead to the negative battery post.

NOTE: This test provides a relative condition of the battery. Load testing of the battery will provide additional and more accurate information.

Voltage Measured	Battery Charge Level
12.68 V (or higher)	Fully charged (100%)
12.45 V	75% charged
12.24 V	50% charged
12.06 V	25% charged
11.89 V	0% charged

Charging System Test

This is a simple test used to determine if a charging system is functioning. It will tell you if the charging system has an output, but not its capacity.

Use a digital multimeter set to DC volts. Connect the positive (+) multimeter lead to the positive battery post and the negative (–) multimeter lead to the negative battery post. Keep the test leads connected to the battery posts and record the battery voltage.

NOTE: Upon starting the engine, the battery voltage will drop and then should increase once the engine is running.

NOTE: Depending upon the condition of the battery charge and battery temperature, the battery voltage will increase at different rates as the battery charges.

Start the engine and run at high idle (**3450 RPM**). Allow the battery to charge for at least 3 minutes. Record the battery voltage.

After running the engine for at least 3 minutes, battery voltage should be at least 0.50 volt higher than initial battery voltage.

An example of a charging system that is functioning:

At least 0.50 volt over initial battery voltage.	
Initial Battery Voltage	= 12.30 v
Battery Voltage after 3 Minute Charge	= 12.85 v
Difference	= +0.55 v

Check Operation of Interlock Switches



CAUTION

Do not disconnect safety switches. They are for the operator's protection. Check the operation of the interlock switches daily for proper operation. Replace any malfunctioning switches before operating the machine.

Interlock switch operation is described in the Operator's Manual. Testing of interlock switches and relays is included in the Component Testing section of this Chapter.

Component Testing

For accurate resistance and/or continuity checks, electrically disconnect the component being tested from the circuit (e.g. unplug the ignition switch connector before doing a continuity check).

NOTE: For engine component testing information, see the Kubota Workshop Manual, Diesel Engine, V2403–M–T–E3B Series at the end of Chapter 3 – Kubota Diesel Engine.



CAUTION

When testing electrical components for continuity with a multimeter (ohms setting), make sure that power to the circuit has been disconnected.

Ignition Switch

The ignition (key) switch has three (3) positions: OFF, ON/ PREHEAT and START (Fig. 7). The terminals are marked as shown in Figure 8. The circuit wiring of the ignition switch is shown in the chart below. With the use of a multimeter (ohms setting), the switch functions may be tested to determine whether continuity exists between the various terminals for each position. Verify continuity between switch terminals.

POSITION	CIRCUIT
OFF	NONE
ON / PREHEAT	B + I + A, X + Y
START	B + I + S




Figure 7




Figure 8

Fuses

The fuse blocks are located under the operator's control panel.

Identification, Function and Wiring

The fuses are held in three (3) fuse blocks. Use Figures 9 and 10 to identify each individual fuse and its correct amperage. Each fuse holder has the following functions and wire connected to it.

Fuse A1

- A. Supplies power to the seat switch.

Fuse A2

- A. Supplies power to ignition switch terminal B.

Fuse A3

- A. Supplies power to the PTO switch.

Fuse A4

- A. Supplies power to the starter solenoid.

Fuse B1

- A. Supplies power to the power point outlet.

Fuse B4 (when optional lighting is installed)

- A. Supplies power for optional light kit.

Fuse C3

- A. Supplies power for seat operation.

Fuse C4

- A. Supplies power for engine cooling fan operation.




Figure 9




Figure 10

Warning Lights

Testing Warning Lights

1. Apply 12 VDC to terminals 1A and 2A.
2. Ground terminals 1B and 2B.
3. Both indicator lights should light.

Engine Oil Pressure Light

The oil pressure light should come on when the ignition switch is in the ON position with the engine not running. Also, it should light with the engine running when the oil pressure drops below 7 PSI (0.5 kg/cm²).

1. Disconnect green wire from the oil pressure switch.
2. Ground green wire to the engine block.
3. Turn ignition switch to ON; the oil pressure light should come on indicating correct operation of the electrical wiring to the oil pressure switch.
4. Turn ignition switch to OFF. Reconnect green wire to the oil pressure switch.

High Temperature Shutdown Light

If the coolant temperature rises to 230°F (110°C), the high temperature light should come on as the high temperature shutdown switch stops the engine.

1. Ground the wire attached to temperature switch on flywheel end of engine. Warning light and audible alarm should go on and engine should stop running.
2. Depress alarm silence and alarm should turn off. Depress high temperature override and hold, engine should start and run.
3. Reconnect wire to temperature switch.

Glow Plug Indicator Light

The glow plug indicator light should come on when the ignition switch is placed in ON prior to placing the ignition switch in START. The light should stay lit for 10 seconds while the ignition switch is left in ON.

Charge Indicator Light

The charge indicator light should come on when the ignition switch is in ON with the engine not running or with an improperly operating charging circuit while the engine is running.




Figure 11

- | | |
|------------------------|------------------------|
| 1. Charge indicator | 3. High temp shutdown |
| 2. Engine oil pressure | 4. Glow plug indicator |




Figure 12

- | | |
|------------------------|------------------------|
| 1. Charge indicator | 4. Glow plug indicator |
| 2. Engine oil pressure | 5. Warning light front |
| 3. High temp shutdown | 6. Warning light back |

PTO Switch

The PTO switch is attached to the control console next to the operator seat (Fig. 13).

The switch terminals are marked as shown in Figure 14. The circuitry of the PTO switch is shown in the chart below. With the use of a multimeter (ohms setting), the switch functions may be tested to determine whether continuity exists between the various terminals for each position. Verify continuity between switch terminals.

NOTE: The PTO ON position requires lifting and pushing the lever toward the switch keyway. The PTO OFF position occurs when the lever is pushed opposite the keyway.

SWITCH POSITION	NORMAL CIRCUITS	OTHER CIRCUITS
PTO ON	2 + 3	5 + 6
CENTER	1 + 2	5 + 6
PTO OFF	1 + 2	4 + 5




Figure 13

1. PTO switch
2. Control console




Figure 14

Transport, Alarm Silence and Temperature Override Switches

The transport, alarm silence and temperature override rocker switches are located on the control console (Fig. 15). These switches have common switching logic.

The switch terminals are marked as shown in Figure 16 and Figure 17. The circuitry of these switches is shown in the chart below. With the use of a multimeter (ohms setting), the switch functions may be tested to determine whether continuity exists between the various terminals for each position. Verify continuity between switch terminals.

SWITCH POSITION	NORMAL CIRCUITS	OTHER CIRCUITS
ON	2 + 3	5 + 6
OFF	1 + 2	4 + 5




Figure 15

1. Transport switch
2. Alarm silence switch
3. Temp. override switch
4. Control console




Figure 16




Figure 17

Seat Switch

The seat switch is normally open and closes when the operator is on the seat. If the traction system or PTO switch is engaged when the operator raises out of the seat, the engine will stop. The seat switch and its electrical connector are located directly under the seat. Testing of the switch can be done without seat removal by disconnecting the seat wire from the machine wiring harness.

1. Make sure the engine is off.
2. Disconnect wire harness electrical connector for the seat switch.
3. Check the continuity of the switch by connecting a multimeter (ohms setting) across the connector terminals.
4. With no pressure on the seat, there should be no continuity between the seat switch terminals.
5. Press directly onto the seat switch through the seat cushion. There should be continuity as the seat cushion approaches the bottom of its travel.
6. Connect seat switch to harness connector after testing is complete.




Figure 18

1. Electrical connector 2. Seat switch

Parking Brake Switch

The switch used for the parking brake is a normally closed switch. The parking brake switch is located under the steering tower cover and opens when the parking brake lever is applied.

1. Make sure the engine is off. Locate switch for testing.
2. Disconnect electrical connector from the switch.
3. Check the continuity of the switch by connecting a multimeter (ohms setting) across the connector terminals.
4. When the switch plunger is extended there should be continuity between the switch terminals.
5. When the switch plunger is depressed, there should be no continuity between the switch terminals.
6. Reconnect switch connector.




Figure 19

1. Parking brake switch 3. Parking brake pawl
2. Parking brake rod

Hour Meter

The hour meter is located on the control console next to the operator seat.

1. Connect the positive (+) terminal of a 12 VDC source to the positive (+) terminal of the hour meter.
2. Connect the negative (-) terminal of the voltage source to the other terminal of the hour meter.
3. The hour meter should move a 1/10 of an hour in six minutes.
4. Disconnect voltage source from the hour meter.




Figure 20

Audio Alarm

The audio alarm for low engine oil pressure or high engine coolant temperature is attached to the control console next to the operator seat.

IMPORTANT: Make sure to observe polarity on the alarm terminals when testing. Damage to the alarm may result from an improper connection.

1. Isolate alarm from the circuit. Correctly connect 12VDC source to the terminals (Fig. 21).
2. Alarm should sound. Remove voltage source from the alarm. Reconnect alarm to the circuit.




Figure 21

1. Top view
2. Bottom view
3. Positive (+) terminal
4. Negative (-) terminal

Glow Relay

The glow relay is attached to the the right side of the fuel tank support under the hood. When energized, the glow relay provides current for the engine glow plugs.

Testing

1. Park machine on a level surface, lower cutting units, stop engine, apply parking brake and remove key from ignition switch.

2. Open hood to gain access to relay.

3. Locate relay and disconnect the machine wire harness connector from the relay. Remove relay from machine for easier testing.

NOTE: Prior to taking small resistance readings with a digital multimeter, short the meter test leads together. The meter will display a small resistance value (usually 0.5 ohms or less). This resistance is due to the internal resistance of the meter and test leads. Subtract this value from the measured value of the component you are testing.

4. Verify coil resistance between terminals 85 and 86 with a multimeter (ohms setting) (Fig. 22). Resistance should be approximately 72 ohms.

5. Connect multimeter (ohms setting) leads to relay terminals 30 and 87. Ground terminal 86 and apply +12 VDC to terminal 85. The relay should have continuity between terminals 30 and 87 as +12 VDC is applied to terminal 85. The relay should not have continuity between terminals 30 and 87 as +12 VDC is removed from terminal 85.




Figure 22

Start, Engine Shutdown, Seat, PTO, Alarm and Over Temperature Relays

These six (6) relays are located under the console housing cover. The wiring harness is tagged to identify each relay.

Testing

1. Make sure that ignition switch is OFF.
2. Locate relay and disconnect the machine wire harness connector from the relay. Remove relay from machine if necessary.

NOTE: Prior to taking small resistance readings with a digital multimeter, short the meter test leads together. The meter will display a small resistance value (usually 0.5 ohms or less). This resistance is due to the internal resistance of the meter and test leads. Subtract this value from the measured value of the component you are testing.

3. Using a multimeter (ohms setting), measure coil resistance between terminals 85 and 86 (Fig. 23). Resistance should be between 70 and 90 ohms.

4. Connect multimeter (ohms setting) leads to relay terminals 30 and 87. Ground terminal 86 and apply +12 VDC to terminal 85. The relay should have continuity between terminals 30 and 87 as +12 VDC is applied to terminal 85. The relay should not have continuity between terminals 30 and 87 as +12 VDC is removed from terminal 85.

5. Disconnect voltage from terminal 85 and multimeter lead from terminal 87.

6. Connect multimeter (ohms setting) leads to relay terminals 30 and 87A. Apply +12 VDC to terminal 85. The relay should have continuity between terminals 30 and 87A as +12 VDC is applied to terminal 85. The relay should not have continuity between terminals 30 and 87A as +12 VDC is removed from terminal 85.

7. Disconnect voltage and multimeter leads from the relay terminals.

8. Secure relay to machine if removed. Connect machine wire harness connector to relay.




Figure 23

Hydraulic Valve Solenoids

There are several hydraulic valve solenoids on the Groundsmaster 4000-D (Fig. 25). Testing of these solenoids can be done with the solenoid on the hydraulic valve.

NOTE: Prior to taking small resistance readings with a digital multimeter, short the meter test leads together. The meter will display a small resistance value (usually 0.5 ohms or less). This resistance is due to the internal resistance of the meter and test leads. Subtract this value from the measured value of the component you are testing.

1. Make sure engine is off. Disconnect wire harness connector from the solenoid (Fig. 24).
2. Measure resistance between the two solenoid connector terminals. The resistance for the solenoid coil should be about 7.2 ohms.
3. Install **new** solenoid if necessary. Torque solenoid nut to specification identified in Figure 25. Over-tightening may damage the solenoid or cause the valve to malfunction.
4. Connect wire harness connector to the solenoid.




Figure 24

1. Manifold (RH shown)
2. Valve solenoid
3. Solenoid connector




Figure 25

1. Hydraulic valve solenoid (decks)
2. Hydraulic manifold (decks)
3. Hydraulic valve solenoid (traction)
4. Hydraulic manifold (traction)

Fuel Sender

The fuel sender is located on top of the fuel tank.

1. Remove white wire and black ground wire from the sender.
2. Remove screws and lock washers that secure the sender to the fuel tank.
3. Remove sender and gasket from the fuel tank. Clean any fuel from the sender.

NOTE: Before taking small resistance readings with a digital multimeter, short meter test leads together. The meter will display a small resistance value. This internal resistance of the meter and test leads should be subtracted from the measured value of the component.



CAUTION

Make sure sending unit is completely dry (no fuel on it) before testing. Perform test away from the tank to prevent an explosion or fire from sparks.

4. Check resistance of the sender with a multimeter.
 - A. Resistance with the float in the full position should be 27.5 to 39.5 ohms.
 - B. Resistance with the float in the empty position should be 240 to 260 ohms.
5. Replace sender as necessary. Reinstall sender into fuel tank. Connect wires.




Figure 26

Fuel Gauge

The fuel gauge can be tested using a new gauge as a substitute or with the use of a DC voltage source and a variable resistance box.



CAUTION

Make sure the voltage source is turned OFF before connecting it to the electrical circuit to avoid electrical shock and prevent damaging the gauge.

1. Connect fuel gauge to the variable resistance and DC voltage source (Fig. 27).

NOTE: When reading the gauge test point, there are two white dots on the gauge face below the edge of the glass cover for the each test point. For each variable resistance setting, the needle must be pointed between the two white dots.

2. Take test point readings (Fig. 28).

IMPORTANT: Allow circuit to warm up for at least 5 minutes before taking test readings.

A. Set variable resistance to 240 ohms. Apply a 14 ± 0.01 VDC to the circuit. The needle should point to the left edge of the red area (empty).

B. Set variable resistance to 33 ohms. The needle should point to the right edge of the green area (full).

3. Turn off the voltage source. Disconnect voltage source, gauge and variable resistance.




Figure 27




Figure 28

1. Empty position
2. Full position

3. Glass face edge

Fuel Pump

The fuel pump is attached to the frame above the fuel water separator.

Operational Test

- 1. Park machine on a level surface, lower cutting units, stop engine and engage parking brake.
- 2. Disconnect electrical connector from the fuel stop solenoid to prevent the engine from firing.
- 3. Disconnect fuel hose (pump discharge) from the water separator.
- 4. Make sure fuel hoses attached to the fuel pump are free of obstructions.
- 5. Place fuel hose (pump discharge) into a large, graduated cylinder sufficient enough to collect 1 quart (0.95 liter).
- 6. Collect fuel in the graduated cylinder by turning ignition switch to the ON position. Allow pump to run for 15 seconds, then turn switch to OFF.
- 7. The amount of fuel collected in the graduated cylinder should be approximately 16 fl oz (475 ml) after 15 seconds.
- 8. Replace fuel pump as necessary. Install fuel hose to the water separator.
- 9. Connect electrical connector to the fuel stop solenoid.
- 10.Prime fuel system.

Fuel Pump Specifications

Pump Capacity	64 fl oz/min (1.9 l/min)
Pressure	7 PSI (48.3 kPa)
Current Draw	2.0 amp

Glow Controller

The glow controller is located under the console cover.

NOTE: Refer to Chapter 9 – Foldout Drawings when troubleshooting the controller.

Controller Operation

1. When the ignition switch is placed in the ON position, the controller energizes the glow plugs and lights up the glow lamp for approximately 10 seconds.
2. When the ignition switch is held in the START position, the glow plugs will energize and the glow lamp will **not** light.
3. When the ignition switch is released from START to ON, the glow plugs will deenergize and the glow lamp will remain off.

Controller Checks

1. Make sure there is power from the battery.
2. Disconnect electrical connector to the run solenoid to prevent the engine from starting.
3. Place ignition switch in the ON position. Verify the following while in the ON position:
 - A. Glow indicator lamp is on.
 - B. Glow relay is energized.
 - C. Glow plugs are energized.
 - D. Glow indicator lamp goes out and glow plugs de-energize after approximately 10 seconds.
4. Place ignition switch in the START position. Verify the following while in the START position:
 - A. Glow indicator lamp is out.
 - B. Glow relay is energized.
 - C. Glow plugs are energized.
 - D. Power to terminal 1 of the glow controller.

NOTE: If there is no power to terminal 1 of the glow controller, verify continuity of the circuitry from the ignition switch to the controller and perform step 4 again (see Chapter 9 – Foldout Drawings).




Figure 29

1. Glow controller end view 2. Controller side view

5. If any of the conditions in step 3 are not met or power to terminal 1 exists and any of the other conditions in step 4 are not met:
 - A. Verify continuity of the circuitry from the battery to the glow relay and glow plugs (see Chapter 9 – Foldout Drawings).
 - B. Verify continuity of the circuitry from the battery to ignition switch, glow controller, glow lamp, glow relay and ground (see Chapter 9 – Foldout Drawings).
 - C. Replace parts as necessary.
6. Connect electrical connector to the run solenoid.

Temperature Sender

The temperature sender is located near the alternator on the water flange attached to the engine cylinder head (Fig. 30). There is a gray wire attached to the terminal of the switch.

1. Lower coolant level in the engine and remove the temperature sender from water flange.
2. Put switch in a container of oil with a thermometer and slowly heat the oil (Fig. 31).



CAUTION

Handle the hot oil with extreme care to prevent personal injury or fire.

NOTE: Prior to taking resistance readings with a digital multi meter, short the meter test leads together. The meter will display a small resistance value (usually 0.5 ohms or less). This resistance is due to the internal resistance of the meter and test leads. Subtract this value from the measured value of the component you are testing.

3. Check resistance of the sender with a multimeter (ohms setting) as the temperature increases.

A. The meter should indicate from 54 to 78 ohms at 200°F (93.3°C).

B. Replace sender if specification is not met.

4. Install sender to the water flange.

A. Clean threads of water flange and sender thoroughly. Apply thread sealant to the threads of the sender.

B. Screw sender into the water flange and tighten.

C. Reconnect gray wire to sender. Apply skin-over grease (Toro Part No. 505-165) to sender terminal.

5. Fill engine cooling system.




Figure 30

1. Temperature sender
2. Alternator




Figure 31

Dual Temperature Switch

The dual temperature switch is attached to the engine near the alternator on the water flange attached to the engine cylinder head (Fig. 32). Two (2) electrical harness wires (a blue wire and a yellow wire) are attached to the switch.

The terminal on the switch is used to activate the engine over temperature warning. The warning illuminates the overtemp warning light and also causes the PTO to disengage. The harness blue wire attaches to this switch terminal.

The wire lead on the switch is used to shutdown the engine. The harness yellow wire attaches to this switch lead.

Testing



CAUTION

Make sure engine is cool before removing the temperature switch.

1. Lower coolant level in the engine and remove the dual temperature switch from the engine water flange.
2. Put switch in a container of oil with a thermometer and slowly heat the oil (Fig. 33).



CAUTION

Handle the hot oil with extreme care to prevent personal injury or fire.

3. Check continuity of the switch with a multimeter (ohms setting). Both circuits of the temperature switch are normally open and should close at the following temperatures:

A. The warning terminal should open from 214° to 226° F (101 to 108° C).

B. The shutdown wire lead should open from 234° to 246° F (112 to 119° C).

4. Replace switch if necessary.
5. Install switch to the water flange.

A. Clean threads of cylinder head and switch thoroughly. Apply thread sealant to the threads of the switch.

B. Screw switch into the cylinder head and tighten.

C. Connect harness wires to switch.

6. Fill engine cooling system.




Figure 32

1. Dual temp switch

2. Alternator




Figure 33




Figure 34

1. Dual temperature switch

2. Warning (terminal)

3. Shutdown (wire lead)

Temperature Gauge

The temperature gauge can be tested using a new gauge as a substitute or by the use of a DC voltage source and a variable resistance box.



CAUTION

Make sure the voltage source is turned OFF before connecting variable resistance to the electrical circuit to avoid electrical shock and to prevent damaging the gauge.

1. Connect temperature gauge to the variable resistance and DC voltage source (Fig. 27).

NOTE: When reading the gauge test point, there are two white dots on the gauge face below the edge of the glass cover for the each test point. For each variable resistance setting, the needle must be pointed between the two white dots.

2. Take test point readings (Fig. 28).

IMPORTANT: Allow circuit to warm up for at least 5 minutes before taking test readings.

A. Set variable resistance to 71 ohms. Apply a 14 ± 0.01 VDC to the circuit. The needle should point to the middle of the green area (80°C).

B. Set variable resistance to 38 ohms. The needle should point between the green and red area (105°C).

3. Turn off the voltage source. Disconnect voltage source, gauge and variable resistance.




Figure 35




Figure 36

1. Middle position
2. High temp position
3. Edge of glass cover

Traction Neutral Switch

The traction neutral switch is closed when the traction pedal is in the neutral position and opens when the pedal is depressed in either direction. The switch is located on the right side of the piston (traction) pump.

Test the switch by disconnecting the wires from the switch terminals and connecting a continuity tester across the two switch terminals. With the engine turned off, slowly push the traction pedal in a forward or reverse direction while watching the continuity tester. There should be indications that the traction neutral switch is opening and closing. Allow the traction pedal to return to the neutral position. There should be continuity across the switch terminals when the traction pedal is in the neutral position.

See Piston Pump Control Assembly in Chapter 4 – Hydraulic Systems for disassembly and assembly procedures for the neutral switch.




Figure 37
1. Piston pump (bottom) 2. Neutral switch

Diode Assemblies

The Groundsmaster 4000–D electrical system includes several diode assemblies (Fig. 38) that are used for circuit protection and circuit logic control. The diodes plug into the wiring harness at various locations on the machine.

The diodes D2, D4, D5, D6 and D7 are used for circuit protection that occur when a hydraulic valve solenoid is de–energized. Diode D2 is in the Transport/Mow circuit, D4 is in the left cutting deck circuit, D5 is in the front cutting deck circuit, D6 is in the right cutting deck circuit and D7 is in the cruise control circuit.

Diode D8 provides a latching circuit to keep the cruise relay energized.

Diode D9 provides logic for the high temperature warning system.

Testing

The diodes can be individually tested using a digital multimeter (diode test or ohms setting) and the table to the right.




Figure 38
1. Diode 2. Male terminal 3. Female terminal

Multimeter Red Lead (+) on Terminal	Multimeter Black Lead (–) on Terminal	Continuity
Female	Male	YES
Male	Female	NO

Diode Circuit Board

The circuit board contains four diodes (Fig. 39) and is located under the console housing. The diodes are used for circuit protection from inductive voltage spikes that occur when a hydraulic valve solenoid is de-energized. Diode D1 is in the left cutting deck circuit, D2 is in the Transport/Mow circuit, D3 is in the front cutting deck circuit and D4 is in the right cutting deck circuit.

Testing

The diodes can be individually tested using a digital multimeter (ohms setting) and the table to the right. If any of the diodes are damaged, the diode circuit board must be replaced.




Figure 39

Red Lead (+) on Terminal	Black Lead (-) on Terminal	Continuity
H	A	YES
A	H	NO
G	B	YES
B	G	NO
F	C	YES
C	F	NO
E	D	YES
D	E	NO

Electrical
System

Cutting Deck Position Switch

The cutting deck position switches on the Groundsmaster 4000–D are located on the traction unit frame (Fig. 40 and 41) and are normally open. The position switch is a powered proximity switch that incorporates an internal reed switch and relay (see schematic in Figure 42). The sensing plate is located on the cutting deck lift arm. The switches for front and side decks are the same although their operation depends on deck location.

When a side cutting deck is raised, the sensing plate is moved away from the position switch and the switch opens. The open switch prevents current flow to the side deck solenoid and keeps the deck from operating.

When the front cutting deck is raised, the sensing plate is moved near the position switch and the switch closes. The closed switch prevents current flow to the front deck solenoid and keeps the deck from operating.

Testing

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Locate switch that requires testing and disconnect switch connector from machine wiring harness.
3. Ground switch connector terminal for black wire and apply 12 VDC to switch connector terminal for red wire.
4. Using a multimeter, verify that switch connector terminal for blue wire has 12 VDC and terminal for white wire has 0 VDC.
5. Place metal object near sensing area of switch (opposite end from wires). Ground switch connector terminal for black wire and apply 12 VDC to switch connector terminal for red wire.
6. Using a multimeter, verify that switch connector terminal for blue wire has 0 VDC and terminal for white wire has 12 VDC.
7. Replace switch as needed.

Adjustment

NOTE: Deck Proximity Switch Adjustment Tool (TOR4095) can be used for switch adjustment.

1. Sensing plate on side deck lift arms should be 0.060" to 0.120" (1.5 to 3.0 mm) from target surface of position switch.
2. On front deck lift arm, slide sensing plate as far from the lift arm as possible.




Figure 40

1. Position switch (front)
2. Sensing plate
3. Front lift cylinder




Figure 41

1. Position switch (side)
2. Sensing plate




Figure 42

Service and Repairs

NOTE: For more component repair information, see the Kubota Workshop Manual, Diesel Engine, V2403–M–T–E3B Series at the end of Chapter 3 – Kubota Diesel Engine.


Battery Storage

If the machine will be stored for more than 30 days:

1. Remove the battery and charge it fully (see Battery Service).
2. Either store battery on a shelf or on the machine.
3. Leave cables disconnected if the battery is stored on the machine.
4. Store battery in a cool atmosphere to avoid quick deterioration of the battery charge.
5. To help prevent the battery from freezing, make sure it is fully charged (see Battery Service).

Battery Care

1. Battery electrolyte level must be properly maintained. The top of the battery must be kept clean. If the machine is stored in a location where temperatures are extremely high, the battery will run down more rapidly than if the machine is stored in a location where temperatures are cool.
3. Battery cables must be tight on terminals to provide good electrical contact.

**WARNING**

Wear safety goggles and rubber gloves when working with electrolyte. Charge battery in a well ventilated place so gasses produced while charging can dissipate. Since the gases are explosive, keep open flames and electrical sparks away from the battery; do not smoke. Nausea may result if the gases are inhaled. Unplug charger from electrical outlet before connecting or disconnecting charger leads to or from battery posts.

IMPORTANT: Do not remove fill caps while cleaning.

2. Check battery condition weekly or after every 50 hours of operation. Keep terminals and entire battery case clean because a dirty battery will discharge slowly.
 - A. Clean battery by washing entire case with a solution of baking soda and water. Rinse with clear water.
 - B. Coat battery posts and cable connectors with battery terminal protector (Toro Part No. 107–0392) or petroleum jelly to prevent corrosion.

**WARNING**

Connecting cables to the wrong post could result in personal injury and/or damage to the electrical system.

4. If corrosion occurs at terminals, disconnect cables. Always disconnect negative (–) cable first. Clean clamps and terminals separately. Reconnect cables with positive (+) cable first. Coat battery posts and cable connectors with battery terminal protector (Toro Part No. 107–0392) or petroleum jelly to prevent corrosion.
5. Check electrolyte level every 25 operating hours and every 30 days if machine is in storage.
6. Maintain cell level with distilled or demineralized water. Do not fill cells above the fill line.

Electrical
System

Battery Service

The battery is the heart of the electrical system. With regular and proper service, battery life can be extended. Additionally, battery and electrical component failure can be prevented.



CAUTION

When working with batteries, use extreme caution to avoid splashing or spilling electrolyte. Electrolyte can destroy clothing and burn skin or eyes. Always wear safety goggles and a face shield when working with batteries.

Electrolyte Specific Gravity

Fully charged: 1.265 corrected to 80°F (26.7°C)
Discharged: less than 1.240

Battery Specifications

BCI Group Size 24
650 CCA at 0° F (-17.8° C)
Reserve Capacity of 110 minutes at 80°F (26.7°C)

Dimensions (including terminal posts and caps)

Length 10.2 inches (25.9 cm)
Width 6.64 inches (16.9 cm)
Height 8.99 inches (22.8 cm)

Removal and Installation (Fig. 43)

See Operator's Manual for battery removal and installation information.

NOTE: Before connecting the negative (ground) cable, connect a digital multimeter (set to amps) between the negative battery post and the negative (ground) cable connector. The reading should be less than 0.1 amp. If the reading is 0.1 amp or more, the unit's electrical system should be tested and repaired.

Inspection, Maintenance and Testing

1. Perform following inspections and maintenance:

- A. Check for cracks. Replace battery if cracked or leaking.
- B. Check battery terminal posts for corrosion. Use wire brush to clean corrosion from posts.

IMPORTANT: Before cleaning the battery, tape or block vent holes to the filler caps and make sure the caps are on tightly.

- C. Check for signs of wetness or leakage on the top of the battery which might indicate a loose or missing filler cap, overcharging, loose terminal post or overfilling. Also, check battery case for dirt and oil. Clean the battery with a solution of baking soda and water, then rinse it with clean water.




Figure 43

- 1. Negative cable
- 2. Positive cable
- 3. Battery retainer

D. Check that the cover seal is not broken away. Replace the battery if the seal is broken or leaking.

E. Check the electrolyte level in each cell. If the level is below the tops of the plates in any cell, fill all cells with **distilled** water between the minimum and maximum fill lines. Charge at 15 to 25 amps for 15 minutes to allow sufficient mixing of the electrolyte.

2. Conduct a hydrometer test of the battery electrolyte.

IMPORTANT: Make sure the area around the cells is clean before opening the battery caps.

A. Measure the specific gravity of each cell with a hydrometer. Draw electrolyte in and out of the hydrometer barrel prior to taking a reading to warm-up the hydrometer. At the same time take the temperature of the cell.

B. Temperature correct each cell reading. For each 10°F (5.5°C) above 80°F (26.7°C) add 0.004 to the specific gravity reading. For each 10°F (5.5°C) below 80°F (26.7°C) subtract 0.004 from the specific gravity reading.

Example: Cell Temperature	100°F
Cell Gravity	1.245
100°F minus 80°F equals	20°F
(37.7°C minus 26.7°C equals	11.0°C)
20°F multiply by 0.004/10°F equals	0.008
(11°C multiply by 0.004/5.5°C equals	0.008)
ADD (conversion above)	<u>0.008</u>
Correction to 80°F (26.7°C)	1.253

PRELIMINARY – For Toro Distributor and Toro Company use only.

C. If the difference between the highest and lowest cell specific gravity is 0.050 or greater or the lowest cell specific gravity is less than 1.225, charge the battery. Charge at the recommended rate and time given in **Charging** or until all cells specific gravity is 1.225 or greater with the difference in specific gravity between the highest and lowest cell less than 0.050. If these charging conditions can not be met, replace the battery.

3. Perform a high-discharge test with an adjustable load tester.

This is one of the most reliable means of testing a battery as it simulates the cold-cranking test. A commercial battery load tester is **required** to perform this test.



A. Check the voltage across the battery terminals prior to testing the battery. If the voltage is less than 12.4 VDC, recharge the battery.

B. If the battery has been charged, apply a 150 amp load for 15 seconds to remove the surface charge. Use a battery load tester following the manufacturer's instructions.

C. Make sure battery terminals are free of corrosion.

D. Measure the temperature of the center cell.

E. Connect a battery load tester to the battery terminals **following the manufacturer's instructions**. Connect a digital multimeter to the battery terminals.

F. Apply a test load of one half the Cranking Performance (see Battery Specifications) rating of the battery for 15 seconds.

G. Take a voltage reading at 15 seconds, then remove the load.

H. Using the table below, determine the minimum voltage for the cell temperature reading:

Minimum Voltage	Battery Electrolyte Temperature	
9.6	70°F (and up)	21.1°C (and up)
9.5	60°F	15.6°C
9.4	50°F	10.0°C
9.3	40°F	4.4°C
9.1	30°F	-1.1°C
8.9	20°F	-6.7°C
8.7	10°F	-12.2°C
8.5	0°F	-17.8°C

I. If the test voltage is below the minimum, replace the battery. If the test voltage is at or above the minimum, return the battery to service.

Charging

To minimize possible damage to the battery and allow the battery to be fully charged, the slow charging method is presented here. This charging method can be accomplished with a constant current battery charger which is available in most shops.



CAUTION

Follow the manufacturer's instructions when using a battery charger.

NOTE: Using specific gravity of the battery cells is the most accurate method of determining battery condition.

1. Determine the battery charge level from either its specific gravity or open circuit voltage.

Battery Charge Level	Specific Gravity	Open Circuit Voltage
100%	1.265	12.68
75%	1.225	12.45
50%	1.190	12.24
25%	1.155	12.06
0%	1.120	11.89

2. Determine the charging time and rate **using the manufacturer's battery charger instructions** or the following table.

Battery Reserve Capacity (Minutes)	Battery Charge Level (Percent of Fully Charged)			
	75%	50%	25%	0%
80 or less	3.8 hrs @ 3 amps	7.5 hrs @ 3 amps	11.3 hrs @ 3 amps	15 hrs @ 3 amps
81 to 125	5.3 hrs @ 4 amps	10.5 hrs @ 4 amps	15.8 hrs @ 4 amps	21 hrs @ 4 amps
126 to 170	5.5 hrs @ 5 amps	11 hrs @ 5 amps	16.5 hrs @ 5 amps	22 hrs @ 5 amps
171 to 250	5.8 hrs @ 6 amps	11.5 hrs @ 6 amps	17.3 hrs @ 6 amps	23 hrs @ 6 amps
above 250	6 hrs @ 10 amps	12 hrs @ 10 amps	18 hrs @ 10 amps	24 hrs @ 10 amps



CAUTION

Do not charge a frozen battery because it can explode and cause injury. Let the battery warm to 60°F (15.5° C) before connecting to a charger.

Charge the battery in a well-ventilated place to dissipate gases produced from charging. These gases are explosive; keep open flame and electrical spark away from the battery. Do not smoke. Nausea may result if the gases are inhaled. Unplug the charger from the electrical outlet before connecting or disconnecting the charger leads from the battery posts.

3. **Following the manufacturer's instructions**, connect the charger cables to the battery. Make sure a good connection is made.

4. Charge the battery **following the manufacturer's instructions**.

5. Occasionally check the temperature of the battery electrolyte. If the temperature exceeds 125°F (51.6°C) or the electrolyte is violently gassing or spewing, the charging rate must be lowered or temporarily stopped.

6. Three hours prior to the end of the charging, measure the specific gravity of a battery cell once per hour. The battery is fully charged when the cells are gassing freely at a low charging rate and there is less than a 0.003 change in specific gravity for three consecutive readings.

This page is intentionally blank.



Axles, Planetaries and Brakes

Table of Contents

SPECIFICATIONS 2

ADJUSTMENTS 3

SERVICE AND REPAIRS 4

 Brake Assembly 4

 Brake Inspection and Repair 6

 Planetary Wheel Drive Assembly 8

 Planetary Wheel Drive Service 10

 Rear Axle Assembly 12

 Bevel Gear Case and Axle Case 15

 Differential Shafts 20

 Axle Shafts 21

 Input Shaft/Pinion Gear 22

 Differential Gear 24

 Pinion Gear to Ring Gear Engagement 27

Axles, Planetaries
and Brakes

Specifications

Item	Specification
Wheel lug nut torque	85 to 100 ft-lb (115 to 135 N-m), front and rear
Steering cylinder bolt torque	100 to 125 ft-lb (139 to 169 N-m)
Rear wheel toe-in	.125 in (3.18 mm)
Tire pressure	25 to 30 PSI (1.7 to 2.1 bar), front and rear
Planetary brake housing and wheel motor mounting screw torque	75 to 85 ft-lb (101 to 115 N-m)
Planetary gear drive oil System gear lube capacity (each wheel)	SAE 85W-140 wt. gear lube 16 fl. oz. (.47 liters)
Rear axle lubricant System gear lube capacity	SAE 85W-140 wt. gear lube 80 fl. oz. (2.37 liters)
Rear axle gear box lubricant System gear lube capacity	SAE 85W-140 wt. gear lube 16 fl. oz. (.47 liters)

Adjustments

See Operator's Manual for adjustment procedures for Groundsmaster 4000-D axles, planetaries and brakes.

PRELIMINARY – For Toro Distributor and Toro Company use only.

Service and Repairs

Brake Assembly




Figure 1

- | | | |
|--------------------------|-------------------------|-----------------------------|
| 1. Planetary assembly | 7. Flat washer | 13. Brake cable |
| 2. Retaining ring | 8. Cap screw | 14. Spring plate |
| 3. Splined brake shaft | 9. Flange head screw | 15. Flange head screw |
| 4. Brake assembly (RH) | 10. Brake assembly (LH) | 16. Tire and wheel assembly |
| 5. O-ring | 11. Jam nut | 17. Lug nut |
| 6. Hydraulic wheel motor | 12. Compression spring | 18. Gasket |

Remove Brake Assembly (Fig. 1)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Drain oil from planetary wheel drive/brake assembly.



CAUTION

When changing attachments, tires or performing other service, use correct jacks and supports. Make sure machine is parked on a solid, level surface such as a concrete floor. Prior to raising machine, remove any attachments that may interfere with the safe and proper raising of the machine. Always chock or block wheels. Use jack stands to support the raised machine. If the machine is not properly supported by jack stands, the machine may move or fall, which may result in personal injury.

3. Chock rear wheels and jack up front of machine (see Jacking Instructions in Chapter 1 – Safety). Support machine with jack stands or solid wood blocks.
4. Remove wheel assembly.
5. Remove hydraulic wheel motor (see Front Wheel Motors in the Service and Repairs section of Chapter 4 – Hydraulic System).
6. Disconnect brake cable from pull rod on brake.
7. Remove flange head capscrews (5) securing brake assembly to frame; be careful not to drop splined brake shaft as brake assembly is removed.
8. Remove splined brake shaft.
9. Complete brake inspection and repair.

Install Brake Assembly (Fig. 1)

1. Install splined brake shaft into brake assembly.
Note: The stepped end of the splined brake shaft must be aligned toward the hydraulic wheel motor (Fig. 2).
2. Install brake assembly onto frame, aligning splined brake shaft with input shaft on planetary wheel drive.
3. Install flange head screws (5) to secure brake assembly to frame. Tighten screws in a crossing pattern to a torque from **75 to 85 ft-lb (101 to 115 N-m)**.
4. Install brake cable to pull rod on brake assembly. Brake cable end should be completely threaded onto pull rod.
5. Install new o-ring on hydraulic wheel motor. Install wheel motor and torque capscrews from **75 to 85 ft-lb (101 to 115 N-m)**.



WARNING

Failure to maintain proper wheel lug nut torque could result in failure or loss of wheel and may result in personal injury.

6. Install wheel assembly. Torque lug nuts from **85 to 100 ft-lb (115 to 135 N-m)**.
7. Lower machine to ground.
8. Make sure drain plug is installed in bottom of brake assembly (Fig. 3). Fill planetary wheel drive/brake assembly with SAE 85W-140 gear lube. Capacity is approximately 16 fl. oz. (0.47 liters) per wheel.
9. Check and adjust brake cables for proper brake operation.




Figure 2

1. Splined brake shaft step
2. Hydraulic motor end
3. Planetary assembly end




Figure 3

1. Brake housing
2. Check plug
3. Drain plug

Brake Inspection and Repair




Figure 4

- | | | |
|-----------------------------|--------------------|-----------------------|
| 1. Brake housing (LH shown) | 6. Hitch pin | 11. Rotating actuator |
| 2. Seal | 7. Stationary disc | 12. Extension spring |
| 3. Pull rod | 8. Rotating disc | 13. Ball |
| 4. Clevis pin | 9. Retaining ring | 14. Plug |
| 5. Link | 10. Gasket | 15. O-ring |

Brake Inspection and Repair (Fig. 4)

1. Scrape gasket material (item 10) from brake housing and planetary wheel drive mounting surfaces.
2. Remove retaining ring (item 9).
3. Remove stationary discs (item 7) and rotating discs (item 8).
4. Remove extension springs (item 12).
5. Remove actuator assembly (items 11, 6, 5, 4, 3) and balls (item 13).
6. Remove seal (item 2) from brake housing.
7. Wash parts in cleaning solvent. Inspect components for wear or damage.
8. Reverse steps 2 – 6 to assemble brakes, installing new parts as necessary. Install a new seal (2).
9. Use a new gasket (item 10) when installing brake assembly to machine.

This page is intentionally blank.

Planetary Wheel Drive Assembly




Figure 5

- | | | |
|------------------------|--------------------------|-----------------------------|
| 1. Planetary assembly | 6. Hydraulic wheel motor | 11. Gasket |
| 2. Retaining ring | 7. Flat washer | 12. Flange head screw |
| 3. Splined brake shaft | 8. Cap screw | 13. Tire and wheel assembly |
| 4. Brake assembly (RH) | 9. Flange head screw | 14. Lug nut |
| 5. O-ring | 10. Brake assembly (LH) | |

Planetary Wheel Drive Removal

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Drain oil from planetary wheel drive/brake assembly.



CAUTION

When changing attachments, tires or performing other service, use correct jacks and supports. Make sure machine is parked on a solid, level surface such as a concrete floor. Prior to raising machine, remove any attachments that may interfere with the safe and proper raising of the machine. Always chock or block wheels. Use jack stands to support the raised machine. If the machine is not properly supported by jack stands, the machine may move or fall, which may result in personal injury.

3. Chock rear wheels and jack up front of machine (see Jacking Instructions in Chapter 1 – Safety). Support machine with jack stands or solid wood blocks.
4. Remove front wheel assembly.
5. Remove hydraulic wheel motor (see Front Wheel Motors in the Service and Repairs section of Chapter 4 – Hydraulic System).
6. Remove brake assembly (see Brake Assembly in this section).
7. Support planetary assembly to prevent it from falling. Loosen and remove flange head screws that secure planetary assembly to frame. Remove planetary assembly from machine.

Planetary Wheel Drive Installation

1. Position planetary assembly to machine. Install flange head screws that secure planetary assembly. Torque screws from **75 to 85 ft-lb (101 to 115 N-m)**.
2. Install brake assembly (see Brake Assembly in this section).
3. Install hydraulic wheel motor (see Front Wheel Motors in the Service and Repairs section of Chapter 4 – Hydraulic System).



WARNING

Failure to maintain proper wheel lug nut torque could result in failure or loss of wheel and may result in personal injury.

4. Install wheel assembly. Torque lug nuts from **85 to 100 ft-lb (115 to 135 N-m)**.
5. Lower machine from jack stands.
6. Make sure drain plug is installed in bottom of brake assembly (Fig. 6). Fill planetary wheel drive/brake assembly with SAE 85W-140 gear lube. Capacity is approximately 16 fl. oz. (0.47 liters) per wheel.
7. Check and adjust brake cables for proper brake operation.




Figure 6

1. Brake housing
2. Check plug

3. Drain plug

Planetary Wheel Drive Service




Figure 7

- | | | |
|-----------------|-------------------------------|----------------------|
| 1. Spindle | 9. Thrust washer | 17. Input shaft |
| 2. Seal | 10. Retaining ring (external) | 18. Carrier assembly |
| 3. Bearing cone | 11. Ring gear | 19. Cap screw |
| 4. Bearing cup | 12. Retaining ring (internal) | 20. Seal |
| 5. Wheel stud | 13. Plug | 21. O-ring |
| 6. Housing | 14. Cover plate | 22. O-ring |
| 7. Bearing cup | 15. Input spacer | 23. Dowel pin |
| 8. Bearing cone | 16. Thrust washer | |

Planetary Wheel Drive Disassembly (Figure 7)

1. Remove retaining ring (item 12).
2. Remove cover plate (item 14).
3. Remove input spacer (item 15) and thrust washer (item 16).
4. Remove input shaft (item 17).
5. Remove carrier assembly (item 18).

NOTE: Steps 6 –10 are necessary only if inspecting or replacing bearings and/or seals.

6. Remove cap screws (item 19) and remove ring gear (item 11).
7. Remove retaining ring (item 10) and thrust washer (item 9).
8. Use a puller to remove spindle (item 1) from housing (item 6). Remove bearing cone (item 8).
9. Remove and discard all seals.
10. If bearings will be replaced, use a puller to remove bearing cone (item 3) from spindle. Remove bearing cups (items 4 and 7) from housing (item 6).

Planetary Wheel Drive Assembly (Figure 7)

NOTE: Use new seal kit when assembling planetary wheel drive.

1. Clean parts in solvent. Inspect parts for damage or excessive wear and replace as necessary.
2. Install lip seal (item 2) to spindle (item 1).
3. Press bearing cups (items 4 and 7) into housing (item 6).
4. Press bearing cone (item 3) onto spindle (item 1).
5. Install seal (item 20) to housing (item 6). Assemble housing (item 6) to spindle (item 1).
6. Press bearing cone (item 8) onto spindle and secure with thrust washer (item 9) and retaining ring (item 10).
7. Install o-ring (item 21), then assemble ring gear (item 11) to housing (item 6) with cap screws (item 19). Torque cap screws to **9 ft-lb (12 N-m)**.
8. Install carrier assembly (item 18).
9. Install input shaft (item 17).
10. Install thrust washer (item 16) and input spacer (item 15).
11. Install o-ring (item 22), then install cover plate (item 14). Secure cover with retaining ring (item 12).
12. Check operation of planetary wheel drive before installing assembly on the machine. With a constant turning force applied, rotation of the planetary should be consistent. If there is more drag at certain points, gears are not rolling freely and the planetary should be examined for improper assembly or damaged components.

Rear Axle Assembly




Figure 8

- | | | |
|--------------------------|-------------------------|------------------------------|
| 1. Frame assembly | 8. Rear axle assembly | 14. Lock nut |
| 2. Cap screw | 9. Thrust washer (thin) | 15. Flange nut |
| 3. Lock washer | 10. Washer head screw | 16. Rear bumper |
| 4. Flat washer | 11. Pivot pin | 17. Hydraulic manifold (4WD) |
| 5. Support frame | 12. Rear frame mount | 18. Cap screw |
| 6. Thrust washer (thick) | 13. Washer | 19. Flange nut |
| 7. Grease fitting | | |

Remove Rear Axle

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.



CAUTION

When changing attachments, tires or performing other service, use correct jacks and supports. Make sure machine is parked on a solid, level surface such as a concrete floor. Prior to raising machine, remove any attachments that may interfere with the safe and proper raising of the machine. Always chock or block wheels. Use jack stands to support the raised machine. If the machine is not properly supported by jack stands, the machine may move or fall, which may result in personal injury.

2. Chock front wheels and jack up rear of machine (see Jacking Instructions in Chapter 1 – Safety). Support machine with jack stands or solid wood blocks.

3. Drain oil from rear axle and axle gearbox.

4. Remove wheels from rear axle.

5. Remove hydraulic motor from rear axle assembly (see Rear Axle Motor in the Service and Repairs section of Chapter 4 – Hydraulic System).

6. Remove steering cylinder from rear axle (see Steering Cylinder in the Service and Repairs section of Chapter 4 – Hydraulic System).

7. Disconnect both steering cylinder hydraulic hoses from hydraulic tubes at rear frame mount (Fig. 9). Remove bulkhead locknuts that secure steering cylinder hydraulic tubes to rear frame mount. Separate tubes from frame mount.

PRELIMINARY – For Toro Distributor and Toro Company use only.

8. Remove cap screw and flange nut that secures front corner of 4WD hydraulic manifold to rear frame mount.

9. If required, remove tie rod ends from steering arms on rear axle (Fig. 10). Remove the cotter pins and castle nuts from the tie rod ball joints. Use a ball joint fork and remove the tie rod ends from the axle steering arms.

10. Support rear axle to prevent it from falling. Remove six cap screws, flat washers and flange nuts that secure rear frame mount to equipment frame. Lower rear axle and rear frame mount from machine.

11. Remove lock nut and washer from pivot pin that attaches rear axle to rear frame mount. Remove washer head screw that secures flange of pivot pin to frame mount (Fig. 11).

12. Remove pivot pin. Separate rear frame mount from rear axle. Note location of thrust washers on both ends of axle mounting boss.

Install Rear Axle

1. Position rear frame mount to axle. Install thrust washers between axle boss and frame mount. The thinner thrust washer should be installed on the hydraulic motor end of the axle (toward the rear of the machine). With washers installed, there should be 0.002" to 0.020" (0.05 mm to 0.51 mm) clearance between rear frame mount and axle mounting boss. Add thrust washers if needed to adjust clearance.

2. Install axle pivot pin to secure axle to rear frame mount. Install washer and lock nut onto pivot pin. Tighten lock nut and then loosen it slightly to allow the axle pin to pivot freely. Secure pivot pin with washer head screw (Fig. 11).

3. If removed, install the tie rod to rear axle (Fig. 10). Tighten ball joint castle nuts and install new cotter pins.

4. Position axle and rear mount under machine with a jack. Raise assembly to machine frame and align mounting holes of rear mount and machine frame.

5. Secure rear mount to frame with six (6) cap screws, flat washers and flange nuts.

6. Install cap screw and flange nut that secures front corner of 4WD hydraulic manifold to rear frame mount.

7. If removed, install the tie rod to rear axle. Tighten ball joint castle nuts and install new cotter pins.

8. Attach steering cylinder hydraulic tubes to rear frame mount with washers and bulkhead locknuts (Fig. 9). Install steering cylinder hoses to hydraulic tubes.




Figure 9

- | | |
|-------------------|---------------------|
| 1. Hydraulic hose | 4. Hydraulic tube |
| 2. Hydraulic hose | 5. Rear frame mount |
| 3. Hydraulic tube | |




Figure 10

- | | |
|---------------|----------------------|
| 1. Tie rod | 4. Castle nut |
| 2. Dust cover | 5. Tie rod end |
| 3. Cotter pin | 6. Steering arm (LH) |




Figure 11

- | | |
|--------------|----------------------|
| 1. Pivot pin | 2. Washer head screw |
|--------------|----------------------|

PRELIMINARY – For Toro Distributor and Toro Company use only.

9. Install steering cylinder to axle assembly (see Steering Cylinder in the Service and Repairs section of Chapter 4 – Hydraulic System).

10. Install hydraulic motor to axle assembly (see Rear Axle Motor in the Service and Repairs section of Chapter 4 – Hydraulic System).



WARNING

Failure to maintain proper wheel lug nut torque could result in failure or loss of wheel and may result in personal injury.

11. Install wheels to axle. Torque wheel lug nuts from **85 to 100 ft-lb (115 to 135 N-m)**.

12. Lower machine to ground.

13. Fill axle with SAE 85W-140 weight gear lube. Lubricant capacity is approximately 80 fl. oz. (2.37 l) for the axle and 16 fl. oz. (.47 l) for the gearbox.

14. Check rear wheel toe-in and adjust if necessary.

15. Check steering stop bolt adjustment. When the steering cylinder is fully extended (right turn), a gap of 1/16" (1.6 mm) should exist between bevel gear case casting and stop bolt on left axle case. Figure 12 shows stop bolt location.




Figure 12

1. Steering stop bolt

2. Bevel gear case (LH)

Bevel Gear Case and Axle Case

The following procedures assume the rear axle assembly has been removed from the machine.

Removal

1. Remove the mounting screws, nuts and lock washers. Remove the bevel gear case/axle case assembly and O-ring from the axle support (Fig. 13).
2. Mark both right and left bevel gear case/axle case assemblies.

IMPORTANT: Do not interchange right and left bevel gear case/axle case assemblies.




Figure 13

- | | |
|-----------------|---------------------------------------|
| 1. Cap screw | 5. Bevel gear case/axle case assembly |
| 2. Lock nut | 6. O-ring |
| 3. Lock washer | |
| 4. Axle support | |

3. Remove the axle cover mounting screws. Remove the axle cover from the axle case as an assembly (Fig. 14).




Figure 14

- | | |
|------------------------|-------------------|
| 1. Axle case | 3. Mounting screw |
| 2. Axle cover assembly | 4. O-ring |

4. Remove the axle case support mounting screws, the axle case support and the support shims (Fig. 15).




Figure 15

- | | |
|----------------------|-------------------|
| 1. Axle case | 3. Mounting screw |
| 2. Axle case support | 4. Support shim |

PRELIMINARY – For Toro Distributor and Toro Company use only.

5. Remove the knuckle pin mounting screws and the knuckle pin. Remove the gasket and any remaining gasket material from either mating surface (Fig. 16).

6. While holding the bevel gear case, tap the upper end of the bevel gear shaft out of the upper bearing and upper bevel gear.

7. Pull the bevel gear case from the axle case and remove the upper bevel gear and collar from the gear case.

8. Remove the axle case cover screws, cover and the O-ring from the axle case.

9. Remove the plug and sealing washer from the center of the axle case cover. While holding the axle case cover, lightly tap the lower end of the bevel gear shaft out of the lower bearing and lower bevel gear.

10. Remove and discard bevel gear shaft seal from axle case (Fig. 16).




Figure 16

- | | |
|---------------------|---------------------|
| 1. Knuckle pin | 9. Lower bevel gear |
| 2. Mounting screw | 10. Lower bearing |
| 3. O-ring | 11. Axle case |
| 4. Bevel gear case | 12. Axle case cover |
| 5. Upper bearing | 13. O-ring |
| 6. Bevel gear shaft | 14. Shaft seal |
| 7. Collar | 15. Bushing |
| 8. Upper bevel gear | |

Inspection

1. Measure the knuckle pin O.D. and the axle case support bushing I.D. to determine the bushing to pin clearance (Fig. 17). Replace components as necessary.

BUSHING TO PIN CLEARANCE:
0.002 to 0.016 in. (0.05 to 0.40 mm)

KNUCKLE PIN O.D. (Factory Spec.):
0.982 to 0.983 in. (24.95 to 24.98 mm)

AXLE CASE SUPPORT BUSHING I.D. (Factory Spec.):
0.984 to 0.987 in. (25.00 to 25.08 mm)

2. Inspect all gears, shafts, bearings, cases and covers for damage and wear. Replace components as necessary.




Figure 17

- | | |
|----------------|----------------------|
| 1. Knuckle pin | 2. Axle case support |
|----------------|----------------------|

Installation

1. Coat new shaft seal with grease and install in axle case as shown (Fig. 18).




Figure 18

- | | |
|--------------------|---------------|
| 1. Axle case | 3. Shaft seal |
| 2. Bevel gear case | |

2. Install the lower bevel gear and bevel gear shaft in the axle case cover. Coat a new O-ring with grease and install the axle case cover (Fig. 19). Tighten cover screws from **17 to 20 ft-lb (23 to 27 N-m)**.

3. Slide the bevel gear case over the bevel gear shaft and install the bevel gear and collar. Make sure the bevel gear shaft is completely seated in the upper and lower bearings (Fig. 19).

4. Install the knuckle pin. Use medium strength Loctite thread locker and tighten the knuckle pin mounting screws from **17 to 20 ft-lb (23 to 27 N-m)**.




Figure 19

- | | |
|---------------------|---------------------|
| 1. Axle case cover | 5. Upper bevel gear |
| 2. Lower bevel gear | 6. Collar |
| 3. Bevel gear shaft | 7. Upper bearing |
| 4. Lower bearing | 8. Knuckle pin |

PRELIMINARY – For Toro Distributor and Toro Company use only.

5. Determine necessary quantity of support shims.

A. Lubricate the axle case support bushing with a thin coat of grease and slide axle case support onto knuckle pin.

B. Position support shims that were removed during disassembly between axle case support and axle case. Install mounting screws into axle case. Slowly tighten screws while frequently checking for clearance (vertical endplay) between axle case support and knuckle pin. If binding of components is noted before screws are fully tightened, add additional support shims. Torque screws from **57 to 67 ft-lb (77 to 91 N-m)**.

C. Use dial indicator to measure vertical endplay of axle case (Fig. 20).

AXLE CASE ASSEMBLY ENDPLAY:

0.001 to 0.008 in. (0.02 to 0.20 mm)

D. Adjust endplay by increasing or reducing number of axle case support shims.

NOTE: Axle case support shims are available in 0.004 in. (0.1 mm), 0.008 in. (0.2 mm) and 0.016 in. (0.4 mm) thickness.

6. After correct support shims have been determined, remove mounting screws, apply heavy strength thread-locking compound to screw threads, reinstall screws and torque from **57 to 67 ft-lb (77 to 91 N-m)**.

IMPORTANT: Correct engagement between bevel gears is critical to axle performance and durability.

7. Temporarily install the bevel gear case/axle case assembly on the axle support. Position a dial indicator at the tooth's center. Prevent the axle from turning and measure the upper bevel gear backlash (Fig. 21).

UPPER BEVEL GEAR BACKLASH:

0.004 to 0.016 in. (0.10 to 0.40 mm)

8. Adjust backlash by increasing or reducing axle bearing shim thickness (see Differential Shafts in this section of this manual).

NOTE: Axle bearing shims are available in 0.004 in. (0.1 mm), 0.008 in. (0.2 mm) and 0.020 in. (0.5 mm) thickness.




Figure 20

- | | |
|----------------------|--------------------------|
| 1. Axle case support | 4. Dial indicator |
| 2. Axle case | 5. Knuckle pin |
| 3. Bevel gearcase | 6. Support shim location |




Figure 21

- | | |
|----------------------------|-----------------------|
| 1. Axle support | 4. Dial indicator |
| 2. Upper bevel gear | 5. Axle bearing shims |
| 3. Differential shaft gear | |




Figure 22

- | | |
|------------------------|-----------------------|
| 1. Axle cover assembly | 4. Dial indicator |
| 2. Lower bevel gear | 5. Axle bearing shims |
| 3. Axle gear | |

PRELIMINARY – For Toro Distributor and Toro Company use only.

9. Remove the bevel gear case/axle case assembly from the axle support. Coat a new O-ring with grease and temporarily install the axle cover assembly. Position a dial indicator at the tooth's center. Prevent the axle from turning and measure the lower bevel gear to axle gear backlash (Fig. 22).

LOWER BEVEL GEAR BACKLASH:

0.004 to 0.016 in. (0.10 to 0.40 mm)

10. Adjust backlash by increasing or reducing axle bearing shim thickness (see Axle Shafts in this section of this manual).

NOTE: Axle bearing shims are available in 0.008 in. (0.2 mm), 0.012 in. (0.3 mm) and 0.020 in. (0.5 mm) thickness.

11. Tighten axle cover screws from **17 to 20 ft-lb (23 to 27 N-m)**.

12. Coat a new O-ring with grease and install the bevel gear case/axle case assembly on the axle support. Tighten mounting screws and nuts from **35 to 41 ft-lb (47 to 56 N-m)** (Fig. 13).

Differential Shafts

The following procedures assume the rear axle assembly has been removed from the machine.

Removal

IMPORTANT: Do not interchange right and left differential shaft assemblies.

1. Remove the mounting screws, nuts and lock washers. Remove the bevel gear case/axle case assembly and O-ring from the axle support (Fig. 23).
2. Mark and pull the differential shaft assembly from the axle support.
3. Remove the retaining ring and bevel gear (Fig 24).
4. Drive the differential shaft out of the bearings. Remove the bearings and bearing shims.
5. Inspect all gears, shafts, bearings and cases for damage and wear. Replace components as necessary.

Installation

1. Press bearings onto differential shaft. Place correct combination of bearing shims in axle support and drive differential shaft and bearing assembly into axle support.
2. Install bevel gear and retaining ring.
3. Coat new O-ring with grease. Align differential shaft splines with differential gear assembly and slide differential shaft assembly onto axle support.
4. Install bevel gear case/axle case assembly (see Bevel Gear Case/Axle Case Assembly in this section of this manual).




Figure 23

- | | |
|-----------------|----------------------------------|
| 1. Cap screw | 5. Bevel gear/axle case assembly |
| 2. Lock nut | 6. O-ring |
| 3. Lock washer | 7. Stud |
| 4. Axle support | |




Figure 24

- | | |
|-----------------------|------------------|
| 1. Retaining ring | 4. Bearing |
| 2. Bevel gear | 5. Bearing shims |
| 3. Differential shaft | 6. O-ring |

Axle Shafts

The following procedures assume the rear axle assembly has been removed from the machine.

Removal

1. Remove the axle cover mounting screws. Remove the axle cover from the axle case as an assembly (Fig. 25).
2. Use a bearing puller to remove the bearing and bevel gear as shown (Fig. 26).
3. Remove the shims, spacer and retaining ring. Drive the axle out of the bearing and cover. Remove and discard the axle shaft seal.
4. Inspect all gears, shafts, bearings, spacers and cases for damage and wear. Replace components as necessary.

Installation

1. Coat new axle shaft seal with grease and install in axle cover as shown (Fig. 27).
2. Press the axle cover and bearing assembly onto the axle shaft. Press only on the inner race of the cover bearing (Fig. 27).
3. Install retaining ring, spacer and correct combination of bearing shims. Install bevel gear and bearing.
4. Coat a new O-ring with grease and install the axle cover assembly. Tighten axle cover screws from **17 to 20 ft-lb (23 to 27 N-m)**.




Figure 25

- | | |
|------------------------|-------------------|
| 1. Axle case | 3. Mounting screw |
| 2. Axle cover assembly | 4. O-ring |




Figure 26

- | | |
|---------------|-------------------|
| 1. Bearing | 4. Spacer |
| 2. Bevel gear | 5. Retaining ring |
| 3. Shims | |




Figure 27

- | | |
|--------------------|---------------|
| 1. Axle shaft seal | 3. Bearing |
| 2. Axle cover | 4. Axle shaft |

Input Shaft/Pinion Gear




Figure 28

- | | | |
|-----------------|-----------------------------|-----------------|
| 1. Nut | 7. O-ring | 13. Shim |
| 2. Lockwasher | 8. Seal collar | 14. Screw |
| 3. Stud | 9. Bearing | 15. Gear case |
| 4. Locknut | 10. O-ring | 16. Gasket |
| 5. Stake washer | 11. Input shaft/pinion gear | 17. Cover plate |
| 6. Oil seal | 12. Bearing case | 18. Dowel pin |

The following procedures assume the rear axle assembly has been removed from the machine.

Removal

1. Remove the cover plate, gasket and gear case assembly from the axle assembly. Remove the gasket and any remaining gasket material.
2. Remove the retaining rings and the driven gear from the input shaft/pinion gear.
3. Remove input shaft/pinion gear assembly from the gear case. Remove the shims and bearing case O-rings.
4. Release the stake washer and remove the locknut. Remove and discard the stake washer.
5. Drive the input shaft/pinion gear out from the outer bearing cone and bearing case. Remove and discard the oil seal and O-ring.
6. Inspect all gears, shafts, bearings, spacers and cases for damage and wear. Replace components as necessary.

NOTE: Replacement input shaft/pinion gears are only available in matched ring and pinion sets.

Installation

NOTE: When installing new bearing cones, press only on the inner race of the bearing cone.

1. If the inner bearing cone was removed, press a new bearing cone all the way onto the input shaft/pinion gear.
2. Place the shaft and bearing assembly in the bearing case and install the outer bearing cone.

NOTE: The bearings must be completely seated. There should be no input shaft/pinion gear end play.

3. Coat a new oil seal with grease and install as shown (Fig. 29). The seal should be installed with the garter spring towards the hydraulic motor.
4. Coat new O-ring with grease. Install O-ring in the oil seal collar and install the collar.
5. Install a new stake washer. Install the lock nut finger tight.

PRELIMINARY – For Toro Distributor and Toro Company use only.

6. Set the bearing preload by securing the bearing case in a vise. Thread a M12 x 1.5 hex head cap screw into the splined end of the input shaft/pinion gear and slowly tighten the locknut until 4 to 6 in-lb (0.4 to 0.7 N-m) of force is required to rotate the input shaft/pinion gear in the bearing case.

7. Secure the lock nut with the stake washer.

8. Use a depth gauge to measure the distance from the end face of the input shaft/pinion gear to the mating surface of the bearing case. Subtract the "Design Cone Center Distance" from this distance to determine initial shim thickness (Fig. 30).

DESIGN CONE CENTER DISTANCE

(distance from mating surface of axle support to end face of pinion gear):

1.870 ± 0.002 in. (47.5 ± 0.05 mm)

NOTE: Bearing case shims are available in 0.004 in. (0.1 mm) and 0.008 in. (0.2 mm) thickness.

9. Coat new O-rings with grease and install the bearing case in the gear case. Place shims on the gear case and temporarily install gear case assembly into axle case. Tighten mounting nuts and screws from **35 to 41 ft-lb (47 to 56 N-m)**.

10. Insert a screwdriver through the drain plug hole to hold ring gear and measure the pinion gear to ring gear backlash (Fig. 31).

PINION GEAR TO RING GEAR BACKLASH:

0.004 to 0.016 in. (0.10 to 0.40 mm)

11. Adjust backlash by increasing or reducing gear case shim thickness.

12. Check pinion gear to ring gear engagement (see Pinion Gear to Ring Gear Engagement in this section of this manual).

13. Place the correct combination of shims on the gear case. Tighten mounting nuts and screws from **35 to 41 ft-lb (47 to 56 N-m)**.

14. Install retaining rings and driven gear on input shaft/pinion gear.

15. If the drive gear (on drive motor shaft) was removed, install the retaining rings and drive gear on the motor shaft.

16. Use a new gasket and install the cover plate. Use a new O-ring and install the drive motor.




Figure 29

- 1. Oil seal
- 2. Bearing case
- 3. Seal garter spring




Figure 30

- 1. Input shaft/pinion gear
- 2. Bearing case




Figure 31

- 1. Axle case
- 2. Screwdriver
- 3. Dial indicator
- 4. Input shaft/pinion gear

Differential Gear

The following procedures assume the rear axle assembly has been removed from the machine.

Removal

1. Remove bevel gear case/axle case assemblies (see Bevel Gear Case/Axle Case Assembly in this section of this manual).

IMPORTANT: Do not interchange right and left differential shafts assemblies.

2. Mark and pull the differential shaft assemblies from the axle support.

3. Remove input shaft/pinion gear assembly, shims and O-ring from the axle support (Fig. 32).

4. Remove the axle support case screws. Separate the axle support halves and remove the O-ring.

5. Remove the differential gear assembly, bearings and adjusting shims from the axle case.

6. Drive the spring pin from the differential case with a punch and hammer. Discard the spring pin (Fig. 33).

NOTE: Mark and arrange all components so they can be reassembled in their original position.

7. Remove the differential pinion shaft, pinion gears and pinion washers. Remove the differential side gears and side gear shims. Remove the ring gear only if it will be replaced (Fig. 34).

NOTE: Replacement ring gears are only available in matched ring and pinion sets.




Figure 32

- | | |
|-------------------------|----------------------|
| 1. Gear Case | 5. Case screw |
| 2. Pinion Gear | 6. Differential gear |
| 3. Axle support (left) | 7. O-ring |
| 4. Axle support (right) | |




Figure 33

- | | |
|----------------------|---------------|
| 1. Differential case | 2. Spring pin |
|----------------------|---------------|




Figure 34

- | | |
|------------------------------|----------------------|
| 1. Differential pinion shaft | 5. Side gear shims |
| 2. Pinion gear | 6. Ring gear |
| 3. Pinion washer | 7. Differential case |
| 4. Side gear | |

Inspection

1. Measure the differential side gear O.D. and the differential case I.D. to determine the side gear to case clearance (Fig. 35). Replace components as necessary.

SIDE GEAR TO CASE CLEARANCE:
0.002 to 0.012 in. (0.05 to 0.30 mm)

SIDE GEAR O.D. (Factory Spec.):
1.335 to 1.337 in. (33.91 to 33.95 mm)

DIFFERENTIAL CASE I.D. (Factory Spec.):
1.339 to 1.341 in. (34.00 to 34.06 mm)

2. Measure the differential pinion shaft O.D. and the pinion gear I.D. to determine the pinion shaft to pinion gear clearance (Fig. 36). Replace components as necessary.

PINION SHAFT TO PINION GEAR CLEARANCE:
0.001 to 0.010 in. (0.03 to 0.25 mm)

PINION SHAFT O.D. (Factory Spec.):
0.550 to 0.551 in. (13.97 to 13.10 mm)

PINION GEAR I.D. (Factory Spec.):
0.551 to 0.552 in. (13.10 to 14.02 mm)

3. Inspect all gears, shafts, bearings, cases and covers for damage and wear. Replace components as necessary.




Figure 35

1. Side gear

2. Differential case




Figure 36

1. Pinion shaft

2. Pinion gear

Installation

1. If the ring gear was removed from the differential case, use medium strength Loctite thread locker and tighten the mounting screws from **22 to 25 ft-lb (30 to 34 N-m)**.

2. Apply molybdenum disulfide lubricant (Three Bond 1901 or equivalent) to the splines and bearing surfaces of the differential pinion gears, pinion washers and side gears.

3. Install the side gear shims and side gears in their original location in the differential case.

4. Place the differential pinion gears and pinion washers in their original location in the differential case. Temporarily install the differential pinion shaft.

5. Secure the differential case in a soft jawed vise. Position a dial indicator on a tooth of the differential pinion gear. Press the pinion and side gear against the differential case and measure the pinion gear to side gear backlash (Fig. 37).

PINION GEAR TO SIDE GEAR BACKLASH:
0.004 to 0.016 in. (0.10 to 0.40 mm)

6. Adjust backlash by increasing or reducing side gear shim thickness.

NOTE: Side gear shims are available in 0.043 in. (1.10 mm), 0.047 in. (1.20 mm) and 0.051 in. (1.30 mm) thickness.

7. Apply gear marking compound, such as DyKem® Steel Blue lightly over several gear teeth.

8. While applying a light load to either side gear, rotate either pinion gear until the side gears have made one complete revolution.

9. Ideal tooth contact should cover more than 35% of each tooth surface. The contact area should be in the center of each tooth and extend 1/3 to 1/2 way across each tooth from the toe (small) end (Fig. 38).

10. Adjust side gear shims if necessary to correct tooth contact. Recheck differential pinion gear to side gear backlash if any changes are made.

11. After backlash and tooth contact have been adjusted, align the hole in the differential pinion shaft with the hole in the differential case and install a new spring pin.




Figure 37

- 1. Vise
- 2. Differential gear case
- 3. Dial indicator




Figure 38

12. Install differential gear assembly in right side axle support half.

13. Coat a new o-ring with grease and install left side axle support half. Tighten axle support case screws from **35 to 41 ft-lb (47 to 56 N-m)**.

14. Install input shaft/pinion gear assembly (see Input Shaft/Pinion Gear in this section of this manual).

15. Coat new o-rings with grease, align differential shaft splines with differential gear assembly and slide differential shaft assemblies onto axle support.

16. Install bevel gear case/axle case assemblies (see Bevel Gear Case/Axle Case Assembly in this section of this manual).

Pinion Gear to Ring Gear Engagement (4 Wheel Drive Axle)

The final position of the pinion gear is verified by using the gear contact pattern method as described in the following procedure.

GEAR TOOTH DEFINITIONS (Fig. 39):

Toe – the portion of the tooth surface at the end towards the center.

Heel – the portion of the gear tooth at the outer end.

Top Land – top surface of tooth.

1. Paint the teeth of the ring gear, both drive and coast side, with a gear marking compound, such as DyKem® Steel Blue.

2. Install the input shaft/pinion gear assembly into axle case.

3. While applying a light load to the ring gear, rotate the pinion gear in the direction of forward travel until the ring gear has made one complete revolution.

Ideal tooth contact observed on the ring gear should cover more than 35% of each tooth surface. The contact area should be in the center of each tooth and extend 1/3 to 1/2 way across each tooth from the toe end (Fig. 40).

Adjustments to the gear contact position are made by moving the input shaft/pinion gear (bearing case shims) or by moving the differential gear case (differential bearing shims) (Fig. 41).

NOTE: Bearing case shims are available in 0.004 in. (0.10 mm) and 0.008 in. (0.20 mm) thickness.

NOTE: Differential bearing shims are available in 0.004 in. (0.10 mm), 0.008 in. (0.20 mm) and 0.016 in. (0.40 mm) thickness.

Study the different contact patterns (Figs. 42 and 43) and correct gear engagement as necessary.

NOTE: When making changes, note that two variables are involved (see Gear Pattern Movement Summary in this section of this manual).

Example: If the pinion gear to ring gear backlash is set correctly to specifications and the bearing case shim is changed to adjust tooth contact, it may be necessary to readjust backlash to the correct specification before checking the contact pattern.




Figure 39




Figure 40




Figure 41

- | | |
|----------------------------|-------------------------------|
| 1. Input shaft/pinion gear | 4. Differential bearing shims |
| 2. Bearing case shims | |
| 3. Differential gear case | |

Gear Pattern Movement Summary

Every gear has a characteristic pattern. The illustrations show typical patterns only and explain how patterns shift as gear location is changed.

1. If contact is toward the heel or base of the gear (Fig. 42):

- A. Install thicker or additional bearing case shim(s) to move pinion shaft toward ring gear.
- B. Install thinner or remove differential bearing shim(s) to move ring gear backward.
- C. Repeat until proper tooth contact and pinion gear to ring gear backlash are correct.

2. If contact is toward the toe or tip of the gear (Fig. 43):

- A. Install thinner or remove bearing case shim(s) to move pinion shaft away from ring gear.
- B. Install thicker or additional differential bearing shim(s) to move ring gear forward.
- C. Repeat until proper tooth contact and pinion gear to ring gear backlash are correct.




Figure 42




Figure 43



Chapter 7

Chassis

Table of Contents

SERVICE AND REPAIRS 2

 Steering Tower 2

 Front Deck Lift Arm 4

 Side Deck Lift Arm 6

 Side Deck Rear Arm Assembly 8

 Lift Arm Yoke Joint 12

 Operator Seat 14

 Operator Seat Service 16

 Operator Seat Suspension 18

 Hood 20

Chassis

Service and Repairs

Steering Tower




Figure 1

- | | | |
|--------------------------------|--|--------------------------|
| 1. Hex nut | 15. Lock nut | 29. Cap screw |
| 2. Flat washer | 16. Parking brake switch | 30. Pivot hub |
| 3. Steering wheel | 17. Cotter pin | 31. Flange head screw |
| 4. Foam collar | 18. Brake pawl | 32. Switch bracket |
| 5. Steering seal | 19. Cotter pin | 33. Flange nut |
| 6. External snap ring (2 used) | 20. Lock nut | 34. Cap screw |
| 7. Knob | 21. Nut insert | 35. Steering tower |
| 8. Steering tower cover | 22. Flange head screw | 36. Phillips head screw |
| 9. Steering shaft | 23. Flange bushing | 37. Clevis pin |
| 10. Compression spring | 24. Thrust washer | 38. Steering valve |
| 11. Cap | 25. Temperature gauge | 39. Steering wheel cover |
| 12. Rod assembly | 26. Warning lamp (temp/glow plug) | 40. Front wire harness |
| 13. Extension spring | 27. Warning lamp (charge/oil pressure) | 41. Snap ring location |
| 14. Tilt rod | 28. Steering column | |

PRELIMINARY – For Toro Distributor and Toro Company use only.

Disassembly (Fig. 1)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Disassemble steering tower as needed using Figure 1 as a guide.

Assembly (Fig. 1)

1. Assemble steering tower using Figure 1 as a guide.
 - A. Thrust washer(s) (item 24) on steering column are used as needed to remove end play of steering shaft.
 - B. If steering wheel was removed, torque hex nut that secures steering wheel from **16 to 20 ft-lb (22 to 27 N-m)**.

Front Deck Lift Arm




Figure 2

- | | | |
|--------------------------|-------------------------|---------------------|
| 1. Flange bushing | 14. Lift arm pin | 27. Cotter pin |
| 2. Ball joint | 15. Cotter pin | 28. Washer |
| 3. Lock nut | 16. Upper lift pin | 29. Cap screw |
| 4. Clevis pin | 17. Grease fitting | 30. Lock nut |
| 5. Height-of-cut chain | 18. Lift cylinder | 31. Flat washer |
| 6. U-bolt | 19. Lock nut | 32. Sensing plate |
| 7. Hex nut | 20. Pin | 33. Carriage screw |
| 8. Flat washer | 21. Cap screw | 34. Lock nut |
| 9. Lock nut | 22. Flat washer | 35. Flat washer |
| 10. Lock nut | 23. Lift arm (LH shown) | 36. Sensing switch |
| 11. Grease fitting (45°) | 24. Jam nut | 37. Spacer |
| 12. Grease fitting | 25. Hair pin | 38. Carriage screw |
| 13. Slotted roll pin | 26. Ball joint mount | 39. Slotted hex nut |

PRELIMINARY – For Toro Distributor and Toro Company use only.

Removal (Fig. 2)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Remove front cutting deck (see Front Cutting Unit in Chapter 8 – Cutting Units).



CAUTION

When changing attachments, tires or performing other service, use correct jacks and supports. Make sure machine is parked on a solid, level surface such as a concrete floor. Prior to raising machine, remove any attachments that may interfere with the safe and proper raising of the machine. Always chock or block wheels. Use jack stands to support the raised machine. If the machine is not properly supported by jack stands, the machine may move or fall, which may result in personal injury.

3. Chock rear wheels and jack up front of machine. Support machine on jack stands.
4. Remove front wheel next to lift arm that is being removed.
5. Remove cap screw, washers and lock nut that secure lift cylinder pin to lift arm. Remove pin and separate lift cylinder and lift arm.
6. Remove lock nut that secures lift arm pin. Support lift arm and slide pin from frame and lift arm. Remove lift arm from frame.
7. Remove height-of-cut chain, ball joint mount and ball joint from removed lift arm as required.

Installation (Fig. 2)

1. Position lift arm to frame and insert lift arm pin. Engage roll pin into frame slots and install lock nut on pin. Torque lock nut from **60 to 70 ft-lb (81 to 94 N-m)**.
2. Align lift cylinder with lift arm. Slide pin through lift arm and cylinder end. Secure pin with cap screw, washers and lock nut.
3. Install front wheel assembly.
4. Lower machine to the ground.
5. If height-of-cut chain u-bolt was removed from lift arm, assemble u-bolt so that threaded portion extends **0.870" (22.1 mm)** above mounting plate on lift arm (Fig. 3).

6. If removed, install ball joint to lift arm. Distance from end of lift arm to center of ball joint should be from **2.210" to 2.390" (56.1 to 60.7 mm)** (Fig. 4). Make sure that ball joint is horizontal and that stud is centered in ball joint. Torque ball joint jam nut from **150 to 175 ft-lb (203 to 237 N-m)**.

7. Install ball joint mount to ball joint with slotted hex nut. Torque nut from **90 to 100 ft-lb (123 to 135 N-m)** while aligning cotter pin holes. Install cotter pin.

8. Install front cutting deck (see Front Cutting Unit in Chapter 8 – Cutting Units).

9. Lubricate lift arm grease fittings.

10. After assembly is completed, raise and lower the cutting deck to verify that hydraulic hoses and fittings do not contact anything.

11. Check height-of-cut and deck pitch adjustment.




Figure 3

1. U-bolt

2. Height-of-cut chain




Figure 4

1. Lift arm

2. Ball joint

Chassis

Side Deck Lift Arm




Figure 5

- | | | |
|-------------------------|-----------------------|-----------------------|
| 1. Lift arm (LH shown) | 14. Rubber bumper | 27. Lock nut |
| 2. Shoulder screw | 15. Slotted roll pin | 28. Flat washer |
| 3. Lift cylinder pin | 16. Lock nut | 29. Socket head screw |
| 4. Lift cylinder | 17. Flat washer | 30. Flat washer |
| 5. Thrust washer | 18. Latch (LH shown) | 31. Carriage screw |
| 6. Flange nut | 19. Thrust washer | 32. Flange bushing |
| 7. Pivot hub | 20. Flange head screw | 33. Lock nut |
| 8. Lift arm pivot shaft | 21. Plastic grip | 34. Grease fitting |
| 9. Thrust washer | 22. Cam bracket | 35. Flange bushing |
| 10. Cap screw | 23. Lock washer | 36. Flange bushing |
| 11. Spring pin | 24. Switch spacer | 37. Bushing |
| 12. Cylinder pin | 25. Sensing switch | 38. Grease fitting |
| 13. Rivet | 26. Sensing plate | |

Removal (Fig. 5)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Remove side deck from lift arm (see Side Cutting Unit in Chapter 8 – Cutting Units).
3. Remove side deck rear arm assembly from pivot hub (see Side Deck Rear Arm Assembly in this section).
4. Remove lift cylinder pin that secures lift cylinder to lift arm.
5. Drive out roll pin that retains lift arm pivot shaft. Discard roll pin.
6. Support lift arm and pull lift arm pivot shaft from lift arm and frame. Locate and remove thrust washers during pivot shaft removal.
 - A. If pivot shaft is difficult to remove, fabricate a puller as shown in Figure 6.
 - B. Attach puller to end of pivot shaft with the pictured bolt and flat washer.
 - C. Drive pivot shaft from lift arm and frame with hammer.




Figure 6

7. Remove lift arm from machine.

Installation (Fig. 5)

1. Apply anti-seize lubricant to lift arm pivot shaft.
2. Position lift arm to frame with thrust washers properly placed (Fig. 5). Slide pivot shaft into frame and lift arm until roll pin holes align.
3. Install new roll pin to secure lift arm pivot shaft.
4. If pivot hub was removed from pivot shaft, slide pivot hub on shaft. Apply thread locking compound to cap screw and secure pivot hub with washer and cap screw. Torque cap screw from **77 to 96 ft-lb (105 to 130 N-m)**.
5. Install side deck rear arm assembly (see Side Deck Rear Arm Assembly in this section).
6. Position and install side cutting deck to machine (see Side Cutting Unit in Chapter 8 – Cutting Units).
7. Lubricate lift arm grease fittings after assembly is complete.
8. After assembly is completed, raise and lower the cutting deck to verify that hydraulic hoses and fittings do not contact anything.

Side Deck Rear Arm Assembly




Figure 7

- | | | |
|----------------------------|---------------------------|--------------------|
| 1. Cutting deck (LH shown) | 16. Lock nut | 31. Damper rod end |
| 2. Deck mount (LH shown) | 17. Cap screw | 32. Cap screw |
| 3. Cap screw | 18. Pivot shaft | 33. Link tube |
| 4. Lock nut | 19. Retaining ring | 34. Lock nut |
| 5. Clevis pin | 20. Thrust washer | 35. Flat washer |
| 6. Hair pin | 21. Flange bushing | 36. Bushing |
| 7. Spacer | 22. Rear arm (LH shown) | 37. Damper spring |
| 8. Rod end | 23. Lock nut | 38. Lock nut |
| 9. Jam nut | 24. Lock washer | 39. Carriage screw |
| 10. Cap screw | 25. Lock nut | 40. Grease fitting |
| 11. Straight bushing | 26. Bumper pad | 41. Jam nut |
| 12. Spring shaft | 27. Bumper bracket | 42. Lock nut |
| 13. Flat washer | 28. Cap screw | 43. Jam nut |
| 14. Compression spring | 29. Bell crank (LH shown) | 44. Rod end |
| 15. Plastic bearing | 30. Damper | 45. Plate |

PRELIMINARY – For Toro Distributor and Toro Company use only.

Rear Arm Removal (Fig. 7)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Remove hair pin and clevis pin that connects damper link to cutting deck (Fig. 8).
3. Remove cap screw and lock nut that secures rod end of rear arm to cutting deck. Locate and remove spacer from each side of rod end.
4. Remove lock nut and lock washer that secures rear arm pivot shaft. Slide pivot shaft from hub and rear arm. Remove rear arm assembly from machine.

Rear Arm Disassembly (Fig. 7)

1. Disassemble rear arm assembly using Figure 7 as a guide.

Rear Arm Assembly (Fig. 7)

1. Slide large flat washer, spring, plastic bearing, another large flat washer and small flat washer onto spring shaft. Loosely secure components to shaft with one jam nut.
2. Slide the straight bushing and plate onto other end of spring shaft.
3. While holding flats on end of spring shaft, rotate jam nut (on other end of assembly) until components are snug but spring is not compressed.
4. Insert assembly into rear arm housing.
5. From open end of rear arm housing, insert a 3/4" socket onto spring shaft jam nut. Tighten jam nut fully.
6. Mount plate to rear arm housing with two (2) cap screws and lock nuts. Grasp end of spring shaft. Push inward and pull outward on shaft to determine endplay in assembly.

IMPORTANT: All endplay must be removed from assembly to allow proper operation and ensure long life.

7. Loosen jam nut, 1/2 turn at a time, until all endplay in shaft is removed.
8. Remove two (2) cap screws and nuts securing plate to rear arm housing. Remove spring shaft assembly from housing.
9. Thread remaining jam nut onto end of spring shaft and, while retaining inner jam nut to prevent it from moving, torque outer jam nut from **22 to 28 ft-lb (30 to 37 N-m)** to lock adjustment.

10. Thoroughly pack spring with grease. Install spring shaft assembly into housing and secure plate with four (4) cap screws and lock nuts.

11. Thread rod end with jam nut into end of spring shaft. Do not tighten jam nut at this time.

12. If rod ends (item 31) were removed from damper (item 30), apply thread locking compound to damper shaft threads before installing rod ends. Secure damper to bellcrank and rear arm with cap screws and lock nuts. Torque fasteners from **270 to 330 in-lb (31 to 37 N-m)**.

13. If damper link was disassembled, adjust the length of the link to $5.370" \pm .075"$ ($13.6 \text{ cm} \pm .2 \text{ cm}$) (Fig. 8).

14. If damper springs (item 37) were removed, tighten lock nuts so that bushings (item 36) are free to rotate.




Figure 8

1. Damper link

2. Clevis pin

PRELIMINARY – For Toro Distributor and Toro Company use only.

Rear Arm Installation (Fig. 7)

1. Position rear arm assembly to cutting deck and frame.
2. Slide pivot shaft through rear arm clevis and hub. Secure pivot shaft with lock washer and locknut.
3. Connect damper link to cutting deck with clevis pin and hair pin (Fig. 8).
4. Position spacers on both sides of rod end of rear arm assembly. Secure rod end of rear arm to deck mount with cap screw and lock nut.
5. Lubricate rear arm grease fittings.
6. Align cutting deck to traction unit as follows:
 - A. Make sure the machine is on a level, hard surface.
 - B. Place a square or straight edge against the deck weldment that contains the castor fork assembly (Fig. 9). Do not use the castor fork assembly itself.
 - C. Measure from the inset bead of the rim (not the outer edge of the rim) to the straight edge at two locations as indicated in Figure 9. Rim and paint irregularities make the rim outer edge an unreliable point of measure. These two measurements should be the same within a tolerance of 1/8" (3 mm).
 - D. Rotate spring shaft in rear arm assembly until correct dimension is attained. Shaft should rotate freely inside the assembly. All adjustments must be made with the rod end of the rear arm bolted to the deck.
 - E. Raise and lower the deck and recheck dimensions for correct alignment. Tighten rod end jam nut to **114 ft-lb (155 N-m)** on the rear arm assembly.




Figure 9

NOTE: Due to differences in grass conditions and the counterbalance setting of traction unit, it is advised that grass be cut and appearance checked before formal cutting is started. Refer to Operator's Manual for correcting cutting unit mismatch procedures.

This page is intentionally blank.

Lift Arm Yoke Joint




Figure 10

- | | | |
|---------------------------------|---------------------|-----------------------|
| 1. Side cutting deck (LH shown) | 7. Cap screw | 13. Cotter pin |
| 2. Deck mount (LH shown) | 8. Flat washer | 14. Slotted hex nut |
| 3. Shim | 9. Yoke joint | 15. Flange head screw |
| 4. Base mount | 10. Spacer | 16. Flat washer |
| 5. Plate | 11. Thrust washer | 17. Lock nut |
| 6. Rubber pad | 12. Hardened washer | |

Removal (Fig. 10)

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Remove eight (8) flange head screws, flat washers and lock nuts that secure deck mount to cutting deck.
3. Remove cotter pin from yoke joint shaft. Make sure that deck mount is supported and remove slotted hex nut that secures yoke joint to lift arm. Take hardened washer and thrust washer from yoke joint shaft. Raise lift arm enough to free yoke joint from lift arm. Remove second thrust washer and spacer washer from yoke shaft.
4. Remove cap screws and flat washers that secure base mounts to deck mount.
5. Lift yoke joint and base mounts from deck mount. Remove shims, plate and rubber pad from deck mount.
6. Press yoke joint from base mounts.

Yoke Joint Disassembly

1. Remove snap rings from yoke (Fig. 11).

IMPORTANT: Support yoke when removing and installing cross and bearings to prevent yoke damage.

2. Use a press to remove cross and bearing assembly from yoke.

Yoke Joint Assembly

1. Apply a coating of grease to bearing bores of yoke.
2. Press one bearing partially into yoke.
3. Insert cross into yoke and bearing.
4. Hold cross in alignment and press bearing in until it hits the yoke.
5. Install snap ring to secure installed bearing.
6. Place second bearing into yoke bore and onto cross shaft. Press second bearing into yoke and install snap ring.

Installation (Fig. 10)

1. Press yoke joint to cutting deck base mounts with the angled edge of the mount assembled away from the joint (Fig. 11). The outside of the yoke bearing cup should be flush with the mount surface.
2. Place rubber pad and plate into deck mount. Make sure that tabs on plate and pad align with slots in base mount.
3. Position yoke joint with base mounts to deck mounts (Fig. 11) and install shims. Secure base mounts with cap screws and flat washers. Torque screws from **27 to 33 ft-lb (37 to 44 N-m)**.
4. Place spacer washer (chamfered ID side down) and then thrust washer onto yoke joint shaft. Insert yoke shaft up through lift arm bushings. Place additional thrust washer and then hardened washer on yoke shaft and secure with slotted hex nut. Torque nut from **150 to 180 ft-lb (203 to 244 N-m)** while aligning hole in shaft with slot in nut. Install cotter pin.
5. Secure deck mount to cutting deck with eight (8) flange head screws, flat washers and lock nuts.
6. Grease yoke joint and lift arm bushing after installation on machine.
7. After assembly is completed, raise and lower the cutting deck to verify that hydraulic hoses and fittings do not contact anything.




Figure 11

- | | |
|-------------------------|---------------|
| 1. Joint yoke | 4. Deck mount |
| 2. Base mount | 5. Snap ring |
| 3. Angled edge of mount | |

Operator Seat




Figure 12

- | | | |
|-------------------------|-----------------------------------|-------------------------|
| 1. Seat assembly | 9. R-clamp (2 used) | 17. Screw (2 used) |
| 2. Flat washer (5 used) | 10. Manual tube | 18. Hair pin (2 used) |
| 3. Seat belt | 11. Screw | 19. Clevis pin (2 used) |
| 4. Cap screw (4 used) | 12. Lock nut | 20. Spring |
| 5. Seat platform | 13. Seat belt mount | 21. Latch shaft |
| 6. Flange nut (4 used) | 14. Lock washer (2 used) | 22. Cotter pin (2 used) |
| 7. Seat belt buckle | 15. R-clamp (2 used) | 23. Latch |
| 8. Cap screw (2 used) | 16. Wire harness seat switch lead | 24. Prop rod |

Removal (Fig. 12)

1. Park machine on a level surface, lower cutting decks, stop engine, apply parking brake and remove key from the ignition switch.

2. Remove seat from seat suspension (Fig. 13):

A. Disconnect seat electrical connector from machine wire harness.

B. Remove four (4) Torx head screws that secure seat to seat suspension. Note that the screw near the seat adjustment handle is longer than the other three screws.

C. Lift seat from seat suspension and remove from machine.

NOTE: Most of the seat suspension components can be serviced with the seat suspension base mounted to the frame platform.

3. If necessary, remove seat suspension from seat platform:

A. Tilt seat to gain access to mounting fasteners. Support seat suspension to prevent it from falling.

B. Remove four (4) cap screws and flange nuts that secure seat suspension to seat plate. Note that two (2) r-clamps that retain wire harness are secured with seat suspension fasteners.

C. Lift seat suspension from machine.

Installation (Fig. 12)

1. If removed, install seat suspension to seat platform:

A. Position seat suspension onto seat plate.

B. Secure seat suspension and two (2) wire harness r-clamps to seat platform with four (4) cap screws and flange nuts.

C. Lower seat plate and suspension.

2. Install seat to seat suspension (Fig. 13):

A. Carefully position seat to seat suspension.

B. Secure seat to seat suspension with four (4) Torx head screws. Make sure that longer screw is positioned near the seat adjustment handle.

C. Torque screws **18 ft-lb (25 N-m)**.

3. Connect seat electrical connector to machine wire harness.




Figure 13

- | | |
|------------------------|---------------------------|
| 1. Seat | 3. Screw (M8x12) (3 used) |
| 2. Suspension assembly | 4. Screw (M8x16) |

Operator Seat Service




Figure 14

1. Backrest cushion
2. Seat cushion
3. Armrest cover
4. LH armrest
5. Bushing (2 used)
6. Backrest
7. Plug (2 used)
8. Cable tie (3 used)
9. LH adjustment rail
10. Bumper (2 used)

11. Washer
12. Cap screw (2 used)
13. Seat
14. Nut
15. Spring (2 used)
16. Magnet
17. Seat switch
18. Rivet (4 used)
19. Mounting plate
20. Return spring

21. Torx screw (5 used)
22. RH adjustment rail
23. Rail stop
24. Torx screw
25. Torx screw (3 used)
26. Washer (3 used)
27. Handle
28. Nut
29. Support bracket
30. Cap screw

PRELIMINARY – For Toro Distributor and Toro Company use only.

Disassembly (Fig. 14)

1. Disassemble operator seat as necessary using Figure 14 as a guide.

Assembly (Fig. 14)

1. Assemble operator seat using Figure 14 as a guide.

Operator Seat Suspension




Figure 15

- | | | |
|-------------------------|------------------------------|----------------------------|
| 1. Cover | 14. Washer (2 used) | 27. Clamp (2 used) |
| 2. Cover | 15. Tether | 28. Hose nipple |
| 3. Level control | 16. Rivet (2 used) | 29. Screw |
| 4. Air control valve | 17. Washer (4 used) | 30. Handle |
| 5. Shock absorber | 18. C-clip (4 used) | 31. Bumper |
| 6. Air spring | 19. Pin (2 used) | 32. Nut |
| 7. Air tube assembly | 20. Rivet (2 used) | 33. Plastic plug (23 used) |
| 8. Wire harness | 21. Washer (3 used) | 34. Screw (2 used) |
| 9. Compressor | 22. Screw (2 used) | 35. Roller (2 used) |
| 10. Bellows | 23. Washer | 36. Screw (4 used) |
| 11. Stop | 24. Housing support (4 used) | 37. Base plate |
| 12. Bumper set (2 used) | 25. Spacer (4 used) | 38. Suspension frame |
| 13. Roller (4 used) | 26. Hose nipple | 39. Upper plate |

PRELIMINARY – For Toro Distributor and Toro Company use only.

NOTE: Most of the seat suspension components can be serviced with the seat suspension base mounted to the frame platform. If the air spring assembly (item 6) requires removal, the seat suspension base will have to be removed from the seat platform.

Disassembly (Fig. 15)

1. Remove operator seat from seat suspension (see Operator Seat Removal in this section).
2. If the air spring assembly (item 6) or base plate (item 37) requires removal, remove seat suspension from seat platform (see Operator Seat Removal in this section).
3. Remove seat suspension components as needed using Figure 15 as a guide.

Assembly (Fig. 15)

1. Install all removed seat suspension components using Figure 15 as a guide.
2. Install seat suspension if it was removed from seat platform (see Operator Seat Installation in this section):
3. Install operator seat to seat suspension (see Operator Seat Installation in this section).
4. Make sure that seat electrical connectors are secured to machine wire harness.

Hood




Figure 16

- | | | |
|-----------------------|--------------------------|-------------------------|
| 1. Hood | 11. Clevis pin | 21. Flexible latch draw |
| 2. Latch bracket (RH) | 12. Hood rod | 22. Latch bracket (LH) |
| 3. Screen assembly | 13. Hair pin | 23. Flange head nut |
| 4. Bulb seal | 14. Door handle | 24. Flat washer |
| 5. Bulb seal | 15. Flange head screw | 25. Cap screw |
| 6. Screen seal corner | 16. Oil filter deflector | 26. Cap screw |
| 7. Hair pin | 17. Lock nut | 27. Hex flange screw |
| 8. Flange head screw | 18. Latch | 28. Hood support |
| 9. Screen pivot | 19. Latch plate | 29. R-clamp |
| 10. Hood pivot | 20. Hood latch bracket | 30. Latch keeper |

Removal

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.
2. Remove hood using Figure 16 as a guide.

Installation

1. Install hood using Figure 16 as a guide.
2. Align hood to machine to allow correct operation of hood latch and dust seals:
 - A. Place shim (3/8" to 7/16" thick) on top of frame (both RH and LH sides) near the sides of oil cooler (Fig. 17).
 - B. Close hood so that it rests on shims and fasten the hood latches.
 - C. Loosen hood pivots at frame to adjust vertical placement of pivots. Re-tighten hood pivot fasteners.
 - D. Loosen screen pivots to allow hood latches to pull hood against radiator support. Re-tighten screen pivot fasteners.
3. After hood is assembled to machine, check for the following:
 - A. Check that bulb seals are equally compressed at all contact points with hood.
 - B. Hood should open and close without contacting oil cooler hardware.




Figure 17

- | | |
|-----------------------|-----------------|
| 1. Shim location (LH) | 3. Hood pivot |
| 2. Shim location (RH) | 4. Screen pivot |

This page is intentionally blank.



Cutting Units

Table of Contents

- SPECIFICATIONS 2
- TROUBLESHOOTING 3
 - Factors That Can Affect Quality of Cut 3
- ADJUSTMENTS 4
 - Castor Wheel Tire Pressure 4
 - Blade Stopping Time 4
- SERVICE AND REPAIRS 6
 - Front Cutting Unit 6
 - Side Cutting Unit 8
 - Blade Spindle Service 10
 - Castor Forks and Wheels 12

Specifications



MOUNTING: Cutting decks are supported by lift arms controlled with individual hydraulic lift levers.

CONSTRUCTION: Deck chamber is welded 12 gauge steel construction reinforced with channels and plates.

HEIGHT-OF-CUT RANGE: 1" to 5" (25.4 mm to 127 mm) in 1/2" (12.7 mm) increments. Front deck height-of-cut adjustment is achieved by changing spacers on castor wheels and adjusting length of deck support chains. Side deck adjustment requires adding or removing spacers from the castor forks, re-positioning the castor wheel axles in the castor forks and securing the pivot arms to the correct height-of-cut bracket holes.

DECK DRIVE: Closed loop hydraulic system operates hydraulic motor on each cutting deck. The motor drives one spindle directly with remaining deck spindle(s) driven by B section kevlar v-belt(s). Blade spindles are 1-1/4" (31.7 mm) shafts supported by greaseable, tapered roller bearings.

CUTTING BLADE: Cutting blade dimensions are 21.75" (552 mm) long, 2.5" (64 mm) wide and 0.25" (6.4 mm) thick. Anti-scalp cup installed on each cutting blade. Three (3) blades on front deck and two (2) blades on each side deck.

WIDTH OF CUT: Front deck provides 62" (1575 mm) width of cut. Each side deck has 42" (1067 mm) width of cut. Total width of cut is 132" (3353 mm) with 7" (128 mm) overlap.

DISCHARGE: Clippings are discharged from the rear of the cutting decks. Provided mounting holes allow attachment of optional Guardian Recycler Kit.

SUSPENSION SYSTEM: A fully floating suspension with hydraulic counterbalance. Front deck suspended at rear from lift arms and has two (2) castor wheels, two (2) adjustable skids and two (2) anti-scalp rollers. Each side deck supported by three (3) castor wheels and a spring damper system which connects the fourth deck corner to the traction unit. There is a main lift arm that provides counterbalance to the side decks along with a rear anti-rotation link which also provides bi-directional impact protection. Optional Guardian Recycler Kit includes one anti-scalp roller on each cutting deck.

Troubleshooting

There are a number of factors that can contribute to unsatisfactory quality of cut, some of which may be turf conditions. Turf conditions such as excessive thatch, uneven ground conditions, “sponginess” or attempting to cut off too much grass height may not always be overcome by adjusting the machine.

Remember that the “effective” or actual height-of-cut depends on cutting unit weight, tire pressures, hydraulic counterbalance settings and turf conditions. Effective height-of-cut will be different than the bench set height-of-cut.

Factors That Can Affect Quality of Cut

Factor	Possible Problem/Correction
1. Maximum governed engine speed.	Check maximum governed engine speed. Adjust speed to specifications if necessary.
2. Blade speed.	All deck blades should rotate at the same speed. See items in Troubleshooting Section of Chapter 4 – Hydraulic System.
3. Tire pressure.	Check air pressure of each tire including castor tires. Adjust to pressures specified in Operator's Manual.
4. Blade condition.	Sharpen blades if their cutting edges are dull or nicked. Inspect blade sail for wear or damage. Replace blade if needed.
5. Mower housing condition.	Make sure that cutting chambers are in good condition. Keep underside of deck clean. Debris buildup will reduce cutting performance.
6. Height-of-cut.	Make sure all cutting units are set at the same height-of-cut. Set units as specified in the Operator's Manual.
7. Cutting unit alignment and ground following.	Check lift arms and cutting unit pivot linkages for wear, damage or binding. Also, inspect for bent or damaged pivot shafts.
8. Roller and castor wheel condition.	All rollers and caster wheels should rotate freely. Replace bearings if worn or damaged.
9. Grass conditions.	Mow when grass is dry for best cutting results. Also, remove only 1" (25 mm) or 1/3 of the grass blade when cutting.

Adjustments



CAUTION

Never install or work on the cutting units or lift arms with the engine running. Always stop engine and remove key first.

See Operator's Manual for adjustment procedures for the cutting units on the Groundsmaster 4000-D.

Castor Wheel Tire Pressure

Castor tires on the front and side decks should be inflated to 50 PSI (3.5 bar).

Blade Stopping Time

The blades of the cutting deck are to come to a complete stop in approximately 5 seconds after the cutting deck engagement switch is shut down.

NOTE: Make sure the decks are lowered onto a clean section of turf or hard surface to avoid dust and debris.

To verify this stopping time, have a second person stand back from the deck at least 20 feet and watch the blades on one of the cutting decks. Have the operator shut the cutting decks down and record the time it takes for the blades to come to a complete stop. If this time is greater than 7 seconds, the braking valve on the hydraulic manifold needs adjustment.

This page is intentionally blank.

Service and Repairs



CAUTION

Never install or work on the cutting units or lift arms with the engine running. Always stop engine and remove key first.

Front Cutting Unit




Figure 1

- | | | |
|--------------------------------|-------------------------|------------------------|
| 1. Spider | 9. Ball joint | 17. Clevis pin |
| 2. Mounting shim (if required) | 10. Jam nut | 18. Lock nut |
| 3. Hydraulic deck motor | 11. Lift arm (LH shown) | 19. Front cutting deck |
| 4. Cap screw | 12. Lock nut | 20. Woodruff key |
| 5. Washer | 13. Flat washer | 21. Spider hub |
| 6. Cotter pin | 14. Nut | 22. Tab washer |
| 7. Ball joint mount | 15. U-bolt | 23. Nut |
| 8. Hairpin | 16. Height-of-cut chain | |

Removal (Fig. 1)

1. Position machine on a clean, level surface. Lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.

NOTE: Removal of clevis pin from deck and height-of-cut chain is easier if deck is lifted slightly.

2. Remove hairpin and clevis pin that secure the height-of-cut chain to the rear of the cutting deck (Fig. 2).

3. Remove hydraulic motor from cutting deck (see Cutting Deck Motor Removal in the Service and Repairs Section of Chapter 4 – Hydraulic Systems).

4. Remove cap screws, washers and lock nuts securing ball joint mounts to front deck castor arms (Fig. 4).

5. Slide the cutting unit away from the traction unit.

Installation (Fig. 1)

1. Position machine on a clean, level surface. Lower lift arms, stop engine, engage parking brake and remove key from the ignition switch.

2. Position the front deck to the lift arms.

3. Align ball joint mounts to front deck castor arms and secure with cap screws, washers and lock nuts (Fig. 4).

NOTE: Installation of clevis pin to deck and height-of-cut chain is easier if deck is lifted slightly.

4. Install clevis pin and hairpin that secure the height-of-cut chain to the rear of the cutting deck (Fig. 2).

5. Install hydraulic motor to cutting deck (see Cutting Deck Motor Installation in the Service and Repairs Section of Chapter 4 – Hydraulic Systems).

6. Lubricate grease fittings on cutting deck and lift assembly (see Operator's Manual).




Figure 2

1. Hairpin and clevis pin 2. Height-of-cut chain




Figure 3

1. Flange head screw 2. Hydraulic motor




Figure 4

1. Ball joint mount 3. Castor arm
2. Lift arm

Side Cutting Unit




Figure 5

- | | | |
|---------------------------------|---------------|----------------------|
| 1. Side cutting deck (LH shown) | 5. Lock nut | 8. Jam nut |
| 2. Deck mount (LH shown) | 6. Clevis pin | 9. Rod end |
| 3. Flange head screw | 7. Hair pin | 10. Damper link tube |
| 4. Flat washer | | |

Removal (Fig. 5)

1. Position machine on a clean, level surface. Lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.

2. Remove hydraulic motor from cutting deck (see Cutting Deck Motor Removal in the Service and Repairs Section of Chapter 4 – Hydraulic Systems).

IMPORTANT: Do not change the length of the damper link. The length of the damper link should be $5.370'' \pm .075''$ ($136 \text{ mm} \pm 2 \text{ mm}$) measured between rod end centers.

3. Remove hairpin and clevis pin that secure the damper link to the rear of the cutting deck (Fig. 7).

4. Remove eight flange head screws, flat washers and lock nuts that secure deck mount to cutting deck (Fig. 6).

5. Raise lift arm enough to separate deck mount from cutting deck.

6. Slide the cutting deck away from the traction unit.

Installation (Fig. 5)

1. Position machine on a clean, level surface. Stop engine, engage parking brake and remove key from the ignition switch.

2. Position the side cutting deck to the lift arm.

3. Lower lift arm while aligning deck mount to cutting deck.

4. Install deck mount to cutting deck with eight flange head screws, flat washers and lock nuts (Fig. 6). Tighten fasteners.

IMPORTANT: Do not change the length of the damper link. The length of the damper link should be $5.370'' \pm .075''$ ($136 \text{ mm} \pm 2 \text{ mm}$) measured between rod end centers.

5. Install clevis pin and hairpin that secure the damper link to the rear of the cutting deck (Fig. 7).

6. Install hydraulic motor to cutting deck (see Cutting Deck Motor Installation in the Service and Repairs Section of Chapter 4 – Hydraulic Systems).

7. Lubricate grease fittings on cutting deck and lift assembly.




Figure 6

- 1. Flange head screw
- 2. Hydraulic motor
- 3. Deck mount screw




Figure 7

- 1. Damper link
- 2. Clevis pin

Blade Spindle Service

Disassembly

1. Park machine on a level surface, lower cutting units, stop engine, engage parking brake and remove key from the ignition switch.

2. Remove belt covers from top of cutting deck. Loosen idler pulley to release belt tension. Remove drive belt from spindle to be serviced.

3. If drive spindle is to be serviced, remove hydraulic motor from cutting deck (see Cutting Deck Motor Removal in the Service and Repairs Section of Chapter 4 – Hydraulic Systems).

4. Start the engine and raise the cutting unit. Stop engine and remove key from the ignition switch. Latch or block up the cutting unit so it cannot fall accidentally. Front deck can be tilted for spindle service.

5. Remove cutting blade, anti-scalp cup and bolt from spindle to be serviced.

6. For drive spindle assemblies (Fig. 8), remove flange head screws that secure spindle to deck. Remove spindle housing assembly with motor mount from deck.

7. For driven spindle assemblies, remove flange head screws and lock nuts that secure spindle to deck. Remove spindle housing assembly from the deck.

8. Loosen and remove lock nut from top of spindle shaft. Remove washer, pulley and O-ring from spindle. For drive spindle, remove motor mount.

9. Remove the spindle shaft from the spindle housing which may require the use of an arbor press. The spacer should remain on the spindle shaft as the shaft is being removed.

10. Remove seals from spindle housing.

11. Allow the bearings, inner spacer and spacer ring to drop out of the spindle housing.

12. Using a punch and hammer, drive both of the bearing cups out of the spindle housing. Remove the large outer spacer from the housing.

13. The large snap ring can remain inside the spindle housing. Removal of snap ring is very difficult.




Figure 8

- | | |
|-------------------------|-----------------------|
| 1. Lock nut | 9. Spindle housing |
| 2. Washer | 10. Grease fitting |
| 3. Pulley (drive shown) | 11. Flange head screw |
| 4. Motor mount | 12. Spacer |
| 5. O-ring | 13. Spindle shaft |
| 6. Oil seal | 14. Blade |
| 7. Bearing set | 15. Anti-scalp cup |
| 8. Spacer set (2 piece) | 16. Blade bolt |




Figure 9

- | | |
|--------------------|-----------------|
| 1. Bearing | 4. Inner spacer |
| 2. Spacer ring | 5. Outer spacer |
| 3. Large snap ring | |

Assembly

IMPORTANT: If new bearings are installed into a used spindle housing, it may not be necessary to replace the original large snap ring. If the original snap ring is in good condition with no evidence of damage (e.g. spun bearing), leave the snap ring in the housing and discard the snap ring that comes with the new bearings. If the large snap ring is found to be damaged, replace the snap ring. Replacement bearings are sold only with a matched spacer ring and large snap ring (Fig. 9). These parts cannot be purchased separately.

1. If large snap ring was removed, install snap ring into spindle housing groove. Make sure snap ring is seated in groove.
2. Install large outer spacer into top of spindle housing. The spacer should fit against the snap ring.
3. Using an arbor press, push the bearing cups into the top and bottom of spindle housing. The top bearing cup must contact the spacer previously installed and the bottom bearing cup must contact the snap ring. Make sure that the assembly is correct by supporting the first bearing cup and pressing the second against it (Fig 10).
4. Pack the bearing cones with grease. Apply a film of grease on lips of new oil seals and O-ring.
5. Install lower bearing and seal into bottom of spindle housing. **Note:** The bottom seal must have the lip facing out (down) (Fig. 11).

IMPORTANT: If bearings are being replaced, make sure to use the spacer ring that is included in bearing set (Fig. 9).

6. Slide spacer ring and inner spacer into spindle housing, then install upper bearing and seal into top of housing. **Note:** The upper seal must have the lip facing in (down) and be recessed into the spindle housing 0.095" (2.4 mm) (Fig. 11).
7. Inspect the spindle shaft and spindle spacer to make sure they are free of burrs or nicks that could possibly damage the seals. Lubricate the shaft with grease.
8. Install spindle spacer onto shaft. Carefully slide spindle shaft up through spindle housing. The bottom seal and spindle spacer fit together when the spindle is installed fully.
9. Install greased O-ring onto spindle shaft.
10. For drive spindle, position motor mount to top of spindle assembly.

11. Install pulley (hub down), washer and lock nut to spindle shaft. Tighten lock nut from **130 to 150 ft-lb (176 to 203 N-m)**.

IMPORTANT: Pneumatic grease guns can produce air pockets when filling large cavities and therefore, are not recommended to be used for proper greasing of spindle housings.

12. Attach a hand pump grease gun to grease fitting and fill housing cavity with grease until grease starts to come out of lower seal.
13. Rotate spindle shaft to make sure that it turns freely.
14. Secure drive spindle assembly to deck with flange head screws. Driven spindle assemblies are attached to the deck with flange head screws and flange lock nuts.
15. Install cutting blade, anti-scalp cup and bolt. Tighten blade bolt from **85 to 110 ft-lb (115 to 149 N-m)**.
16. Install drive belt and adjust belt tension (see Operator's Manual).
17. If drive spindle was removed, install hydraulic motor to cutting deck (see Cutting Deck Motor Installation in the Service and Repairs Section of Chapter 4 – Hydraulic Systems). Install belt covers to cutting deck.




Figure 10

- | | |
|--------------------|---------------------|
| 1. Bearing cups | 4. Arbor press |
| 2. Large snap ring | 5. Support |
| 3. Large spacer | 6. Arbor press base |




Figure 11

- | | |
|-----------------------------|----------------------------|
| 1. Bottom seal installation | 2. Upper seal installation |
|-----------------------------|----------------------------|

Castor Forks and Wheels




Figure 12

- | | | |
|----------------------------|-------------------------|-----------------------------|
| 1. Castor arm (front deck) | 11. Retaining ring | 21. Hairpin |
| 2. Flange head screw | 12. Cap washer | 22. Cutting deck (RH shown) |
| 3. Castor fork | 13. Compression spring | 23. Bearing |
| 4. Cap screw | 14. Cap | 24. Inner bearing spacer |
| 5. Lock nut | 15. Clevis pin | 25. Wheel hub |
| 6. Castor spacer | 16. Lock nut | 26. Wheel rim half |
| 7. Thrust washer | 17. Carriage screw | 27. Castor tire |
| 8. Flange lock nut | 18. Castor fork bracket | 28. Wheel rim half |
| 9. Grease fitting | 19. Shim | 29. Plate |
| 10. Flange bushing | 20. Castor bracket | 30. Flange nut |

Disassembly

1. Disassemble castor wheel using Figure 12 as a guide.

Assembly

1. Assemble castor wheel using Figure 12 as a guide.
2. Torque castor wheel lock nut (item 5) from **60 to 80 ft-lb (81 to 108 N-m)**.




Foldout Drawings

Table of Contents


HYDRAULIC SCHEMATIC	3
ELECTRICAL SCHEMATIC	4
Sheet 1	4
Sheet 2	5
WIRE HARNESS DRAWINGS	6
Console Wire Harness	6
Engine Wire Harness	9
Front Wire Harness	11

This page is intentionally blank.



Groundsmaster 4000-D
Hydraulic Schematic

PRELIMINARY – For Toro Distributor and Toro Company use only.




Groundsmaster 4000-D

Electrical Schematic

Sheet 1


All relays and solenoids are shown as de-energized.
All ground wires are black.



Groundsmaster 4000-D
Electrical Schematic
Sheet 2


All relays and solenoids
are shown as de-energized.
All ground wires are black.

PRELIMINARY – For Toro Distributor and Toro Company use only.




Groundsmater 4000-D Console Wire Harness


PRELIMINARY – For Toro Distributor and Toro Company use only.



Groundsmaster 4000-D
Console Wire Harness
Sheet 1


PRELIMINARY – For Toro Distributor and Toro Company use only.






Groundsmaster 4000-D
Engine Wire Harness

PRELIMINARY – For Toro Distributor and Toro Company use only.



PRELIMINARY – For Toro Distributor and Toro Company use only.



Groundsmaster 4000-D
Front Wire Harness

PRELIMINARY – For Toro Distributor and Toro Company use only.

