

WSM

WORKSHOP MANUAL
TRACTOR

L3130 • L3430 • L3830
L4330 • L4630 • L5030

Kubota

TO THE READER

This Workshop Manual has been prepared to provide servicing personnel with information on the mechanism, service and maintenance of KUBOTA Tractor L3130, L3430, L3830, L4330, L4630 and L5030. It is divided into two parts, "Mechanism" and "Servicing" for each section.

■ Mechanism

Information on the construction and function are included. This part should be understood before proceeding with troubleshooting, disassembling and servicing.

Refer to Diesel engine / Tractor Mechanism Workshop Manual (Code No. 97897-01872 / 97897-18200) for the one which has not been described to this workshop manual.

■ Servicing

The heading "General" includes general precautions, check and maintenance and special tools. Other section, there are troubleshooting, servicing specification lists, checking and adjusting, disassembling and assembling, and servicing which cover procedures, precautions, factory specifications and allowable limits.

All information illustrations and specifications contained in this manual are based on the latest product information available at the time of publication.

The right is reserved to make changes in all information at any time without notice.

September 2002

© KUBOTA Corporation 2002



SAFETY FIRST

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you attempt to repair or use this unit.



DANGER : Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING : Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.




CAUTION : Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



IMPORTANT : Indicates that equipment or property damage could result if instructions are not followed.




NOTE : Gives helpful information.



BEFORE SERVICING AND REPAIRING

- Read all instructions and safety instructions in this manual and on your machine safety decals.
- Clean the work area and machine.
- Park the machine on a firm and level ground, and set the parking brake.
- Lower the implement to the ground.
- Stop the engine, and remove the key.
- Disconnect the battery negative cable.
- Hang a "DO NOT OPERATE" tag in operator station.






SAFETY STARTING

- Do not start the engine by shorting across starter terminals or bypassing the safety start switch.
- Do not alter or remove any part of machine safety system.
- Before starting the engine, make sure that all shift levers are in neutral positions or in disengaged positions.
- Never start the engine while standing on ground. Start the engine only from operator's seat.




SAFETY WORKING

- Do not work on the machine while under the influence of alcohol, medication, or other substances or while fatigued.
- Wear close fitting clothing and safety equipment appropriate to the job.
- Use tools appropriate to the work. Makeshift tools, parts, and procedures are not recommended.
- When servicing is performed together by two or more persons, take care to perform all work safely.
- Do not work under the machine that is supported solely by a jack. Always support the machine by safety stands.
- Do not touch the rotating or hot parts while the engine is running.
- Never remove the radiator cap while the engine is running, or immediately after stopping. Otherwise, hot water will spout out from radiator. Only remove radiator cap when cool enough to touch with bare hands. Slowly loosen the cap to first stop to relieve pressure before removing completely.
- Escaping fluid (fuel or hydraulic oil) under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting hydraulic or fuel lines. Tighten all connections before applying pressure.




AVOID FIRES

- Fuel is extremely flammable and explosive under certain conditions. Do not smoke or allow flames or sparks in your working area.
- To avoid sparks from an accidental short circuit, always disconnect the battery negative cable first and connect it last.
- Battery gas can explode. Keep sparks and open flame away from the top of battery, especially when charging the battery.
- Make sure that no fuel has been spilled on the engine.



VENTILATE WORK AREA

- If the engine must be running to do some work, make sure the area is well ventilated. Never run the engine in a closed area. The exhaust gas contains poisonous carbon monoxide.



PREVENT ACID BURNS

- Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, clothing and cause blindness if splashed into eyes. Keep electrolyte away from eyes, hands and clothing. If you spill electrolyte on yourself, flush with water, and get medical attention immediately.



DISPOSE OF FLUIDS PROPERLY

- Do not pour fluids into the ground, down a drain, or into a stream, pond, or lake. Observe relevant environmental protection regulations when disposing of oil, fuel, coolant, electrolyte and other harmful waste.



PREPARE FOR EMERGENCIES

- Keep a first aid kit and fire extinguisher handy at all times.
- Keep emergency numbers for doctors, ambulance service, hospital and fire department near your telephone.

SAFETY DECALS

The following safety decals are installed on the machine.

If a decal becomes damaged, illegible or is not on the machine, replace it. The decal part number is listed in the parts list.

(1) Part No. TA040-4965-2



⚠ DANGER


TO AVOID POSSIBLE INJURY OR DEATH FROM A MACHINE RUNAWAY.

1. Do not start engine by shorting across starter terminals or bypassing the safety start switch. Machine may start in gear and move if normal starting circuitry is bypassed.
2. Start engine only from operator's seat with transmission and PTO OFF. Never start engine while standing on the ground.

(4) Part No. TA040-4956-2
Diesel fuel only. No fire



(2) Part No. TA040-4932-2 [Rigid ROPS Type]



⚠ WARNING

TO AVOID PERSONAL INJURY OR DEATH FROM ROLL-OVER:


1. Kubota recommends the use of a Roll-Over Protective Structures (ROPS) and seat belt in almost all applications.
2. Remove the ROPS only when it substantially interferes with operation or itself presents a safety risk. (Examples include work in orchards and vineyards.) ALWAYS REINSTALL IT BEFORE USING THE TRACTOR IN OTHER APPLICATIONS.
3. Never use just the seat belt or just the ROPS. They must be used together. For further details, consult your Operator's Manual or your local dealer.

(5) Part No. TA040-4934-1

⚠ WARNING

TO AVOID PERSONAL INJURY:
Do not operate rear-PTO driven implements and mid-PTO driven implements at the same time.

(3) Part No. TA040-4959-3



⚠ WARNING

TO AVOID PERSONAL INJURY.

1. Keep PTO shield in place at all times.
2. Do not operate the PTO at speeds faster than the speed recommended by the implement manufacturer.
3. For trailing PTO-driven implements, set drawbar at towing position (see operator's manual).

(6) Part No. TA040-4935-1

⚠ WARNING



TO AVOID PERSONAL INJURY:

1. Attach pulled or towed loads to the drawbar only.
2. Use the 3-point hitch only with equipment designed for 3-point hitch usage.


(7) Part No. 6C140-4746-1

⚠ WARNING


TO AVOID PERSONAL INJURY:
Do not modify or repair a ROPS because welding, grinding, drilling or cutting any portion may weaken the structure.




(1) Part No. TA140-4992-1 [GST Type]

	<p>⚠ WARNING BEFORE DISMOUNTING TRACTOR:</p> <p>1. ALWAYS SET PARKING BRAKE. Leaving transmission in gear with the engine stopped will not prevent tractor from rolling.</p> <p>2. PARK ON LEVEL GROUND WHENEVER POSSIBLE. If parking on a slope, position tractor across the slope.</p> <p>3. LOWER ALL IMPLEMENTS TO THE GROUND. Failure to comply to this warning may allow the wheels to slip, and could cause injury or death.</p> <p>4. LOCK SHUTTLE SHIFT LEVER IN NEUTRAL POSITION AND STOP THE ENGINE.</p>
---	--

(1) Part No. TA140-4933-1 [Manual Transmission Type]

	<p>⚠ WARNING BEFORE DISMOUNTING TRACTOR:</p> <p>1. ALWAYS SET PARKING BRAKE. Leaving transmission in gear with the engine stopped will not prevent tractor from rolling.</p> <p>2. PARK ON LEVEL GROUND WHENEVER POSSIBLE. If parking on a slope, position tractor across the slope.</p> <p>3. LOWER ALL IMPLEMENTS TO THE GROUND. Failure to comply to this warning may allow the wheels to slip, and could cause injury or death.</p> <p>4. LOCK SHUTTLE SHIFT LEVER IN NEUTRAL POSITION AND STOP THE ENGINE.</p>
---	--


(1) Part No. TA240-4933-1 [HST Type]



	<p>⚠ WARNING BEFORE DISMOUNTING TRACTOR:</p> <p>1. ALWAYS SET PARKING BRAKE. Leaving transmission in gear with the engine stopped will not prevent tractor from rolling.</p> <p>2. PARK ON LEVEL GROUND WHENEVER POSSIBLE. If parking on a slope, position tractor across the slope.</p> <p>3. LOWER ALL IMPLEMENTS TO THE GROUND. Failure to comply to this warning may allow the wheels to slip, and could cause injury or death.</p> <p>4. STOP THE ENGINE.</p>
--	---

(2) Part No. 3A111-9554-1 [Foldable ROPS Type]

<p>⚠ WARNING</p> <p>Never modify or repair a ROPS because welding, grinding, drilling or cutting any portion may weaken the structure.</p>
<p>⚠ CAUTION</p> <p>TO AVOID INJURY WHEN RAISING OR FOLDING ROPS:</p> <ul style="list-style-type: none"> • Set parking brake and stop engine. • Remove any obstruction that may prevent raising or folding of the ROPS. • Do not allow any bystanders. • Always perform function from a stable position at the rear of the tractor. • Hold the top of the ROPS securely when raising or folding. • Make sure all pins are installed and locked.

(3) Part No. TA240-9848-1 [Foldable ROPS Type]

	<p>⚠ WARNING</p> <p>TO AVOID INJURY OR DEATH FROM ROLL-OVER:</p> <ul style="list-style-type: none"> • Keep Roll-Over Protective Structures (ROPS) in the upright and locked position. • Fasten SEAT BELT before operating.
	<p>THERE IS NO OPERATOR PROTECTION WHEN THE ROPS IS IN THE FOLDED POSITION.</p> <ul style="list-style-type: none"> • Check the operating area and fold the ROPS only when absolutely necessary. • Do not wear SEAT BELT if ROPS is folded. • Raise and lock ROPS as soon as vertical clearance allows. • Read ROPS related instructions and warnings.



(1) Part No. 35260-3491-4

CAUTION

TO AVOID PERSONAL INJURY:

1. Read and understand the operator's manual before operation.
2. Before starting the engine, make sure that everyone is at a safe distance from the tractor and that the PTO is OFF.
3. Do not allow passengers on the tractor at any time.
4. Before allowing other people to use the tractor, have them read the operator's manual.
5. Check the tightness of all nuts and bolts regularly.
6. Keep all shields in place and stay away from all moving parts.
7. Lock the two brake pedals together before driving on the road.
8. Slow down for turns, or rough roads, or when applying individual brakes.
9. On public roads use SMV emblem and hazard lights, if required by local traffic and safety regulations.
10. Pull only from the drawbar.
11. Before dismantling, lower the implement to the ground, set the parking brake, stop the engine and remove the key.
12. Securely support tractor and implements before working underneath.

(3) Part No. 32751-4958-1

Stay clear of engine fan and fan belt.





(2) Part No. TD060-3012-1

 RECYCLE	 FLAMMABLES	 SHIELD EYES	 KEEP OUT OF THE REACH OF CHILDREN	 CAUTION OF SULFURIC ACID	 READ INSTRUCTION MANUAL CAREFULLY	 EXPLOSIVE	HYDROMETER CK CHARGE BATTERY ○ REPLACE BATTERY DK 0000	
NX110-5MF 12V AMP HR (20HR) 55 RESERVE CAPACITY (MIN) 133 COLD CRANKING AMPS (-18°C) 582	- DUE TO HYDROGEN GAS GENERATED FROM BATTERY, HANDLING WITHOUT CARE CAN CAUSE FIRE AND EXPLOSION - THIS 12V BATTERY IS ONLY FOR STARTING ENGINE. DO NOT APPLY THIS PRODUCT FOR OTHER USES. - CHARGE THIS BATTERY ONLY AT WELL VENTILATED PLACES, AND AVOID SHORTS OR SPARKS. - REFER TO THE INSTRUCTION MANUAL OF VEHICLE OR BATTERY BEFORE USING BOOSTER CABLE. - SULFURIC ACID MAY CAUSE BLINDNESS OR SEVERE BURN. IN CASE EYES, SKIN, CLOTHES OR ANY ARTICLES ARE STAINED WITH ACID, FLUSH OBJECTS IMMEDIATELY WITH WATER. IF ACID BEING SWALLOWED, DRINK PLENTY OF WATER PROMPTLY. IN CASE OF ACCIDENTAL CONTACT, CONSULT A DOCTOR IMMEDIATELY. - BATTERY FILLED WITH ACID (DO NOT TILT OR SPILL) - FLAMMABLE. DO NOT CHARGE NEAR FIRE OR SPARKS - DO NOT CHARGE RAPIDLY - DO NOT DISASSEMBLE THE BATTERY (SEALED TYPE)						80D26R FITTING DATE YEAR: 0 1 2 3 4 5 6 7 8 9 MONTH: 1 2 3 4 5 6 7 8 9 10 11 12	
DANGER EXPLOSIVE GASES Cigarettes, flames or sparks could cause battery to explode. Always shield eyes and face from battery. Do not charge or use booster cables or adjust post connections without proper instruction and training.			POISON CAUSES SEVERE BURNS Contains sulfuric acid. Avoid contact with skin, eyes or clothing. In event of accident flush with water and call a physician immediately.				KEEP OUT OF REACH OF CHILDREN	

(4) Part No. TC030-4958-1

Do not touch hot surface like muffler etc.



(1) Part No. 35260-3491-4

CAUTION

TO AVOID PERSONAL INJURY:

1. Read and understand the operator's manual before operation.
2. Before starting the engine, make sure that everyone is at a safe distance from the tractor and that the PTO is OFF.
3. Do not allow passengers on the tractor at any time.
4. Before allowing other people to use the tractor, have them read the operator's manual.
5. Check the tightness of all nuts and bolts regularly.
6. Keep all shields in place and stay away from all moving parts.
7. Lock the two brake pedals together before driving on the road.
8. Slow down for turns, or rough roads, or when applying individual brakes.
9. On public roads use SMV emblem and hazard lights, if required by local traffic and safety regulations.
10. Pull only from the drawbar.
11. Before dismounting, lower the implement to the ground, set the parking brake, stop the engine and remove the key.
12. Securely support tractor and implements before working underneath.

(2) Part No. TA040-4902-1

(3) Part No. TA240-4933-2

WARNING




TO AVOID INJURY OR DEATH FROM ROLL-OVER:
Always use seat belt when driving.

WARNING



BEFORE DISMOUNTING TRACTOR:

1. **ALWAYS SET PARKING BRAKE.**
Leaving transmission in gear with the engine stopped will not prevent tractor from rolling.
2. **PARK ON LEVEL GROUND WHENEVER POSSIBLE.**
If parking on a slope, position tractor across the slope.
3. **LOWER ALL IMPLEMENTS TO THE GROUND.**
Failure to comply to this warning may allow the wheels to slip, and could cause injury or death.
4. **STOP THE ENGINE.**



CARE OF DANGER, WARNING AND CAUTION LABELS

1. Keep danger, warning and caution labels clean and free from obstructing material.
2. Clean danger, warning and caution labels with soap and water, dry with a soft cloth.
3. Replace damaged or missing danger, warning and caution labels with new labels.
4. If a component with danger, warning or caution label (s) affixed is replaced with new part, make sure new label (s) is (are) attached in the same location (s) as the replaced component.
5. Mount new danger, warning and caution labels by applying on a clean dry surface and pressing any bubbles to outside edge.

SPECIFICATIONS

Model		L3130			
		Manual		GST	HST
		2WD (ROPS)	4WD (ROPS)	4WD (ROPS)	4WD (ROPS)
Engine	Model	D1503-MA-E-GST			D1503-MA-E-HST
	Type	Indirect injection vertical, water-cooled, 4-cycle diesel			
	Number of cylinders	3			
	Total displacement	1.499 L (91.5 cu.in.)			
	Bore and stroke	83 × 92.4 mm (3.3 × 3.6 in.)			
	Net power	23.1 kW (31.0 HP)*			
	PTO power (factory observe)	19.0 kW (25.5 HP)* / 2700 min ⁻¹ (rpm)			17.9 kW (24.0 HP)* / 2700 min ⁻¹ (rpm)
	Maximum torque	102.9 N·m (10.5 kgf·m, 75.9 ft·lbs)			
	Battery capacity	12 V, RC : 123 min, CCA : 490 A			
	Fuel	Diesel fuel No. 1 [below -10 °C (14 °F)], Diesel fuel No. 2-D [above -10 °C (14 °F)]			
Capacities	Fuel tank	40 L (10.6 U.S.gals., 8.8 Imp.gals.)			
	Engine crankcase (with filter)	5.7 L (6.0 U.S.qts., 5.0 Imp.qts.)			
	Engine coolant	6.0 L (6.3 U.S.qts., 5.3 Imp.qts.)			
	Transmission case	42 L (11.1 U.S.gals., 9.2 Imp.gals.)			
Dimensions	Overall length (without 3P)	2915 mm (114.8 in.)			
	Overall width (min. tread)	1520 mm (59.8 in.)			
	Overall height (with ROPS foldable / rigid)	2305 mm (90.7 in.) / 2140 mm (84.3 in.)			
	Wheel base	1810 mm (71.3 in.)	1805 mm (71.1 in.)		
	Min. ground clearance	360 mm (14.2 in.)			
	Tread	Front	1310 mm (51.6 in.) 1410 mm (55.5 in.) 1510 mm (59.4 in.) 1610 mm (63.4 in.)	1155 mm (45.5 in.)	
	Rear	1200 mm (47.2 in.), 1300 mm (51.2 in.), 1385 mm (54.5 in.), 1480 mm (58.3 in.)			
Weight (with ROPS)		1415 kg (3120 lbs)	1460 kg (3220 lbs)	1480 kg (3265 lbs)	1500 kg (3305 lbs)
Travelling system	Standard tire size	Front	6-16		
		Rear	12.4-24		
	Clutch	Dry type single stage			
	Steering	Hydrostatic power steering			
	Transmission	F8, R8 fully synchronized main and shuttle transmission		F12, R8 Glide shift transmission	Hydrostatic transmission (3 speeds)
	Braking system	Wet disk type			
	Min. turning radius (with brake)	2.6 m (8.5 feet)	2.7 m (8.9 feet)		
Hydraulic system	Hydraulic control system	Position control			
	Pump capacity	31.5 L (8.3 U.S.gals., 6.9 Imp.gals.) / min.			
	Three point hitch	SAE Category I			
	Max. lift force	At lift points	1700 kg (3750 lbs)		
		24 in. behind lift points	1200 kg (2650 lbs)		
	System pressure	17.1 to 18.1 MPa (175 to 185 kgf/cm ² , 2491 to 2633 psi)			
PTO	Rear PTO	SAE 1-3/8, 6 splines			
	PTO / Engine speed	540 min ⁻¹ (rpm) / 2550 min ⁻¹ (rpm)			540 min ⁻¹ (rpm) / 2640 min ⁻¹ (rpm)
	Mid-PTO (if equipped)	USA No. 5 (KUBOTA 10-tooth) involute spline			
	PTO / Engine speed	2000 min ⁻¹ (rpm) / 2580 min ⁻¹ (rpm)			2000 min ⁻¹ (rpm) / 2670 min ⁻¹ (rpm)

Note : * Manufacture's estimate

The company reserves the right to change the specifications without notice.

W10281170

Model		L3430					
		Manual		GST		HST	
		4WD (ROPS)		4WD (ROPS)		4WD (CABIN)	
Model		D1703-MA-E-GST		D1703-MA-E-HST			
Type		Indirect injection vertical, water-cooled, 4-cycle diesel					
Number of cylinders		3					
Total displacement		1.647 L (100.5 cu.in.)					
Bore and stroke		87 × 92.4 mm (3.4 × 3.6 in.)					
Net power		25.1 kW (33.6 HP)*					
PTO power (factory observe)		21.3 kW (28.5 HP)* / 2700 min ⁻¹ (rpm)		20.1 kW (27.0 HP)* / 2700 min ⁻¹ (rpm)			
Maximum torque		108.3 N·m (11.05 kgf·m, 79.9 ft·lbs)					
Battery capacity		12 V, RC : 123 min, CCA : 490 A					
Fuel		Diesel fuel No. 1 [below -10 °C (14 °F)], Diesel fuel No. 2-D [above -10 °C (14 °F)]					
Fuel tank		40 L (10.6 U.S.gals., 8.8 Imp.gals.)					
Engine crankcase (with filter)		5.7 L (6.0 U.S.qts., 5.0 Imp.qts.)					
Engine coolant		6.0 L (6.3 U.S.qts., 5.3 Imp.qts.)					
Transmission case		42 L (11.1 U.S.gals., 9.2 Imp.gals.)					
Overall length (without 3P)		2915 mm (114.8 in.)					
Overall width (min. tread)		1520 mm (59.8 in.)					
Overall height (with CABIN or ROPS foldable / rigid)		2305 mm (90.7 in.) / 2140 mm (84.3 in.)		2195 mm (86.4 in.)			
Wheel base		1805 mm (71.1 in.)					
Min. ground clearance		360 mm (14.2 in.)					
Tread		1155 mm (45.5 in.)					
		1200 mm (47.2 in.), 1300 mm (51.2 in.), 1385 mm (54.5 in.), 1480 mm (58.3 in.)					
Weight (with ROPS or CABIN)		1460 kg (3220 lbs)	1480 kg (3265 lbs)	1500 kg (3305 lbs)	1650 kg (3638 lbs)		
Standard tire size		Front		7.2-16			
		Rear		12.4-24			
Clutch		Dry type single stage					
Steering		Hydrostatic power steering					
Transmission		F8, R8 fully synchronized main and shuttle transmission		F12, R8 Glide shift transmission			
Braking system		Wet disk type					
Min. turning radius (with brake)		2.7 m (8.9 feet)					
Hydraulic control system		Position control					
Pump capacity		31.5 L (8.3 U.S.gals., 6.9 Imp.gals.) / min.					
Three point hitch		SAE Category I					
Max. lift force		At lift points		1700 kg (3750 lbs)			
		24 in. behind lift points		1200 kg (2650 lbs)			
System pressure		17.1 to 18.1 MPa (175 to 185 kgf/cm ² , 2491 to 2633 psi)					
Rear PTO		SAE 1-3/8, 6 splines					
PTO / Engine speed		540 min ⁻¹ (rpm) / 2550 min ⁻¹ (rpm)		540 min ⁻¹ (rpm) / 2640 min ⁻¹ (rpm)			
Mid-PTO (if equipped)		USA No. 5 (KUBOTA 10-tooth) involute spline					
PTO / Engine speed		2000 min ⁻¹ (rpm) / 2580 min ⁻¹ (rpm)		2000 min ⁻¹ (rpm) / 2670 min ⁻¹ (rpm)			

Note : * Manufacture's estimate

The company reserves the right to change the specifications without notice.

W10357910

Model		L3830			
		Manual		GST	HST
		2WD (ROPS)	4WD (ROPS)	4WD (ROPS)	4WD (ROPS)
Engine	Model	D1803-MA-E-GST		D1803-MA-E-HST	
	Type	Indirect injection vertical, water-cooled, 4-cycle diesel			
	Number of cylinders	3			
	Total displacement	1.826 L (111.4 cu.in.)			
	Bore and stroke	87 × 102.4 mm (3.4 × 4.0 in.)			
	Net power	27.9 kW (37.4 HP)*			
	PTO power (factory observe)	23.9.0 kW (32.0 HP)* / 2700 min ⁻¹ (rpm)		22.8 kW (30.5 HP)* / 2700 min ⁻¹ (rpm)	
	Maximum torque	120.7 N·m (12.3 kgf·m, 89.0 ft·lbs)			
	Battery capacity	12 V, RC : 133 min, CCA : 582 A			
	Fuel	Diesel fuel No. 1 [below -10 °C (14 °F)], Diesel fuel No. 2-D [above -10 °C (14 °F)]			
Capacities	Fuel tank	40 L (10.6 U.S.gals., 8.8 Imp.gals.)			
	Engine crankcase (with filter)	5.7 L (6.0 U.S.qts., 5.0 Imp.qts.)			
	Engine coolant	7.5 L (7.9 U.S.qts., 6.6 Imp.qts.)			
	Transmission case	43 L (11.4 U.S.gals., 9.5 Imp.gals.)			
Dimensions	Overall length (without 3P)	2985 mm (117.5 in.)			
	Overall width (min. tread)	1690 mm (66.5 in.)			
	Overall height (with ROPS foldable / rigid)	2315 mm (91.1 in.) / 2155 mm (84.8 in.)			
	Wheel base	1845 mm (72.6 in.)	1840 mm (72.4 in.)		
	Min. ground clearance	375 mm (14.8 in.)			
	Tread	Front	1310 mm (51.6 in.) 1410 mm (55.5 in.) 1510 mm (59.4 in.) 1610 mm (63.4 in.)	1155 mm (45.5 in.)	
	Rear	1285 mm (50.6 in.), 1435 mm (56.5 in.), 1530 mm (60.2 in.)			
Weight (with ROPS)		1430 kg (3155 lbs)	1480 kg (3265 lbs)	1495 kg (3295 lbs)	1515 kg (3340 lbs)
Travelling system	Standard tire size	Front	6-16	8.3-16	
		Rear	14.9-24		
	Clutch	Dry type single stage			
	Steering	Hydrostatic power steering			
	Transmission	F8, R8 fully synchronized main and shuttle transmission		F12, R8 Glide shift transmission	Hydrostatic transmission (3 speeds)
	Braking system	Wet disk type			
Min. turning radius (with brake)	2.6 m (8.5 feet)		2.7 m (8.9 feet)		
Hydraulic system	Hydraulic control system	Position control			
	Pump capacity	31.5 L (8.3 U.S.gals., 6.9 Imp.gals.) / min.			
	Three point hitch	SAE Category I			
	Max. lift force	At lift points	1750 kg (3860 lbs)		
		24 in. behind lift points	1250 kg (2760 lbs)		
System pressure	17.1 to 18.1 MPa (175 to 185 kgf/cm ² , 2491 to 2633 psi)				
PTO	Rear PTO	SAE 1-3/8, 6 splines			
	PTO / Engine speed	540 min ⁻¹ (rpm) / 2550 min ⁻¹ (rpm)		540 min ⁻¹ (rpm) / 2640 min ⁻¹ (rpm)	
	Mid-PTO (if equipped)	USA No. 5 (KUBOTA 10-tooth) involute spline			
	PTO / Engine speed	2000 min ⁻¹ (rpm) / 2580 min ⁻¹ (rpm)		2000 min ⁻¹ (rpm) / 2670 min ⁻¹ (rpm)	

Note : * Manufacture's estimate

The company reserves the right to change the specifications without notice.

W10375160

Model		L4330			
		Manual		GST	HST
		4WD (ROPS)	4WD (ROPS)	4WD (ROPS)	4WD (CABIN)
Engine	Model	V2203-MA-E-GST		V2203-MA-E-HST	
	Type	Indirect injection vertical, water-cooled, 4-cycle diesel			
	Number of cylinders	4			
	Total displacement	2.197 L (134.1 cu.in.)			
	Bore and stroke	87 × 92.4 mm (3.4 × 3.6 in.)			
	Net power	30.6 kW (41.0 HP)*			
	PTO power (factory observe)	26.9 kW (36.0 HP)* / 2600 min ⁻¹ (rpm)		25.7 kW (34.5 HP)* / 2600 min ⁻¹ (rpm)	
	Maximum torque	146.2 N·m (14.9 kgf·m, 107.8 ft-lbs)			
	Battery capacity	12 V, RC : 133 min, CCA : 582 A			
	Fuel	Diesel fuel No. 1 [below -10 °C (14 °F)], Diesel fuel No. 2-D [above -10 °C (14 °F)]			
Capacities	Fuel tank	40 L (10.6 U.S.gals., 8.8 Imp.gals.)			
	Engine crankcase (with filter)	8.2 L (8.7 U.S.qts., 7.2 Imp.qts.)			
	Engine coolant	7.5 L (7.9 U.S.qts., 6.6 Imp.qts.)			
	Transmission case	43 L (11.4 U.S.gals., 9.5 Imp.gals.)			
Dimensions	Overall length (without 3P)	3080 mm (121.3 in.)			
	Overall width (min. tread)	1690 mm (66.5 in.)			
	Overall height (with CABIN or ROPS foldable / rigid)	2315 mm (91.1 in.) / 2155 mm (84.8 in.)		2210 mm (87.0 in.)	
	Wheel base	1895 mm (74.6 in.)			
	Min. ground clearance	375 mm (14.8 in.)			
	Tread	Front	1300 mm (51.2 in.)		
	Rear	1285 mm (50.6 in.), 1435 mm (56.5 in.), 1530 mm (60.2 in.)			
Weight (with ROPS or CABIN)		1560 kg (3440 lbs)	1575 kg (3470 lbs)	1600 kg (3525 lbs)	1750 kg (3858 lbs)
Travelling system	Standard tire size	Front	8.3-16		
		Rear	14.9-24		
	Clutch	Dry type single stage			
	Steering	Hydrostatic power steering			
	Transmission	F8, R8 fully synchronized main and shuttle transmission	F12, R8 Glide shift transmission	Hydrostatic transmission (3 speeds)	
	Braking system	Wet disk type			
	Min. turning radius (with brake)	2.7 m (8.9 feet)			
Hydraulic system	Hydraulic control system	Position control			
	Pump capacity	35.6 L (9.4 U.S.gals., 7.8 Imp.gals.) / min.			
	Three point hitch	SAE Category I			
	Max. lift force	At lift points	1750 kg (3860 lbs)		
		24 in. behind lift points	1250 kg (2760 lbs)		
System pressure	18.1 to 19.1 MPa (185 to 195 kgf/cm ² , 2633 to 2775 psi)				
PTO	Rear PTO	SAE 1-3/8, 6 splines			
	PTO / Engine speed	540 min ⁻¹ (rpm) / 2550 min ⁻¹ (rpm)		540 min ⁻¹ (rpm) / 2440 min ⁻¹ (rpm)	
	Mid-PTO (if equipped)	USA No. 5 (KUBOTA 10-tooth) involute spline			
	PTO / Engine speed	2000 min ⁻¹ (rpm) / 2580 min ⁻¹ (rpm)		2000 min ⁻¹ (rpm) / 2470 min ⁻¹ (rpm)	

Note : * Manufacturer's estimate

The company reserves the right to change the specifications without notice.

W10388600

Model		L4630			
		Manual	GST		HST
		4WD (ROPS)	4WD (ROPS)	4WD (CABIN)	4WD (ROPS)
Engine	Model	V2203-MB-E-GST			V2203-MB-E-HST
	Type	Indirect injection vertical, water-cooled, 4-cycle diesel			
	Number of cylinders	4			
	Total displacement	2.197 L (134.1 cu.in.)			
	Bore and stroke	87 × 92.4 mm (3.4 × 3.6 in.)			
	Net power	33.3 kW (44.7 HP)*			
	PTO power (factory observe)	29.5 kW (39.5 HP)* / 2700 min ⁻¹ (rpm)			28.3 kW (38.0 HP)* / 2700 min ⁻¹ (rpm)
	Maximum torque	146.2 N·m (14.9 kgf·m, 107.8 ft-lbs)			
	Battery capacity	12 V, RC : 133 min, CCA : 582 A			
	Fuel	Diesel fuel No. 1 [below -10 °C (14 °F)], Diesel fuel No. 2-D [above -10 °C (14 °F)]			
Capacities	Fuel tank	40 L (10.6 U.S.gals., 8.8 Imp.gals.)			
	Engine crankcase (with filter)	8.2 L (8.7 U.S.qts., 7.2 Imp.qts.)			
	Engine coolant	7.5 L (7.9 U.S.qts., 6.6 Imp.qts.)			
	Transmission case	43 L (11.4 U.S.gals., 9.5 Imp.gals.)			
Dimensions	Overall length (without 3P)	3080 mm (121.3 in.)			
	Overall width (min. tread)	1690 mm (66.5 in.)			
	Overall height (with CABIN or ROPS foldable / rigid)	2315 mm (91.1 in.) / 2155 mm (84.8 in.)		2210 mm (87.0 in.)	2315 mm (91.1 in.) / 2155 mm (84.8 in.)
	Wheel base	1895 mm (74.6 in.)			
	Min. ground clearance	375 mm (14.8 in.)			
	Tread	Front	1300 mm (51.2 in.)		
	Rear	1285 mm (50.6 in.), 1435 mm (56.5 in.), 1530 mm (60.2 in.)			
Weight (with ROPS or CABIN)		1560 kg (3440 lbs)	1575 kg (3470 lbs)	1730 kg (3815 lbs)	1600 kg (3525 lbs)
Travelling system	Standard tire size	Front	8.3-16		
		Rear	14.9-24		
	Clutch	Dry type single stage			
	Steering	Hydrostatic power steering			
	Transmission	F8, R8 fully synchronized main and shuttle transmission	F12, R8 Glide shift transmission		Hydrostatic transmission (3 speeds)
	Braking system	Wet disk type			
	Min. turning radius (with brake)	2.7 m (8.9 feet)			
Hydraulic system	Hydraulic control system	Position control			
	Pump capacity	37.0 L (9.8 U.S.gals., 8.1 Imp.gals.) / min.			
	Three point hitch	SAE Category I			
	Max. lift force	At lift points	1750 kg (3860 lbs)		
		24 in. behind lift points	1250 kg (2760 lbs)		
System pressure	18.1 to 19.1 MPa (185 to 195 kgf/cm ² , 2633 to 2775 psi)				
PTO	Rear PTO	SAE 1-3/8, 6 splines			
	PTO / Engine speed	540 min ⁻¹ (rpm) / 2550 min ⁻¹ (rpm)			540 min ⁻¹ (rpm) / 2640 min ⁻¹ (rpm)
	Mid-PTO (if equipped)	USA No. 5 (KUBOTA 10-tooth) involute spline			
	PTO / Engine speed	2000 min ⁻¹ (rpm) / 2580 min ⁻¹ (rpm)			2000 min ⁻¹ (rpm) / 2670 min ⁻¹ (rpm)

Note : * Manufacturer's estimate

The company reserves the right to change the specifications without notice.

W10400750

Model		L5030		
		GST		HST
		4WD (ROPS)		4WD (ROPS) / 4WD (CABIN)
Model		V2403-MA-E-GST		V2403-MA-E-HST
Type		Indirect injection vertical, water-cooled, 4-cycle diesel		
Number of cylinders		4		
Total displacement		2.434 L (148.5 cu.in.)		
Bore and stroke		87 × 102.4 mm (3.4 × 4.0 in.)		
Net power		37.3 kW (50.0 HP)*		
PTO power (factory observe)		32.8 kW (44.0 HP)* / 2700 min ⁻¹ (rpm)	31.7 kW (42.5 HP)* / 2700 min ⁻¹ (rpm)	
Maximum torque		162.4 N·m (16.6 kgf·m, 119.8 ft-lbs)		
Battery capacity		12 V, RC : 133 min, CCA : 582 A		
Fuel		Diesel fuel No. 1 [below -10 °C (14 °F)], Diesel fuel No. 2-D [above -10 °C (14 °F)]		
Fuel tank		43 L (11.4 U.S.gals., 9.5 Imp.gals.)		
Engine crankcase (with filter)		8.2 L (8.7 U.S.qts., 7.2 Imp.qts.)		
Engine coolant		8.0 L (8.5 U.S.qts., 7.0 Imp.qts.)		
Transmission case		45 L (11.9 U.S.gals., 9.9 Imp.gals.)		
Overall length (without 3P)		3205 mm (126.2 in.)		
Overall width (min. tread)		1710 mm (67.3 in.)		
Overall height (with CABIN or ROPS foldable / rigid)		2355 mm (92.7 in.) / 2190 mm (86.2 in.)		2270 mm (89.4 in.)
Wheel base		1915 mm (75.4 in.)		
Min. ground clearance		405 mm (15.9 in.)		
Tread		1340 mm (52.8 in.)		
		1325 mm (52.2 in.), 1430 mm (56.3 in.)		
Weight (with ROPS or CABIN)		1680 kg (3705 lbs)	1700 kg (3750 lbs)	1855 kg (4090 lbs)
Standard tire size		9.5-16		
		14.9-26		
Clutch		Dry type single stage		
Steering		Hydrostatic power steering		
Transmission		F12, R8 Glide shift transmission	Hydrostatic transmission (3 speeds)	
Braking system		Wet disk type		
Min. turning radius (with brake)		2.8 m (9.2 feet)		
Hydraulic control system		Position control		
Pump capacity		37.0 L (9.8 U.S.gals., 8.1 Imp.gals.) / min.		
Three point hitch		SAE Category I		
Max. lift force		1750 kg (3860 lbs)		
		1350 kg (2980 lbs)		
System pressure		18.1 to 19.1 MPa (185 to 195 kgf/cm ² , 2633 to 2775 psi)		
Rear PTO		SAE 1-3/8, 6 splines		
PTO / Engine speed		540 min ⁻¹ (rpm) / 2550 min ⁻¹ (rpm)	540 min ⁻¹ (rpm) / 2660 min ⁻¹ (rpm)	
Mid-PTO (if equipped)		USA No. 5 (KUBOTA 10-tooth) involute spline		
PTO / Engine speed		2000 min ⁻¹ (rpm) / 2580 min ⁻¹ (rpm)	2000 min ⁻¹ (rpm) / 2690 min ⁻¹ (rpm)	

Note : * Manufacturer's estimate

The company reserves the right to change the specifications without notice.

W10417330

TRAVELLING SPEEDS

[Manual Transmission Type]

Model			L3130 L3430	L3830	L4330	L4630	L5030
Tire size (Rear)			12.4-24	14.9-24	14.9-24	14.9-24	14.9-26
Shuttle shift lever	Range gear shift lever	Main gear shift lever	km/h (mph)	km/h (mph)	km/h (mph)	km/h (mph)	km/h (mph)
Forward (At rated engine rpm)	Low	1	1.6 (1.0)	1.5 (0.9)	1.6 (1.0)	1.5 (0.9)	1.5 (0.9)
		2	2.3 (1.4)	2.1 (1.3)	2.2 (1.4)	2.1 (1.3)	2.2 (1.4)
		3	3.7 (2.3)	3.5 (2.2)	3.6 (2.2)	3.5 (2.2)	3.5 (2.2)
		4	5.4 (3.4)	5.1 (3.2)	5.3 (3.3)	5.1 (3.2)	5.2 (3.2)
	High	1	7.8 (4.8)	7.6 (4.7)	7.7 (4.8)	7.6 (4.7)	7.8 (4.8)
		2	11.1 (6.9)	10.7 (6.6)	10.9 (6.8)	10.7 (6.6)	11.0 (6.8)
		3	18.0 (11.2)	17.4 (10.8)	17.6 (10.8)	17.4 (10.8)	17.9 (10.9)
		4	26.6 (16.5)	25.7 (16.0)	26.0 (16.2)	25.7 (16.0)	26.4 (16.4)
Reverse (At rated engine rpm)	Low	1	1.5 (0.9)	1.4 (0.9)	1.5 (0.9)	1.4 (0.9)	1.5 (0.9)
		2	2.2 (1.4)	2.0 (1.2)	2.1 (1.3)	2.0 (1.2)	2.1 (1.3)
		3	3.5 (2.2)	3.3 (2.1)	3.4 (2.1)	3.3 (2.1)	3.4 (2.1)
		4	5.2 (3.2)	4.9 (3.0)	5.1 (3.2)	4.9 (3.0)	5.0 (3.1)
	High	1	7.5 (4.7)	7.2 (4.5)	7.3 (4.5)	7.2 (4.5)	7.4 (4.6)
		2	10.6 (6.6)	10.2 (6.3)	10.4 (6.5)	10.2 (6.3)	10.4 (6.5)
		3	17.2 (10.7)	16.6 (10.3)	16.8 (10.4)	16.6 (10.3)	17.1 (10.6)
		4	25.4 (15.8)	24.5 (15.2)	24.8 (15.4)	24.5 (15.2)	25.2 (15.7)

The company reserves the right to change the specifications without notice.

W1035065	
Hydraulic system	Transmission
Blading system	Wet disk type
Min turning radius (with gear)	5.8 m (19.2 feet)
Hydraulic control system	Position control
Hydraulic system	SAE Category I
Max lift force	1350 kg (2980 lbs)
System pressure	18.1 to 18.7 MPa (185 to 195 kg/cm ² , 2693 to 2775 psi)
Foot PTO	SAE 1-3/8" B spline
PTO engine speed	540 min ⁻¹ (9000 rpm) / 580 min ⁻¹ (9500 rpm)
PTO engine speed	500 min ⁻¹ (7500 rpm) / 550 min ⁻¹ (8250 rpm)

[GST Type]

Model		L3130 L3430	L3830	L4330	L4630	L5030
Tire size (Rear)		12.4-24	14.9-24	14.9-24	14.9-24	14.9-26
Shuttle shift lever	Main gear shift lever	km/h (mph)	km/h (mph)	km/h (mph)	km/h (mph)	km/h (mph)
Forward (At rated engine rpm)	1	1.6 (1.0)	1.5 (0.9)	1.6 (1.0)	1.5 (0.9)	1.5 (0.9)
	2	2.3 (1.4)	2.1 (1.3)	2.2 (1.4)	2.1 (1.3)	2.2 (1.4)
	3	3.1 (1.9)	2.9 (1.8)	3.0 (1.9)	2.9 (1.8)	2.9 (1.8)
	4	3.7 (2.3)	3.5 (2.2)	3.6 (2.2)	3.5 (2.2)	3.5 (2.2)
	5	4.5 (2.8)	4.2 (2.6)	4.4 (2.7)	4.2 (2.6)	4.3 (2.7)
	6	5.4 (3.4)	5.1 (3.2)	5.3 (3.3)	5.1 (3.2)	5.2 (3.2)
	7	6.5 (4.0)	6.3 (3.9)	6.4 (4.0)	6.3 (3.9)	6.5 (4.0)
	8	7.8 (4.8)	7.6 (4.7)	7.7 (4.8)	7.6 (4.7)	7.8 (4.8)
	9	9.2 (5.7)	8.9 (5.5)	9.0 (5.6)	8.9 (5.5)	9.1 (5.7)
	10	11.1 (6.9)	10.7 (6.6)	10.9 (6.8)	10.7 (6.6)	11.0 (6.8)
	11	18.0 (11.2)	17.4 (10.8)	17.6 (10.8)	17.4 (10.8)	17.9 (10.9)
	12	26.6 (16.5)	25.7 (16.0)	26.0 (16.2)	25.7 (16.0)	26.4 (16.4)
Reverse (At rated engine rpm)	1	1.5 (0.9)	1.4 (0.9)	1.5 (0.9)	1.4 (0.9)	1.5 (0.9)
	2	2.2 (1.4)	2.0 (1.2)	2.1 (1.3)	2.0 (1.2)	2.1 (1.3)
	3	3.5 (2.2)	3.3 (2.1)	3.4 (2.1)	3.3 (2.1)	3.4 (2.1)
	4	5.2 (3.2)	4.9 (3.0)	5.1 (3.2)	4.9 (3.0)	5.0 (3.1)
	5	7.5 (4.7)	7.2 (4.5)	7.3 (4.5)	7.2 (4.5)	7.4 (4.6)
	6	10.6 (6.6)	10.2 (6.3)	10.4 (6.5)	10.2 (6.3)	10.4 (6.5)
	7	17.2 (10.7)	16.6 (10.3)	16.8 (10.4)	16.6 (10.3)	17.1 (10.6)
	8	25.4 (15.8)	24.5 (15.2)	24.8 (15.4)	24.5 (15.2)	25.2 (15.7)

The company reserves the right to change the specifications without notice.

W1032246

[With Creep Speed Model]

Model		L4630 CABIN	
Creep gear shift lever		High	Low
Tire size (Rear)		14.9-24	
Shuttle shift lever	Main gear shift lever	km/h (mph)	km/h (mph)
Forward (At rated engine rpm)	1	1.5 (0.9)	0.17 (0.11)
	2	2.1 (1.3)	0.24 (0.15)
	3	2.9 (1.8)	0.32 (0.20)
	4	3.5 (2.2)	0.39 (0.24)
	5	4.2 (2.6)	0.47 (0.29)
	6	5.1 (3.2)	0.57 (0.35)
	7	6.3 (3.9)	0.71 (0.44)
	8	7.6 (4.8)	0.85 (0.53)
	9	8.9 (5.5)	1.00 (0.62)
	10	10.7 (6.6)	1.20 (0.75)
	11	17.4 (10.8)	1.95 (1.21)
	12	25.7 (16.0)	2.88 (1.79)
Reverse (At rated engine rpm)	1	1.4 (0.9)	0.16 (0.10)
	2	2.0 (1.2)	0.23 (0.14)
	3	3.3 (2.1)	0.37 (0.23)
	4	4.9 (3.0)	0.55 (0.34)
	5	7.2 (4.5)	0.81 (0.50)
	6	10.2 (6.2)	1.15 (0.71)
	7	16.6 (10.3)	1.86 (1.16)
	8	24.5 (15.2)	2.75 (1.71)

The company reserves the right to change the specifications without notice.


W1033852

[HST Type]

Model		L3130 L3430	L3830	L4330	L4630	L5030
Tire size (Rear)		12.4-24	14.9-24	14.9-24	14.9-24	14.9-26
Shuttle shift lever	Main gear shift lever	km/h (mph)	km/h (mph)	km/h (mph)	km/h (mph)	km/h (mph)
Forward (At rated engine rpm)	L	0 to 6.3 (0 to 3.9)	0 to 5.9 (0 to 3.7)	0 to 6.2 (0 to 3.9)	0 to 5.9 (0 to 3.7)	0 to 6.1 (0 to 3.8)
	M	0 to 12.1 (0 to 7.5)	0 to 11.4 (0 to 7.1)	0 to 11.9 (0 to 7.4)	0 to 11.4 (0 to 7.1)	0 to 11.8 (0 to 7.3)
	H	0 to 27.0 (0 to 16.8)	0 to 25.3 (0 to 15.7)	0 to 26.4 (0 to 16.4)	0 to 25.3 (0 to 15.7)	0 to 26.1 (0 to 16.2)
Reverse (At rated engine rpm)	L	0 to 5.7 (0 to 3.5)	0 to 5.3 (0 to 3.3)	0 to 5.5 (0 to 3.4)	0 to 5.3 (0 to 3.3)	0 to 5.5 (0 to 3.4)
	M	0 to 10.9 (0 to 6.8)	0 to 10.3 (0 to 6.4)	0 to 10.7 (0 to 6.6)	0 to 10.3 (0 to 6.4)	0 to 10.6 (0 to 6.6)
	H	0 to 24.3 (0 to 15.1)	0 to 22.8 (0 to 14.2)	0 to 23.8 (0 to 14.8)	0 to 22.8 (0 to 14.2)	0 to 23.5 (0 to 14.6)

The company reserves the right to change the specifications without notice.



W1034865



DIMENSIONS


[L3130, L3430, L3830]

Unit : mm (in.)



3TLABABFP001A

[L4330, L4630, L5030]



G GENERAL

GENERAL







CONTENTS

1.	TRACTOR IDENTIFICATION	G-1
2.	GENERAL PRECAUTIONS	G-2
3.	HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING ..	G-3
	[1] WIRING	G-3
	[2] BATTERY.....	G-5
	[3] FUSE.....	G-5
	[4] CONNECTOR.....	G-5
	[5] HANDLING OF CIRCUIT TESTER.....	G-6
4.	LUBRICANTS, FUEL AND COOLANT	G-7
5.	TIGHTENING TORQUES	G-9
	[1] GENERAL USE SCREWS, BOLTS AND NUTS.....	G-9
6.	MAINTENANCE	G-10
7.	CHECK AND MAINTENANCE	G-12
	[1] DAILY CHECK	G-12
	[2] CHECK POINTS OF INITIAL 50 HOURS.....	G-13
	[3] CHECK POINTS OF EVERY 50 HOURS.....	G-17
	[4] CHECK POINTS OF EVERY 100 HOURS.....	G-20
	[5] CHECK POINTS OF EVERY 200 HOURS.....	G-25
	[6] CHECK POINTS OF EVERY 400 HOURS.....	G-30
	[7] CHECK POINTS OF EVERY 600 HOURS.....	G-30
	[8] CHECK POINTS OF EVERY 800 HOURS.....	G-30
	[9] CHECK POINTS OF EVERY 1500 HOURS.....	G-30
	[10]CHECK POINTS OF EVERY 3000 HOURS.....	G-30
	[11]CHECK POINTS OF EVERY 1 YEAR.....	G-31
	[12]CHECK POINTS OF EVERY 2 YEARS.....	G-31
	[13]OTHERS	G-33
8.	SPECIAL TOOLS.....	G-37
	[1] SPECIAL TOOLS FOR ENGINE	G-37
	[2] SPECIAL TOOLS FOR TRACTOR.....	G-45
9.	TIRES.....	G-53
	[1] TIRE PRESSURE	G-53
	[2] TREADS ADJUSTMENT	G-54
	(1) Front Wheels.....	G-54
	(2) Rear Wheels	G-55
	[3] TIRE LIQUID INJECTION.....	G-57
	[4] IMPLEMENT LIMITATIONS.....	G-60

1. TRACTOR IDENTIFICATION


When contacting your local KUBOTA distributor, always specify engine serial number, tractor serial number and hour meter reading.

- (1) Tractor Identification Plate
- (2) CABIN Identification Plate (CABIN Serial Number)
- (3) Tractor Serial Number
- (4) Engine Serial Number
- (5) Hour Meter (Intelipanel Display)



- (1) Grease
- (2) Force
- (3) Start Engine
- (4) Hold Force
- (5) Rotating Movement

2. GENERAL PRECAUTIONS



- During disassembly, carefully arrange removed parts in a clean area to prevent confusion later. Screws, bolts and nuts should be installed in their original position to prevent reassembly errors.
- When special tools are required, use KUBOTA genuine special tools. Special tools which are not frequently used should be made according to the drawings provided.
- Before disassembling or servicing electrical wires, always disconnect the ground cable from the battery first.
- Remove oil and dirt from parts before measuring.
- Use only KUBOTA genuine parts for parts replacement to maintain machine performance and to assure safety.
- Gaskets and O-rings must be replaced during reassembly. Apply grease to new O-rings or oil seals before assembling. See the figure left side.
- When reassembling external snap rings or internal snap rings, they must be positioned so that sharp edge faces against the direction from which a force is applied. See the figure left side.
- When inserting spring pins, their splits must face the direction from which a force is applied. See the figure left side.
- To prevent damage to the hydraulic system, use only specified fluid or equivalent.

- (1) Grease
- (2) Force
- (3) Sharp Edge
- (4) Axial Force
- (5) Rotating Movement

(A) External Snap Ring
(B) Internal Snap Ring

W10109040

3. HANDLING PRECAUTIONS FOR ELECTRICAL PARTS AND WIRING



3TMABAB0P006A

To ensure safety and prevent damage to the machine and surrounding equipment, heed the following precautions in handling electrical parts and wiring.

■ IMPORTANT


- Check electrical wiring for damage and loosened connection every year. To this end, educate the customer to do his or her own check and at the same time recommend the dealer to perform periodic check for a fee.
- Do not attempt to modify or remodel any electrical parts and wiring.
- When removing the battery cables, disconnect the negative cable first. When installing the battery cables, connect the positive cable first.

(1) Negative Terminal

(2) Positive Terminal

W10111140

[1] WIRING




3TMABAB0P007A

- Securely tighten wiring terminals.

(1) Correct
(Securely Tighten)

(2) Incorrect
(Loosening Leads to Faulty Contact)

W10112160




3TMABAB0P008A

- Do not let wiring contact dangerous part.

(1) Wiring (Correct)
(2) Wiring (Incorrect)

(3) Dangerous Part
(4) Dangerous Part

W10113130



3TMABAB0P009A

- Securely insert grommet.

(1) Grommet


(A) Correct
(B) Incorrect

W10113880




• Securely clamp, being careful not to damage wiring.

- (1) Clamp
 - Wind Clamp Spirally
- (2) Wire Harness
- (3) Clamp
- (4) Welding Dent




W10114580



• Clamp wiring so that there is no twist, unnecessary sag, or excessive tension, except for movable part, where sag be required.


- (1) Wiring
- (2) Clamp
- (A) Correct
- (B) Incorrect

W10115870




• In installing a part, take care not to get wiring caught by it.

- (1) Wiring
- (A) Incorrect




W10116700




• After installing wiring, check protection of terminals and clamped condition of wiring, only connect battery.

- (1) Cover
 - Securely Install Cover




W10117350



W10115870

[2] BATTERY




- Take care not to confuse positive and negative terminal posts.
- When removing battery cables, disconnect negative cable first. When installing battery cables, check for polarity and connect positive cable first.
- Do not install any battery with capacity other than is specified (Ah).
- After connecting cables to battery terminal posts, apply high temperature grease to them and securely install terminal covers on them.
- Do not allow dirt and dust to collect on battery.

! CAUTION

- Take care not to let battery liquid spill on your skin and clothes. If contaminated, wash it off with water immediately.
- Before recharging the battery, remove it from the machine.
- Before recharging, remove cell caps.
- Do recharging in a well-ventilated place where there is no open flame nearby, as hydrogen gas and oxygen are formed.

W10118160

[3] FUSE




- Use fuses with specified capacity. Neither too large or small capacity fuse is acceptable.
- Never use steel or copper wire in place of fuse.
- Do not install working light, radio set, etc. on machine which is not provided with reserve power supply.
- Do not install accessories if fuse capacity of reserve power supply is exceeded.

(1) Fuse

(2) Slow Blow Fuse

W10120920


[4] CONNECTOR



- For connector with lock, push lock to separate.

(A) Push

W10122110




- In separating connectors, do not pull wire harnesses.
- Hold connector bodies to separate.

(A) Correct

(B) Incorrect


W10122720



- Use sandpaper to remove rust from terminals.
- Repair deformed terminal. Make certain there is no terminal being exposed or displaced.

- (1) Exposed Terminal
- (2) Deformed Terminal

- (3) Sandpaper
- (4) Rust




- Make certain that there is no female connector being too open.

- (A) Correct


- (B) Incorrect

W10124300




- Make certain plastic cover is large enough to cover whole connector.


- (1) Cover



[5] HANDLING OF CIRCUIT TESTER



- Use tester correctly following manual provided with tester.
- Check for polarity and range.



4. LUBRICANTS, FUEL AND COOLANT

	Place	Capacity			Lubricants, fuel and coolant	
		L3130	L3430	L3830		
1	Fuel tank	40 L 10.6 U.S.gals. 8.8 Imp.gals.			No. 2-D diesel fuel No. 1-D diesel fuel if temperature is below -10 °C (14 °F)	
2	Cooling system	6.0 L 6.3 U.S.qts. 5.3 Imp.qts.		7.5 L 7.9 U.S.qts. 6.6 Imp.qts.	Fresh clean water with anti-freeze	
3	Engine crankcase (with filter)	5.7 L 6.0 U.S.qts. 5.0 Imp.qts.			Engine oil : API service classification CD, CE or CF Above 25 °C : SAE30, (77 °F) 10W-30 or 10W-40 0 to 25 °C : SAE20, (32 to 77 °F) 10W-30 or 10W-40 Below 0 °C : SAE10W, (32 °F) 10W-30 or 10W-40	
4	Transmission case	42 L 11.1 U.S.gals. 9.2 Imp.gals.		43 L 11.4 U.S.gals. 9.5 Imp.gals.	KUBOTA UDT or SUPER UDT fluid*	
5	Front axle case (4WD)	6.5 L 6.9 U.S.qts. 5.7 Imp.qts.			KUBOTA UDT or SUPER UDT fluid* or SAE80, 90 gear oil	
Greasing						
	Place	No. of greasing point			Capacity	Type of grease
6	Front wheel hub (2WD)	2	—	2	Until grease overflows	Multipurpose type grease
	Knuckle shaft (2WD)	2	—	2		
	Front axle case support	—				
	Front axle support (4WD)	2				
	Top link	1				
	Top link bracket (if equipped)	2 (with draft control)				
	Lift rod	2				
	Lift cylinder	4				
	Battery terminal	2				
	Throttle cable	Oiling				

* KUBOTA original transmission hydraulic fluid.

	Place	Capacity			Lubricants, fuel and coolant	
		L4330	L4630	L5030		
1	Fuel tank	40 L 10.6 U.S.gals. 8.8 Imp.gals.		43 L 11.4 U.S.gals. 9.5 Imp.gals.	No. 2-D diesel fuel No. 1-D diesel fuel if temperature is below -10 °C (14 °F)	
2	Cooling system	7.5 L 7.9 U.S.qts. 6.6 Imp.qts.		8.0 L 8.5 U.S.qts. 7.0 Imp.qts.	Fresh clean water with anti-freeze	
3	Engine crankcase (with filter)		8.2 L 8.7 U.S.qts. 7.2 Imp.qts.		Engine oil : API service classification CD, CE or CF Above 25 °C : SAE30, (77 °F) 10W-30 or 10W-40 0 to 25 °C : SAE20, (32 to 77 °F) 10W-30 or 10W-40 Below 0 °C : SAE10W, (32 °F) 10W-30 or 10W-40	
4	Transmission case	43 L 11.4 U.S.gals. 9.5 Imp.gals.		45 L 11.9 U.S.gals. 9.9 Imp.gals.	KUBOTA UDT or SUPER UDT fluid*	
5	Front axle case (4WD)		9.0 L 9.5 U.S.qts. 7.9 Imp.qts.		KUBOTA UDT or SUPER UDT fluid* or SAE80, 90 gear oil	
Greasing						
	Place	No. of greasing point			Capacity	Type of grease
6	Front wheel hub (2WD)	-			Until grease overflows	Multipurpose type grease
	Knuckle shaft (2WD)	-				
	Front axle case support	2				
	Front axle support (4WD)	2				
	Top link	1	2			
	Top link bracket (if equipped)	2 (with draft control)				
	Lift rod	2				
	Lift cylinder	4				
	Battery terminal	2				
	Throttle cable	Oiling			Moderate amount	Engine oil

* KUBOTA original transmission hydraulic fluid.

5. TIGHTENING TORQUES

Screws, bolts and nuts whose tightening torques are not specified in this Workshop Manual should be tightened according to tables below.

[1] GENERAL USE SCREWS, BOLTS AND NUTS

Indication on top of bolt	4 No-grade or 4T						7 7T						9 9T		
Material of bolt	SS400, S20C						S43C, S48C						SCr435, SCM435		
Material of opponent part	Ordinariness			Aluminum			Ordinariness			Aluminum			Ordinariness		
Diameter	Unit			Unit			Unit			Unit			Unit		
	N·m	kgf·m	ft·lbs	N·m	kgf·m	ft·lbs	N·m	kgf·m	ft·lbs	N·m	kgf·m	ft·lbs	N·m	kgf·m	ft·lbs
M6 (6 mm, 0.24 in.)	7.85	0.80	5.79	7.85	0.80	5.79	9.81	1.00	7.24	7.85	0.80	5.79	12.3	1.25	9.05
	to	to	to	to	to	to	to	to	to	to	to	to	to	to	to
	9.31	0.95	6.87	8.82	0.90	6.50	11.2	1.15	8.31	8.82	0.90	6.50	14.2	1.45	10.4
M8 (8 mm, 0.31 in.)	17.7	1.8	13.1	16.7	1.7	12.3	23.6	2.4	17.4	17.7	1.8	13.1	29.5	3.0	21.7
	to	to	to	to	to	to	to	to	to	to	to	to	to	to	to
	20.5	2.1	15.1	19.6	2.0	14.4	27.4	2.8	20.2	20.5	2.1	15.1	34.3	3.5	25.3
M10 (10 mm, 0.39 in.)	39.3	4.0	29.0	31.4	3.2	23.2	48.1	4.9	35.5	39.3	4.0	29.0	60.9	6.2	44.9
	to	to	to	to	to	to	to	to	to	to	to	to	to	to	to
	45.1	4.6	33.2	34.3	3.5	25.3	55.8	5.7	41.2	44.1	4.5	32.5	70.6	7.2	52.0
M12 (12 mm, 0.47 in.)	62.8	6.4	46.3	-	-	-	77.5	7.9	57.2	62.8	6.4	46.3	103	10.5	76.0
	to	to	to	-	-	-	to	to	to	to	to	to	to	to	to
	72.5	7.4	53.5	-	-	-	90.2	9.2	66.5	72.5	7.4	53.5	117	12.0	86.7
M14 (14 mm, 0.55 in.)	108	11.0	79.6	-	-	-	124	12.6	91.2	-	-	-	167	17.0	123
	to	to	to	-	-	-	to	to	to	-	-	-	to	to	to
	125	12.8	92.5	-	-	-	147	15.0	108	-	-	-	196	20.0	144
M16 (16 mm, 0.63 in.)	167	17.0	123	-	-	-	197	20.0	145	-	-	-	260	26.5	192
	to	to	to	-	-	-	to	to	to	-	-	-	to	to	to
	191	19.5	141	-	-	-	225	23.0	166	-	-	-	304	31.0	224
M18 (18 mm, 0.71 in.)	246	25.0	181	-	-	-	275	28.0	203	-	-	-	344	35.0	254
	to	to	to	-	-	-	to	to	to	-	-	-	to	to	to
	284	29.0	209	-	-	-	318	32.5	235	-	-	-	402	41.0	296
M20 (20 mm, 0.79 in.)	334	34.0	246	-	-	-	368	37.5	272	-	-	-	491	50.0	362
	to	to	to	-	-	-	to	to	to	-	-	-	to	to	to
	392	40.0	289	-	-	-	431	44.0	318	-	-	-	568	58.0	419

W10345420

G-32	Replace	Light bulb
G-31	Replace	Fuse
G-30	Service as required	Clutch housing water drain
G-29	Check	Fuel system bleed
G-28	Check	Clutch
G-27	Check	Clutch pump
G-26	Check	Fuel injection nozzle function
G-25	Adjust	Engine valve clearance
G-24	Adjust	Clutch bearing (2WD form wheel hub)
G-23	Check	Clutch
G-22	Check	Clutch
G-21	Check	Clutch
G-20	Check	Clutch
G-19	Check	Clutch
G-18	Check	Clutch
G-17	Check	Clutch
G-16	Check	Clutch
G-15	Check	Clutch
G-14	Check	Clutch
G-13	Check	Clutch
G-12	Check	Clutch
G-11	Check	Clutch
G-10	Check	Clutch
G-9	Check	Clutch
G-8	Check	Clutch
G-7	Check	Clutch
G-6	Check	Clutch
G-5	Check	Clutch
G-4	Check	Clutch
G-3	Check	Clutch
G-2	Check	Clutch
G-1	Check	Clutch

IMPORTANT

- The jobs indicated by * must be done after the first 50 hours of operation.
- * All cleaners should be cleaned more often in dusty conditions than in normal conditions.
- ** Every year or every 8 times of cleaning.
- *** Replace only if necessary.
- **** Consult your local KUBOTA distributor for this service.
- ***** When the battery is used for less than 100 hours per year, check the battery condition by reading the indication annually.

The above listed items (20 items) are indicated as scheduled or condition related items of KUBOTA in the U.S. EPA non-road emission regulation. As the engine owner, you are responsible for the performance of the scheduled maintenance on the engine according to the above instruction. Please see the Warranty Statement in detail.

6. MAINTENANCE

No.	Item	Period	Service Time Interval										Important	Reference page	
			50	100	200	400	600	800	1500	3000	1 year	2 years			
1	Engine oil	Change	★	☆											G-13
2	Engine oil filter cartridge	Replace	★		☆										G-13
3	Hydraulic oil filter cartridge	Replace	★		☆										G-14
4	Transmission oil filter [HST]	Replace	★		☆										G-14
5	Transmission fluid	Change	★			☆									G-15
6	Front axle case oil	Change	★			☆									G-16
7	Front axle pivot	Adjust						☆							G-30
8	Greasing	—	☆												G-17
9	Engine start system	Check	☆												G-18
10	Wheel bolt torque	Check	☆												G-19
11	Battery condition	Check		☆									*****		G-23
12	Air cleaner element [Double type]	Primary element	Clean	☆									·		G-20
		Secondary element	Replace							☆			**	@	G-20
			Replace							☆					G-31
13	Fuel filter element	Clean		☆										@	G-21
		Replace				☆									G-30
14	Fan belt	Adjust		☆											G-21
15	Clutch	Adjust		☆											G-22
16	Brake	Adjust	★	☆											G-16
17	Radiator hose and clamp	Check			☆										G-25
		Replace									☆				G-31
18	Power steering oil line	Check			☆										G-27
		Replace									☆				G-31
19	Fuel line	Check		☆											G-22
		Replace									☆	***	@		G-31
20	HST oil line [HST]	Check			☆										G-27
		Replace									☆				G-31
21	Toe-in	Adjust			☆										G-26
22	Intake air line	Check			☆										G-27
		Replace									☆	***	@		G-31
23	Greasing (2WD front wheel hub)					☆									G-30
24	Engine valve clearance	Adjust						☆					****		1-S27
25	Fuel injection nozzle injection pressure	Check							☆				****	@	1-S65
26	Injection pump	Check								☆			****	@	1-S64
27	Cooling system	Flush									☆				G-32
28	Coolant	Change									☆				G-33
29	Fuel system	Bleed													G-33
30	Clutch housing water	Drain													G-34
31	Fuse	Replace													G-34
32	Light bulb	Replace													G-35

■ IMPORTANT

- The jobs indicated by ★ must be done after the first 50 hours of operation.
- * : Air cleaner should be cleaned more often in dusty conditions than in normal conditions.
- ** : Every year or every 6 times of cleaning.
- *** : Replace only if necessary.
- **** : Consult your local KUBOTA distributor for this service.
- ***** : When the battery is used for less than 100 hours per year, check the battery condition by reading the indication annually.
- The items listed above (@ marked) are registered as emission related critical parts by KUBOTA in the U.S.EPA nonroad emission regulation. As the engine owner, you are responsible for the performance of the required maintenance on the engine according to the above instruction. Please see the Warranty Statement in detail.

W10357690

(Only the Check Points Different from Those for Tractors with CABIN)

No.	Item	Period	Service Time Interval										Important	Reference page	
			50	100	200	400	600	800	1500	3000	1 year	2 years			
1	Clogging of air conditioner condenser screen	Clean												Daily	-
2	Tension of air conditioner drive belt	Adjust			☆										G-28
3	Clogging of inner air filter	Clean			☆										G-28
4	Clogging of fresh air filter	Clean			☆☆										G-29
5	Clogging of air conditioner condenser	Check			☆										G-29
6	Air conditioner pipes and hoses	Check									☆				G-31
7	CABIN isolation cushion	Check									☆				G-31
8	Lubricating points	Check	Service as required											G-35	
9	Washer liquid	Check												G-35	
10	Amount of refrigerant (gas)	Check												G-36	

W11154790

7. CHECK AND MAINTENANCE

CAUTION

- Be sure to check and service the tractor on a flat place with engine shut off, the parking brake on and chock the wheels.





[1] DAILY CHECK

To prevent trouble from occurring, it is important to know the condition of the tractor. Check the following items before starting.

Checking

- Check areas where previous trouble was experienced.
- Walk around the tractor.
 1. Check the tire pressure, and check for wear and damage.
 2. Check for oil and water leak.
 3. Check the engine oil level.
 4. Check the transmission fluid level.
 5. Check the coolant level.
 6. Check the condition of seat belt and ROPS attaching hardware.
 7. Check and clean the radiator screen and grill.
 8. Check and clean the air condenser screen. (CABIN only)
 9. Check the nuts of tires are tight.
 10. Check the number plate.
 11. Care of danger, warning and caution labels.
 12. Clean around the exhaust manifold and the muffler of the engine.
 - While sitting in the operator's seat.
 1. Check the brake pedals and clutch pedal.
 2. Check the parking brake.
 3. Check the steering wheel.
 - Turning the key switch.
 1. Check the performance of the easy checker lights.
 2. Check the lights, turn signal lights, hazard lights and other light equipment. Clean if necessary.
 3. Check the performance of the meters and gauges.
 - Starting the engine.
 1. Check to see that the lights on the easy checker go off.
 2. Check the color of the exhaust gas.
 3. Check the brakes for proper operation.

[2] CHECK POINTS OF INITIAL 50 HOURS



Changing Engine Oil

⚠ CAUTION

- Before changing oil, be sure to stop the engine.
 - Allow engine to cool down sufficiently, oil can be hot and can burn.
1. Start and warm up the engine for approx. 5 minutes.
 2. Place an oil pan underneath the engine.
 3. To drain the used oil, remove the both drain plugs (1) at the bottom of the engine and drain the oil completely.
 4. Screw in the both drain plugs (1).
 5. Fill new oil up to upper line on the dipstick (2).

■ IMPORTANT

- When using an oil of different manufacture or viscosity from the previous one, remove all of the old oil.
- Never mix two different types of oil.
- Use the proper SAE Engine Oil according to ambient temperatures.
- Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7, 8.)

Engine oil capacity (with filter)	L3130	5.7 L
	L3430	6.0 U.S.qts.
	L3830	5.0 Imp.qts.
	L4330	8.2 L
	L4630	8.7 U.S.qts.
	L5030	7.2 Imp.qts.

- (1) Drain Plug
 - (2) Dipstick
 - (3) Oil Inlet
- (A) L3130, L3430, L4330, L4630, L5030
 - (B) L3830
 - (C) Oil level is acceptable within this range.

W10145330

Replacing Engine Oil Filter Cartridge

⚠ CAUTION






- Be sure to stop the engine before changing oil filter cartridge.
 - Allow engine to cool down sufficiently, oil can be hot and can burn.
1. Remove the oil filter cartridge with the filter wrench.
 2. Apply a slight coat of oil onto the new cartridge gasket.
 3. To install the new cartridge, screw it in by hand. Over tightening may cause deformation of rubber gasket.
 4. After the new cartridge has been replaced, the engine oil normally decrease a little. Thus see that the engine oil does not leak through the seal and be sure to read the oil level on the dipstick. Then, replenish the engine oil up to the specified level.

■ IMPORTANT

- To prevent serious damage to the engine, replacement element must be highly efficient. Use only a KUBOTA genuine filter or its equivalent.

- (1) Engine Oil Filter Cartridge

W10148920



Replacing Hydraulic Oil Filter / Replacing Transmission Oil Filter [HST Type]

CAUTION

- Be sure to stop the engine before changing the oil filter cartridge.
- Allow engine to cool down sufficiently, oil can be hot and can burn.




1. Remove the drain plugs at the bottom of the transmission case drain the oil completely into the oil pan.
2. After draining reinstall the drain plugs.
3. Remove the oil filter.
4. Put a film of clean transmission oil on the rubber seal of the new filter.
5. [Hydraulic oil filter]
Quickly tighten the filter until it contacts the mounting surface, then tighten it by hand an additional 1/2 turn only.
[Transmission oil filter]
Quickly tighten the filter until it contacts the mounting surface, then with a filter wrench, tighten it an additional 1 turn only.
6. After the new filters have been replaced, fill the transmission oil up to the upper notch on the dipstick.
7. After running the engine for a few minutes, stop the engine and check the oil level again, add oil to the prescribed level.
8. Make sure that the transmission fluid does not leak past the seal on the filter.

IMPORTANT

- To prevent serious damage to the hydraulic system, use only a KUBOTA genuine filter.

- | | |
|--|--|
| (1) Drain Plugs | (A) With Mid-PTO Type |
| (2) Hydraulic Oil Filter | (B) Without Mid-PTO Type |
| (3) Transmission Oil Filter [HST Type] | (C) Oil level is acceptable within this range. |
| (4) Dipstick | |
| (5) Oil Inlet | |

W1064569



Changing Transmission Fluid

⚠ CAUTION

- Be sure to stop the engine checking and changing the transmission fluid.
 - Allow engine to cool down sufficiently, oil can be hot and can burn.
1. Place an oil pan under the tractor.
 2. Remove the drain plugs (1) at the bottom of the transmission case.
 3. Drain the transmission fluid.
 4. After draining, screw in the drain plugs.
 5. Fill new oil from filling port after removing the filling plug (2) up to the upper line of the gauge (3).
 6. After running the engine for a few minutes, stop it and check the oil level again, if low, add oil prescribed level.

■ IMPORTANT


- Use only multi-grade transmission oil. Use of other oils may damage the transmission or hydraulic system. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7, 8.)
- Never work the tractor immediately after changing the transmission oil. Keeping the engine at medium speed for a few minutes to prevents damage to the transmission.
- Do not mix different brands oil together.

Transmission fluid capacity	L3130, L3430	42 L 11.1 U.S.gals. 9.2 Imp.gals.
	L3830, L4330, L4630	43 L 11.4 U.S.gals. 9.5 Imp.gals.
	L5030	45 L 11.9 U.S.gals. 9.9 Imp.gals.

- (1) Drain Plug
- (2) Filling Plug
- (3) Dipstick

- (A) With Mid-PTO Type
- (B) Without Mid-PTO Type
- (C) Oil level is acceptable within this range.

W1068655



Changing Front Axle Case Oil [4WD Type]


CAUTION

- Be sure to stop the engine before changing the front axle case oil.
 - Allow engine to cool down sufficiently, oil can be hot and can burn.
1. Remove the right and left drain plugs (3) and filling plug (2) at the front axle case and drain the oil completely.
 2. After draining, reinstall the drain plugs (3).
 3. Remove the right and left check plugs (1).
 4. Fill new oil from filling port with specified amount of oil. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7, 8.)
 5. Reinstall the filling plug (2) and check plug (1).

Front axle case oil capacity	L3130	6.5 L
	L3430 L3830	6.9 U.S.qts. 5.7 Imp.qts.
	L4330	9.0 L
	L4630	9.5 U.S.qts.
	L5030	7.9 Imp.qts.

- (1) Check Plug (3) Drain Plug
(2) Filling Plug

W10300640



Adjusting Brake Pedal Free Travel

CAUTION






- Stop the engine and chock the wheels before checking brake pedal.
1. Release the parking brake.
 2. Slightly depress the brake pedals and measure free travel (L) at top of pedal stroke.
 3. If the measurement is not within the factory specifications, loosen the lock nut (1) and turn the turnbuckle (2) to adjust the rod length within acceptable limits.
 4. Retighten the lock nut (1) securely. Keep the free travel in the right and left brake pedals equal.

Brake pedal free travel "L"	Factory spec.	15 to 20 mm 0.59 to 0.79 in.
-----------------------------	---------------	---------------------------------

- (1) Lock Nut (2) Turnbuckle L : Free Travel

W10293350

[3] CHECK POINTS OF EVERY 50 HOURS




Greasing

1. Apply a grease to the following position as figures.

NOTE

- Apply a small amount of multipurpose grease to the following points every 50 hours.
If you operated the machine in extremely wet and muddy conditions, lubricate grease fittings more often.
- When apply a grease to the front axle support, remove the breather plug and apply a grease until grease overflows from breather plug. After greasing reinstall the plug.




- | | |
|--|--------------------------------------|
| (1) Grease Fitting (Knuckle Shaft RH, LH) | (6) Grease Fitting (Top Link) |
| (2) Grease Fitting (Front Wheel Case Support RH, LH) | (7) Grease Fitting (Lifting Rod RH) |
| (3) Grease Fitting (Front Axle Support) | (8) Grease Fitting (Toplink Bracket) |
| (4) Breather Plug | (9) Battery Terminal |
| (5) Grease Fitting (Lift Cylinder) | |

[A] 2WD Type

[B] L4330, L4630, L5030

W10308650



Oiling

⚠ CAUTION

- Be sure to stop the engine and remove the key before oiling.

(1) Hand Throttle Cable

(2) Foot Throttle Cable
(GST/Manual Transmission Type)

W1072984

Checking Engine Start System (GST/Manual Transmission Type)

⚠ CAUTION

- Do not allow anyone near the tractor while testing.
- If the tractor does not pass the test, do not operate the tractor.

■ Preparation before testing.

1. Place all control levers in the "NEUTRAL" position.
2. Set the parking brake and stop the engine.

■ Test 1 : Switch for the shuttle shift lever.

1. Sit on operator's seat.
2. Shift the shuttle shift lever to the forward or reverse position.
3. Depress the clutch pedal fully.
4. Disengage the PTO clutch control lever.
5. Turn the key to "START" position.
6. The engine must not crank.

■ Test 2 : Switch for the PTO clutch control lever.

1. Sit on operator's seat.
2. Engage the PTO clutch control lever.
3. Depress the clutch pedal fully.
4. Shift the range gear shift lever to the neutral position.
5. Turn the key to "START" position.
6. The engine must not crank.

■ If it cranks at the test 1 or 2, adjust or replace the required safety switch.

■ Test 3 : Switch for the operator's seat.


1. Sit on operator's seat.
2. Start the engine.
3. Engage the PTO clutch control lever.
4. Stand up. (Do not get off the machine.)
5. The engine must shut off after approximately 1 second.

■ If it does not stop, adjust or replace the required safety switch.

(1) Shuttle Shift Lever
(2) Clutch Pedal

(3) PTO Clutch Control Lever

W10312010



Checking Engine Start System (HST Type)

1. Place all control levers in the "NEUTRAL" position.
2. Set the parking brake and stop the engine.

■ Test 1 : Switch for the speed control lever.

1. Sit on operator's seat.
2. Depress the speed control pedal to the desired direction.
3. Depress the clutch pedal fully.
4. Disengage the PTO clutch control lever.
5. Turn the key to "START" position.
6. The engine must not crank.

■ Test 2 : Switch for the PTO clutch control lever.

1. Sit on operator's seat.
2. Engage the PTO clutch control lever.
3. Depress the clutch pedal fully.
4. Place the speed control pedal to the neutral position.
5. Turn the key to "START" position.
6. The engine must not crank.

■ Test 3 : Switch for the clutch pedal.

1. Sit on operator's seat.
2. Disengage the PTO clutch control lever.
3. Place the speed control pedal to the neutral position.
4. Release the clutch pedal.
5. Turn the key to "START" position.
6. The engine must not crank.

■ If it cranks at the test 1, 2 or 3, adjust or replace the required safety switch.


■ Test 4 : Switch for the operator's seat.

1. Sit on operator's seat.
2. Start the engine.
3. Engage the PTO clutch control lever.
4. Stand up. (Do not get off the machine.)
5. The engine must shut off after approximately 1 second.

■ If it does not stop, adjust or replace the required safety switch.

- (1) Speed Control Pedal
- (2) Clutch Pedal
- (3) PTO Clutch Control Lever

W10739440



Checking Wheel Mounting Screws and Nuts Tightening Torque

⚠ CAUTION

• **Never operate tractor with a loose rim, wheel, or axle.**

1. Check wheel screws and nuts regularly especially when new. If there are loosened, tighten as follows.

Tightening torque	Front wheel mounting nuts	137 N·m 14 kgf·m 100 ft-lbs
	Rear wheel mounting nuts	215 N·m 22 kgf·m 166 ft-lbs

- (1) Front Wheel Mounting Nut
- (2) Rear Wheel Mounting Nut

W1030725

[4] CHECK POINTS OF EVERY 100 HOURS

Changing Engine Oil


1. See page G-13.

W10320350

Adjusting Brake Pedal

1. See page G-16.

W1075566



Cleaning Air Cleaner Primary Element

1. Remove the air cleaner cover and primary element.
2. Clean the primary element :
 - When dry dust adheres to the element, blow compressed air from the inside turning the element. Pressure of compressed air must be under 490 kPa (5 kgf/cm², 71 psi).
 - When carbon or oil adheres to the element, soak the element in detergent for 15 minutes then wash it several times in water, rinse with clean water and dry it naturally. After element is fully dried, inspect inside of the element with a light and check if it is damaged or not.
3. Replace air cleaner primary element :
Once yearly or after every six times of cleaning, whichever comes first.

■ NOTE

- Check to see if the evacuator valve is blocked with dust.

■ IMPORTANT

- The air cleaner uses a dry element, never apply oil.
- Do not run the engine with filter element removed.
- Be sure to refit the cover with the arrow ↑ (on the rear of cover) upright. If the cover is improperly fitted, evacuator valve will not function and dust will adhere to the element.
- Do not touch the secondary element except in cases where replacing is required.


See "Replacing Air Cleaner Secondary Element" in Every 1 Year section. (See page G-31.)

■ Evacuator Valve

Open the evacuator valve (4) once a week under ordinary conditions or daily when used in a dusty place to get rid of large particles of dust and dirt.


- (1) Secondary (Safety) Element
- (2) Primary Element

- (3) Cover
- (4) Evacuator Valve



W1076669

Tightening torque	
Front wheel mounting nut	177 N·m 14 kgf·m 100 ft·lbf
Rear wheel mounting nut	218 N·m 18 kgf·m 138 ft·lbf




Cleaning Fuel Filter

This job should not be done in the field, but in a clean place.

1. Close the fuel filter cock (1).
2. Unscrew the screw ring and remove the fuel filter bowl (2), and rinse the inside with kerosene.
3. Take out the filter element (4) and dip it in the kerosene to rinse.
4. After cleaning, reassemble the fuel filter, keeping out dust and dirt.
5. Bleed the fuel system. (See page G-33.)


■ IMPORTANT

- If dust and dirt enters the fuel system the fuel pump and injection nozzles are subject to premature wear. To prevent this, be sure to clean the fuel filter and element bowl periodically.



- | | |
|----------------------|--------------------|
| (1) Fuel Cock | (4) Filter Element |
| (2) Fuel Filter Bowl | (5) Spring |
| (3) O-ring | (6) Screw Ring |
- A : Close

W1078193



Adjusting Fan Belt Tension

⚠ CAUTION


- Be sure to stop the engine before checking fan belt tension.
1. Stop the engine and remove the key.
 2. Apply moderate thumb pressure to belt between pulleys.
 3. If tension is incorrect, loosen the alternator mounting bolts and using a lever placed between the alternator and the engine block, pull the alternator out until the deflection of the belt falls within the factory specifications.
 4. Replace fan belt if it is damaged.

Fan belt tension	Factory spec.	A deflection of between 7 to 9 mm (0.28 to 0.34 in.) when the belt is pressed in the middle of the span.
------------------	---------------	--

(1) Alternator Mounting Bolt

A : Check the belt tension
B : To Tighten

W10326270



Checking Fuel Line

CAUTION

- Stop the engine when attempting the check and change prescribed below.
- Remember to check the fuel line periodically. The fuel line is subject to wear and aging, fuel may leak out onto the running engine, causing a fire.

1. Check to see that all line and hose clamp are tight and not damaged.
2. If hoses and clamps are found worn or damaged, replace or repair them at once.
3. The fuel line is made of rubber and ages regardless of period of service. Replace the fuel pipe together with the clamp every two years and securely tighten.
4. However if the fuel pipe and clamp are found damaged or deteriorated earlier than two years, then change or remedy.
5. After the fuel line and clamp have been changed, bleed the fuel system.

IMPORTANT

- When the fuel line is disconnected for change, close both ends of the fuel line with a piece of clean cloth or paper to prevent dust and dirt from entering. Entrance of dust and dirt causes malfunction of the fuel injection pump. In addition, particular care must be taken not to admit dust and dirt into the fuel pump.

(1) Fuel Hose

(2) Clamp


W10342570

Adjusting Clutch Pedal Free Travel

CAUTION

- When checking, park the tractor on flat ground, apply the parking brake, stop the engine and remove the key.

1. Slightly depress the clutch pedal and measure free travel "L" at top of clutch pedal.
2. If the measurement is not within the factory specifications, loosen the lock nut (2), remove the clevis pin (3) adjust the length of rod (1) within acceptable limits.
3. Retighten the lock nut (2) and split the cotter pin (4).



Clutch pedal free travel on top of clutch pedal "L"	Factory spec.	20 to 30 mm 0.78 to 1.18 in.
---	---------------	---------------------------------

(1) Clutch pedal Rod


(4) Cotter Pin

(2) Lock Nut

(3) Clevis Pin

L : Free Travel

W1032993



Checking Battery Condition

⚠ DANGER

To avoid the possibility of battery explosion:

For the refillable type battery, follow the instructions below.

- Do not use or charge the refillable type battery if the fluid level is below the LOWER (lower limit level) mark. Otherwise, the battery component parts may prematurely deteriorate, which may shorten the battery's service life or cause an explosion. Check the fluid level regularly and add distilled water as required so that the fluid level is between the UPPER and LOWER levels.

⚠ CAUTION

- Never remove the vent plugs while the engine is running.
- Keep electrolyte away from eyes, hands and clothes. If you are spattered with it, wash it away completely with water immediately and get medical attention.
- Wear eye protection and rubber gloves when working around battery.

■ NOTE

- The factory-installed battery is of non-refillable type. If the indicator turns white, do not charge the battery but replace it with new one.

1. Mishandling the battery shortens the service life and adds to maintenance costs.
2. The original battery is maintenance free type battery, but need some servicing.

If the battery is weak, the engine is difficult to start and the lights be dim. It is important check the battery periodically.

3. Check the battery condition by reading the indicator.


State of indicator display.
 Green: Specify gravity of electrolyte and quality of electrolyte are both in good condition.
 Black: Need charging battery.
 White: Need charging battery.

Year	Capacity (Ah)	Capacity (Ah)	Capacity (Ah)	Capacity (Ah)
15	85	123	190	252
15	86	123	190	252

(1) Battery

(2) Indicator

W1095602



■ Battery Charging

⚠ CAUTION

- When the battery is being activated, hydrogen and oxygen gases in the battery are extremely explosive. Keep open sparks and flames away from the battery at all times, especially when charging the battery.
 - When charging battery, remove battery vent plugs.
 - When disconnecting the cable from the battery, start with the negative terminal first.
- When connecting the cable to the battery, start with the positive terminal first.
- Never check battery charge by placing a metal object across the posts.

Use a voltmeter or hydrometer.

1. To slow charge the battery, connect the battery positive terminal to the charger positive terminal and the negative to the negative, then recharge in the standard fashion.
2. A boost charge is only for emergencies. It will partially charge the battery at a high rate and in a short time.
When using a boost-charged battery, it is necessary to recharge the battery as early as possible.
Failure to do this will shorten the battery's service life.
3. The battery is charged if the indicator display turns green from black.
4. When exchanging an old battery into new one, use battery of equal specification shown in table 1.

Table 1

Tractor model	Battery Type	Volt (V)	Capacity at 5 H.R. (A.H.)	Reserve Capacity (min.)	Cold Cranking Amps	Normal Charging Rate (A)
L3130 L3430	75D26R	12	52	123	490	6.5
L3830 L4330 L4630 L5030	80D26R	12	55	133	582	6.5

■ Direction for Storage

1. When storing the tractor for long periods of time, remove the battery from tractor, adjust the electrolyte to the proper level and store in a dry place out of direct sunlight.
2. The battery self-discharges while it is stored.
Recharge it once every three months in hot seasons and once every six months in cold seasons.

(1) Battery

W1033925

[5] CHECK POINTS OF EVERY 200 HOURS

Replacing Engine Oil Filter Cartridge

1. See page G-13.

W10344210

Replacing Hydraulic Oil Filter / Replacing Transmission Oil Filter [HST Type]

1. See page G-14.

W10344720

Checking Radiator Hose and Hose Clamp

Check to see if radiator hoses are properly fixed every 200 hours of operation or six months, whichever comes first.

1. If hose clamps are loose or water leaks, tighten bands securely.
2. Replace hoses and tighten hose clamps securely, if radiator hoses are swollen, hardened or cracked.

Replace hoses and hose clamps every 2 years or earlier if checked and found that hoses are swollen, hardened or cracked.

■ **Precaution at Overheating**



Take the following actions in the event the coolant temperature be nearly or more than the boiling point, what is called "Overheating".



1. Stop the machine operation in a safe place and keep the engine unloaded idling.
2. Don't stop the engine suddenly, but stop it after about 5 minutes of unloaded idling.
3. Keep yourself well away from the machine for further 10 minutes or while the steam blown out.
4. Checking that there gets no danger such as burn, get rid of the causes of overheating according to the manual, see "Troubleshooting" section, and then, start again the engine.

(1) Radiator Hose

(2) Clamp

W10347370





Adjusting Toe-in

1. Park the tractor on the flat place.
2. Inflate the tires to the specified pressure.
3. Turn steering wheel so front wheels are in the straight ahead position.
4. Lower the implement, lock the parking brake and stop the engine.
5. Measure distance between tire beads at front of tire, hub height.
6. Measure distance between tire beads at rear of tire, hub height.
7. Front distance should be 2 to 8 mm (0.079 to 0.315 in.) less than rear distance.
8. If the measurement is not within the factory specifications, adjust by changing the tie-rod length.

Toe-in (B - A)	Factory spec.	2 to 8 mm 0.079 to 0.315 in.
----------------	---------------	---------------------------------

Adjusting

1. Detach the snap ring (1).
2. Loosen the tie-rod nut (2) and turn the tie-rod joint (3) to adjust the tie-rod length until the proper toe-in measurement is obtained.
3. Retighten the tie-rod nut (2).
4. Attach the snap ring (1) of the tie-rod joint.

Tightening torque	Tie-rod lock nut	166.7 to 196.1 N·m 17.0 to 20.0 kgf·m 123 to 145 ft-lbs
-------------------	------------------	---


IMPORTANT

- A right and left tie-rod joint is adjusted to the same length.

- (1) Snap Ring
- (2) Tie-rod Nut
- (3) Tie-rod Joint

- (A) Wheel to Wheel Distance at front
- (B) Wheel to Wheel Distance at rear
- (C) Front

W1082751






Checking HST Oil Line [HST Type] / Checking Power Steering Line

1. Check to see that all lines and hose clamps are tight and not damaged.
2. If hoses and clamps are found worn or damaged, replace repair them at once.

- (1) HST Oil Line
(2) Power Steering Pressure Hoses

(A) HST Type

W1085565




Checking Intake Air Line

1. Check to see that hose and hose clamps are tight and not damaged.
2. If hose and clamps are found worn or damaged, replace or repair them at once.

- (1) Hose

- (2) Hose Clamp

W10345660



Adjusting Air Conditioner Belt Tension (Cabin Model)

CAUTION


- **Be sure to stop the engine before checking air conditioner belt tension.**
1. Stop the engine and remove the key.
 2. Apply 98 N (10 kgf, 22 lbs) pressure to the belt between the pulleys.
 3. If tension is incorrect, adjust the belt tension.
 4. If belt is damaged, replace it.

Air conditioner belt tension	Factory spec.	A deflection of between 10 to 12 mm (0.39 to 0.47 in.) when the belt is pressed in the middle of the span
------------------------------	---------------	---

- (1) Adjusting Bolt
- (2) Nut

A : Deflection

W1019789



Cleaning Inner Air Filter (Cabin Model)

1. Remove the inner filter, and blow air from the direction opposite to the filter's normal air flow.



(Reference)



- Detach and attach the push-ribose (2) as follows.
 - Detaching procedure **(A)**
Push in the center rivet (a) and pull out the push-ribose assembly (b).
 - Attaching procedure **(B)**
Pull out the center rivet (a), attach the push-ribose assembly (b) and push up the center-rivet (c).

- (1) Inner Air Filter
- (2) Push-ribose
- (3) Center-rivet

- a : Pull out center-rivet
- b : Attach push-ribose assembly
- c : Push up center-rivet

W1118812





Cleaning Air Filter (Cabin Model)

■ Fresh Air Filter

1. Remove the knob bolts (3) and pull out the fresh air filter (1).
2. Blow air from the opposite direction to the filter's normal air flow.

■ NOTE

- If the filter is very dirty :
Dip the filter in lukewarm water with mild dish washing detergent.
Move it up and down as well as left and right to loosen dirt.
Rinse the filter with clean water and let it air-dry.

■ IMPORTANT

- Do not use gasoline, thinner or similar chemicals to clean the filter as damage to the filter may occur.
- It may also cause an unpleasant odor in the CABIN when the system is used next.
- Do not hit the filter. If the filter becomes deformed, dust may enter into the air-conditioner, which may cause damage and malfunction.

- (1) Fresh Air Filter
(2) Cover
(3) Knob Bolt

- A : Air Inlet Port
B : Air Conditioner Air Flow

W1019336

Checking Air Conditioner Condenser (Cabin Model)

1. Check the air conditioner condenser (1).
2. If dust and dirt, wash off all dirt and dust from the condenser (1) with a soft brush, use care not to damage or bend the fins.

- (1) Air Conditioner Condenser

W1019699

[6] CHECK POINTS OF EVERY 400 HOURS**Changing Transmission Fluid**

1. See page G-15.

W10365120

Changing Front Axle Case Oil [4WD Type]

1. See page G-16.

W10365590

Replacing Fuel Filter Element

1. See page G-21.



W1085936

Lubricating Grease Fitting [2WD]

1. Detach the cover, and apply bearing grease.

- (1) Front Wheel Hub Cover

W1085994

**[7] CHECK POINTS OF EVERY 600 HOURS****Adjust Front Axle Pivot**

1. Loosen the lock nut (2), tighten the adjusting screw (1) all the way, and then loosen the adjusting screw (1) by 1/6 turn.
2. Retighten the lock nut (2).



■ NOTE

- If the axle pivot pin adjustment is not correct, front wheel vibration can occur causing vibration in the steering wheel.

- (1) Adjusting Screw

- (2) Lock Nut

W1036668

**[8] CHECK POINTS OF EVERY 800 HOURS****Checking Valve Clearance**

1. See page 1-S27.

W1036805

[9] CHECK POINTS OF EVERY 1500 HOURS**Checking Fuel Injection Nozzle Injection Pressure**

1. See page 1-S65.

W1036874

[10] CHECK POINTS OF EVERY 3000 HOURS**Checking Injection Pump**

1. See page 1-S64.


W1036957

[11] CHECK POINTS OF EVERY 1 YEAR

Replacing Air Cleaner Primary Element and Secondary Element

1. Replace the both primary and secondary elements.
Refer to “**Cleaning Air Cleaner Primary Element**”. (See page G-20.)

W1037077




3TLABABWP032D

Checking Air Conditioner Pipe and Clamp

1. Check to see that all lines and hose clamps are tight and not damaged.
2. If hoses (1) and clamps are found worn or damaged, replace or repair them at once.

(1) Hose

W1021331



3TLABAB3P175B

Checking Cabin Isolation Cushion

1. Check the isolation cushion (1) for any breakage or fatigue.
2. Replace them if they have deteriorated.

(1) Isolation Cushion

F : Front Side
R : Rear Side

W1021413

[12] CHECK POINTS OF EVERY 2 YEARS

Replacing Fuel Hose

1. Replace the fuel hoses and clamps, if necessary.
Refer to “**Checking Fuel Line**”. (See page G-22.)

W1037148

Replacing Intake Line

1. Replace the intake hoses and clamps, if necessary.
Refer to “**Checking Intake Air Line**”. (See page G-27.)

W1037203

Replacing HST Oil Line

1. Replace the hoses and clamps.
Refer to “**Checking HST Oil Line and Power Steering Line**”.
(See page G-27.)

W1037296

Replacing Power Steering Hose



1. Replace the hoses and clamps.
Refer to “**Checking HST Oil Line and Power Steering Line**”.
(See page G-27.)

W1037361

Replacing Radiator Hose (Water Pipes)

1. Replace the hoses and clamps.
Refer to “**Checking Radiator Hose and Hose Clamp**”. (See page G-25.)

W1037429



Flushing Cooling System and Changing Coolant

CAUTION

• **Do not remove the radiator cap when the engine is hot. Then loosen cap slightly to the stop to relieve any excess pressure before removing cap completely.**

1. Stop the engine and let cool down.
2. To drain the coolant, open the radiator drain plug (3) and remove the radiator cap (1). The radiator cap (1) must be removed to completely drain the coolant.
3. After all coolant is drained, close the drain plug (3).
4. Fill with clean water and cooling system cleaner.
5. Follow directions of the cleaner instruction.
6. After flushing, fill with clean water and anti-freeze until the coolant level is just below the port. Install the radiator cap (1) securely.
7. Fill with coolant up to "FULL" mark on the recovery tank.
8. Start and operate the engine for few minutes.
9. Stop the engine and let cool. Check coolant level of recovery tank (2) and add coolant if necessary.

IMPORTANT

- **Do not start engine without coolant.**
- **Use clean, fresh water and anti-freeze to fill the radiator and recovery tank.**
- **When the anti-freeze is mixed with water, the anti-freeze mixing ratio must be less than 50 %.**
- **Securely tighten radiator cap. If the cap is loose or improperly fitted, water may leak out and the engine could overheat.**
- **Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7, 8.)**

Coolant capacity (with recovery tank)	L3130 L3430 (ROPS)	6.0 L 6.3 U.S.qts. 5.3 Imp.qts.
	L3430 (CABIN)	7.2 L 7.6 U.S.qts. 6.3 Imp.qts.
	L3830 L4330 (ROPS) L4630 (ROPS)	7.5 L 7.9 U.S.qts. 6.6 Imp.qts.
	L4330 (CABIN) L4630 (CABIN)	8.7 L 9.2 U.S.qts. 7.7 Imp.qts.
	L5030 (ROPS)	8.0 L 8.5 U.S.qts. 7.0 Imp.qts.
	L5030 (CABIN)	9.2 L 9.7 U.S.qts. 8.1 Imp.qts.

- (1) Radiator Cap
- (2) Recovery Tank
- (3) Drain Plug

A : FULL
B : LOW

W1037510

Flushing Cooling System and Changing Coolant (Continued)

■ Anti-Freeze

If coolant freezes, it can damage the cylinders and radiator. It is necessary, if the ambient temperature falls below 0 °C (32 °F), to remove coolant after operating or to add anti-freeze to it.

1. There are two types of anti-freeze available ; use the permanent type (PT) for this engine.
2. Before adding anti-freeze for the first time, clean the radiator interior by pouring fresh water and draining it a few times.
3. The procedure for mixing of water and anti-freeze differs according to the make of the anti-freeze and the ambient temperature, basically is should be referred to SAE J1034 standard, more specifically also to SAE J814c.
4. Mix the anti-freeze with water, and ten fill in to the radiator.

Vol % Anti-freeze	Freeze Point		Boiling Point*	
	°C	°F	°C	°F
40	-24	-12	106	222
50	-37	-34	108	226


*At 760 mmHg pressure (atmospheric). A higher boiling points is obtained by using a radiator pressure cap which permits the development of pressure within the cooling system.

■ NOTE

- The above data represent industry standards that necessitate a minimum glycol content in the concentrated anti-freeze.
- When the coolant level drops due to evaporation, add water only. In case of leakage, add anti-freeze and water in the specified mixing ratio.
- Anti-freeze absorbs moisture. Keep unused anti-freeze in a tightly sealed container.
- Do not use radiator cleaning agents when anti-freeze has been added to the coolant. (Anti-freeze contains an anti-corrosive agent, which will react with the radiator cleaning agent forming sludge which will affect the engine parts.)

W10385910

[13] OTHERS



3TLABAB0P035A

Bleeding Fuel System

Air must removed :

1. When the fuel filter or lines are removed.
 2. When tank is completely empty.
 3. After the tractor has not been used for a long period of time.
- Bleeding procedure is as follows.
1. Fill the fuel tank with fuel, and open the fuel cock (1).
 2. Open the air vent cock (2) on the fuel injection pump.
 3. Start the engine and run for about 30 seconds, and then stop the engine.
 4. Close the air vent cock.


■ IMPORTANT

- Always close the air vent cock except for bleeding fuel lines. Otherwise, engine runs irregularly or stalls frequently.

- (1) Fuel Cock
 (2) Air Vent Cock

- A : Close
 B : Open

W1039026



Draining Clutch Housing Water


■ **NOTE**

- The tractor is equipped with split pin plug (1) under the clutch housing.
- After operating in rain, snow or tractor has been washed, water may get into the clutch housing.

1. Check it by pushing in the split pin (1).
2. If water enters into the clutch housing, remove the plug (1) and drain the water, then reinstall the plug.

(1) Split Pin (Plug)

W1039199



Replacing Fuse

1. The tractor electrical system is protected from potential damage by fuses. A blown fuse indicates that there is an overload or short somewhere in the electrical system.
2. If any of the fuses should blow, replace with a new one of the same capacity.

■ **IMPORTANT**

- Before replacing a blown fuse, determine why the fuse blew and make any necessary repairs. Failure to follow this procedure may result in serious damage to the tractor electrical system. Refer to troubleshooting section of this manual.

If any of them should blow, replace with a new one of the same capacity.


■ **Protected Circuit**

Fuse No.	Capacity (A)	Protected circuit	ROPS	CABIN
1	7.5	Alternator	☆	☆
2	15	Head lights	☆	☆
3	15	Hazard	☆	—
4	5	Panel	☆	☆
5	5	T/M controller 1 (GST Type)	☆	☆
6	7.5	Work light	☆	—
7	5	Brake lamp switch	☆	—
8	10	T/M controller 2 (GST Type)	☆	☆
9	5	Key stop	☆	☆
10	30	Starter relay	☆	☆
11	20	Hazard	—	☆
12	10	Dome lamp	—	☆
13	15	A/C blower	—	☆
14	10	Radio cassette	—	☆
15	20	Cigar lighter	—	☆
16	7.5	A/C compressor	—	☆
17	30	Wiper	—	☆
18	15	Flasher	—	☆
19	15	Work light	—	☆
20	30	Defogger	—	☆
21	Slow blow fuse	Check circuit against wrong battery connection.	☆	☆

(A) ROPS Model

(B) CABIN Model

W1039315



Replacing Light Bulb

1. Head lights and rear combination lights :
Take the bulb out of the light body and replace with a new one.
2. Other lights :
Detach the lens and replace the bulb.


Light	Capacity	
	ROPS	CABIN
Head lights	25 W / 25 W	
Tail light	8 W	
Hazard and turn signal light	27 W	-
Hazard and turn signal light (rear)	-	23 W
Hazard and turn signal light (front)	-	23 W
Side marker light	-	10 W
Room light	-	10 W
Work light	-	27 W
Instrument panel light	1.1 W	

W1039659

Lubricating Points

- (1) Door Hinge
- (2) Rear Window Hinge

W1120093




Adding Washer Liquid



1. Add a proper amount of automobile washer liquid.

Tank capacity	2.0 L 0.53 U.S.gals. 0.44 Imp.gals.
---------------	---

- (1) Washer Liquid Tank

W1120170





Checking Refrigerant (Gas)

CAUTION

- Liquid contact with eyes or skin may cause frostbite.
- In the event of a leakage, wear safety goggles. Escaping refrigerant can cause severe injuries to eyes.
- In contact with a flame, R134a refrigerant gives a toxic gas.
- Do not disconnect any part of the refrigeration circuit of the air conditioning system.

A shortage of refrigerant impairs the air-conditioner performance. Check the following points. If it is indicated that the amount of refrigerant is extremely low, inspect and charge. (See page 10-S21.)

Checking Procedure

1. Run the air-conditioner in the following conditions.
 - Engine speed : About 1500 min⁻¹ (rpm)
 - Temperature control lever : Maximum cooling position (leftmost)
 - Fan switch : Highest blow (HI)
 - Air-conditioner switch : ON
2. Look into the sight glass to see if the refrigerant is flowing through its circuit.

IMPORTANT

- Charge only with R134a not R12 refrigerant (gas).

(1) Side Glass

(A) Proper : Little or no air bubbles in the refrigerant flow.

(B) Low : Lots of air bubbles in the refrigerant flow (air bubbles or foam passing continuously).


(C) Overfull or no refrigerant : Colorless and transparent.

W1120282



8. SPECIAL TOOLS

[1] SPECIAL TOOLS FOR ENGINE



3TMABAB0P049A

Special Use Puller Set

Code No: 07916-09032

Application: Use exclusively for pulling out bearing, gears and other parts with ease.

W10240500




3TMABAB0P050A

Piston Ring Compressor

Code No: 07909-32111

Application: Use exclusively for pushing in the piston with piston rings into the cylinder.

W10241000




3TMABAB0P051A

Piston Ring Tool

Code No: 07909-32121

Application: Use exclusively for removing or installing the piston ring with ease.

W10241500



3TMABAB0P052A

Diesel Engine Compression Tester

Code No: 07909-30208 (Assembly)

07909-31251 (G)

07909-30934 (A to F)

07909-31271 (I)

07909-31211 (E and F)

07909-31281 (J)


07909-31231 (H)

Application: Use to measure diesel engine compression and diagnostics of need for major overhaul.

- (1) Gauge
- (2) L Joint
- (3) Adaptor A
- (4) Adaptor B
- (5) Adaptor C
- (6) Adaptor E

- (7) Adaptor F
- (8) Adaptor G
- (9) Adaptor H
- (10) Adaptor I
- (11) Adaptor J


W10242000

**Oil Pressure Tester**

Code No: 07916-32032

Application: Use to measure lubricating oil pressure.

- | | |
|--------------------|---------------|
| (1) Gauge | (5) Adaptor 2 |
| (2) Cable | (6) Adaptor 3 |
| (3) Threaded Joint | (7) Adaptor 4 |
| (4) Adaptor 1 | (8) Adaptor 5 |

**Valve Seat Cutter**

Code No: 07909-33102

Application: Use to reseat valves.

Angle: 0.785 rad. (45°)

0.262 rad. (15°)

Diameter: 28.6 mm (1.126 in.)

31.6 mm (1.244 in.)


35.0 mm (1.378 in.)

38.0 mm (1.496 in.)

41.3 mm (1.626 in.)


50.8 mm (2.000 in.)

W10244580

**Radiator Tester**

Code No: 07909-31551

Application: Use to check of radiator cap pressure, and leaks from cooling system.

**Connecting Rod Alignment Tool**

Code No: 07909-31661

Application: Use to check the connecting rod alignment.


Applicable: Connecting rod big end I.D.

range 30 to 75 mm (1.18 to 2.95 in.) dia.

Connecting rod length

65 to 300 mm (2.56 to 11.81 in.)

W10245830

**Nozzle Tester**


Code No: 07909-31361

Application: Use to check the fuel injection pressure and spray pattern of nozzle.

Measuring: 0 to 50 MPa

range (0 to 500 kgf/cm², 0 to 7000 psi)

W10246530



Plastigage

Code No: 07909-30241

Application: Use to check the oil clearance between crankshaft and bearing, etc.

Measuring: Green 0.025 to 0.076 mm (0.001 to 0.003 in.)
 range Red 0.051 to 0.152 mm (0.002 to 0.006 in.)
 Blue 0.102 to 0.229 mm (0.004 to 0.009 in.)

W10247190



Red Check

Code No: 07909-31371

Application: Use to check cracks on cylinder head, cylinder block, etc.

W10249090




Crankshaft Nut Socket 46

Code No: 07916-30821

Application: Use exclusively for removing or installing the crankshaft nut.

W10443610



Socket Wrench 46

Code No: 07916-30901

Application: Use exclusively for removing or installing the crankshaft nut.

W10444600



Auxiliary Socket For Fixing Crankshaft Sleeve


Code No: 07916-32091

Application: Use to fix the crankshaft sleeve of the diesel engine.

W10771140

■ NOTE


- The following special tools are not provided, so make them referring to the figure.




Valve Guide Replacing Tool

Application: Use to press out and press fit the valve guide.

A	20 mm dia. (0.79 in. dia.)
B	11.7 to 11.9 mm dia. (0.460 to 0.468 in. dia.)
C	6.5 to 6.6 mm dia. (0.256 to 0.259 in. dia.)
D	225 mm (8.86 in.)
E	70 mm (2.76 in.)
F	45 mm (1.77 in.)
G	25 mm (0.98 in.)
H	5 mm (0.197 in.)
I	6.7 to 7.0 mm dia. (0.263 to 0.275 in. dia.)
J	20 mm dia. (0.787 in. dia.)
K	12.5 to 12.8 mm dia. (0.492 to 0.504 in. dia.)
L	8.9 to 9.1 mm (0.350 to 358 in.)
C1	Chamfer 1.0 mm (0.039 in.)
C2	Chamfer 2.0 mm (0.079 in.)
C0.3	Chamfer 0.3 mm (0.012 in.)



W10250170




Injection Pump Pressure Tester

Application: Use to check fuel tightness of injection pumps.

A	Pressure gauge full scale : More than 29.4 MPa (300 kgf/cm ² , 4267 psi)
B	Copper gasket
C	Flange (Material : Steel)
D	Hex. nut 27 mm (1.06 in.) across the plat
E	Injection pipe
F	PF 1/2
G	5 mm (0.20 in.)
H	17 mm dia. (0.67 in. dia.)
I	8 mm dia. (0.31 in. dia.)
J	1.0 mm (0.039 in.)
K	17 mm dia. (0.67 in. dia.)
L	6.10 to 6.20 mm dia. (0.2402 to 0.2441 in. dia.)
M	8 mm (0.31 in.)
N	4 mm (0.16 in.)
O	11.97 to 11.99 mm dia. (0.4713 to 0.4721 in. dia.)
P	PF 1/2
Q	23 mm (0.91 in.)
R	17 mm (0.67 in.)
S	4 mm (0.16 in.)
T	12.00 to 12.02 mm dia. (0.4724 to 0.4732 in. dia.)
U	100 mm (3.94 in.)
V	M12 × P1.5
a	Adhesive application
b	Fillet welding on the enter circumference

W10252400



Bushing Replacing Tools

Application: Use to press out and to press fit the bushing.


(1) For small end bushing

A	162 mm (6.38 in.)
B	35 mm (1.38 in.)
C	27 mm (1.06 in.)
D	35 mm dia. (1.38 in. dia.)
E	27.90 to 27.95 mm dia. (1.098 to 1.100 in. dia.)
F	25.00 to 25.01 mm dia. (0.984 to 0.985 in. dia.)

(2) For idle gear bushing

A	175 mm (6.89 in.)
B	40 mm (1.57 in.)
C	38 mm (1.49 in.)
D	45 mm dia. (1.77 in. dia.)
E	41.90 to 41.95 mm dia. (1.650 to 1.652 in. dia.)
F	37.95 to 37.97 mm dia. (1.494 to 1.495 in. dia.)

W10255000



Flywheel Stopper

Application: Use to loosen and tighten the flywheel screw.

A	200 mm (7.87 in.)
B	30 mm (1.18 in.)
C	20 mm (0.79 in.)
D	15 mm (0.59 in.)
E	15 mm (0.59 in.)
F	8 mm (0.31 in.)
G	10 mm dia. (0.39 in. dia.)

W10259480

Crankshaft Bearing 1 Replacing Tool

Application: Use to press out and press fit the crankshaft bearing 1.


1. Extracting tool

A	135 mm (5.31 in.)
B	72 mm (2.83 in.)
C	R40 mm (R1.57 in.)
D	10 mm (0.39 in.)
E	20 mm (0.79 in.)
F	20 mm dia. (0.79 in. dia.)
G	56.8 to 56.9 mm dia. (2.236 to 2.240 in. dia.)
H	51.8 to 51.9 mm dia. (2.039 to 2.043 in. dia.)

2. Inserting tool


A	130 mm (5.12 in.)
B	72 mm (2.83 in.)
C	R40 mm (R1.57 in.)
D	9 mm (0.35 in.)
E	4 mm (0.16 in.)
F	20 mm (0.79 in.)
G	20 mm dia. (0.79 in. dia.)
H	68 mm dia. (2.68 in. dia.)
I	51.8 to 51.9 mm dia. (2.039 to 2.043 in. dia.)
J	56.8 to 56.9 mm dia. (2.236 to 2.240 in. dia.)

W10261390



Balancer Metal Replacing Tool (for Removing)

Application: Use to remove the metal bearing.



3TMABAB0P069A


A	25 mm (0.98 in. dia.)	L	41.934 to 41.950 mm dia. (1.6509 to 1.6516 in. dia.)
B	10 mm (0.39 in.)	M	24.959 to 24.980 mm dia. (0.9826 to 0.9835 in. dia.)
C	Chamfer 0.3 mm (0.01 in.)	N	21.947 to 21.960 mm dia. (0.8641 to 0.8646 in. dia.)
D	0.52 rad. (30 °)	O	28 mm (1.10 in.)
E	46.950 to 46.975 mm dia. (1.8484 to 1.8494 in. dia.)	P	29 mm (1.14 in.)
F	43.934 to 43.950 mm dia. (1.7297 to 1.7303 in. dia.)	Q	5 mm (0.20 in.)
G	41 mm (1.61 in.)	R	36 mm (1.42 in.)
H	32.5 mm (1.28 in.)	S	195.25 to 195.75 mm (7.687 to 7.707 in.)
I	148.5 mm (5.85 in.)	T	145 mm (5.71 in.)
J	46.50 to 46.75 mm dia. (1.831 to 1.841 in. dia.)	U	384.75 to 385.25 mm (15.148 to 15.167 in.)
K	44.950 to 44.975 mm dia. (1.7697 to 1.7707 in. dia.)		

Balancer Metal Replacing Tool (for Fitting)

Application: Use to press fit the metal bearing.

Balancer Metal Replacing Tool (for Fitting)


Application: Use to remove the metal bearing.



3TMABABOP070A

A	0.52 rad. (30 °)	O	5 mm (0.20 in.)
B	10 mm (0.39 in.)	P	3.3 to 3.7 mm (0.130 to 0.146 in.)
C	Chamfer 0.3 mm (0.01 in.)	Q	43.934 to 43.950 mm dia. (1.7297 to 1.7303 in. dia.)
D	182 mm (7.16 in.)	R	140 mm (5.51 in.)
E	140 mm (5.51 in.)	S	36 mm (1.42 in.)
F	35 mm dia. (1.38 in. dia.)	T	60 mm dia. (2.36 in. dia.)
G	60 mm dia. (2.36 in. dia.)	U	46.950 to 46.975 mm dia. (1.8484 to 1.8494 in. dia.)
H	37 mm (1.46 in.)	V	44.950 to 44.975 mm dia. (1.7697 to 1.7707 in. dia.)
I	21.947 to 21.960 mm dia. (0.8641 to 0.8646 in. dia.)	W	41.934 to 41.950 mm dia. (1.6509 to 1.6516 in. dia.)
J	24.959 to 24.980 mm dia. (0.9826 to 0.9835 in. dia.)	X	145 mm (5.71 in.)
K	8.8 to 9.2 mm (0.346 to 0.362 in.)	Y	195.25 to 195.75 mm (7.687 to 7.707 in.)
L	25 mm dia. (0.98 in. dia.)	Z	29 mm (1.14 in.)
M	60 mm dia. (2.36 in. dia.)	a	36 mm (1.42 in.)
N	46.950 to 46.975 mm dia. (1.8484 to 1.8494 in. dia.)		

[2] SPECIAL TOOLS FOR TRACTOR




3TMABAB0P071A

Tie-rod End Lifter

Code No: 07909-39051

Application: Use for removing the tie-rod end with ease.

W10264720




3TMABAB0P072A

Steering Wheel Puller

Code No: 07916-51090

Application: Use for removing the steering wheel without damaging the steering shaft.

W10265330




3TMABAB0P073A

Injector CH3

Code No: 07916-52501

Application: Use for injecting calcium chloride solution into, and removing it from, rear and 4WD type front wheel tires.

W10265850




3TMABAB0P074A

Clutch Center Tool (For B and L Series Tractors)

Application: The clutch center tool can be used for all B and L series tractors with a diaphragm clutch by changing tip guides. Center piece diameter is 20 mm (0.79 in.).

W10266370




3TMABAB0P075A

Toe-in Gauge

Code No: 07909-31681

Application: This allows easy measurement of toe-in for all machine models.

W10266890




Rear Axle Cover Puller

Code No: 07916-51041

Application: Use for removing a rear axle cover from rear axle.

W10732590




Relief Valve Pressure Tester

Code No: 07916-50045

Application: This allows easy measurement of relief set pressure.

- | | |
|--|---------------------------------------|
| (1) Gauge (07916-50322) | (6) Adaptor C (PS3/8) (07916-50371) |
| (2) Cable (07916-50331) | (7) Adaptor D (PT1/8) (07916-50381) |
| (3) Threaded Joint (07916-50401) | (8) Adaptor E (PS3/8) (07916-50392) |
| (4) Threaded Joint (07916-50341) | (9) Adaptor F (PF1/2) (07916-62601) |
| (5) Adaptor B (M18 x P1.5) (07916-50361) | (10) Adaptor 5B (PT1/4) (07916-52391) |

W10267410



Flow Meter


Code No: 07916-52791 (Flow Meter)

07916-52651 (Hydraulic Test Hose)

Application: This allows easy testing of hydraulic system.

- | | |
|----------------|-------------------------|
| (1) Flow Meter | (2) Hydraulic Test Hose |
|----------------|-------------------------|

W10313180




Adaptor Set for Flow Meter

Code No: 07916-54031

Application: Use for testing the hydraulic system.

- | | |
|----------------|--------------------------|
| (1) Adaptor 52 | (8) Adaptor 65 |
| (2) Adaptor 53 | (9) Adaptor 66 |
| (3) Adaptor 54 | (10) Adaptor 67 |
| (4) Adaptor 61 | (11) Adaptor 68 |
| (5) Adaptor 62 | (12) Adaptor 69 |
| (6) Adaptor 63 | (13) Hydraulic Adaptor 1 |
| (7) Adaptor 64 | |

W10313960




Power Steering Adapter

Code No: 07916-54021

Application: Use for measuring the relief valve setting pressure for power steering.

W10442870



3TMABAB0P081A

Pinion Locking Tool

Code No: 07916-52311

Application: Use for preventing the shaft from turning when removing or tighten a bevel pinion shaft staking nut.

W10445520




3TMABAB0P082A

Rear Axle Nut Wrench 71

Code No: 07916-52531

Application: Use for removing and installing a rear axle nut.

W10446460



3TMABAB0P083A

Relief Valve Setting Pressure Adaptor G


Code No: 07916-52751

Application: This offers easy measurement of relief valve setting pressure from the hydraulic coupler. This is available with the relief valve setting pressure tester.

W10623960

NOTE

- The following special tools are not provided, so make them referring to the figure.




3TMABAB0P084A

Pinion Shaft Remover

Application: Use for removing a pinion shaft.

A	106 mm (4.17 in.)
B	350 mm (13.78 in.)
C	6 mm (0.24 in.)
D	90 mm (3.54 in.)
E	10 mm (0.39 in.)
F	40 mm (1.57 in.)
G	10 mm (0.39 in.)
H	35.6 mm (1.40 in.)
I	36 mm (1.42 in.)
J	41.6 mm (1.64 in.)
K	Part code No. 3A201-4130 nut
L	M27 × P1.5
M	M10 × P1.25

W10315930




Hydraulic Arm Shaft Bushing Press-Fitting Tool

Application: Use for replacing the hydraulic arm shaft bushings in the hydraulic cylinder body.

	Right	Left
A	54.7 to 54.9 mm (2.1535 to 2.1614 in.)	49.7 to 49.9 mm (1.9567 to 1.9646 in.)
B	24.5 to 25.5 mm (0.9646 to 1.0039 in.)	21.5 to 22.5 mm (0.8465 to 0.8858 in.)
C	40 mm (1.57 in.)	40 mm (1.57 in.)
D	32 mm (1.26 in.)	30 mm (1.18 in.)
E	49.7 to 49.9 mm (1.9567 to 1.9646 in.)	44.7 to 44.9 mm (1.7598 to 1.7677 in.)
F	70 mm dia. (2.76 in. dia.)	
G	40 mm dia. (1.57 in. dia.)	
H	50 mm (1.97 in.)	
I	10 mm (0.39 in.)	
a	6.3 μm (250 μin.)	
b	6.3 μm (250 μin.)	
c	6.3 μm (250 μin.)	
d	6.3 μm (250 μin.)	

W10316550



Draft Control Test Bar


Application: Use for checking the lift range and floating range of hydraulic draft control.

A	1045 mm (41.14 in.)
B	1000 mm (29.37 in.)
C	20 mm dia. (0.79 in. dia.)
D	30 mm dia. (1.18 in. dia.)
E	90 mm (3.54 in.)
F	30 mm (1.18 in.)
G	30 mm (1.18 in.)
H	15 mm (0.59 in.)
I	20 mm dia. (0.79 in. dia.)
J	Weld all around
K	Weld all around
L	20 mm (0.79 in.)

W10625190

■ NOTE

- Special tools for R134a refrigerant air conditioning system introduced below are available from NIPPONDENSO CO. LTD.




3TLABAB0P051A

Air Conditioner Service Tool

Code No: NIPPONDENSO 95048-00061

Application: Use for charging, testing or discharging the air conditioning system.


W1013507



3TLABAB0P052A

- | | |
|-------------------------------|-------------|
| (1) Manifold Gauge Assembly | 95048-10090 |
| (2) Charging Hose (Red : HI) | 95948-10270 |
| (3) Charging Hose (Blue : LO) | 95948-10280 |
| (4) Charging Hose (Green) | 95948-10260 |
| (5) Can Tap Valve | 95048-10150 |
| (6) T Joint | 95048-10160 |
| (7) Quick Coupler (HI) | 95048-10130 |
| (8) Quick Coupler (LO) | 95048-10140 |
| (9) Service Valve Packing | 95906-10310 |
| (10) Charging Hose Packing | 95906-10300 |
| (11) Tool Case | 95949-10610 |

W1014733




3TLABAB0P053A

Electric Gas Leak Tester

Code No: NIPPONDENSO 95146-00060

Application: Use for gas leak testing the air conditioning system.

W1013817



3TLABABWP012A


Vacuum Pump

Code No: NIPPONDENSO 95046-00040 (AC220V)
95046-00050 (AC240V)

Application: Use for evacuating the air conditioning system.

- | | |
|------------------------|-----------------|
| (1) Adaptor (For 134a) | (2) Vacuum Pump |
|------------------------|-----------------|

W1013764



Adaptor (For R134a)


Code No: NIPPONDENSO 95048-10190 (AC220V)
95048-10200 (AC240V)

Application: Use for evacuating the air conditioning system.

W1013888

3TLABAB0P054A

Stopper Magnet Clutch (For A/C Compressor)




3TLABAB0P038A

Application: Use for loosen and tighten the magnet clutch mounting nut.

NOTE

- This special tool is not provided, so make it referring to the figure.

A	125 mm (4.92 in.)	G	3 × M8 × 1.25 All screws
B	40 mm dia. (1.57 in. dia.)	H	4.52 rad. (120 °)
C	Radius 33 mm (Radius 1.30 in.)	I	Radius 27 mm (Radius 1.06 in.)
D	16 mm (0.63 in.)	J	Radius 50 mm (Radius 1.97 in.)
E	120 mm dia. (4.72 in. dia.)	K	Weld all around
F	12 mm dia. (0.47 in. dia.)	L	20 mm (0.78 in.)



Stopper Bolt (for A/C Compressor)


Application: Use with the stopper magnet clutch.

■ **NOTE**

- This special tool is not provided, so make it referring to the figure.

A	12 mm (0.47 in.)	E	5.5 mm dia. (0.22 in. dia.)
B	35 mm (1.38 in.)	F	6.5 mm dia. (0.26 in. dia.)
C	7 mm (0.28 in.)	G	0.52 rad. (30 °)
D	0.4 mm (0.016 in.)	H	M8 × P1.25

W1065437



Remover Magnet Clutch (for A/C Compressor)


Application: Use to remove the hub plate or center piece.

■ **NOTE**

- This special tool is not provided, so make it referring to the figure.

A	12 mm (0.47 in.)
B	55 mm (2.16 in.)
C	20 mm (0.79 in.)
D	5 mm dia. (0.20 in. dia.)
E	M8 × P1.25

W1066199



Valve Adaptor


Application: Use for measuring the system pressure of shuttle valve.

A	24 mm (0.94 in.)
B	27.7 mm (1.09 in.)
C	PS1/4
D	11 mm (0.43 in.)
E	15 mm (0.59 in.)
F	40 mm (1.57 in.)
G	60 mm (2.36 in.)
H	15 mm (0.59 in.)
I	PT1/8
J	4 mm dia. (0.15 in. dia.)
C1	Chamfer 1 mm (0.039 in.)
C2	Chamfer 2 mm (0.079 in.)

W1039227

1	39 mm (1.50 in.)	T	30 mm dia. (1.18 in. dia.)
2	40 mm (1.57 in.)	S	40 mm (1.57 in.)
3	42 mm (1.65 in.)	R	42 mm (1.65 in.)
4	44 mm (1.73 in.)	Q	44 mm (1.73 in.)
5	46 mm (1.81 in.)	P	46 mm (1.81 in.)
6	48 mm (1.89 in.)	O	48 mm (1.89 in.)
7	50 mm (1.97 in.)	N	50 mm (1.97 in.)
8	52 mm (2.05 in.)	M	52 mm (2.05 in.)
9	54 mm (2.13 in.)	L	54 mm (2.13 in.)
10	56 mm (2.21 in.)	K	56 mm (2.21 in.)

Pump Adaptor



Application: Use for checking the main hydraulic pump.

NOTE

- When using, attach with following parts.
O-ring : 04811-00180
- this adaptor is modified from Adaptor 61 of flowmeter adaptor set (see page G-46).


A	22 mm (0.872 in.)	K	135 mm (5.31 in.)
B	11 mm (0.437 in.)	L	7 mm dia. (0.28 in. dia.)
C	24 mm dia. (0.94 in. dia.)	M	8.5 mm dia. (0.33 in. dia.)
D	18 mm dia. (0.71 in. dia.)	N	37 mm (1.46 in.)
E	12 mm dia. (0.47 in. dia.)	O	61.5 mm (2.42 in.)
F	1.7 to 1.9 mm (0.067 to 0.075 in.)	P	24 mm (0.94 in.)
G	30 mm Round (1.18 in. Round)	Q	27.7 mm (1.09 in.)
H	10 mm dia. (0.39 in. dia.)	R	0.244 rad. (14 °)
I	G 3/8	S	40 mm (1.57 in.)
J	89 mm (3.50 in.)	T	60 mm dia. (2.36 in. dia.)

(Reference)

- From size A to size R are same size as adaptor 61.

9. TIRES

[1] TIRE PRESSURE



Though the tire pressure is factory-set to the prescribed level, it naturally drops slowly in the course of time. Thus, check it everyday and inflate as necessary. To inflate the wheel tires, use an air compressor or hand pump.

- **Recommended inflation pressure**
Maintain the pressure shown below.

	Tire sizes	Inflation Pressure
Rear	12.4-24, 4PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	13.6-28, 4PR	150 kPa (1.5 kgf/cm ² , 22 psi)
	14.9-24, 6PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	14.9-26, 4PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	41/18LL × 16.1, 6PR	70 kPa (0.7 kgf/cm ² , 10 psi)
	355/80-D20, 4PR	100 kPa (1.0 kgf/cm ² , 14 psi)
	44 × 18-20, 6PR	170 kPa (1.7 kgf/cm ² , 24 psi)
	420/70-24, 6PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	17.5L-24, 6PR	140 kPa (1.4 kgf/cm ² , 20 psi)
Front	6.00-16, 4PR	220 kPa (2.2 kgf/cm ² , 32 psi)
	7.2-16, 4PR	150 kPa (1.5 kgf/cm ² , 22 psi)
	8.3-16, 4PR	150 kPa (1.5 kgf/cm ² , 22 psi)
	9.5-16, 4PR	205 kPa (2.1 kgf/cm ² , 30 psi)
	27 × 8.50-15, 4PR	85 kPa (0.8 kgf/cm ² , 12 psi)
	27 × 10.50-15, 4PR	85 kPa (0.8 kgf/cm ² , 12 psi)
	29 × 12.50-15, 4PR	140 kPa (1.4 kgf/cm ² , 20 psi)
	10-16.5, 6PR	140 kPa (1.4 kgf/cm ² , 20 psi)
7.5L-15, 6PR	220 kPa (2.2 kgf/cm ² , 32 psi)	

! CAUTION

- Do not attempt to mount a tire. This should be done by a qualified person with the proper equipment. Qualified person with the proper tire mounting equipment should recognize the following warning.

! WARNING

- Never exceed 241 kPa (2.5 kgf/cm², 35 psi) when attempting to seat a bead. If beads have not been seated by the time the pressure reached 241 kPa (2.5 kgf/cm², 35 psi), deflate the assembly, reposition the tire on the rim, relubricate and reinflate. After seating the bead, adjust inflation pressure as recommended in the inflation pressure chart.

- (A) Insufficient
- (B) Standard
- (C) Excessive

(1) Ground

W10440050


[2] TREADS ADJUSTMENT

⚠ CAUTION

- When working on slopes or working with trailer, set the wheel tread as wide as practice for the job for maximum stability.
- Support tractor securely on stands before removing a wheel.
- Do not work under any hydraulically supported devices. They can settle, suddenly leak down, or be accidentally lowered. If necessary to work under tractor or any machine elements for servicing or adjustment, securely support them with stands or suitable blocking beforehand.
- Never operate tractor with a loose rim, wheel, or axle.

(1) Front Wheels

(A) 2WD Type



Front tread width can be adjusted as shown with the standard equipped tires.

To change the tread width.

1. Remove the front axle mounting bolts and the tie-rod mounting bolts.
2. Move the front axles (right and left) to the desired position, and tighten the bolts.
3. Adjust the toe-in.

Toe-in	Factory spec.	2 to 8 mm 0.1 to 0.3 in.
Tightening torque	Front axle mounting bolt	124 to 147 N·m 12.6 to 15.0 kgf·m 91.5 to 108.4 ft-lbs
	Tie-rod mounting bolt	61 to 71 N·m 6.2 to 7.2 kgf·m 44.8 to 52.1 ft-lbs

- (1) Front Axle Mounting Bolt
(2) Tie-rod Mounting Bolt

- (3) Tie-rod Clamp


W1092845

Models				
	3TMABAB0P091A	3TMABAB0P092A	3TMABAB0P093A	3TMABAB0P094A
6.00-15 Farm	1310 mm (51.6 in.)	1410 mm (55.5 in.)	1510 mm (59.4 in.)	1610 mm (63.4 in.)
7.5L-15 Farm	1280 mm (50.4 in.)	1380 mm (54.3 in.)	1480 mm (58.3 in.)	1580 mm (62.2 in.)
27 × 8.50-15 Turf	1235 mm (48.6 in.)	1335 mm (52.6 in.)	1435 mm (56.5 in.)	1535 mm (60.4 in.)
27 × 10.50-15 Turf	1215 mm (47.8 in.)	1315 mm (51.8 in.)	1415 mm (55.7 in.)	1515 mm (59.6 in.)
29 × 12.50-15 Turf	1315 mm (51.8 in.)	1415 mm (55.7 in.)	1515 mm (59.6 in.)	1615 mm (63.6 in.)

■ IMPORTANT

- The front tread width for the front loader application on 2WD models should not be greater than 1310 mm (51.6 in.) for 3130, L3430.

W10522820



3TLABAB0P037A

■ **IMPORTANT**

- Do not turn front discs to obtain wider tread.

■ **NOTE**

- Wheels with beveled or tapered holes : use the tapered side of lug nut.

W1093036

(B) 4WD Type

Front axle is not adjustable

<p>3TMABAB0P095A</p>	Models	L3130, L3430					
	Tire	7.2-16 Farm	-	27 × 8.50-15 Turf	27 × 10.50-15 Turf	29 × 12.50-15 Turf	10-16.5 IND
	Tread	1115 mm (43.9 in.)	-	1200 mm (47.2 in.)	1230 mm (48.4 in.)	1280 mm (50.4 in.)	1235 mm (48.6 in.)
	Models	L3830					
	Tire	-	8.3-16 Farm	27 × 8.50-15 Turf	27 × 10.50-15 Turf	29 × 12.50-15 Turf	10-16.5 IND
	Tread	-	1155 mm (45.5 in.)	1200 mm (47.2 in.)	1230 mm (48.4 in.)	1280 mm (50.4 in.)	1235 mm (48.6 in.)
	Models	L4330, L4630					
	Tire	-	8.3-16 Farm	-	27 × 10.50-15 Turf	29 × 12.50-15 Turf	10-16.5 IND
	Tread	-	1300 mm (51.2 in.)	-	1375 mm (54.1 in.)	1425 mm (56.1 in.)	1380 mm (54.3 in.)
	Models	L5030					
	Tire	-	9.5-16 Farm	-	27 × 10.50-15 Turf	29 × 12.50-15 Turf	10-16.5 IND
	Tread	-	1340 mm (52.8 in.)	-	1375 mm (54.1 in.)	1425 mm (56.1 in.)	1380 mm (54.3 in.)

■ **NOTE**

- IND : for industrial

W10527070

(2) Rear Wheels





Rear tread can be adjusted in 6 steps depending on the model.

To change the tread


1. Lift the rear tires off the ground.
2. Follow the illustrations below to get the desired tread width.

■ **IMPORTANT**

- If not attached as illustrated, transmission parts may be damaged.
- When re-fitting or adjusting a wheel, tighten the bolts to the following torques then recheck after driving the tractor 200 m (200 yards) and thereafter according to service interval.

Models	 3TMABAB0P097A	 3TMABAB0P098A	 3TMABAB0P099A	 3TMABAB0P100A
L3130, L3430 12.4-24 Farm	1200 mm (47.2 in.)	1300 mm (51.2 in.)	1385 mm (54.5 in.)	1480 mm (58.3 in.)
L3830, L4330, L4630 14.9-24 Farm	—	1285 mm (50.6 in.)	1435 mm (56.5 in.)	1530 mm (60.2 in.)
L3130, L3430 420/70-24 IND	—	1325 mm (52.2 in.)	1360 mm (53.5 in.)	1465 mm (57.7 in.)
L3830, L4330, L4630 17.5L-24 IND	—	1340 mm (52.8 in.)	1380 mm (54.3 in.)	1490 mm (58.7 in.)
L5030 13.6-28 Farm	1220 mm (48.0 in.)	1330 mm (52.4 in.)	1425 mm (56.1 in.)	1530 mm (60.2 in.)
L5030 14.9-26 Farm	—	—	1325 mm (52.2 in.)	1430 mm (56.3 in.)
L5030 17.5L-24 IND	—	1360 mm (53.5 in.)	1395 mm (54.9 in.)	1500 mm (59.1 in.)

W10529090

Models	 3TMABAB0P101A
L3130, L3430 355/80-D20 Turf	1270 mm (50.0 in.)
L3830 355/80-D20 Turf	1290 mm (50.8 in.)
L3130, L3430 41/18LL × 16.1 Turf	1420 mm (55.9 in.)
L3830, L4330, L4630, L5030 41/18LL × 16.1 Turf	1440 mm (56.7 in.)
L3130, L3430 44 × 18-20 Turf	1400 mm (55.1 in.)
L3830, L4330, L4630, L5030 44 × 18-20 Turf	1415 mm (55.7 in.)

W10531370


[3] TIRE LIQUID INJECTION

Auxiliary weights can be used to increase traction force for plowing in fields or clayey ground.

Another way is to inject water or another liquid, such as a calcium chloride solution in the tires. Water must not be used in winter since it freezes at 0 °C (32 °F). The calcium chloride solution will not freeze and moreover, affords higher effect than water since its specific gravity is higher than that of water by about 20 %. Below is an explanation of calcium chloride solution injection.

■ IMPORTANT

- Do not fill the front tires with liquid.



3TMABABOP104A

Preparation of Calcium Chloride Solution

⚠ CAUTION

- When making a calcium chloride solution, do not pour water over calcium chloride since this results in chemical reaction which will cause high temperature. Instead add a small amount of calcium chloride to the water at a time until the desired solution is achieved.

Freezing temp.	Weight of CaCl ₂ to be dissolved in 100 L (26.5 U.S.gals., 22.0 Imp.gals.) of water
-5 °C (23 °F)	12 kg (26.4 lbs)
-10 °C (14 °F)	21 kg (46.3 lbs)
-15 °C (5 °F)	28 kg (61.7 lbs)
-20 °C (-4 °F)	34 kg (75.0 lbs)
-25 °C (-13 °F)	40 kg (88.2 lbs)
-30 °C (-22 °F)	44 kg (97.0 lbs)
-35 °C (-31 °F)	49 kg (108 lbs)
-40 °C (-40 °F)	52 kg (114.6 lbs)
-45 °C (-49 °F)	56 kg (123.5 lbs)
-50 °C (-58 °F)	61 kg (134.5 lbs)

(a) Water

(b) CaCl₂ (Calcium Chloride)

W10330830


Attaching Injector

1. Lift the rear tires off the ground.
2. Turn the tire so that the air valve is at the top.
3. Remove the air valve, and attach the injector. (Code No. 07916-52501)


(1) Injector

(2) Hose

W10333310



3TMABABOP105A



3TMABABOP106A

Fig. 1




Fig. 2






Fig. 3



3TMABAB0P111A



3TMABAB0P107A

Injection

CAUTION

- When a calcium chloride solution is used, cool it before pouring it into the tire.
- Do not fill tires with water or solution more than 75 % of full capacity (to the valve stem level).

The following four ways can be used to inject water or a calcium chloride solution into tires.

1. Gravity injection (Fig. 1)
2. Pump injection (Fig. 2)
3. Pressure tank injection (Fig. 3)
4. Injection directly from tap (only when water is being used).

NOTE

- Once injection is completed, reset the air valve, and pump air into the tire to the specified pressure.

Weight of Calcium Chloride Solution Filling 75 % of Full Capacity of a Tire


Tire sizes	12.4-24	420/70-24	14.9-24
Slush free at -10 °C (14 °F) Solid at -30 °C (-22 °F) [Approx. 1 kg (2 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	130 kg (285 lbs)	195 kg (430 lbs)	205 kg (450 lbs)
Slush free at -24 °C (-11 °F) Solid at -47 °C (-53 °F) [Approx. 1.5 kg (3.5 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	135 kg (295 lbs)	205 kg (450 lbs)	215 kg (475 lbs)
Slush free at -47 °C (-53 °F) Solid at -52 °C (-62 °F) [Approx. 2.25 kg (5 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	145 kg (320 lbs)	220 kg (485 lbs)	225 kg (495 lbs)

Tire sizes	17.5L-24	14.9-26	13.6-28
Slush free at -10 °C (14 °F) Solid at -30 °C (-22 °F) [Approx. 1 kg (2 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	235 kg (515 lbs)	215 kg (475 lbs)	185 kg (405 lbs)
Slush free at -24 °C (-11 °F) Solid at -47 °C (-53 °F) [Approx. 1.5 kg (3.5 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	250 kg (550 lbs)	225 kg (495 lbs)	200 kg (441 lbs)
Slush free at -47 °C (-53 °F) Solid at -52 °C (-62 °F) [Approx. 2.25 kg (5 lbs.) CaCl ₂ per 4 L (1 gal.) of water]	265 kg (585 lbs)	235 kg (515 lbs)	215 kg (475 lbs)

- (1) Pump
- (2) Pressure Tank
- (3) Compressor
- (4) Air
- (5) Water

**(A) Correct : 75 %
Air Compresses Like A Cushion**
**(B) Incorrect : 100 % Full
Water Can Not Be Compressed**

W10334350




3TMABAB0P108A

Draining Water or Solution

1. Lift the rear tires off the ground.
2. Turn the tire so that the air valve is at the bottom.
3. Remove the air valve, and drain liquid (liquid can only be drained to the level of the valve and liquid under that level remains inside).
4. To drain liquid completely, use the injector, and direct compressed air into the tire to force out the liquid through the injector's vent.

- (1) Injector
- (2) Hose
- (3) Vent

A: Compressed Air



3TMABAB0P073B

W10451670

Actual figures	Max. Drawbar Load (W)	Trailer loading weight (W _T)	Max. capacity	Implement weight (W _I) and/or size	Model
	1500 kg (3300 lbs)	3000 kg (6600 lbs)	3000 kg (6600 lbs)	As in the following list (shown on the next page)	L5030
	1340 kg (2950 lbs)	2600 kg (5720 lbs)	2600 kg (5720 lbs)		L4630
	1300 kg (2870 lbs)	2500 kg (5500 lbs)	2500 kg (5500 lbs)		L3830
	1155 kg (2550 lbs)	2000 kg (4400 lbs)	2000 kg (4400 lbs)		L3430
	1810 kg (4000 lbs)	1800 kg (3960 lbs)	1800 kg (3960 lbs)		L3130

Lower link and max. hydraulic lift capacity: W_L
 Implement weight: W_I
 Max. drawbar load: W_D
 Trailer loading weight (without trailer's weight): W_T
 The max. loading weight for trailer (without trailer's weight): W_T

NOTE
 • Implement size may vary depending on soil operating conditions.

[4] IMPLEMENT LIMITATIONS

The KUBOTA Tractor has been thoroughly tested for proper performance with implements sold or approved by KUBOTA. Use with implements which exceed the maximum specifications listed below, or which are otherwise unfit for use with the KUBOTA Tractor may result in malfunctions or failures of the tractor, damage to other property and injury to the operator or others. [Any malfunctions or failures of the tractor resulting from use with improper implements are not covered by the warranty.]

	Tread (max. width)			Lower link end max. loading weight W_0
	Front		Rear	
	2WD	4WD		
L3130	1610 mm (63.4 in.)	1155 mm (45.5 in.)	1480 mm (58.3 in.)	1700 kg (3750 lbs.)
L3430	—			
L3830	1580 mm (62.2 in.)	1300 mm (51.2 in.)	1530 mm (60.2 in.)	1750 kg (3860 lbs.)
L4330	—			
L4630	—			
L5030	—		1340 mm (52.8 in.)	


	Actual figures		
	Implement weight W_1 and / or size	Max. Drawbar Load W_2	Trailer loading weight W_3 Max. capacity
L3130	As in the following list (Shown on the next page)	500 kg (1100 lbs)	1500 kg (3300 lbs)
L3430			2000 kg (4400 lbs)
L3830		650 kg (1430 lbs)	2500 kg (5500 lbs)
L4330			3000 kg (6600 lbs)
L4630			
L5030			

Lower link end max. hydraulic lift capacity W_0

Implement weight.....The implement's weight which can be put on the link : W_1

Max. drawbar load W_2

Trailer loading weightThe max. loading weight for trailer (without trailer's weight) : W_3



3TMABABOP109A

■ NOTE

- Implement size may vary depending on soil operating conditions.

No.	Implement	Remarks	L3130	L3430
1	Trailer	Max. Load Capacity	1500 kg (3300 lbs)	2000 kg (4400 lbs)
		Max. Drawbar Load	500 kg (1100 lbs)	650 kg (1430 lbs)
2	Mower	Mid-mount	Max. Cutting Width	1829 mm (72 in.)
			Max. Weight	200 kg (440 lbs)
		Rotary-cutter	Max. Cutting Width	1829 mm (72 in.)
			Max. Weight	350 kg (770 lbs)
		Flail Mower (Heavy)	Max. Cutting Width	1524 mm (60 in.)
			Max. Weight	400 kg (880 lbs)
Sickle Bar	Max. Cutting Width	2134 mm (84 in.)		
	Max. Weight	500 kg (1100 lbs)		
3	Sprayer	Rear Mount	Max. Tank-capacity 300 L (80 U.S.gals., 66 Imp.gals.)	
		Pull Type	Max. Tank-capacity 800 L (210 U.S.gals., 176 Imp.gals.)	1000 L (264 U.S.gals., 220 Imp.gals.)
4	Rotary Tiller	Max. Tilling Width	1524 mm (60 in.)	
5	Bottom Plow	Max. Size	12 in. × 2, 16 in. × 1	
6	Disc-harrow Pull Type	Max. Harrowing Width	1829 mm (72 in.)	
		Max. Weight	350 kg (770 lbs)	
7	Chisel Plow	Max. Width	1829 mm (72 in.)	
		Max. Weight	350 kg (770 lbs)	
8	Broad Caster	Max. Tank-capacity	200 L (53 U.S.gals., 44 Imp.gals.)	250 L (66 U.S.gals., 55 Imp.gals.)
		Max. Weight	100 kg (220 lbs)	
9	Manure Spreader	Max. Capacity	1500 kg (3300 lbs)	
10	Cultivator	Max. Width	1829 mm (72 in.)	
		Number of Rows	1	
		Max. Weight	300 kg (660 lbs)	350 kg (770 lbs)
11	Front Blade	Max. Cutting Width	1829 mm (72 in.)	
		Max. Oil Pressure	17.2 MPa (175 kgf/cm ² , 2490 psi)	
		Sub Frame	Necessary	
12	Rear Blade	Max. Cutting Width	1829 mm (72 in.)	
		Max. Oil Pressure	17.2 MPa (175 kgf/cm ² , 2490 psi)	
13	Front Loader	Max. Lifting Capacity	720 kg (1590 lbs)	
		Max. Oil Pressure	17.7 MPa (180 kgf/cm ² , 2560 psi)	
		Sub Frame	Necessary	
14	Box Blade	Max. Cutting Width	1651 mm (65 in.)	
		Max. Weight	400 kg (880 lbs)	
15	Back Hoe	Max. Digging Depth	2286 mm (90 in.)	
		Max. Weight	450 kg (990 lbs)	
		Sub Frame	Necessary	

W1012736

No.	Implement	Remarks	L3130	L3430
16	Snow Blade	Max. Width	1829 mm (72 in.)	
		Max. Weight	350 kg (770 lbs)	
17	Snow Blower	Max. Working Width	1702 mm (67 in.)	
		Max. Weight	280 kg (620 lbs)	

■ NOTE

- Implement size may vary depending on soil operating conditions.

No.	Implement	Remarks	L3130	L3430
1	Sprayer	Max. Tank Capacity 1000 L (264 U.S. gal) 750 imp. gal.	800 L (210 U.S. gal) 600 imp. gal.	W1102494
2	Bottom Plow	Max. Size 12 m x 2.18 m x 1		
3	Disc Narrow	Max. Hauling Width 1829 mm (72 in.)		
4	Disc Plow	Max. Weight 320 kg (710 lbs)		
5	Grass Plow	Max. Width 1829 mm (72 in.)		
6	Brush Cutter	Max. Tank Capacity 250 L (66 U.S. gal) 180 imp. gal.	250 L (66 U.S. gal) 180 imp. gal.	
7	Manure Spreader	Max. Capacity 1800 kg (3990 lbs)	100 kg (220 lbs)	
8	Cultivator	Max. Width 1829 mm (72 in.)		
9	Front Blade	Max. Cutting Width 1829 mm (72 in.)		
10	Front Blade	Max. Oil Pressure 17.5 MPa (175 kg/cm ² , 2490 psi)		
11	Front Loader	Max. Lifting Capacity 750 kg (1650 lbs)		
12	Box Blade	Max. Cutting Width 1829 mm (72 in.)		
13	Back Hoe	Max. Digging Depth 1288 mm (50 in.)		

No.	Implement	Remarks	L3830	L4330
1	Trailer	Max. Load Capacity	2500 kg (5500 lbs)	3000 kg (6600 lbs)
		Max. Drawbar Load	650 kg (1430 lbs)	
2	Mid-mount	Max. Cutting Width	1829 mm (72 in.)	—
		Max. Weight	200 kg (440 lbs)	—
	Rotary-cutter	Max. Cutting Width	1829 mm (72 in.)	
		Max. Weight	420 kg (926 lbs)	
	Flail Mower (Heavy)	Max. Cutting Width	1524 mm (60 in.)	
		Max. Weight	400 kg (880 lbs)	
	Sickle Bar	Max. Cutting Width	2134 mm (84 in.)	
		Max. Weight	500 kg (1100 lbs)	
3	Rear Mount	Max. Tank-capacity	400 L (106 U.S.gals., 88 Imp.gals.)	
	Pull Type	Max. Tank-capacity	1200 L (317 U.S.gals., 264 Imp.gals.)	
4	Rotary Tiller	Max. Tilling Width	1524 mm (60 in.)	
5	Bottom Plow	Max. Size	14 in. × 2	
6	Disc-harrow Pull Type	Max. Harrowing Width	1981 mm (78 in.)	
		Max. Weight	400 kg (880 lbs)	
7	Chisel Plow	Max. Width	1829 mm (72 in.)	
		Max. Weight	350 kg (770 lbs)	
8	Broad Caster	Max. Tank-capacity	300 L (80 U.S.gals., 66 Imp.gals.)	
		Max. Weight	100 kg (220 lbs)	
9	Manure Spreader	Max. Capacity	2000 kg (4400 lbs)	
10	Cultivator	Max. Width	2134 mm (84 in.)	
		Number of Rows	2	
		Max. Weight	400 kg (880 lbs)	
11	Front Blade	Max. Cutting Width	1829 mm (72 in.)	2134 mm (84 in.)
		Max. Oil Pressure	17.2 MPa (175 kgf/cm ² , 2490 psi)	
		Sub Frame	Necessary	
12	Rear Blade	Max. Cutting Width	1829 mm (72 in.)	
		Max. Oil Pressure	17.2 MPa (175 kgf/cm ² , 2490 psi)	
13	Front Loader	Max. Lifting Capacity	720 kg (1590 lbs)	850 kg (1880 lbs)
		Max. Oil Pressure	17.7 MPa (180 kgf/cm ² , 2560 psi)	
		Sub Frame	Necessary	
14	Box Blade	Max. Cutting Width	1651 mm (65 in.)	1829 mm (72 in.)
		Max. Weight	400 kg (880 lbs)	470 kg (1040 lbs)
15	Back Hoe	Max. Digging Depth	2286 mm (90 in.)	
		Max. Weight	450 kg (990 lbs)	
		Sub Frame	Necessary	

W1012736

No.	Implement	Remarks	L3830	L4330
16	Snow Blade	Max. Width	1829 mm (72 in.)	2134 mm (84 in.)
		Max. Weight	350 kg (770 lbs)	400 kg (880 lbs)
17	Snow Blower	Max. Working Width	1702 mm (67 in.)	1829 mm (72 in.)
		Max. Weight	280 kg (620 lbs)	330 kg (730 lbs)

■ NOTE

- Implement size may vary depending on soil operating conditions.

No.	Implement	Remarks	L3830	L4330
18	Back Hoe	Max. Weight	430 kg (950 lbs)	525 kg (1160 lbs)
		Max. Digging Depth	2268 mm (90 in.)	2268 mm (90 in.)
14	Box Blade	Max. Weight	470 kg (1040 lbs)	470 kg (1040 lbs)
		Max. Cutting Width	1829 mm (72 in.)	1829 mm (72 in.)
13	Front Loader	Sub Frame	Necessary	Necessary
		Max. Oil Pressure	17.7 MPa (180 kgf/cm ² , 2580 psi)	17.7 MPa (180 kgf/cm ² , 2580 psi)
12	Front Loader	Max. Lifting Capacity	750 kg (1650 lbs)	850 kg (1880 lbs)
		Max. Oil Pressure	17.5 MPa (175 kgf/cm ² , 2490 psi)	17.5 MPa (175 kgf/cm ² , 2490 psi)
11	Front Blade	Sub Frame	Necessary	Necessary
		Max. Oil Pressure	17.5 MPa (175 kgf/cm ² , 2490 psi)	17.5 MPa (175 kgf/cm ² , 2490 psi)
10	Cultivator	Max. Weight	470 kg (1040 lbs)	470 kg (1040 lbs)
		Number of Rows	2	2
9	Manure Spreader	Max. Width	2134 mm (84 in.)	2134 mm (84 in.)
		Max. Capacity	2000 kg (4400 lbs)	2000 kg (4400 lbs)
8	Broad Castor	Max. Weight	100 kg (220 lbs)	100 kg (220 lbs)
		Max. Tank Capacity	300 L (80 U.S. gals., 66 Imp. gals.)	300 L (80 U.S. gals., 66 Imp. gals.)
7	Chisel Plow	Max. Weight	380 kg (840 lbs)	380 kg (840 lbs)
		Max. Width	1829 mm (72 in.)	1829 mm (72 in.)
6	Disc Harrow	Max. Weight	400 kg (880 lbs)	400 kg (880 lbs)
		Max. Harrowing Width	1981 mm (78 in.)	1981 mm (78 in.)
5	Bottom Plow	Max. Size	14 in × 3	14 in × 3
		Max. Tilling Width	1524 mm (60 in.)	1524 mm (60 in.)
3	Sprayer	Full Type	Max. Tank Capacity	1500 L (397 U.S. gals., 324 Imp. gals.)
		Rear Mount	Max. Tank Capacity	400 L (106 U.S. gals., 88 Imp. gals.)
2	Slide Bar	Max. Weight	500 kg (1100 lbs)	500 kg (1100 lbs)
		Max. Cutting Width	2134 mm (84 in.)	2134 mm (84 in.)
1	Flat Mower (Heavy)	Max. Weight	400 kg (880 lbs)	400 kg (880 lbs)
		Max. Cutting Width	1829 mm (72 in.)	1829 mm (72 in.)
Rotary Cutter	Max. Weight	400 kg (880 lbs)	400 kg (880 lbs)	
	Max. Cutting Width	1829 mm (72 in.)	1829 mm (72 in.)	

W1104121

No.	Implement	Remarks	L4630	L5030
1	Trailer	Max. Load Capacity	3000 kg (6600 lbs)	
		Max. Drawbar Load	650 kg (1430 lbs)	
2	Mid-mount	Max. Cutting Width	-	
		Max. Weight	-	
	Rotary-cutter	Max. Cutting Width	1829 mm (72 in.)	2134 mm (84 in.)
		Max. Weight	420 kg (926 lbs)	480 kg (1058 lbs)
	Flail Mower (Heavy)	Max. Cutting Width	1524 mm (60 in.)	1829 mm (72 in.)
		Max. Weight	400 kg (880 lbs)	500 kg (1100 lbs)
	Sickle Bar	Max. Cutting Width	2134 mm (84 in.)	
		Max. Weight	500 kg (1100 lbs)	
3	Rear Mount	Max. Tank-capacity	400 L (106 U.S.gals., 88 Imp.gals.)	500 L (132 U.S.gals., 110 Imp.gals.)
	Pull Type	Max. Tank-capacity	1200 L (317 U.S.gals., 264 Imp.gals.)	2000 L (528 U.S.gals., 440 Imp.gals.)
4	Rotary Tiller	Max. Tilling Width	1524 mm (60 in.)	1829 mm (72 in.)
5	Bottom Plow	Max. Size	14 in. × 2	16 in. × 2
6	Disc-harrow Pull Type	Max. Harrowing Width	1981 mm (78 in.)	2134 mm (84 in.)
		Max. Weight	400 kg (880 lbs)	
7	Chisel Plow	Max. Width	1829 mm (72 in.)	
		Max. Weight	350 kg (770 lbs)	
8	Broad Caster	Max. Tank-capacity	300 L (80 U.S.gals., 66 Imp.gals.)	
		Max. Weight	100 kg (220 lbs)	
9	Manure Spreader	Max. Capacity	2000 kg (4400 lbs)	
10	Cultivator	Max. Width	2134 mm (84 in.)	2438 mm (96 in.)
		Number of Rows	2	4
		Max. Weight	400 kg (880 lbs)	
11	Front Blade	Max. Cutting Width	2134 mm (84 in.)	
		Max. Oil Pressure	17.2 MPa (175 kgf/cm ² , 2490 psi)	
		Sub Frame	Necessary	
12	Rear Blade	Max. Cutting Width	1829 mm (72 in.)	
		Max. Oil Pressure	17.2 MPa (175 kgf/cm ² , 2490 psi)	
13	Front Loader	Max. Lifting Capacity	850 kg (1880 lbs)	
		Max. Oil Pressure	17.7 MPa (180 kgf/cm ² , 2560 psi)	
		Sub Frame	Necessary	
14	Box Blade	Max. Cutting Width	1829 mm (72 in.)	
		Max. Weight	470 kg (1040 lbs)	
15	Back Hoe	Max. Digging Depth	2286 mm (90 in.)	
		Max. Weight	450 kg (990 lbs)	
		Sub Frame	Necessary	

W1012736

No.	Implement	Remarks	L4630	L5030
16	Snow Blade	Max. Width	2134 mm (84 in.)	
		Max. Weight	400 kg (880 lbs)	
17	Snow Blower	Max. Working Width	1829 mm (72 in.)	
		Max. Weight	330 kg (730 lbs)	

- NOTE
- Implement size may vary depending on soil operating conditions.

W1105114

3	Sprayer	Max. Tank Capacity	1500 L (397 U.S. gal.)	2000 L (528 U.S. gal.)
4	Rear Mount	Max. Tank Capacity	108 U.S. gal. (407 imp. gal.)	132 U.S. gal. (505 imp. gal.)
		Max. Tank Capacity	88 imp. gal. (407 U.S. gal.)	110 imp. gal. (505 U.S. gal.)
5	Roller	Max. Tank Capacity	1524 mm (60 in.)	1829 mm (72 in.)
6	Roller	Max. Tank Capacity	1524 mm (60 in.)	1829 mm (72 in.)
7	Roller	Max. Tank Capacity	1524 mm (60 in.)	1829 mm (72 in.)
8	Roller	Max. Tank Capacity	1524 mm (60 in.)	1829 mm (72 in.)
9	Roller	Max. Tank Capacity	1524 mm (60 in.)	1829 mm (72 in.)
10	Roller	Max. Tank Capacity	1524 mm (60 in.)	1829 mm (72 in.)
11	Roller	Max. Tank Capacity	1524 mm (60 in.)	1829 mm (72 in.)
12	Roller	Max. Tank Capacity	1524 mm (60 in.)	1829 mm (72 in.)
13	Roller	Max. Tank Capacity	1524 mm (60 in.)	1829 mm (72 in.)
14	Roller	Max. Tank Capacity	1524 mm (60 in.)	1829 mm (72 in.)
15	Roller	Max. Tank Capacity	1524 mm (60 in.)	1829 mm (72 in.)


1 ENGINE

MECHANISM

CONTENTS

1. FEATURES	1-M1
2. FUEL SYSTEM	1-M2
3. LUBRICATING SYSTEM	1-M3


1. FEATURES



The engine model shown in the table below is adopted in the L30 series tractor. These are 03-M series engine.

Tractor Model	Engine Model
L3130	D1503-MA-E
L3430	D1703-MA-E
L3830	D1803-MA-E
L4330	V2203-MA-E
L4630	V2203-MB-E
L5030	V2403-MA-E


W1012642



- (1) Fuel Overflow Pipe
- (2) Injection Nozzle
- (3) Injection Pipe
- (4) Fuel Tank
- (5) Injection Pump
- (6) Fuel Filter Air Vent Pipe
- (7) Fuel Filter
- (8) Fuel Feed Pump
- (9) Fuel Filter Air Vent Pipe
- (10) Fuel Feed Pump
- (11) Returned Fuel Flow
- (12) Injected Fuel Flow

The fuel system of this tractor is shown in the diagram above. Fuel from the tank flows in the passage as shown by the arrow, and is injected from the nozzle via the fuel injection pump. Overflow fuel returns to the tank. The system includes filter and other concerns to protect it from entrance of air, water and dust. While the engine is running, fuel is led into the injection pump (8) by the fuel feed pump (8) after passing through the fuel filter (7). The fuel camshaft actuates the injection pump and force-feeds fuel to the injection nozzle (2) the injection pipe (3). Fuel is then sprayed through the nozzle into the combustion chamber. The fuel discharged after lubricating and cooling the injection nozzle is returned to the fuel tank (4) automatically through the overflow pipe (1).

2. FUEL SYSTEM



3TLBAB1P054A

- | | | |
|------------------------|----------------------------------|-------------------------------|
| (1) Fuel Overflow Pipe | (4) Fuel Tank | (7) Fuel Filter |
| (2) Injection Nozzle | (5) Injection Pump Air Vent Pipe | (8) Fuel Feed Pump |
| (3) Injection Pipe | (6) Injection Pump | (9) Fuel Filter Air Vent Pipe |

a : Injected Fuel Flow
b : Returned Fuel Flow


The fuel system of this tractor is shown in the diagram above.

Fuel from the tank flows in the passage as shown by the arrows, and is injected from the nozzle via the fuel injection pump. Overflow fuel returns to the tank.

The system includes filters and other concerns to protect it from entrance of air, water and dust.

While the engine is running, fuel is fed into the injection pump (6) by the fuel feed pump (8) after passing through the fuel filter (7). The fuel camshaft actuates the injection pump and force-feeds fuel to the injection nozzle (2) the injection pipe (3). Fuel is then sprayed through the nozzle into the combustion chamber. The fuel discharged after lubricating and cooling the injection nozzle is returned to the fuel tank (4) automatically through the overflow pipe (1).

3. LUBRICATING SYSTEM



- (1) Rocker Arm
- (2) Oil Pressure Switch
- (3) Rocker Arm Shaft
- (4) Valve
- (5) Governor Shaft
- (6) Idle Gear
- (7) Crankshaft
- (8) Oil Pump
- (9) Oil Strainer
- (10) Relief Valve
- (11) Oil Filter Cartridge
- (12) Push Rod
- (13) Tappet
- (14) Camshaft
- (15) Piston
- (16) Connecting Rod
- (17) Oil Cooler

W1012968

A lubricating system consists of an oil strainer (9), oil pump (8), relief valve (10), oil filter cartridge (11), oil cooler (17) and oil pressure switch (2).

The oil pump sucks lubricating oil from the oil pan through the oil strainer and the oil flows down to the oil filter, cartridge where it is further filtered. Then the oil is forced to crankshaft (7), connecting rods (16), idle gear (6), governor shaft (5), camshaft (14) and rocker arm shaft (3) to lubricate each part through the oil gallery.

SERVICING

CONTENTS

1. TROUBLESHOOTING	1-S1
2. SERVICING SPECIFICATIONS	1-S4
3. TIGHTENING TORQUES	1-S11
4. CHECKING, DISASSEMBLING AND SERVICING.....	1-S12
[1] SEPARATING ENGINE FROM TRACTOR	1-S12
[2] ENGINE BODY	1-S26
(1) Checking and Adjusting	1-S26
(2) Disassembling and Assembling	1-S28
(3) Servicing	1-S42
[3] LUBRICATING SYSTEM	1-S61
(1) Checking	1-S61
(2) Servicing	1-S61
[4] COOLING SYSTEM.....	1-S62
(1) Checking and Adjusting	1-S62
[5] FUEL SYSTEM	1-S64
(1) Checking and Adjusting	1-S64

1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
Engine Does Not Start	<ul style="list-style-type: none"> No fuel Air in the fuel system Water in the fuel system 	Replenish fuel Bleed Change fuel and repair or replace fuel system	G-7, 8 G-33 -
	<ul style="list-style-type: none"> Fuel pipe clogged Fuel filter clogged Excessively high viscosity of fuel or engine oil at low temperature Fuel with low cetane number Fuel leak due to loose injection pipe retaining nut Incorrect injection timing Fuel camshaft worn Injection nozzle clogged Injection pump malfunctioning Seizure of crankshaft, camshaft, piston, cylinder or bearing Compression leak from cylinder 	Clean Change Use the specified fuel or engine oil Use the specified fuel Tighten nut Adjust Replace Clean Repair or replace Repair or replace Replace head gasket, tighten cylinder head screw, glow plug and nozzle holder	- G-13 G-7, 8 G-7, 8 1-S29 1-S64 1-S35 - 1-S32 1-S35, S37, S40 1-S29, S30
Starter Does Not Run	<ul style="list-style-type: none"> Improper valve timing Piston and cylinder worn Excessive valve clearance 	Correct or replace timing gear Replace Adjust	1-S34 1-S37 1-S27
	<ul style="list-style-type: none"> Battery discharged Starter malfunctioning Main switch malfunctioning Safety switches improperly adjusted or defective Starter relay defective Wiring disconnected Electronic instrument panel connector disconnected 	Charge Repair or replace Repair or replace Repair or replace Replace Connect Connect	G-24 9-S41 9-S32 9-S34 9-S38 - -
Engine Revolution Is Not Smooth	<ul style="list-style-type: none"> Fuel filter clogged or dirty Air cleaner clogged Fuel leak due to loose injection pipe retaining nut 	Change Clean or change Tighten nut	G-13 G-20 1-S29
	<ul style="list-style-type: none"> Injection pump malfunctioning Incorrect nozzle injection pressure Injection nozzle stuck or clogged Governor malfunctioning 	Repair or replace Adjust Repair or replace Repair	1-S32 1-S65 1-S29 -
Either White or Blue Exhaust Gas Is Observe	<ul style="list-style-type: none"> Excessive engine oil Piston ring and cylinder worn or stuck Incorrect injection timing Deficient compression 	Reduce to the specified level Repair or replace Adjust Adjust top clearance	G-7, 8 1-S38 1-S64 1-S28

W1014322

Symptom	Probable Cause	Solution	Reference Page
Either Black or Dark Gray Exhaust Gas Is Observe	<ul style="list-style-type: none"> • Overload • Low grade fuel used • Fuel filter clogged • Air cleaner clogged • Deficient nozzle injection 	Lessen the load Use the specified fuel Change Clean or change Repair or replace the nozzle	– G-7, 8 G-13 G-20 1-S29
Deficient Output	<ul style="list-style-type: none"> • Incorrect injection timing • Engine's moving parts seem to be seizing • Uneven fuel injection • Deficient nozzle injection • Compression leak 	Adjust Repair or replace Repair or replace the injection pump Repair or replace the nozzle Replace head gasket, tighten cylinder head bolt, glow plug and nozzle holder	1-S64 – 1-S32 1-S29, S65 1-S29, S30
Excessive Lubricant Oil Consumption	<ul style="list-style-type: none"> • Piston ring's gap facing the same direction • Oil ring worn or stuck • Piston ring groove worn • Valve stem and guide worn • Oil leaking due to defective seals or packing 	Shift ring gap direction Replace Replace the piston Replace Replace	1-S38 1-S38 1-S37, S38 1-S31 –
Fuel Mixed Into Lubricant Oil	<ul style="list-style-type: none"> • Injection pump's plunger worn • Deficient nozzle injection • Injection pump broken 	Replace pump element or pump Repair or replace the nozzle Replace	1-S32 1-S29, S65 1-S32
Water Mixed Into Lubricant Oil	<ul style="list-style-type: none"> • Head gasket defective • Cylinder block or cylinder head flawed 	Replace Replace	1-S30 1-S30
Low Oil Pressure	<ul style="list-style-type: none"> • Engine oil insufficient • Oil straight clogged • Relief valve stuck with dirt • Relief valve spring weaken or broken • Excessive oil clearance of crankshaft bearing • Excessive oil clearance of crankpin bearing • Excessive oil clearance of rocker arm • Oil passage clogged • Different type of oil • Oil Pump defective 	Replenish Clean Clean Replace Replace Replace Replace Clean Use the specified type of oil Repair or replace	G-7, 8 1-S36 – – 1-S41 1-S41 1-S30 – G-7, 8 1-S36
High Oil Pressure	<ul style="list-style-type: none"> • Difference type oil • Relief valve defective 	Use the specified type of oil Replace	G-7, 8 –

W1014322

Symptom	Probable Cause	Solution	Reference Page
Engine Overheated	<ul style="list-style-type: none"> Engine oil insufficient Fan belt broken or elongated 	Replenish Change or adjust	G-7, 8 G-21, 1-S25
	<ul style="list-style-type: none"> Coolant insufficient Radiator net and radiator fin clogged with dust Inside of radiator corroded Coolant flow route corroded Radiator cap defective Overload running Head gasket defective Incorrect injection timing Unsuitable fuel used 	Replenish Clean Clean or replace Clean or replace Replace Loosen the load Replace Adjust Use the specified fuel	- - - G-25 1-S63 - 1-S30 1-S64 G-7, 8

W1014322

-	0.25 to 0.70 mm 0.0217 to 0.0278 in.		
-	0.18 to 0.22 mm 0.0071 to 0.0087 in.		Valve Clearance (When Cold)
-	5.12 mm 0.2015 in.	Width (Intake)	Valve Seat
-	5.12 mm 0.2015 in.	Width (Exhaust)	
-	1.047 rad 60°	Angle (Intake)	Valve Seat
-	0.788 rad 45°	Angle (Exhaust)	
-	1.047 rad 60°	Angle (Intake)	Valve Face
-	0.788 rad 45°	Angle (Exhaust)	
0.1 mm 0.0039 in.	0.040 to 0.070 mm 0.00157 to 0.00278 in.	Clearance	Valve Stem to Valve Guide
-	7.980 to 7.975 mm 0.31339 to 0.31308 in.	O.D.	Valve Stem
-	8.018 to 8.030 mm 0.31562 to 0.31614 in.	I.D.	Valve Guide
-	0.05 mm 0.0020 in.	Protrusion	Valve Recessing
0.4 mm 0.0157 in.	0.15 mm 0.0059 in.	Recessing	

2. SERVICING SPECIFICATIONS

ENGINE BODY

Item		Factory Specification	Allowable Limit
Cylinder Head Surface	Flatness	—	0.05 mm / 500 mm 0.0020 in. / 19.69 in.
Compression Pressure (When Cranking with Starting Motor)		3.53 to 4.02 MPa / 290 min ⁻¹ (rpm) 36 to 41 kgf/cm ² / 290 min ⁻¹ (rpm) 512 to 583 psi / 290 min ⁻¹ (rpm)	2.55 MPa / 290 min ⁻¹ (rpm) 26 kgf/cm ² / 290 min ⁻¹ (rpm) 370 psi / 290 min ⁻¹ (rpm)
Difference among Cylinders		—	10 % or less
Top Clearance		0.55 to 0.70 mm 0.0217 to 0.0276 in.	—
Valve Clearance (When Cold)		0.18 to 0.22 mm 0.0071 to 0.0087 in.	—
Valve Seat	Width (Intake)	2.12 mm 0.0835 in.	—
	Width (Exhaust)	2.12 mm 0.0835 in.	—
Valve Seat	Angle (Intake)	1.047 rad. 60 °	—
	Angle (Exhaust)	0.785 rad. 45 °	—
Valve Face	Angle (Intake)	1.047 rad. 60 °	—
	Angle (Exhaust)	0.785 rad. 45 °	—
Valve Stem to Valve Guide	Clearance	0.040 to 0.070 mm 0.00157 to 0.00276 in.	0.1 mm 0.0039 in.
Valve Stem	O.D.	7.960 to 7.975 mm 0.31339 to 0.31398 in.	—
Valve Guide	I.D.	8.015 to 8.030 mm 0.31555 to 0.31614 in.	—
Valve Recessing	Protrusion	0.05 mm 0.0020 in.	—
	Recessing	0.15 mm 0.0059 in.	0.4 mm 0.0157 in.

W1013874

ENGINE BODY (Continued)

Item		Factory Specification	Allowable Limit	
Valve Timing (Intake Valve)	D1503-M	Open	0.14 rad. (8 °) before T.D.C.	—
		Close	0.35 rad. (20 °) after B.D.C.	—
	D1703-M D1803-M V2203-M V2403-M	Open	0.21 rad. (12 °) before T.D.C.	—
		Close	0.63 rad. (36 °) after B.D.C.	—
Valve Timing (Exhaust Valve)	D1503-M	Open	1.05 rad. (60 °) before B.D.C.	—
		Close	0.21 rad. (12 °) after T.D.C.	—
	D1703-M D1803-M V2203-M V2403-M	Open	1.00 rad. (57 °) before B.D.C.	—
		Close	0.21 rad. (12 °) after T.D.C.	—
Valve Spring	Free Length	41.7 to 42.2 mm 1.6417 to 1.6614 in.	41.2 mm 1.6220 in.	
	Setting Load / Setting Length	117.6 N / 35.0 mm 12.0 kgf / 35.0 mm 26.4 lbs / 1.3780 in.	100.0 N / 35.0 mm 10.2 kgf / 35.0 mm 22.5 lbs / 1.3780 in.	
	Tilt	—	1.0 mm 0.039 in.	
Rocker Arm Shaft to Rocker Arm	Clearance	0.016 to 0.045 mm 0.00063 to 0.00177 in.	0.1 mm 0.0039 in.	
Rocker Arm Shaft	O.D.	13.973 to 13.984 mm 0.55012 to 0.55055 in.	—	
Rocker Arm	I.D.	14.000 to 14.018 mm 0.55118 to 0.55189 in.	—	
Push Rod	Alignment	—	0.25 mm 0.0098 in.	
Tappet to Tappet Guide	Clearance	0.020 to 0.062 mm 0.00079 to 0.00244 in.	0.07 mm 0.0028 in.	
Tappet	O.D.	23.959 to 23.980 mm 0.94327 to 0.94410 in.	—	
Tappet Guide	I.D.	24.000 to 24.021 mm 0.94488 to 0.94571 in.	—	

W1013874

ENGINE BODY (Continued)

Item		Factory Specification	Allowable Limit
Timing Gear Crank Gear to Idle Gear	Backlash	0.0415 to 0.1122 mm 0.00163 to 0.00442 in.	0.15 mm 0.0059 in.
Idle Gear to Cam Gear	Backlash	0.0415 to 0.1154 mm 0.00163 to 0.00454 in.	0.15 mm 0.0059 in.
Idle Gear to Injection Pump Gear	Backlash	0.0415 to 0.1154 mm 0.00163 to 0.00454 in.	0.15 mm 0.0059 in.
Crank Gear to Oil Pump Gear	Backlash	0.0415 to 0.1090 mm 0.00163 to 0.00429 in.	0.15 mm 0.0059 in.
Idle Gear to Balancer Gear	Backlash (Intake side)	0.0350 to 0.1160 mm 0.00138 to 0.00457 in.	0.15 mm 0.0059 in.
	Backlash (Exhaust side)	0.0350 to 0.1160 mm 0.00138 to 0.00457 in.	0.15 mm 0.0059 in.
Idle Gear	Side Clearance	0.12 to 0.48 mm 0.0047 to 0.0189 in.	0.9 mm 0.0354 in.
Idle Gear Shaft to Idle Gear Bushing	Clearance	0.025 to 0.066 mm 0.00098 to 0.00260 in.	0.1 mm 0.0039 in.
Idle Gear Shaft	O.D.	37.959 to 37.975 mm 1.49445 to 1.49508 in.	—
Idle Gear Bushing	I.D.	38.000 to 38.025 mm 1.49606 to 1.49704 in.	—
Camshaft	Side Clearance	0.07 to 0.22 mm 0.0028 to 0.0087 in.	0.3 mm 0.0118 in.
Camshaft	Alignment	—	0.01 mm 0.0004 in.
Cam	Height (Intake / Exhaust)	33.90 mm 1.3346 in.	33.85 mm 1.3327 in.
Camshaft Journal to Cylinder Block Bore	Clearance	0.050 to 0.091 mm 0.00197 to 0.00358 in.	0.15 mm 0.0059 in.
Camshaft Journal	O.D.	39.934 to 39.950 mm 1.57221 to 1.57284 in.	—
Cylinder Block Bore	I.D.	40.000 to 40.025 mm 1.57480 to 1.57579 in.	—
Balancer Shaft	Side Clearance	0.07 to 0.22 mm 0.0028 to 0.0087 in.	0.3 mm 0.0118 in.
Balancer Shaft Journal 1 to Balancer Shaft Bearing 1	Clearance	0.030 to 0.111 mm 0.00118 to 0.00437 in.	0.2 mm 0.0079 in.
Balancer Shaft Journal 1	O.D.	43.934 to 43.950 mm 1.72968 to 1.73031 in.	—
Balancer Shaft Bearing 1	I.D.	43.980 to 44.045 mm 1.73149 to 1.73405 in.	—

W1013874

ENGINE BODY (Continued)

Item		Factory Specification	Allowable Limit
Balancer Shaft Journal 2 to Balancer Shaft Bearing 2 (Balancer Model Only)		Clearance 0.030 to 0.111 mm 0.00118 to 0.00437 in.	0.2 mm 0.0079 in.
Balancer Shaft Journal 2	O.D.	41.934 to 41.950 mm 1.65094 to 1.65157 in.	—
Balancer Shaft Bearing 2	I.D.	41.980 to 42.045 mm 1.65275 to 1.65531 in.	—
Balancer Shaft Journal 3 to Balancer Shaft Bearing 3 (Balancer Model Only)		Clearance 0.020 to 0.094 mm 0.00079 to 0.00370 in.	0.2 mm 0.0079 in.
Balancer Shaft Journal 3	O.D.	21.947 to 21.960 mm 0.86405 to 0.86456 in.	—
Balancer Shaft Bearing 3	I.D.	21.980 to 22.041 mm 0.86535 to 0.86775 in.	—
Piston Pin Bore		I.D. 25.000 to 25.013 mm 0.98425 to 0.98476 in.	25.05 mm 0.9862 in.
Second Ring to Ring Groove	D1503-M	Clearance 0.093 to 0.120 mm 0.0037 to 0.0047 in.	0.2 mm 0.0079 in.
	D1703-M	0.093 to 0.128 mm	0.2 mm
	D1803-M	0.0037 to 0.0050 in.	0.0079 in.
	V2203-M V2403-M		
Oil Ring to Ring Groove		Clearance 0.020 to 0.060 mm 0.0008 to 0.0021 in.	0.15 mm 0.0059 in.
Top Ring	D1503-M	Ring Gap 0.20 to 0.35 mm 0.0079 to 0.0138 in.	1.25 mm 0.0492 in.
	D1703-M	0.20 to 0.40 mm	1.25 mm
	D1803-M	0.0079 to 0.0157 in.	0.0492 in.
	V2203-M V2403-M		
Second Ring		Ring Gap 0.30 to 0.45 mm 0.0118 to 0.0177 in.	1.25 mm 0.0492 in.
Oil Ring		Ring Gap 0.25 to 0.45 mm 0.0098 to 0.0177 in.	1.25 mm 0.0492 in.
Connecting Rod		Alignment —	0.05 mm 0.0020 in.
Piston Pin to Small End Bushing		Clearance 0.014 to 0.038 mm 0.00055 to 0.00150 in.	0.15 mm 0.0059 in.
Piston Pin	O.D.	25.002 to 25.011 mm 0.98433 to 0.98468 in.	—
Small End Bushing	I.D.	25.025 to 25.040 mm 0.98523 to 0.98582 in.	—
Crankshaft		Alignment —	0.02 mm 0.00079 in.

W1013874

ENGINE BODY (Continued)

Item		Factory Specification	Allowable Limit
Crankshaft Journal to Crankshaft Bearing 1		Oil Clearance 0.040 to 0.118 mm 0.00157 to 0.00465 in.	0.2 mm 0.0079 in.
Crankshaft Journal	D1503-M D1703-M V2203-M	O.D. 51.921 to 51.940 mm 2.04413 to 2.04488 in.	—
	D1803-M V2403-M	59.921 to 59.940 mm 2.35909 to 2.35984 in.	—
Crankshaft Bearing 1	D1503-M D1703-M V2203-M	I.D. 51.980 to 52.039 mm 2.04646 to 2.04878 in.	—
	D1803-M V2403-M	59.980 to 60.039 mm 2.36142 to 2.36374 in.	—
Crankshaft Journal to Crankshaft Bearing 2		Oil Clearance 0.040 to 0.104 mm 0.00157 to 0.00409 in.	0.2 mm 0.0079 in.
Crankshaft Journal	D1503-M D1703-M V2203-M	O.D. 51.921 to 51.940 mm 2.04413 to 2.04488 in.	—
	D1803-M V2403-M	59.921 to 59.940 mm 2.35909 to 2.35984 in.	—
Crankshaft Bearing 2	D1503-M D1703-M V2203-M	I.D. 51.980 to 52.025 mm 2.04646 to 2.04823 in.	—
	D1803-M V2403-M	59.980 to 60.025 mm 2.36142 to 2.36318 in.	—
Crankpin to Crankpin Bearing		Oil Clearance 0.025 to 0.087 mm 0.00098 to 0.00343 in.	0.2 mm 0.0079 in.
Crankpin		O.D. 46.959 to 46.975 mm 1.84878 to 1.84941 in.	—
Crankpin Bearing		I.D. 47.000 to 47.046 mm 1.85039 to 1.85220 in.	—
Crankshaft	D1503-M D1703-M V2203-M	Side Clearance 0.15 to 0.35 mm 0.0059 to 0.0138 in.	0.5 mm 0.0197 in.
	D1803-M V2403-M	0.15 to 0.31 mm 0.0059 to 0.0122 in.	0.5 mm 0.0197 in.
Crankshaft Sleeve		Wear —	0.1 mm 0.0039 in.

W1029676

ENGINE BODY (Continued)

	Item		Factory Specification	Allowable Limit
Cylinder Bore [Standard]	D1503-M	I.D.	83.000 to 83.022 mm 3.26772 to 3.26858 in.	+ 0.15 mm + 0.0059 in.
	D1703-M D1803-M V2203-M V2403-M		87.000 to 87.022 mm 3.42519 to 3.42606 in.	+ 0.15 mm + 0.0059 in.
[Oversize]	D1503-M	I.D.	83.250 to 83.272 mm 3.27756 to 3.27843 in.	+ 0.15 mm + 0.0059 in.
	D1703-M D1803-M V2203-M V2403-M		87.250 to 87.272 mm 3.43503 to 3.43590 in.	+ 0.15 mm + 0.0059 in.

W1013874

LUBRICATING SYSTEM

Engine Oil Pressure	At Idle Speed	98 kPa or more 1.0 kgf/cm ² or more 14 psi or more	49 kPa 0.5 kgf/cm ² 7 psi
	At Rated Speed	294 to 441 kPa 3.0 to 4.5 kgf/cm ² 43 to 64 psi	245 kPa 2.5 kgf/cm ² 36 psi
Engine Oil Pressure Switch	Working Pressure	49 kPa 0.5 kgf/cm ² 7 psi	—
Inner Rotor to Outer Rotor	Clearance	0.03 to 0.14 mm 0.0012 to 0.0055 in.	0.2 mm 0.0079 in.
Outer Rotor to Pump Body	Clearance	0.11 to 0.19 mm 0.0043 to 0.0075 in.	0.25 mm 0.0098 in.
Inner Rotor to Cover	Clearance	0.105 to 0.150 mm 0.00413 to 0.00591 in.	0.2 mm 0.0079 in.

W1013973

COOLING SYSTEM

Item	Factory Specification	Allowable Limit
Fan Belt	Tension 7.0 to 9.0 mm (0.28 to 0.35 in.) deflection at 98 N (10 kgf, 22 lbs) of force	—
Thermostat	Valve Opening Temperature (At Beginning)	69.5 to 72.5 °C 157.1 to 162.5 °F
	Valve Opening Temperature (Opened Completely)	85 °C 185 °F
Radiator	Water Tightness	No leaks at 137 kPa 1.4 kgf/cm ² 20 psi
Radiator Cap	Pressure Falling Time	10 seconds or more for pressure falling from 88 to 59 kPa from 0.9 to 0.6 kgf/cm ² from 13 to 9 psi

W1013874

FUEL SYSTEM

Injection Pump	Injection Timing	0.297 to 0.331 rad. (17 to 19 °) before T.D.C.	—
Pump Element	Fuel Tightness	—	14.7 MPa 150 kgf/cm ² 2133 psi
Delivery Valve	Fuel Tightness	10 seconds or more for pressure falling from 14.7 to 13.7 MPa from 150 to 140 kgf/cm ² from 2133 to 1990 psi	5 seconds for pressure falling from 14.7 to 13.7 MPa from 150 to 140 kgf/cm ² from 2133 to 1990 psi
Injection Nozzle	Injection Pressure	13.73 to 14.71 MPa 140 to 150 kgf/cm ² 1991 to 2133 psi	—
Injection Nozzle Valve Seat	Valve Seat Tightness	When the pressure is 12.75 MPa (130 kgf/cm ² , 1849 psi), the valve seat must be fuel tightness.	—

W1013973

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-9.)

Item	N·m	kgf·m	ft-lbs
ROPS lower connector mounting screw	103 to 118	10.5 to 12.0	75.9 to 86.8
ROPS plate mounting screw (M14 × 40)	138 to 147	14.0 to 15.0	102 to 108
(M14 × 30)	167 to 196	17.0 to 20.0	123 to 145
Step mounting bolt and nut	124 to 147	12.6 to 15.0	91.1 to 108
Floor seat mounting bolt and nut	196 to 225	20 to 23	145 to 166
Compressor mounting screw	24.5 to 29.4	2.5 to 3.0	18.1 to 21.7
Muffler mounting screw	31.4 to 37.2	3.2 to 3.8	23.1 to 27.5
Cabin mounting bolt and nut	124 to 147	12.6 to 15.0	91.1 to 108
Joint bolt for main delivery pipe 1	49 to 69	5.0 to 7.0	36.1 to 50.6
Joint bolt for PTO delivery pipe	34 to 39	3.5 to 4.0	25.3 to 28.9
Joint bolt for oil cooler pipe	34 to 39	3.5 to 4.0	25.3 to 28.9
Engine and clutch housing mounting screw and nut	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Engine and clutch housing mounting stud bolt	39.2 to 49.0	4.0 to 5.0	28.9 to 36.2
Joint bolt for power steering delivery pipe	39.2 to 49.0	4.0 to 5.0	28.9 to 36.1
Cap nut of power steering delivery pipe	49.0 to 58.8	5.0 to 6.0	36.1 to 43.4
Front axle frame mounting screw (7T)	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
(9T)	102.9 to 117.6	10.5 to 12.0	76.0 to 86.8
Clutch mounting screw	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Alternator mounting screw (M10)	39.2 to 44.1	4.0 to 4.5	28.9 to 32.5
Tension adjusting screw (M8)	17.6 to 20.6	1.8 to 2.1	13.0 to 15.2

W1012736

Item	Size x Pitch	N·m	kgf·m	ft-lbs
Cylinder head cover screw	M6 × 1.0	6.9 to 11.3	0.7 to 1.15	5.1 to 8.32
* Cylinder head screws	M11 × 1.25	93.1 to 98.0	9.5 to 10.0	68.7 to 72.3
* Main bearing case screws 1	M9 × 1.25	46.1 to 50.9	4.7 to 5.2	34.0 to 37.6
* Main bearing case screws 2	M10 × 1.25	68.6 to 73.5	7.0 to 7.5	50.6 to 54.2
* Flywheel screws	M12 × 1.25	98.0 to 107.8	10.0 to 11.0	72.3 to 79.5
* Connecting rod screws	M8 × 1.0	44.1 to 49.0	4.5 to 5.0	32.5 to 36.2
* Rocker arm bracket screw	M8 × 1.25	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Fan drive pulley mounting nut	—	137.3 to 156.9	14.0 to 16.0	101.3 to 115.7
* Bearing case cover screws	M8 × 1.25	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Glow plugs	M10 × 1.25	19.6 to 24.5	2.0 to 2.5	14.5 to 18.1
Nozzle holder assembly	M20 × 2.0	49.0 to 68.6	5.0 to 7.0	36.2 to 50.6
Nozzle holder	—	34.3 to 39.2	3.5 to 4.0	25.3 to 28.9
Oil Switch taper screw	PT 1/8	14.7 to 19.6	1.5 to 2.0	10.8 to 14.5
Injection pipe retaining nuts	M12 × 1.5	24.5 to 34.3	2.5 to 3.5	18.1 to 25.3
Overflow pipe assembly retaining nuts	—	19.6 to 24.5	2.0 to 2.5	14.5 to 18.1
Camshaft set screw	M8 × 1.25	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Balancer shaft set screw	M8 × 1.25	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Hi-idling body	—	44.1 to 49.0	4.5 to 5.0	32.6 to 36.3




■ NOTE

- For * marked screws, bolts and nuts on the table, apply engine oil to their threads and seats before tightening.
- The letter "M" in Size x Pitch means that the screw, bolt or nut dimension stands for metric. The size is the nominal outside diameter in mm of the threads. The pitch is the nominal distance in mm between two threads.

W1013236

4. CHECKING, DISASSEMBLING AND SERVICING

[1] SEPARATING ENGINE FROM TRACTOR



Draining Engine Oil

1. Start and warm up the engine for approx. 5 minutes.
2. Place an oil pan underneath the engine.
3. Remove the drain plugs (1) to drain oil.
4. Screw in the drain plugs (1).

(When refilling)

- Fill the engine oil up to the upper line on the dipstick (2).

■ IMPORTANT

- **Never mix two different type of oil.**
- **Use the proper SAE Engine Oil according to ambient temperature.**

Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7, 8.)

Engine oil capacity	L3130	5.7 L
	L3430	6.0 U.S.qts.
	L3830	5.0 Imp.qts.
	L4330	8.2 L
	L4630	8.7 U.S.qts.
	L5030	7.2 Imp.qts.

(1) Drain Plug

(2) Dipstick



(3) Oil Inlet Plug

(A) L3130, L3430, L4330, L4630, L5030

(B) L3830

(C) Oil level is acceptable within this range.

W1013940



Draining the Transmission Fluid

1. Place oil pans underneath the transmission case.
2. Remove the drain plugs (1).
3. Drain the transmission fluid.
4. Reinstall the drain plugs (1).

(When refilling)

- Fill up from filling port after removing the filling plug (2) until reaching the upper notch on the dipstick (3).
- After running the engine for few minutes, stop it and check the oil level again, add the fluid to prescribed level if it is not correct level.

Transmission fluid capacity	L3130	42 L
	L3430	11.1 U.S.gals. 9.2 Imp.gals.
	L3830 L4330 L4630	43 L 11.4 U.S.gals. 9.5 Imp.gals.
	L5030	45 L 11.9 U.S.gals. 9.9 Imp.gals.

IMPORTANT



- Use only KUBOTA SUPER UDT fluid. Use of other oils may damage the transmission or hydraulic system. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7, 8.)
- Do not mix different brands of fluid together.

- (1) Drain Plugs
(2) Filling Plug
(3) Dipstick

(A) Oil level is acceptable within this range.

W1014221





Draining Coolant

CAUTION

- **Never remove the radiator cap until coolant temperature is well below its boiling point. Then loosen cap slightly to the stop to relieve any excess pressure before removing cap completely.**

1. Stop the engine and let cool down.
2. Loosen the drain plug (3) to drain the coolant.
3. Remove the radiator cap (1) to completely drain the coolant.
4. After all coolant is drained, retighten the drain plug (3).

(When refilling)

- Fill the coolant between the “FULL” and “LOW” marks of recovery tank (2).

Coolant capacity (with recovery tank)	L3130 L3430 (ROPS)	6.0 L 6.3 U.S.qts. 5.3 Imp.qts.
	L3430 (CABIN)	7.2 L 7.6 U.S.qts. 6.3 Imp.qts.
	L3830 L4330 (ROPS) L4630 (ROPS)	7.5 L 7.9 U.S.qts. 6.6 Imp.qts.
	L4330 (CABIN) L4630 (CABIN)	8.7 L 9.2 U.S.qts. 7.7 Imp.qts.
	L5030 (ROPS)	8.0 L 8.5 U.S.qts. 7.0 Imp.qts.
	L5030 (CABIN)	9.2 L 9.7 U.S.qts. 8.1 Imp.qts.

- (1) Radiator Cap
- (2) Recovery Tank
- (3) Drain Plug

A : FULL
B : LOW

W10314120



Battery, Front Grill, Skirt and Bonnet


1. Open the bonnet and disconnect the battery negative cable.
2. Disconnect the head light connector and remove the front grill (4).
3. Remove the left and right side skirts (3).
4. Disconnect window washer hoses (2). (Cabin model only.)
5. Remove the bonnet (1).

NOTE

- **When disconnecting the battery cords, disconnect the negative cord first, when connecting, positive cord first.**

- (1) Bonnet
- (2) Window Washer Hose
- (3) Skirt
- (4) Front Grill

W1057856




ROPS

1. Remove the lower connector (2).
2. Remove the plate mounting screws (4), (8).
3. Remove the upper frame (1) from ROPS lower frame (5).

(When reassembling)

■ **NOTE**



- Do not firmly tighten all screws until most components are attached.



Tightening torque	Lower connector mounting screw (3)	103 to 118 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Plate mounting screw (4)	138 to 147 N·m 14.0 to 15.0 kgf·m 102 to 108 ft-lbs
	Plate mounting screw (8)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft-lbs

(Reference)





Tightening torque	Upper connector mounting screw (9)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft-lbs
	Fulcrum bolt and nut (11)	118 to 137 N·m 12.0 to 14.0 kgf·m 86.8 to 102 ft-lbs



- | | |
|---|---|
| <ul style="list-style-type: none"> (1) Upper Frame (2) Lower Connector (3) Screw (M12 × 65) (4) Screw (M14 × 40) (5) Lower Frame (6) Plate (7) Connector (8) Screw (M14 × 30) | <ul style="list-style-type: none"> (9) Screw (M14 × 30) (10) Upper Connector (11) Fulcrum Bolt and Nut (12) Lock Bolt <p>A : Rigid Type
B : Foldable Type</p> |
|---|---|

W1058013





Steering Joint, Heater Hoses and Electric Wiring

1. Remove the tank frame support (2).
2. Remove the universal joint bolt (10) and steering joint support (3), and then remove the steering joint (2).
3. Disconnect the hand accelerator wire and foot accelerator wire (7). (A foot accelerator is not equipped in HST model.)
4. Disconnect the wiring connectors for engine stop solenoid (8), engine tachometer sensor (9) and glow plug.
5. Disconnect the heater hoses (4), and then reconnect their hoses to make loop. (Cabin model only.)

NOTE

- Put a mark to the each heater hose before disconnecting.
6. Disconnect the wiring connector for window washer tank (5) and compressor 1P connector (6). (Cabin model only.)
 7. Disconnect the brake pedal rod.



(When reassembling)

- When accelerator wire is installed, adjust the wiring length as hit both the idling speed adjusting bolt and the maximum speed adjusting bolt by lever within the stroke of the accelerator lever.
- Set the steering joint (1) by the joint support (3) so that the steering wheel is turned lightly.
- Be sure to check and adjust the brake pedal free travel. (See page G-16.)

- (1) Steering Joint
- (2) Tank Frame Support
- (3) Steering Joint Support
- (4) Heater Hose
- (5) Window Washer Tank
- (6) 1P Connector

- (7) Accelerator Wire
 - (8) Engine Stop Solenoid
 - (9) Engine Tachometer Sensor
 - (10) Universal Joint Bolt
- [A] ROPS Model (HST)
[B] CABIN Model (GST)

W1014863



Clutch Rod, Brake Pedal Rod and Electric Wiring

1. Disconnect the brake pedal rod (5) and clutch rod (4).
2. Disconnect the wiring connectors for alternator (1), coolant temperature sensor (9), oil pressure switch (2), fuel unit (3), starter motor (6) and battery.
3. Remove the clamps and ground earth of wiring harness and collect wiring harness to the step or cabin.
4. Remove the clamps (7) of A/C hoses (8). (Cabin model only.)

(When reassembling)





- Be sure to check and adjust the clutch and brake pedal free travel. (See page G-16, 22.)

- (1) Alternator
- (2) Oil Pressure Switch
- (3) Fuel Unit
- (4) Clutch Rod
- (5) Brake Pedal Rod
- (6) Starter Motor

- (7) Clamps
- (8) A/C Hoses
- (9) Coolant Temperature Sensor

[A] ROPS Model
[B] Cabin Model

W1061165



Seat, Seat Bracket and Lever Grips

1. Remove the seat.
2. Disconnect the seat switch connector (3) and remove the seat bracket (1) with seat suspension (6).
3. Remove the front wheel drive lever (9).

(Manual Transmission Model)

4. Remove the lever grip for position control lever (2), range gear shift lever (4) and main gear shift lever (5).

(GST Model)

4. Remove the lever grip for position control lever (2) and creep shift lever (7) (if equipped).

(HST Model)

4. Remove the lever grip for position control lever (2), range gear shift lever (4) and cruise control lever (10).

- (1) Seat Bracket
 (2) Position Control Lever
 (3) Seat Switch Connector
 (4) Range Gear Shift Lever
 (5) Main Gear Shift Lever
 (6) Seat Suspension
 (7) Creep Shift Lever

- (8) GST Lever
 (9) Front Wheel Drive Lever
 (10) Cruise Control Lever

A : Manual Transmission Model

B : GST Model

C : HST Model

W1061567

Differential Lock Rod and Lowering Speed Adjusting Knob

1. Disconnect the differential lock rod (1).

(Reference)






- As for location of differential lock rod (1), it is at right side for manual transmission and GST model, and left side for HST model.

2. Remove the lowering speed adjusting knob (2).

- (1) Differential Lock Rod

- (2) Lowering Speed Adjusting Knob

W1063358



Electric Connector for GST

1. Disconnect the ECU connector (1).
2. Disconnect the GST lever sensor connector (2).
3. Remove the GST valve cover.
4. Disconnect the pressure switch connector (4), proportional reducing valve connector (5), solenoid valve connector (6), oil temperature sensor connector (8) and ground cables (7).

(Reference)

- The ground cable (7) is at position where the manual transmission model is the same.

- | | |
|--|---|
| (1) ECU Connector | (5) Proportional Reducing Valve Connector |
| (2) GST Lever Sensor Connector | (6) Solenoid Valve Connector |
| (3) Wiring Harness of GST Lever Sensor | (7) Ground Cable |
| (4) Pressure Switch Connector | (8) Oil Temperature Sensor Connector |

W1063971

Electric Connector for HST

1. Remove the lowering speed adjusting knob (4).
2. Disconnect the differential lock rod (2).
3. Disconnect the range gear shift lever sensor connector (3).
4. Disconnect the cruise switch connector (1).
5. Disconnect the HST pedal neutral switch connector (5).
6. Disconnect the ground earth (a).

- | | |
|---|--|
| (1) Cruise Switch Connector | (4) Lowering Speed Adjusting Knob |
| (2) Differential Lock Pedal | (5) HST Pedal Neutral Switch Connector |
| (3) Range Gear Shift Lever Sensor Connector | (a) Ground earth is connected here |

W1064315

PTO Shift Wire and Electric Connector


1. Disconnect the PTO shift wire (2) at the PTO clutch valve lever (4).
2. Disconnect the traveling speed sensor connector (1).

(When reassembling)

- When connecting the PTO shift wire (2) to the lever (4), be sure to adjust the length of wire as follows.
 1. Set the PTO shift lever to **OFF (Neutral)** position.
 2. Loosen the lock nut (3) of wire, and connect wire to the clutch valve lever (4), and then place the wire to the hook.
 3. Tighten the lock nut (3) clockwise (pull the wire), and lock the nut just before the lever moves.

- | | |
|--------------------------------------|----------------------------|
| (1) Traveling Speed Sensor Connector | (3) Lock Nut |
| (2) PTO Shift Wire | (4) PTO Clutch Valve Lever |

W1064487



Shuttle Switch Connector (Manual and GST Model)

1. Remove the panel cover and steering post cover.
2. Disconnect the shuttle switch connector (1).

(1) Shuttle Switch Connector

W1064666




Cruise Control Release Wire (HST Model)

1. Disconnect the cruise control release wire (1).
- (When reassembling)**

- Be sure to adjust the cruise control release wire (1). (See page 3-S95.)

(1) Cruise Control Release Wire

W1065090




Step and Floor Seat (ROPS Model)

1. Disconnect the panel frame connector (1) from fuel tank frame.
2. Remove the step and floor seat mounting bolt and nut.
3. Dismount the step, fender, floor seat and panel frame as a unit after checking whether there is forgetting to disconnect wiring.

(When reassembling)

- Be sure to set the washers and rubber plates of the floor seat and step mounting bolt at an original positions as shown in figure.
- Before mounting the floor seat and step, be sure to set both the shuttle lever rod and the shuttle arm to the neutral position, and then connect the shuttle lever rod securely. (Manual and GST model)







Tightening torque	Step mounting bolt and nut	124 to 147 N·m 12.6 to 15.0 kgf·m 91.1 to 108 ft-lbs
	Floor seat mounting bolt and nut	196 to 225 N·m 20 to 23 kgf·m 145 to 166 ft-lbs

- (1) Panel Frame Connector
- (2) Floor Seat
- (3) Bolt
- (4) Rubber Plate
- (5) Washer
- (6) Spring Washer

- (7) Nut
- (8) Step

F : Front Side
R : Rear Side

W1065411



Air Conditioner Parts (Cabin Model)

1. Remove the muffler (2).
2. Remove the air conditioner belt (4) and remove the compressor (1) mounting screw.
3. Remove the recovery tank (6) and window washer tank (7).
4. Disconnect the air cleaner hose (8).
5. Disconnect the recovery tank hose (5).
6. Disconnect the radiator upper hose (3).
7. Remove the oil cooler mounting screw. (HST model only)
8. Remove the battery (10).
9. Remove the battery stay mounting bolt.
10. Take out the compressor (1), condenser (11), receiver (12), hoses (13), battery stay (9) and etc. as a unit.

(When reassembling)

- After reassembling the compressor, be sure to adjust the air conditioner belt tension. (See page G-28.)

Tightening torque	Compressor mounting screw	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft·lbs
	Muffler mounting screw	31.4 to 37.2 N·m 3.2 to 3.8 kgf·m 23.1 to 27.5 ft·lbs

- (1) Compressor
- (2) Muffler
- (3) Radiator Upper Hose
- (4) Air Conditioner Belt
- (5) Recovery Tank Hose
- (6) Recovery Tank
- (7) Window Washer Tank

- (8) Air Cleaner Hose
- (9) Battery Stay
- (10) Battery
- (11) Condenser
- (12) Receiver
- (13) Air Conditioner Hose

W1015306

Cabin Assembly

1. Remove the outer roof of cabin.
2. Support the cabin with nylon straps (1) and hoists.
3. Loosen and remove the cabin mounting bolts (2) and nuts (9).
4. Dismounting the cabin from tractor body.

NOTE

- Lift the cabin while making sure it does not catch on anything.



(When reassembling)

- Be sure to install the washers and mount rubbers, etc. in their original positions.
- Before mounting the cabin, be sure to set both the shuttle lever rod and the shuttle arm to the neutral position, and then connect the shuttle lever rod securely. (GST model)

Tightening torque	Cabin mounting bolt and nut	124 to 147 N·m 12.6 to 15.0 kgf·m 91.1 to 108 ft·lbs
-------------------	-----------------------------	--

- (1) Nylon Straps
 - (2) Bolt
 - (3) Plate
 - (4) Mount Rubber
 - (5) Collar
 - (6) Plain Washer (M14)
 - (7) Washer
 - (8) Spring Washer
 - (9) Nut
- F : Front Side**
R : Rear Side

W1067482



Hydraulic Pipes

1. Remove the main delivery pipe 1 (2).
2. Remove the PTO delivery pipe (3). (Manual and GST model)
3. Disconnect the suction hose (1) from hydraulic pump.
4. Remove the joint bolt (4) of oil cooler pipe (5). (HST model)

(When reassembling)


Tightening torque	Joint bolt for main delivery pipe 1 to front hydraulic block	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Joint bolt for PTO delivery pipe	34 to 39 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft-lbs
	Joint bolt for oil cooler pipe	34 to 39 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft-lbs

- (1) Suction Hose
- (2) Main Delivery Pipe 1
- (3) PTO Delivery Pipe
- (4) Joint Bolt

(5) Oil Cooler Pipe

[A] GST Model
[B] HST Model

W1067766



Propeller Shaft (4WD Only)

1. Slide the propeller shaft cover (4) and (8) after removing the screws (7).
2. Tap out the spring pins (2), (6) and slide the couplings (1), (5) and then remove the propeller shaft with covers (4), (8).


(When reassembling)


- Apply grease to the splines of propeller shaft 1 (3).

- (1) Coupling
- (2) Spring Pin
- (3) Propeller Shaft 1
- (4) Propeller Shaft Cover

- (5) Coupling
- (6) Spring Pin
- (7) Screws
- (8) Propeller Shaft Cover

W1068780





3TLABAB1P044A

Separating Engine and Clutch Housing


1. Place the disassembling stand under the engine and clutch housing case.
2. Remove the fuel tank support mounting screws.
3. Remove the engine and clutch housing mounting screws and nuts.
4. Separate the engine and clutch housing while lifting up the tank frame.

(When reassembling)

- Apply grease to the spline of clutch shaft.
- Apply liquid gasket (Three Bond 1211 or equivalent) to joint face of the flywheel housing and clutch housing.

Tightening torque	Engine and clutch housing mounting screw and nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Engine and clutch housing mounting stud bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs

W1069132



3TLABAB1P045A

Fuel Tank


1. Remove the muffler (5). (ROPS model)
2. Disconnect the overflow hoses (3) and fuel hose (8).
3. Remove the reserve tank bracket (6). (ROPS model)
4. Remove the compressor bracket. (Cabin model)
5. Remove the shutter plate (4).
6. Remove the tank frame mounting bolt and remove the fuel tank (2) with frame (1).

(When reassembling)

Tightening torque	Muffler mounting screw	31.4 to 37.2 N·m 3.2 to 3.8 kgf·m 23.1 to 27.5 ft-lbs
-------------------	------------------------	---

- | | |
|---------------------|--------------------------|
| (1) Fuel Tank Frame | (5) Muffler |
| (2) Fuel Tank | (6) Reserve Tank Bracket |
| (3) Overflow Hoses | (7) Recovery Tank |
| (4) Shutter Plate | (8) Fuel Hose |

W1015605




3TLABAB1P046A

Radiator Assembly

1. Disconnect the air cleaner hose (3). (ROPS model)
2. Remove the battery (1). (ROPS model)
3. Remove the oil cooler mounting screws. (ROPS model)
4. Remove the battery stay (4). (ROPS model)
5. Disconnect the radiator hoses (5), (7).
6. Remove the radiator assembly.

- | | |
|---------------------------------|-------------------------|
| (1) Battery | (5) Radiator Upper Hose |
| (2) Oil Cooler (HST Model Only) | (6) Radiator |
| (3) Air Cleaner Hose | (7) Radiator Lower Hose |
| (4) Battery Stay | |

W1015759



Hydraulic Pipes and Fuel Filter

1. Disconnect the hoses and remove the oil cooler (4). (HST model)
2. Remove the oil cooler outlet pipe (1) and inlet pipe (5). (HST model)
3. Remove the power steering delivery pipe (2).
4. Disconnect the power steering return hose (7). (Except HST model.)
5. Remove the fuel filter (6) with bracket (3).

(When reassembling)


Tightening torque	Joint bolt for power steering delivery pipe	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs
	Cap nut of power steering delivery pipe	49.0 to 58.8 N·m 5.0 to 6.0 kgf·m 36.1 to 43.4 ft-lbs

- | | |
|----------------------------------|--|
| (1) Oil Cooler Outlet Pipe | (7) Power Steering Return Hose |
| (2) Power Steering Delivery Pipe | (8) Hydraulic Pump with Regulating Valve |
| (3) Bracket | (9) Steering Controller |
| (4) Oil Cooler | |
| (5) Oil Cooler Outlet Pipe | |
| (6) Fuel Filter | |

[A] HST Model

[B] GST / Manual Transmission Model

W1015859



Front Axle Frame

1. Hoist the engine by the chain at the engine hook (1).
2. Remove the dipstick stay mounting screw (3) and front axle frame mounting screws.
3. Separate the front axle frame (1) from engine.


(When reassembling)





Tightening torque	Front axle frame mounting screw (7T) (L3130, L3430, L3830)	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Front axle frame mounting screw (9T) (L4330, L4630, L5030)	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 76.0 to 86.8 ft-lbs

- (1) Engine Hook
- (2) Front Axle Frame

(3) Dipstick Stay Mounting Screw

W1016162





Outer Parts of Engine

1. Remove the hydraulic pump (7) with pump holder and regulating valve (6).
2. Remove the radiator fan (1), belt and fan pulley (2).
3. Remove the alternator (3).
4. Remove the starter motor (4).

(When reassembling)

- Be sure to adjust the fan belt tension. (Refer to G-21.)

Tightening torque	Alternator mounting screw (M10)	39.2 to 44.1 N·m 4.0 to 4.5 kgf·m 28.9 to 32.5 ft-lbs
	Tension adjusting screw (M8)	17.6 to 20.6 N·m 1.8 to 2.1 kgf·m 13.0 to 15.2 ft-lbs

- | | |
|-------------------|--|
| (1) Radiator Fan | (6) Regulating Valve |
| (2) Fan Pulley | (7) Hydraulic Pump |
| (3) Alternator | A : Manual Transmission and GST Model |
| (4) Starter Motor | B : HST Model |
| (5) Fan Belt | |

W10169070

Clutch Assembly

1. Remove the clutch from the flywheel.

(When reassembling)

- Direct the shorter end of the clutch disc boss toward the flywheel.
- Apply molybdenum disulphide (Three Bond 1901 or equivalent) to the splines of clutch disc boss.
- Install the pressure plate, noting the position of straight pins.

■ IMPORTANT

- Align the center of disc and flywheel by inserting the clutch center tool. (See page G-45.)

■ NOTE


- Do not allow grease and oil on the clutch disc facing.

Tightening torque	Clutch mounting screws	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.5 to 20.3 ft-lbs
-------------------	------------------------	---

W10171850

[2] ENGINE BODY

(1) Checking and Adjusting



Compression Pressure




1. Run the engine until it is warmed up.
2. Stop the engine and disconnect the **2P** connector from the fuel pump.
3. Remove the air cleaner, the muffler and all injection nozzles.
4. Set a compression tester (Code No. 07909-30208) with the adaptor to the nozzle hole.
5. Keep the engine stop lever at **"Stop Position"**.
6. While cranking the engine with the starter, measure the compression pressure.
7. Repeat steps 4 through 6 for each cylinder.
8. If the measurement is below the allowable limit, apply a small amount of oil to the cylinder wall through the nozzle hole and measure the compression pressure again.
9. If the compression pressure is still less than the allowable limit, check the top clearance, valve and cylinder head.
10. If the compression pressure increases after applying oil, check the cylinder wall and piston rings.

■ NOTE

- Check the compression pressure with the specified valve clearance.
- Always use a fully charged battery for performing this test.
- Variances in cylinder compression values should be under 10 %.

Compression pressure	Factory spec.	3.53 to 4.02 MPa 36 to 41 kgf/cm ² 512 to 583 psi
	Allowable limit	2.55 MPa 26 kgf/cm ² 370 psi

W1018639



Valve Clearance

■ **IMPORTANT**

- Valve clearance must be checked and adjusted when engine is cold.
1. Remove the head cover, the glow plugs and the timing window cover on the clutch housing.
 2. Align the "1TC" mark line on the flywheel and center of timing window so that the No. 1 piston comes to the compression or overlap top dead center.
 3. Check the following valve clearance marked with "☆" using a feeler gauge.
 4. If the clearance is not within the factory specifications, adjust with the adjusting screw.

Valve clearance	Factory spec.	0.18 to 0.22 mm 0.0071 to 0.0087 in.
-----------------	---------------	---

■ **NOTE**



- The "TC" marking line on the flywheel is just for No. 1 cylinder. There is no "TC" marking for the other cylinders.
- No. 1 piston comes to the T.D.C. position when the "TC" marking is aligned with center of timing window on clutch-housing. Turn the flywheel 0.26 rad. (15 °) clockwise and counterclockwise to see if the piston is at the compression top dead center or the overlap position. Now referring to the table below, readjust the valve clearance. (The piston is at the compression top dead center when both the IN. and EX. valves do not move; it is at the overlap position when both the valves move.)
- Finally turn the flywheel 6.28 rad. (360 °) and align the "TC" marking line and the center of timing window. Adjust all the other valve clearance as required.
- After turning the flywheel counterclockwise twice or three times, recheck the valve clearance, firmly tighten the lock nut of the adjusting screw.

Valve arrangement		D1503-M D1703-M D1803-M		V2203-M V2403-M	
		IN.	EX.	IN.	EX.
Adjustable cylinder location of piston	No. 1	☆	☆	☆	☆
	No. 2		☆	☆	
	No. 3	☆			☆
	No. 4	-	-		
When No. 1 piston is compression top dead center	No. 1				
	No. 2	☆			☆
	No. 3		☆	☆	
	No. 4	-	-	☆	☆

- (1) TC Mark Line
- (2) Timing Window

A : Valve Clearance

W1018974



Top Clearance

1. Remove the cylinder head.
2. Move the piston up and stick a strip of fuse on the piston head at three position with grease.
3. Lower the piston and install the cylinder head. (Use a new cylinder head gasket and tighten with a specified tightening torque.)
4. Turn the flywheel until the piston passes through the T.D.C..
5. Remove the cylinder head and measure the thickness of the fuses.
6. If the measurement is not within the factory specifications, check the oil clearances between the crankpin and bearing and between the piston pin and bushing.

Top clearance	Factory spec.	0.55 to 0.70 mm 0.0217 to 0.0276 in.
---------------	---------------	---

Tightening torque	Cylinder head screws	93.1 to 98.0 N·m 9.5 to 10.0 kgf·m 68.7 to 72.3 ft-lbs
-------------------	----------------------	--


(1) Piston

(2) Fuse

W1020190

(2) Disassembling and Assembling

(A) Cylinder Head and Valves




Cylinder Head Cover

1. Remove the lead (1).
2. Remove the breather hose (2).
3. Remove the head cover screws (3).
4. Remove the cylinder head cover (4).

(When reassembling)

- Check to see if the cylinder head cover gasket is not defective.


Tightening torque	Cylinder head cover screw	6.9 to 11.3 N·m 0.7 to 1.15 kgf·m 5.1 to 8.32 ft-lbs
-------------------	---------------------------	--




- (1) Lead
- (2) Breather Hose
- (3) Head Cover Screw
- (4) Cylinder Head Cover

- (5) Cylinder Head Cover Gasket
- (6) Breather Valve
- (7) Plate

W1060460





Injection Pipes

1. Loosen the screws on the pipe clamps (1).
2. Detach the injection pipes (2).

(When reassembling)


- Blow out dust inside the pipes.

Tightening torque	Injection pipe retaining nut	24.5 to 34.3 N·m 2.5 to 3.5 kgf·m 18.1 to 25.3 ft-lbs

(1) Pipe Clamp

(2) Injection Pipe

W1060970



Nozzle Holder Assembly and Glow Plug

1. Remove the overflow pipe assembly (5).
2. Remove the nozzle holder assemblies (2) using a 21 mm deep socket wrench.
3. Remove the copper gasket and heat seal (3).
4. Remove the glow plugs (1).

(When reassembling)

- Replace the copper gasket and heat seal with new one.

Tightening torque	Nozzle holder assembly	49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 ft-lbs
	Overflow pipe assembly retaining nut	19.6 to 24.5 N·m 2.0 to 2.5 kgf·m 14.5 to 18.1 ft-lbs
	Glow plug	19.6 to 24.5 N·m 2.0 to 2.5 kgf·m 14.5 to 18.1 ft-lbs

(1) Glow Plug


(2) Nozzle Holder Assembly

(3) Heat Seal

(4) Lead

(5) Overflow Pipe Assembly

W1020917



Nozzle Heat Seal Service Removal Procedure

■ IMPORTANT

- Use a plus (phillips head) screw driver (1) that has a Dia. which is bigger than the heat seal hole (Approx. 6 mm) 1/4 in.

1. Drove screw drive (1) lightly into the heat seal hole.
2. Turn screw driver three or four times each way.
3. While turning the screw driver, slowly pull the heat seal (4) out together with the copper gasket (3).
4. If the heat seal drops, repeat the above procedure.

(When reassembling)

- Heat seal and copper gasket must be changed when the injection nozzle is removed for cleaning or for service.


(1) Plus Screw Driver

(2) Nozzle Holder

(3) Copper Gasket

(4) Heat Seal

W1021255



3TMABAB1P028A

Rocker Arm and Push Rod

1. Remove the rocker arm bracket nuts.
2. Detach the rocker arm assembly (1).
3. Remove the push rods (2).

(When reassembling)

- When putting the push rods (2) onto the tappets (3), check to see if their ends are properly engaged with the grooves.

■ IMPORTANT


- **After installing the rocker arm, be sure to adjust the valve clearance.**

Tightening torque	Rocker arm bracket nut	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft-lbs
-------------------	------------------------	---

- (1) Rocker Arm Assembly
(2) Push Rod

- (3) Tappet

W1021437



3EEABAB1P062A

Cylinder Head

1. Loosen the pipe clamp (1), and remove the water return pipe (2).
2. Remove the cylinder head screw in the order of (r or n) to (a).
3. Lift up the cylinder head (3) to detach.
4. Remove the cylinder head gasket (4).

(When reassembling)


- Replace the cylinder head gasket with a new one.
- Tighten the cylinder head screws after applying sufficient oil.
- Tighten the cylinder head screws in diagonal sequence starting from the center in the order of (a) to (n or r).
- Tighten them uniformly, or the head may deform in the long run.

Tightening torque	Cylinder head screw	93.1 to 98.0 N·m 9.5 to 10.0 kgf·m 68.7 to 72.3 ft-lbs
-------------------	---------------------	--


- (1) Pipe Clamp
(2) Return Pipe
(3) Cylinder Head
(4) Cylinder Head Gasket

- (r or n) to (a): To Loosen
(a) to (n or r): To Tighten
(A) Gear Case Side
(B) Flywheel Side


W1021755



3TLABAB1P005A



3GFABAB1P017B



Tappets

1. Remove the tappets (1) from the crankcase.

(When reassembling)


- Visually check the contact between tappets and cams for proper rotation. If defect is found, replace tappets.
- Before installing the tappets, apply engine oil thinly around them.

■ IMPORTANT

- **Do not change the combination of tappet and tappet guide.**

(1) Tappet

W1022001



Valves

1. Remove the valve caps (2).
2. Remove the valve spring collet (3), pushing the valve spring retainer (4) by valve spring replacer (1).
3. Remove the valve spring retainer (4), valve spring (5) and valve stem seal (6).
4. Remove the valve (7).

(When reassembling)

- Wash the valve stem and valve guide hole, and apply engine oil sufficiently.
- After installing the valve spring collets, lightly tap the stem to assure proper fit with a plastic hammer.

■ IMPORTANT

- **Don't change the combination of valve and valve guide.**

(1) Valve Spring Replacer

(2) Valve Cap

(3) Valve Spring Collet






(4) Valve Spring Retainer

(5) Valve Spring

(6) Valve Stem Seal

(7) Valve

W1022102

(B) Timing Gears, Camshaft and Fuel Camshaft**Injection Pump**

1. Remove the stop solenoid (1) and hi-idling body (2).
2. Remove the engine stop lever (3) and stop solenoid guide (5).
3. Remove the fuel injection pump assembly (4).

■ IMPORTANT

- Before removing the injection pump assembly (4), be sure to remove the stop solenoid (1), hi-idling body (2), engine stop lever (3) and stop solenoid guide (5).






(When reassembling)

- Before attaching the stop solenoid, hi-idling body and solenoid guide, install the injection pump first into position.
- Replace the hi-idling body gasket (6) with a new one.
- Before fitting the stop lever to the gear case, install the solenoid guide first into position. Then attach the stop lever and use it to see if it functions well.
- Before fitting the idling limiter in place, attach the solenoid guide and the engine stop lever in their respective positions.
- When installing the stop solenoid, be careful to keep the O-ring in place.
- Be sure to insert the push rod of the stop solenoid into the hole at the center of the solenoid guide.

Tightening torque	Hi-idling body	
		44.1 to 49.0 N·m
		4.5 to 5.0 kgf·m
		32.6 to 36.3 ft·lbs

- | | |
|--------------------|-----------------------------|
| (1) Stop Solenoid | (4) Injection Pump Assembly |
| (2) Hi-idling Body | (5) Solenoid Guide |
| (3) Stop Lever | (6) Hi-idling Body Gasket |

W1023686



Speed Control Plate

1. Remove the injection pump cover.
2. Disconnect the governor spring 1 (3) and 2 (4).
3. Remove the speed control plate (1).

(When reassembling)

- Check that the speed control lever (2) positions low idle, after assembling governor spring.
- Check that the speed control lever returns to the high idle position rather than the low idle position, after moving the lever to the maximum speed position.
- After assembling the engine, check the idling speed referring to adjusting idle speed [950 to 1000 min⁻¹ (rpm)].

- (1) Speed Control Plate
- (2) Speed Control Lever
- (3) Governor Spring 1
- (4) Governor Spring 2

W1024090

Fan Drive Pulley

1. Lock the flywheel not to turn using the flywheel stopper.
2. Remove the fan drive pulley mounting nut (1).
3. Remove the fan drive pulley (2) with gear puller (3).
4. Remove the feather key.


(When reassembling)

- Apply grease to the splines of coupling.

Tightening torque	Fan drive pulley mounting nut	137.3 to 156.9 N·m 14.0 to 16.0 kgf·m 101.3 to 115.7 ft·lbs
-------------------	-------------------------------	---

- (1) Nut
- (2) Fan Drive Pulley
- (3) Gear Puller

W1024348

**Gear Case**

1. Remove the hour meter gear case.
2. Remove the gear case (2).
3. Remove the O-rings (1).


(When reassembling)

- Apply liquid gasket (Three Bond 1215 or equivalent) to both side of hour meter gear case gasket.
- Check to see if there are four O-rings (1) inside the gear case (2).
- Apply a thin film of engine oil to the oil seal (3), and install it, noting the lip come off.
- Before installing the gear case gasket, apply a non-drying adhesive.

- | | |
|------------|---------------|
| (1) O-ring | (2) Gear Case |
|------------|---------------|

(3) Oil Seal

W1024531


**Crankshaft Oil Slinger**

1. Remove the feather key.
2. Remove the crankshaft collar (3).
3. Remove the O-ring (2).
4. Detach the crankshaft oil slinger (1).

- | | |
|----------------------------|------------|
| (1) Crankshaft Oil Slinger | (2) O-ring |
|----------------------------|------------|

(3) Crankshaft Collar

W1024731

**Idle Gear (for D1503-M, D1703-M and D1803-M)**


1. Remove the external snap ring.
2. Detach the idle gear collar.
3. Detach the idle gear (2).

(When reassembling)

- Check to see each gear is aligned with its aligning mark
 - Idle gear (2) and crank gear (4)
 - Idle gear (2) and camshaft gear (3)
 - Idle gear (2) and injection pump gear (1)

- | | | | | |
|-------------------------|---------------|--------------|----------------|-------------------------|
| (1) Injection Pump Gear | (2) Idle Gear | (3) Cam Gear | (4) Crank Gear | (5) Oil Pump Drive Gear |
|-------------------------|---------------|--------------|----------------|-------------------------|

W1043023

**Idle Gear (for V2203-M and V2403-M)**


1. Remove the external snap ring.
2. Detach the idle gear collar.
3. Detach the idle gear (2).

(When reassembling)

- Check to see each gear is aligned with its aligning mark:
 - 1 Mark : Idle gear (2) and crank gear (5), cam gear (3) and balancer gear (4)
 - 2 Marks : Cam gear (3) and idle gear (2)
 - 3 Marks : Idle gear (2) and injection pump gear (1)
 - 4 Marks : Idle gear (2) and balancer gear (7)

- | | | | | | | |
|-------------------------|---------------|--------------|-------------------|----------------|-------------------------|-------------------|
| (1) Injection Pump Gear | (2) Idle Gear | (3) Cam Gear | (4) Balancer Gear | (5) Crank Gear | (6) Oil Pump Drive Gear | (7) Balancer Gear |
|-------------------------|---------------|--------------|-------------------|----------------|-------------------------|-------------------|

W1024941



Camshaft (for D1503-M, D1703-M and D1803-M)


1. Remove the camshaft set bolts (2) and draw out the camshaft (1).
- (When reassembling)**
- When installing the idle gear, be sure to align the alignment marks on gears.

Tightening torque	Camshaft set bolt	23.5 to 27.5 N·m
		2.4 to 2.8 kgf·m
		17.4 to 20.3 ft-lbs

(1) Camshaft

(2) Camshaft Set Bolt

W1046059



Camshaft and Balancer Shaft (for V2203-M and V2403-M)

1. Remove the camshaft set bolts and draw out the camshaft (1).
 2. Remove the balancer shaft 1 (2) set bolts and draw out the balancer shaft 1 (2).
 3. Remove the balancer shaft 2 (3) set bolts and draw out the balancer shaft 2 (3).
- (When reassembling)**
- When install the balancer shaft 1 and 2, be sure to place the 4th cylinders piston at the top dead center in compression then, align all mating marks on each gear to assemble the timing gears, set the idle gear last.


Tightening torque	Camshaft set bolt	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft-lbs
	Balancer shaft set bolt	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft-lbs

(1) Camshaft

(3) Balancer Shaft 2

(2) Balancer Shaft 1

W1025098



Fuel Camshaft and Fork Lever Assembly

1. Remove the fuel feed pump.
2. Detach the fuel camshaft stopper (1).
3. Remove the three fork lever holder mounting screws (2).
4. Draw out the fuel camshaft assembly (5), (6) and fork lever assembly (3), (4), (7) at the same time.

(When reassembling)

- After installation, check to see that the fork lever 1 (3) and (4) are fixed to the fork lever shaft, and that they can turn smoothly in the holder (7).

(1) Fuel Camshaft Stopper

(5) Injection Pump Gear

(2) Fork Lever Holder Mounting Screws



(6) Fuel Camshaft


(3) Fork Lever 1

(7) Fork Lever Holder

(4) Fork Lever 2

W1025309




**Oil Pump**

1. Remove the nut.
2. Draw out the oil pump drive gear (1) with gear puller (2).
3. Remove the four oil pump mounting screws. Detach the oil pump (3).

(1) Oil Pump Drive Gear
(2) Gear Puller

(3) Oil Pump

W1025581


**Crank Gear**

1. Draw out the crank gear (1) with a puller (2).
2. Remove the feather key.

(1) Crank Gear

(2) Gear Puller

W1025476

(C) Piston and Connecting Rod**Oil Pan and Oil Strainer**

1. Remove the oil pan mounting screws.
2. Remove the oil pan (1) by lightly tapping the rim of the pan with a wooden hammer.
3. Remove the oil pan gasket (2).
4. Remove the oil strainer (3) and O-ring (4).


(When reassembling)

- After cleaning the oil strainer, check to see that the filter mesh is clean, and install it.
- Visually check the O-ring, apply engine oil, and install it.
- Securely fit the O-ring to the oil strainer.
- Apply a liquid gasket (Three Bond 1215 or equivalent) to the oil pan side of the oil pan gasket.
- To avoid uneven tightening, tighten oil pan mounting screws in diagonal order from the center.






(1) Oil Pan
(2) Oil Pan Gasket

(3) Oil Strainer
(4) O-ring

W1025687



3TLABAB1P021A



Pistons

1. Completely clean carbon (1) in the cylinders.
2. Remove the connecting rod cap (3).
3. Turn the flywheel and bring the piston to top dead center.
4. Draw out the piston upward by lightly tapping it from the bottom of the crankcase with the grip of a hammer.
5. Draw out the other piston in the same method as above.


(When reassembling)

- Before inserting piston into the cylinder, apply enough engine oil to the piston.
- When inserting the piston into the cylinder, face the mark on the connecting rod to the injection pump.





■ IMPORTANT

- Do not change the combination of cylinder and piston. Make sure of the position of each piston by marking. For example, mark "1" on the No. 1 piston.
- Place the piston rings with their gaps at 0.79 rad. (45 °) from the piston pin's direction as shown in the figure.
- Carefully insert the pistons using a piston ring compressor.
- When inserting the piston in place, be careful not to get the molybdenum disulfide coating torn off its skirt. This coating is useful in minimizing the clearance with the cylinder liner. Just after the piston pin has been press-fitted, in particular, the piston is still hot and the coating is easy to peel off. Wait until the piston cools down.

Tightening torque	Connecting rod screw	44.1 to 49.0 N·m 4.5 to 5.0 kgf·m 32.5 to 36.2 ft·lbs
-------------------	----------------------	---



- (1) Carbon
- (2) Connecting Rod Screw
- (3) Connecting Rod Cap
- (4) Connecting Rod
- (5) Molybdenum Disulfide Coating in Piston Skirt
- (6) Piston Ring Compressor
- (A) Top Ring Gap
- (B) Second Ring Gap
- (C) Oil Ring Gap
- (D) Piston Pin Hole
- (a) 0.79 rad. (45 °)



Piston Ring and Connecting Rod

1. Remove the piston rings using a piston ring tool (Code No. 07909-32121).
2. Remove the piston pin (7), and separate the connecting rod (6) from the piston (5).

(When reassembling)


- When installing the ring, assemble the rings so that the manufacturer's mark (12) near the gap faces the top of the piston.
- When installing the oil ring onto the piston, place the expander joint (10) on the opposite side of the oil ring gap (11).
- Apply engine oil to the piston pin.
- When installing the connecting rod to the piston, immerse the piston in 80 °C (176 °F) oil for 10 to 15 minutes and insert the piston pin to the piston.

NOTE


- Assemble the piston to the connecting rod with the ↑ mark and the connecting rod mark facing the opposite side.
- Mark the same number on the connecting rod and the piston so as not to change the combination.

- | | |
|--------------------------|--------------------------|
| (1) Top Ring | (7) Piston Pin |
| (2) Second Ring | (8) Mark |
| (3) Oil Ring | (9) Casting Mark |
| (4) Piston Pin Snap Ring | (10) Expander Joint |
| (5) Piston | (11) Oil Ring Gap |
| (6) Connecting Rod | (12) Manufacturer's Mark |

W1026376



(D) Crankshaft



3TLABAB1P027A

Flywheel

1. Fit the stopper to the flywheel (1).
2. At first, remove two pieces of the flywheel screws (2).
3. Insert two pieces of the flywheel guide screws (3) in the holes.
4. Remove the all flywheel screws (2).
5. Remove the flywheel (1) slowly along the flywheel guide screws (3).

(When reassembling)

- Insert two pieces of the flywheel guide screws.
- Check to see that there are no metal particles left on the flywheel mounting surfaces.
- Apply engine oil to the threads and the undercut surface of the flywheel bolt and fit the bolt.


Tightening torque	Flywheel screws	98.0 to 107.8 N·m 10.0 to 11.0 kgf·m 72.3 to 79.5 ft·lbs
-------------------	-----------------	--

(1) Flywheel

(2) Flywheel Screw

(3) Flywheel Guide Screws

W1026863



3GFABAB1P047A

Bearing Case Cover

1. Remove the bearing case cover mounting screws. First, remove inside screws (6) and then outside screws (3).
2. Screw two removed screws into the screw hole of bearing case cover (5) to remove it.

■ IMPORTANT

- The length of inside screws and outside screws are different. Do not take a mistake using inside screws and outside screws.

(When reassembling)

- Fit the bearing case gasket (1) and the bearing case cover gasket (2) with correct directions.
- Install the bearing case cover to position the casting mark "UP" on it upward.
- Apply engine oil to the oil seal lip and take care that it is not rolled when installing.
- Tighten the bearing case cover mounting screws with even force on the diagonal line.

Tightening torque	Bearing case cover mounting screw	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft·lbs
-------------------	-----------------------------------	---

(1) Bearing Case Gasket

(2) Bearing Case Cover Gasket

(3) Bearing Case Cover Mounting Screw


(4) Oil Seal

(5) Bearing Case Cover


(6) Bearing Case Cover Mounting Screw

(a) Upside





W10292140



3TLABAB1P028A



3TLABAB1P029A



Crankshaft

■ **NOTE**

- Before disassembling, check the side clearance of crankshaft. Also check it during reassembling.

For D1503-M, D1703-M and V2203-M

1. Remove the main bearing case screw 2 (1).
2. Pull out the crankshaft assembly, taking care not to damage the crankshaft bearing 1.

For D1803-M

1. Remove the main bearing case screw 2 (1).
2. Turn the crankshaft to set the crank pin of the third cylinder to the bottom dead center. Then draw out the crankshaft until the crank pin of the second cylinder comes to the center of the third cylinder.
3. Turn the crankshaft by 2.09 rad. (120 °) counterclockwise to set the crank pin of the second cylinder to the bottom dead center. Draw out the crankshaft until the crank pin of the first cylinder comes to the center of the third cylinder
4. Repeat the above steps to draw out all the crankshaft.

For V2403-M

1. Remove the main bearing case screw 2 (1).
2. Turn the crankshaft to set the crank pin of the 4th cylinder to the horizontal directions (Right or Left). Then draw out all the crankshaft, holding the crank pins to the horizontal directions (Right or Left).

(When reassembling)

■ **IMPORTANT**

- Install the crankshaft sub assembly, aligning the screw hole of main bearing case 2 with the screw hole of cylinder block.
- When tightening the main bearing case screw 2, apply oil to the screw and screw by hand before tightening the specific torque.






If not smooth to screw by hand, align the screw holes between the cylinder block and the main bearing case.

Tightening torque	Main bearing case screws	68.6 to 73.5 N·m
	2	7.0 to 7.5 kgf·m 50.6 to 54.2 ft·lbs

(1) Main Bearing Case Screw 2

(a) Cut place for removing and installing the crankshaft
[A] D1803-M

W1066311



Main Bearing Case Assembly

1. Remove the two main bearing case screws 1, and remove the main bearing case assembly being careful with thrust bearing and crankshaft bearing.
2. Remove the main bearing case 1, 2 as above.



(When reassembling)

- Clean the oil passage in the main bearing case.
- Apply clean engine oil on the bearings.
- Install the main bearing case assemblies in the original positions. Since diameters of main bearing cases vary, install them in order of markings (A, B for 3 cylinders and A, B, C for 4 cylinders) from the gear case side.
- Match the alignment numbers (1) and mark (2) on the main bearing case.
- When installing the main bearing case 1 and 2, face the mark "FLYWHEEL" to the flywheel.
- Install the thrust bearing with its oil groove facing (7) outward.
- Confirm that the main bearing case moves smoothly after tightening the main bearing case screw 1 to the specified torque.

Tightening torque	Main bearing case screw 1	46.1 to 50.9 N·m
		4.7 to 5.2 kgf·m
		34.0 to 37.6 ft·lbs


- (1) Alignment Number
- (2) Alignment Mark
- (3) A
- (4) B

- (5) C
- (6) No Mark
- (7) Oil Groove




(3) Servicing


(A) Cylinder Head and Valves




3TMABAB1P056A




3EEABAB1P112B



3TMABAB0P059B



3TMABAB1P057A



3TMABAB1P058A

Cylinder Head Surface Flatness

1. Clean the cylinder head surface.
2. Place a straightedge on the cylinder head's four sides and two diagonal as shown in the figure.
3. Measure the clearance with a feeler gauge.
4. If the measurement exceeds the allowable limit, correct it with a surface grinder.

■ IMPORTANT

- Do not place the straightedge on the combustion chamber.
- Be sure to check the valve recessing after correcting.

Cylinder head surface flatness	Factory spec.	0.05 mm / 500 mm 0.0020 in. / 19.69 in.
--------------------------------	---------------	--

W1027737

Cylinder Head Flaw

1. Prepare an air spray red check (Code No. 07909-31371).
2. Clean the surface of the cylinder head with detergent (2).
3. Spray the cylinder head surface with the read permeative liquid (1). Leave it five to ten minutes after spraying.
4. Wash away the read permeative liquid on the cylinder head surface with the detergent (2).
5. Spray the cylinder head surface with white developer (3).
6. If flawed, it can be identified as red marks.

- (1) Red Permeative Liquid
(2) Detergent

- (3) White Developer

W1076542

Valve Recessing


1. Clean the cylinder head surface, valve face and valve seat.
2. Insert the valve into the valve guide.
3. Measure the valve recessing with a depth gauge.
4. If the measurement exceeds the allowable limit, replace the valve.
5. If it still exceeds the allowable limit after replacing the valve, correct the valve seat face of the cylinder head with a valve seat cutter (Code No. 07909-33102) or valve seat grinder.
6. Then, correct the cylinder head surface with a surface grinder, or replace the cylinder head.

Valve recessing	Factory spec.	0.05 (protrusion) to 0.15 (recessing) mm 0.0020 (protrusion) to 0.0059 (recessing) in.
	Allowable limit	0.40 (recessing) mm 0.0157 (recessing) in.


- (1) Cylinder Head Surface

- (A) Recessing
(B) Protrusion


W1076880



3EEABAB1P115A



3EEABAB1P116A



3EEABAB1P117A

Clearance between Valve Stem and Valve Guide

1. Remove carbon from the valve guide section.
2. Measure the valve stem O.D. with an outside micrometer.
3. Measure the valve guide I.D. with a small hole gauge, and calculate the clearance.
4. If the clearance exceeds the allowable limit, replace the valves. If it still exceeds the allowable limit, replace the valve guide.

Clearance between valve stem and guide	Factory spec.	0.040 to 0.070 mm 0.00157 to 0.00276 in.
	Allowable limit	0.1 mm 0.0039 in.

Valve stem O.D.	Factory spec.	7.960 to 7.975 mm 0.31339 to 0.31398 in.
-----------------	---------------	---

Valve guide I.D.	Factory spec.	8.015 to 8.030 mm 0.31555 to 0.31614 in.
------------------	---------------	---

W1077495

Replacing Valve Guide

(When removing)

1. Press out the used valve guide using a valve guide replacing tool.

(When installing)

1. Clean a new valve guide and valve guide bore, and apply engine oil to them.
2. Press in a new valve guide using a valve guide replacing too.
3. Ream precisely the I.D. of the valve guide to the specified dimension.

Valve guide I.D. (Intake and exhaust)	Factory spec.	8.015 to 8.030 mm 0.31555 to 0.31614 in.
---------------------------------------	---------------	---

■ IMPORTANT

- Do not hit the valve guide with a hammer during replacement.

(A) When Removing

(B) When Installing

W1027889




Valve Seating

1. Coat the valve face lightly with prussian blue and put the valve on its seat to check the contact.
2. If the valve does not seat all the way around the valve seat or the valve contact is less than 70 %, correct the valve seating as follows.
3. If the valve contact does not comply with the reference value, replace the valve or correct the contact of valve seating.

- (1) Correct
(2) Incorrect

- (3) Incorrect

W1028219



Correcting Valve and Valve Seat

■ **NOTE**



- Before correcting the valve and seat, check the valve stem and the I.D. of valve guide section, and repair them if necessary.
- After correcting the valve seat, be sure to check the valve recessing.

1) Correcting Valve

1. Correct the valve with a valve refacer.


2) Correcting Valve Seat


1. Slightly correct the seat surface with a 1.047 rad. (60 °) (intake valve) or 0.785 rad. (45 °) (exhaust valve) seat cutter (Code No. 07909-33102).
2. Resurface the seat surface with a 0.523 rad. (30 °) valve seat cutter to intake valve seat and with a 0.262 rad. (15 °) valve seat cutter to exhaust valve seat so that the width is close to specified valve seat width (2.12 mm, 0.0835 in.)
3. After resurfacing the seat, inspect for even valve seating, apply a thin film of compound between the valve face and valve seat, and fit them with valve lapping tool.
4. Check the valve seating with prussian blue. The valve seating surface should show good contact all the way around.



- | | |
|--|------------------------|
| (a) Identical Dimensions | (A) Check Correct |
| (b) Valve Seat Width | (B) Correct Seat Width |
| (c) 0.523 rad. (30 °) or 0.262 rad. (15 °) | (C) Check Contact |
| (d) 0.262 rad. (15 °) or 0.523 rad. (30 °) | |
| (e) 0.785 rad. (45 °) or 1.047 rad. (60 °) | |

W1028350






Valve Lapping

1. Apply compound evenly to the valve lapping surface.
2. Insert the valve into the valve guide. Lap the valve onto its seat with a valve flapper or screwdriver.
3. After lapping the valve, wash the compound away and apply oil, then repeat valve lapping with oil.
4. Apply prussian blue to the contact surface to check the seated rate. If it is less than 70 %, repeat valve lapping again.

■ IMPORTANT

- **When valve lapping is performed, be sure to check the valve recessing and adjust the valve clearance after assembling the valve.**

W1028814



Free Length and Tilt of Valve Spring

1. Measure the free length (A) of valve spring with vernier calipers. If the measurement is less than the allowable limit, replace it.
2. Put the valve spring on a surface plate, place a square on the side of the valve spring.
3. Check to see if the entire side is in contact with the square. Rotate the valve spring and measure the maximum tilt (B). Check the entire surface of the valve spring for scratches. If there is any defect, replace it.

Free length (A)	Factory spec.	41.7 to 42.2 mm 1.6417 to 1.6614 in.
	Allowable limit	41.2 mm 1.6220 in.

Tilt (B)	Allowable limit	1.0 mm 0.039 in.
----------	-----------------	---------------------

W1028935




Valve Spring Setting Load

1. Place the valve spring on a tester and compress it to the same length it is actually compressed in the engine.
2. Read the compression load on the gauge.
3. If the measurement is less than the allowable limit, replace it.

Setting load / Setting length	Factory spec.	117.6 N / 35 mm 12.0 kgf / 35 mm 26.4 lbs / 1.3780 in.
	Allowable limit	100.0 N / 35 mm 10.2 kgf / 35 mm 22.5 lbs / 1.3780 in.

W1078436



3EEABAB1P123A

Oil Clearance between Rocker Arm and Rocker Arm Shaft

1. Measure the rocker arm shaft O.D. with an outside micrometer.
2. Measure the rocker arm I.D. with an inside micrometer, and then calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the rocker arm and measure the oil clearance again. If it still exceeds the allowable limit, replace also the rocker arm shaft.

Oil clearance between rocker arm and rocker arm shaft	Factory spec.	0.016 to 0.045 mm 0.00063 to 0.00177 in.
	Allowable limit	0.10 mm 0.0039 in.

Rocker arm shaft O.D.	Factory spec.	13.973 to 13.984 mm 0.55012 to 0.55055 in.
-----------------------	---------------	---

Rocker arm I.D.	Factory spec.	14.000 to 14.018 mm 0.55118 to 0.55189 in.
-----------------	---------------	---


W1029150

Push Rod Alignment

1. Place the push rod on V blocks.
2. Measure the push rod alignment.
3. If the measurement exceeds the allowable limit, replace the push rod.

Push rod alignment	Allowable limit	0.25 mm 0.0098 in.
--------------------	-----------------	-----------------------

W1029290



3TMABAB1P062A

Oil Clearance between Tappet and Tappet Guide Bore


1. Measure the tappet O.D. with an outside micrometer.
2. Measure the I.D. of the tappet guide bore with a cylinder gauge, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit or the tappet is damaged, replace the tappet.

Oil Clearance between tappet and tappet guide bore	Factory spec.	0.020 to 0.062 mm 0.00079 to 0.00244 in.
	Allowable limit	0.07 mm 0.0028 in.


Tappet O.D.	Factory spec.	23.959 to 23.980 mm 0.94327 to 0.94410 in.
-------------	---------------	---

Tappet guide bore I.D.	Factory spec.	24.000 to 24.021 mm 0.94488 to 0.94571 in.
------------------------	---------------	---

W1028249



3EEABAB1P124A

(B) Timing Gears, Camshaft and Fuel Camshaft**Timing Gear Backlash**

1. Set a dial indicator (lever type) with its tip on the gear tooth.
2. Move the gear to measure the backlash, holding its mating gear.
3. If the backlash exceeds the allowable limit, check the oil clearance of the shafts and the gear.
4. If the oil clearance is proper, replace the gear.

Backlash between idle gear and crank gear	Factory spec.	0.0415 to 0.1122 mm 0.00163 to 0.00442 in.
	Allowable limit	0.15 mm 0.0059 in.

Backlash between idle gear and cam gear	Factory spec.	0.0415 to 0.1154 mm 0.00163 to 0.00454 in.
	Allowable limit	0.15 mm 0.0059 in.

Backlash between idle gear and injection pump gear	Factory spec.	0.0415 to 0.1154 mm 0.00163 to 0.00454 in.
	Allowable limit	0.15 mm 0.0059 in.


Backlash between crank gear and oil pump gear	Factory spec.	0.0415 to 0.1090 mm 0.00163 to 0.00429 in.
	Allowable limit	0.15 mm 0.0059 in.

[for V2203-M and V2403-M only]

Backlash between idle gear and balancer gear (IN. side)	Factory spec.	0.0350 to 0.1160 mm 0.00138 to 0.00457 in.
	Allowable limit	0.15 mm 0.0059 in.

Backlash between cam gear and balancer gear (EX. gear)	Factory spec.	0.0350 to 0.1160 mm 0.00138 to 0.00457 in.
	Allowable limit	0.15 mm 0.0059 in.


W1029564

**Idle Gear Side Clearance**

1. Set a dial indicator with its tip on the idle gear.
2. Measure the side clearance by moving the idle gear to the front and rear.
3. If the measurement exceeds the allowable limit, replace the idle gear collar.

Idle gear side clearance	Factory spec.	0.12 to 0.48 mm 0.0047 to 0.0189 in.
	Allowable limit	0.9 mm 0.0354 in.

W1029843




Camshaft Side Clearance

1. Set a dial indicator with its tip on the camshaft.
2. Measure the side clearance by moving the cam gear to the front and rear.
3. If the measurement exceeds the allowable limit, replace the camshaft stopper.

Camshaft side clearance	Factory spec.	0.07 to 0.22 mm 0.0028 to 0.0087 in.
	Allowable limit	0.30 mm 0.0118 in.

W1030012




Balancer Shaft Side Clearance (for V2203-M and V2403-M)

1. Set a dial indicator with tip on the balancer shaft.
2. Measure the side clearance by moving the balancer shaft to the front and rear.
3. If the measurement exceeds the allowable limit, replace the balancer shaft.

Side clearance of balancer shaft	Factory spec.	0.07 to 0.22 mm 0.0028 to 0.0087 in.
	Allowable limit	0.3 mm 0.0118 in.


W1030111




Idle Gear Side Clearance

1. Set a dial indicator with its tip on the idle gear.
2. Measure the side clearance by moving the idle gear to the front and rear.
3. If the measurement exceeds the allowable limit, replace the idle gear collar.

Idle gear side clearance	Factory spec.	0.12 to 0.48 mm 0.0047 to 0.0193 in.
	Allowable limit	0.5 mm 0.020 in.



3TMABAB1P067A



3TMABAB1P068A

**Oil Clearance of Balancer Shaft Journal
(for V2203-M and V2403-M)**

1. Measure the balancer shaft journal O.D. with an outside micrometer.
2. Measure the cylinder block bore I.D. for balancer shaft with an inside micrometer or cylinder gauge.
3. If the clearance exceeds the allowable limit, replace the balancer shaft.

Oil clearance of balancer shaft journal 1	Factory spec.	0.030 to 0.111 mm 0.00118 to 0.00437 in.
	Allowable limit	0.2 mm 0.0079 in.

Balancer shaft journal 1 O.D.	Factory spec.	43.934 to 43.950 mm 1.72968 to 1.73031 in.
-------------------------------	---------------	---

Balancer shaft bearing 1 I.D.	Factory spec.	43.980 to 44.045 mm 1.73149 to 1.73405 in.
-------------------------------	---------------	---

Oil clearance of balancer shaft journal 2	Factory spec.	0.030 to 0.111 mm 0.00118 to 0.00437 in.
	Allowable limit	0.2 mm 0.0079 in.

Balancer shaft journal 2 O.D.	Factory spec.	41.934 to 41.950 mm 1.65094 to 1.65157 in.
-------------------------------	---------------	---

Balancer shaft bearing 2 I.D.	Factory spec.	41.980 to 42.045 mm 1.65275 to 1.65531 in.
-------------------------------	---------------	---

Oil clearance of balancer shaft journal 3	Factory spec.	0.020 to 0.094 mm 0.00079 to 0.00370 in.
	Allowable limit	0.2 mm 0.0079 in.


Balancer shaft journal 3 O.D.	Factory spec.	21.947 to 21.960 mm 0.86405 to 0.86456 in.
-------------------------------	---------------	---

Balancer shaft bearing 3 I.D.	Factory spec.	21.980 to 22.041 mm 0.86535 to 0.86775 in.
-------------------------------	---------------	---

- (1) Balancer Shaft Journal 1
(2) Balancer Shaft Journal 2

- (3) Balancer Shaft Journal 3

W1030206



3TMABAB1P069A

Oil Clearance between Idle Gear Shaft and Idle Gear Bushing


1. Measure the idle gear shaft O.D. with an outside micrometer.
2. Measure the idle gear bushing I.D. with an inside micrometer, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the bushing.

Clearance between idle gear shaft and idle gear bushing	Factory spec.	0.025 to 0.066 mm 0.00098 to 0.00260 in.
	Allowable limit	0.1 mm 0.0039 in.

Idle gear shaft O.D.	Factory spec.	37.959 to 37.975 mm 1.49445 to 1.49508 in.
----------------------	---------------	---

Idle gear bushing I.D.	Factory spec.	38.000 to 38.025 mm 1.49606 to 1.49704 in.
------------------------	---------------	---

W1030933



Replacing Idle Gear Bushing


(A) (When removing)

1. Using an idle gear bushing replacing tool, press out the used bushing.

(B) (When installing)

1. Clean a new idle gear bushing and idle gear bore, and apply engine oil to them.
2. Using an idle gear bushing replacing tool, press in a new bushing (service parts) to the specified dimension. (See figure.)

W1031083




Camshaft Alignment

1. Support the camshaft with V blocks on the surface plate at both end journals.
2. Set a dial indicator with its tip on the intermediate journal.
3. Measure the camshaft alignment.
4. If the measurement exceeds the allowable limit, replace the camshaft.

Camshaft alignment	Allowable limit	0.01 mm 0.0004 in.
--------------------	-----------------	-----------------------

W1031413



Cam Height

1. Measure the height of the cam at its highest point with an outside micrometer.
2. If the measurement is less than the allowable limit, replace the camshaft.

Cam height of intake	Factory spec.	33.90 mm 1.3346 in.
	Allowable limit	33.85 mm 1.3327 in.

Cam height of exhaust	Factory spec.	33.90 mm 1.3346 in.
	Allowable limit	33.85 mm 1.3327 in.



W1031532



Oil Clearance between Idle Gear Shaft and Idle Gear Bushing

1. Measure the idle gear shaft O.D. with an outside micrometer.
2. Measure the idle gear bushing I.D. with an inside micrometer, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the bushing.

Idle gear bushing I.D.	Factory spec.	34.700 to 34.825 mm 1.4055 to 1.4099 in.
Idle gear shaft O.D.	Factory spec.	33.800 to 33.925 mm 1.4094 to 1.4138 in.
Oil clearance	Allowable limit	0.100 mm 0.0039 in.
Oil clearance	Factory spec.	0.000 to 0.005 mm 0.0000 to 0.0020 in.



Oil Clearance of Camshaft Journal


1. Measure the camshaft journal O.D. with an outside micrometer.
2. Measure the cylinder block bore I.D. for camshaft with a cylinder gauge, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the camshaft.

Oil clearance of camshaft journal	Factory spec.	0.050 to 0.091 mm 0.00197 to 0.00358 in.
	Allowable limit	0.15 mm 0.0059 in.

Camshaft journal O.D.	Factory spec.	39.934 to 39.950 mm 1.57221 to 1.57284 in.
Cylinder block bore I.D.	Factory spec.	40.000 to 40.025 mm 1.57480 to 1.57579 in.

W1031662

(C) Piston and Connecting Rod




Piston Pin Bore I.D.

1. Measure the piston pin bore I.D. in both the horizontal and vertical directions with a cylinder gauge.
2. If the measurement exceeds the allowable limit, replace the piston.

Piston pin bore I.D.	Factory spec.	25.000 to 25.013 mm 0.98425 to 0.98476 in.
	Allowable limit	25.05 mm 0.9862 in.

W1031817




Oil Clearance between Piston Pin and Small End Bushing

1. Measure the piston pin O.D. where it contacts the bushing with an outside micrometer.
2. Measure the small end bushing I.D. with an inside micrometer, and calculate the oil clearance.
3. If the oil clearance exceeds the allowable limit, replace the bushing. If it still exceeds the allowable limit, replace the piston pin.

Oil clearance between piston pin and small end bushing	Factory spec.	0.014 to 0.038 mm 0.00055 to 0.00150 in.
	Allowable limit	0.15 mm 0.0059 in.

Piston pin O.D.	Factory spec.	25.002 to 25.011 mm 0.98433 to 0.98468 in.
Small end bushing I.D.	Factory spec.	25.025 to 25.040 mm 0.98523 to 0.98582 in.

W1031982



Replacing Connecting Rod Small End Bushing


(When removing)

1. Press out the small end bushing with a connecting rod small end bushing replacing tool.

(When installing)

1. Clean a new small end bushing and bore, and apply engine oil to them.
2. Press fit a new bushing, taking due care to see that the connecting rod hole matches the bushing hole.

W1032140



Piston Ring Gap


1. Insert the piston ring into the lower part of the liner (the least worn out part) with the piston.
2. Measure the ring gap with a feeler gauge.
3. If the gap exceeds the allowable limit, replace the ring.

Top ring	Factory spec.	D1503-M	0.20 to 0.35 mm 0.0079 to 0.0138 in.
		D1703-M D1803-M V2203-M V2403-M	0.20 to 0.40 mm 0.0079 to 0.0157 in.
Allowable limit		1.25 mm 0.0492 in.	

Second ring	Factory spec.	0.30 to 0.45 mm 0.0118 to 0.0179 in.
	Allowable limit	1.25 mm 0.0492 in.

Oil ring	Factory spec.	0.25 to 0.45 mm 0.0098 to 0.0177 in.
	Allowable limit	1.25 mm 0.0492 in.

W1032246




Clearance between Piston Ring and Groove

1. Remove carbon from the ring grooves.
2. Measure the clearance between the ring and the groove with a feeler gauge or depth gauge.
3. If the clearance exceeds allowable limit, replace the ring since compression leak and oil shortage result.
4. If the clearance still exceeds the allowable limit after replacing the ring, replace the piston.

Second ring	Factory spec.	D1503-M	0.093 to 0.120 mm 0.0037 to 0.0047 in.
		D1703-M D1803-M V2203-M V2403-M	0.093 to 0.128 mm 0.0037 to 0.0050 in.
Allowable limit		0.2 mm 0.0079 in.	

Oil ring	Factory spec.	0.020 to 0.060 mm 0.0008 to 0.0021 in.
	Allowable limit	0.15 mm 0.0059 in.

W1032489



3TMABAB0P056A

Connecting Rod Alignment

NOTE

- Since the I.D. of the connecting rod small end bushing is the basis of this check, check bushing for wear beforehand.
1. Install the piston pin into the connecting rod.
 2. Install the connecting rod on the connecting rod alignment tool.
 3. Put a gauge over the piston pin and move it against the face plate.
 4. If the gauge does not fit squarely against the face plate, measure the space between the pin of the gauge and the face plate.
 5. If the measurement exceeds the allowable limit, replace the connecting rod.

Connecting rod alignment	Allowable limit	0.05 mm 0.0020 in.
--------------------------	-----------------	-----------------------



W1032720

Model	Code Number	Part Number	Quantity	Unit
20 010	18825-180A1	M-00810	1	mm 0.0
		M-00810	1	
20 020	18825-180A1	M-00810	1	mm 0.0
		M-00810	1	
20 030	18825-180A1	M-00810	1	mm 0.0
		M-00810	1	
20 040	18825-180A1	M-00810	1	mm 0.0
		M-00810	1	
20 050	18825-180A1	M-00810	1	mm 0.0
		M-00810	1	
20 060	18825-180A1	M-00810	1	mm 0.0
		M-00810	1	

Dimension	mm	in.
A	25.40 to 25.75	1.0000 to 1.0142
B	24.2 to 24.7	0.9528 to 0.9732
C	2.0 to 2.5	0.0787 to 0.0984

00000-0000

(D) Crankshaft



Side Clearance of Crankshaft

1. Move the crankshaft to the flywheel side.
2. Set a dial indicator to the crankshaft.
3. Measure the end play by pulling the crankshaft toward the crank gear.
4. If the measurement exceeds the allowable limit, replace the thrust bearing 1 and 2.

Crankshaft side clearance	Factory spec.	D1503-M D1703-M V2203-M	0.15 to 0.35 mm 0.0059 to 0.0138 in.
		D1803-M V2403-M	0.15 to 0.31 mm 0.0059 to 0.0122 in.
	Allowable limit		0.5 mm 0.0197 in.

(Reference)


- Oversize thrust bearing

Oversize	Bearing	Code Number	Marking	
0.2 mm 0.008 in.	Thrust bearing 1 02	D1503-M D1703-M V2203-M	15521-23950	020 OS
		D1803-M V2403-M	1A091-23951	020 OS
	Thrust bearing 2 02	D1503-M D1703-M V2203-M	19202-23970	020 OS
		D1803-M V2403-M	1A091-23971	020 OS
0.4 mm 0.016 in.	Thrust bearing 1 04	D1503-M D1703-M V2203-M	15521-23960	040 OS
		D1803-M V2403-M	1A091-23961	040 OS
	Thrust bearing 2 04	D1503-M D1703-M V2203-M	19202-23980	040 OS
		D1803-M V2403-M	1A091-23981	040 OS

- Oversize dimensions of crankshaft journal

Dimension	Oversize	
	0.2 mm 0.008 in.	0.4 mm 0.016 in.
A	26.20 to 26.25 mm 1.0315 to 1.0335 in.	26.40 to 26.45 mm 1.0394 to 1.0413 in.
B	54.5 to 54.7 mm 2.1456 to 2.1535 in.	54.6 to 54.8 mm 2.1496 to 2.1574 in.
C	2.8 to 3.2 mm radius 0.1102 to 0.1260 in. radius	2.8 to 3.2 mm radius 0.1102 to 0.1260 in. radius
(0.8-S) The crankshaft journal must be fine-finished to higher than ∇∇∇∇		

W1032880




Crankshaft Alignment

1. Support the crankshaft with V blocks on the surface plate and set a dial indicator with its tip on the intermediate journal at right angle.
2. Rotate the crankshaft on the V blocks and get the misalignment (half of the measurement).
3. If the misalignment exceeds the allowable limit, replace the crankshaft.

Crankshaft alignment	Allowable limit	0.02 mm 0.00079 in.
----------------------	-----------------	------------------------

W1033001




Oil Clearance between Crankpin and Crankpin Bearing

1. Clean the crankpin and crankpin bearing.
2. Put a strip of plastigage (Code No.: 07909-30241) on the center of the crankpin in each direction as shown in the figure.
3. Install the connecting rod cap and tighten the connecting rod screws to the specified torque, and remove the cap again.
4. Measure the amount of the flattening with the scale, and get the oil clearance.
5. If the oil clearance exceeds the allowable limit, replace the crankpin bearing.
6. If the same size bearing is useless because of the crankpin wear, replace it with an undersize one referring to the table and figure.

NOTE

- Never insert the plastigage into the crankpin oil hole.
- Be sure not to move the crankshaft while the connecting rod screws are tightened.



Oil clearance between crankpin and crankpin bearing	Factory spec.	0.025 to 0.087 mm 0.00098 to 0.00343 in.
	Allowable limit	0.2 mm 0.0079 in.

Crankpin O.D.	Factory spec.	46.959 to 46.975 mm 1.84878 to 1.84941 in.
Crankpin bearing I.D.	Factory spec.	47.000 to 47.046 mm 1.85039 to 1.85220 in.

(Reference)

- Undersize crankpin bearing




Undersize	Bearing	Code Number	Marking
0.2 mm 0.008 in.	Crankpin bearing 02	17331-22970	020 US
0.4 mm 0.016 in.	Crankpin bearing 04	17331-22980	040 US

- Undersize dimensions of crankpin

Undersize Dimension	0.2 mm 0.008 in.	0.4 mm 0.016 in.
	A	3.3 to 3.7 mm radius 0.1299 to 0.1457 in. radius
B	1.0 to 1.5 mm radius 0.0394 to 0.0591 in. radius	1.0 to 1.5 mm radius 0.0394 to 0.0591 in. radius
C	46.759 to 46.775 mm 1.84091 to 1.84154 in.	46.559 to 46.575 mm 1.83303 to 1.83366 in.

(0.8-S)
The crankpin must be fine-finished to higher than ∇∇∇∇

W1033106



Oil Clearance between Crankshaft Journal and Crankshaft Bearing 1

1. Measure the O.D. of the crankshaft journal with an outside micrometer.
2. Measure the I.D. of the crankshaft bearing 1 with an inside micrometer, and calculate oil clearance.
3. If the clearance exceeds the allowable limit, replace the crankshaft bearing 1.
4. If the same size bearing is useless because of the crankshaft journal wear, replace it with an undersize one referring to the table and figure.

Oil clearance between crankshaft journal and crankshaft bearing 1	Factory spec.	0.040 to 0.118 mm 0.00157 to 0.00409 in.
	Allowable limit	0.2 mm 0.0079 in.

Crankshaft journal O.D.	Factory spec.	D1503-M V1703-M V2203-M	51.921 to 51.940 mm 2.0441 to 2.0449 in.
		D1803-M V2403-M	59.921 to 59.940 mm 2.35909 to 2.35984 in.
Crankshaft bearing 1 I.D.	Factory spec.	D1503-M V1703-M V2203-M	51.980 to 52.039 mm 2.0464 to 2.0488 in.
		D1803-M V2403-M	59.980 to 60.039 mm 2.36142 to 2.36374 in.

(Reference)


- Undersize crankshaft bearing 1

Oversize	Bearing	Code Number	Marking
0.2 mm 0.008 in.	Crankshaft bearing 1 02	D1503-M V1703-M V2203-M	17311-23910
		D1803-M V2403-M	1A091-23911
0.4 mm 0.016 in.	Crankshaft bearing 1 04	D1503-M V1703-M V2203-M	17311-23920
		D1803-M V2403-M	1A091-23921

- Undersize dimensions of crankshaft journal

Dimension	Undersize	0.2 mm 0.008 in.	0.4 mm 0.016 in.
	A		2.8 to 3.2 mm radius 0.1102 to 0.1260 in. radius
B		1.0 to 1.5 mm radius 0.0394 to 0.0591 in. radius	1.0 to 1.5 mm radius 0.0394 to 0.0591 in. radius
C	D1503-M V1703-M V2203-M	51.721 to 51.740 mm 2.0363 to 2.0370 in.	51.521 to 51.540 mm 2.0284 to 2.0291 in.
	D1803-M V2403-M	59.721 to 59.740 mm 2.35122 to 2.35197 in.	59.521 to 59.540 mm 2.34335 to 2.34409 in.
(0.8-S) The crankshaft journal must be fine-finished to higher than ∇∇∇∇			

W1033717



Replacing Crankshaft Bearing 1

(When removing)

1. Press out the used crankshaft bearing 1 using a crankshaft bearing 1 replacing tool.


(When installing)

1. Clean a new crankshaft bearing 1 and crankshaft journal bore, and apply engine oil to them.
2. Using a crankshaft bearing 1 replacing tool, press in a new bearing 1 (2) so that its seam (1) directs toward the exhaust manifold side.

Dimension (A)	Factory spec.	4.2 to 4.5 mm 0.1654 to 0.1772 in.
---------------	---------------	---------------------------------------

- (1) Seam (2) Crankshaft Bearing 1 (3) Cylinder Block

W1033946



Oil Clearance between Crankshaft Journal and Crankshaft Bearing 2

1. Put a strip of plastigage on the center of the journal.
2. Install the bearing case and tighten the bearing case screws 1 to the specified torque, and remove the bearing case again.
3. Measure the amount of the flattening with the scale and get the oil clearance.
4. If the clearance exceeds the allowable limit, replace the crankshaft bearing 2.
5. If the same size bearing is useless because of the crankshaft journal wear, replace it with an undersize one referring to the table and figure.



NOTE

- Be sure not to move the crankshaft while the bearing case screws are tightened.

Oil clearance between crankshaft and crankshaft bearing 2	Factory spec.	0.040 to 0.104 mm 0.00157 to 0.00409 in.
	Allowable limit	0.20 mm 0.0079 in.

Crankshaft O.D.	Factory spec.	D1503-M	51.921 to 51.940 mm
		V1703-M	2.0441 to 2.0449 in.
		D1803-M	59.921 to 59.940 mm
		V2403-M	2.35909 to 2.35984 in.
Crankshaft bearing 2 I.D.	Factory spec.	D1503-M	51.980 to 52.025 mm
		V1703-M	2.0465 to 2.0482 in.
		D1803-M	59.980 to 60.025 mm
		V2403-M	2.36142 to 2.36318 in.

W1083821



Oil Clearance between Crankshaft Journal and Crankshaft Bearing 2 (Continued)

(Reference)


- Undersize crankshaft bearing 2

Oversize	Bearing	Code Number	Marking
0.2 mm 0.008 in.	Crankshaft bearing 2	D1503-M V1703-M V2203-M	17311-23930
		D1803-M V2403-M	1A091-23931
0.4 mm 0.016 in.	Crankshaft bearing 2	D1503-M V1703-M V2203-M	17311-23940
		D1803-M V2403-M	1A091-23941

- Undersize dimensions of crankshaft journal

Dimension	Undersize		
	0.2 mm 0.008 in.	0.4 mm 0.016 in.	
A	2.8 to 3.2 mm radius 0.1102 to 0.1260 in. radius	2.8 to 3.2 mm radius 0.1102 to 0.1260 in. radius	
B	1.0 to 1.5 mm radius 0.0394 to 0.0591 in. radius	1.0 to 1.5 mm radius 0.0394 to 0.0591 in. radius	
C, D	D1503-M V1703-M V2203-M	51.721 to 51.740 mm 2.0363 to 2.0370 in.	51.521 to 51.540 mm 2.0284 to 2.0291 in.
	D1803-M V2403-M	59.721 to 59.740 mm 2.35122 to 2.35197 in.	59.521 to 59.540 mm 2.34335 to 2.34409 in.
(0.8-S) The crankshaft journal must be fine-finished to higher than ∇∇∇∇			

W1034075




Crankshaft Sleeve Wear

1. Check the wear on the crankshaft sleeve (1).
2. If the wear exceeds the allowable limit or when the engine oil leaks, replace the crankshaft sleeve.


Wear of sleeve	Allowable limit
	0.1 mm 0.0004 in.

(1) Crankshaft Sleeve

W1033354




3TMABAB1P083A




3TMABAB1P084A

(E) Cylinder



3EEABAB1P154A



3EEABAB1P155A

Replacing Crankshaft Sleeve

1. Remove the used crankshaft sleeve using a special-use puller set (Code No.: 07916-32091).
2. Set the sleeve guide (2) to the crankshaft.
3. Set the stopper (1) to the crankshaft as shown in figure.
4. Heat a new sleeve to a temperature between 150 to 200 °C (302 to 392 °F), and fix the sleeve to the crankshaft as shown in figure.
5. Press fit the sleeve using the auxiliary socket for pushing (4).

NOTE

- Mount the sleeve with its largely chamfered surface facing outward.

- | | |
|-----------------------|----------------------------------|
| (1) Stopper | (4) Auxiliary Socket for Pushing |
| (2) Sleeve Guide | (5) Crankshaft |
| (3) Crankshaft Sleeve | |

W1033503

Cylinder Wear


1. Measure the I.D. of the cylinder at the six positions (see figure) with a cylinder gauge to find the maximum and minimum I.D.'s.
2. Get the difference (Maximum wear) between the maximum and the minimum I.D.'s.
3. If the wear exceeds the allowable limit, bore and hone to the oversize dimension. (Refer to "Correcting Cylinder".)
4. Visually check the cylinder wall for scratches. If deep scratches are found, the cylinder should be bores. (Refer to "Correcting Cylinder".)

Cylinder I.D.	Factory spec.	D1503-M	83.000 to 83.022 mm 3.2677 to 3.2686 in.
		D1703-M D1803-M V2203-M V2403-M	87.000 to 87.022 mm 3.42519 to 3.42606 in.
Maximum wear	Allowable limit	D1503-M	+0.15 mm +0.0059 in.
		D1703-M D1803-M V2203-M V2403-M	+0.15 mm +0.0059 in.

- (A) Top
- (B) Middle
- (C) Bottom (Skirt)

- (a) Right-angled to Piston Pin
- (b) Piston Pin Direction

W1034389



Correcting Cylinder (Oversize +0.25 mm)

1. When the cylinder is worn beyond the allowable limit, bore and hone it to the specified dimension.

Oversize cylinder I.D.	Factory spec.	D1503-M	83.250 to 83.272 mm 3.2776 to 3.2784 in.
		D1703-M D1803-M V2203-M V2403-M	87.250 to 87.272 mm 3.43503 to 3.43590 in.
Maximum wear	Allowable limit	D1503-M	+0.15 mm +0.0059 in.
		D1703-M D1803-M V2203-M V2403-M	+0.15 mm +0.0059 in.
Finishing	Hone to 2.2 to 3.0 mm μR max. ▽▽▽ (0.00087 to 0.00118 in. μR max.)		

2. Replace the piston and piston rings with oversize (+0.25 mm) ones.

Parts Name	Model	Code Number	Marking
Piston	D1503-M	1A021-21900	0.25 OS
	D1703-M D1803-M V2203-M V2403-M	1A091-21901	0.25 OS
Piston ring assembly	D1503-M	1A021-21090	0.25 OS
	D1703-M D1803-M V2203-M V2403-M	1A091-21091	0.25 OS


NOTE

- When the oversize cylinder is worn beyond the allowable limit, replace the cylinder block with a new one.

(1) Cylinder I.D. (Before Correction) (2) Oversize Cylinder I.D.


W1034448

Model	Factory spec.	Allowable limit
D1503-M	83.250 to 83.272 mm 3.2776 to 3.2784 in.	+0.15 mm +0.0059 in.
D1703-M D1803-M V2203-M V2403-M	87.250 to 87.272 mm 3.43503 to 3.43590 in.	+0.15 mm +0.0059 in.



[3] LUBRICATING SYSTEM

(1) Checking



Engine Oil Pressure

1. Remove the engine oil pressure switch, and set a oil pressure tester (Code No.: 07916-32032).
2. Start the engine. After warming up, measure the oil pressure of both idling and rated speeds.
3. If the oil pressure is less than the allowable limit, check the following.
 - Engine oil insufficient.
 - Oil pump defective
 - Oil strainer clogged
 - Oil filter cartridge clogged
 - Oil gallery clogged
 - Excessive oil clearance
 - Foreign matter in the relief valve

Engine oil pressure	At idle speed	Factory spec.	More than 98 kPa 1.0 kgf/cm ² 14 psi
	At rated speed	Factory spec.	294.2 to 441 kPa 3.0 to 4.5 kgf/cm ² 42.7 to 64 psi
		Allowable limit	245 kPa 2.5 kgf/cm ² 36 psi

(When reassembling)

- After checking the engine oil pressure, tighten the engine oil pressure switch to the specified torque.

W1034952


(2) Servicing



Rotor Lobe Clearance


1. Measure the clearance between lobes of the inner rotor and the outer rotor with a feeler gauge.
2. Measure the clearance between the outer rotor and the pump body with a feeler gauge.
3. If the clearance exceeds the factory specifications, replace the oil pump rotor assembly.

Clearance between inner rotor and outer rotor	Factory spec.	0.03 to 0.14 mm 0.0012 to 0.0055 in.
---	---------------	---



Clearance between outer rotor and pump body	Factory spec.	0.11 to 0.19 mm 0.0043 to 0.0075 in.
---	---------------	---

W1035296



3TMABAB1P088A

Clearance between Rotor and Cover


1. Put a strip of plastigage (Code No.: 07909-30241) onto the rotor face with grease.
2. Install the cover and tighten the screws.
3. Remove the cover carefully, and measure the width of the press gauge with a sheet of gauge.
4. If the clearance exceeds the factory specifications, replace oil pump rotor assembly.

End clearance between inner rotor and cover	Factory spec.	0.105 to 0.150 mm 0.00413 to 0.00591 in.
---	---------------	---

W1035444

[4] COOLING SYSTEM

(1) Checking and Adjusting



3EEABAB1P017B

Fan Belt Tension

1. Measure the deflection (A), depressing the belt halfway between the fan drive pulley and alternator pulley at specified force (98 N, 10 kgf, 22 lbs).
2. If the measurement is not within the factory specifications, loosen the alternator mounting screws and relocate the alternator to adjust.

Deflection (A)	Factory spec.	7.0 to 9.0 mm 0.28 to 0.35 in.
----------------	---------------	-----------------------------------

W1035667




3EEABAB1P019A


Fan Belt Damage and Wear

1. Check the fan belt for damage.
2. If the fan belt is damaged, replace it.
3. Check if the fan belt is worn and sunk in the pulley groove.
4. If the fan belt is nearly worn out and deeply sunk in the pulley groove, replace it.

W1035758



3EEABAB1P018B




3EEABAB1P160A

Thermostat Valve Opening Temperature

1. Suspend the thermostat in the water by a string with its end inserted between the valve and seat.
2. Heating the water gradually, read the temperature when the valve opens and leaves the string.
3. Continue heating and read the temperature when the valve opens approx. 6 mm (0.236 in.).
4. If the measurement is not within the factory specifications, replace the thermostat.

Thermostat's valve opening temperature	Factory spec.	69.5 to 72.5 °C 157.1 to 162.5 °F
Temperature at which thermostat completely opens	Factory spec.	85 °C 185 °F

W1035849



3EEABAB1P162A

Radiator Cap Air Leakage


CAUTION

- **When removing the radiator cap, wait at least ten minutes after the engine has stopped and cooled down. Otherwise, hot water may gush out, scalding nearby people.**

1. Set a radiator tester (Code No.: 07909-31551) on the radiator cap.
2. Apply the specified pressure (88 kPa, 0.9 kgf/cm², 13 psi), and measure the time for the pressure to fall to 59 kPa (0.6 kgf/cm², 9 psi).
3. If the measurement is less than the factory specification, replace the radiator cap.

Pressure falling time	Factory spec.	More than 10 seconds for pressure fall from 88 to 59 kPa (from 0.9 to 0.6 kgf/cm ² , from 13 to 9 psi)
-----------------------	---------------	--

W1036090



3EEABAB1P161A

Radiator Water Leakage

1. Pour a specified amount of water into the radiator.
2. Set a radiator tester (Code No. 07909-31551) with an adapter (BANZAI Code No. RCT-2A-30S) and raise the water pressure to the specified pressure.
3. Check the radiator for water leaks.
4. For water leak from the pinhole, replace the radiator or repair with the radiator cement. When water leak is excessive, replace the radiator.





Radiator water leakage test pressure	Factory spec.	137 kPa 1.4 kgf/cm ² 20 psi
--------------------------------------	---------------	--

W10389070

[5] FUEL SYSTEM

(1) Checking and Adjusting

(A) Injection Pump



Injection Timing

1. Remove the stop solenoid.
2. Remove the injection pipes and nozzle.
3. Set the speed control lever to maximum fuel discharge position.

(Reference)

- Turn the flywheel with screwdriver.

NOTE

- For V2203-M and V2403-M, the pumps have a displacement angle. In adjusting the injection timing, pull the stop lever from its free position by 0.267 ± 0.035 rad. ($15.3 \pm 2^\circ$) toward the stop position.


3. Turn the flywheel counterclockwise (facing the flywheel) until the fuel fills up to the hole of the delivery valve holder for 1st cylinder.
4. Turn the flywheel further and stop turning when the fuel begins to flow over, to get the present injection timing.
5. (The flywheel has mark 1TC and four lines indicating every 0.087 rad. (5°) of crank angle from 0.175 rad. (10°) to 0.436 rad. (25°) before mark 1TC) Calculate the angle which the center of the window points out. If the calculation differs from specified injection timing, add or remove the shim to adjust.

(Injection Timing)

0.297 to 0.331 rad. (17° to 19°) B.T.D.C.

NOTE

- The sealant is applied to both sides of the soft metal gasket shim. The liquid gasket is not required for assembling.
- Shims are available in thickness of 0.20 mm, 0.25 mm and 0.30 mm. Combine these shims for adjustments.
- Addition or reduction of shim (0.05 mm, 0.0020 in.) delays or advances the injection timing by approx. 0.0087 rad. (0.5°).
- In disassembling and replacing, be sure to use the same number of new gasket shims with the same thickness.




- (1) Speed Control Lever
- (2) Stop Lever
- (3) Delivery Valve Holder
- (4) Timing Mark
- (5) 2-Holes: 0.20 mm (Shim)
- (6) 1-hole: 0.25 mm (Shim)
- (7) Without hole: 0.30 mm (Shim)

- (A) To STOP Position
- (B) To Max. Speed Position
- (C) Stop Lever in Free Position

(a) 0.267 ± 0.035 rad. ($15.3 \pm 2^\circ$)

(B) Injection Nozzle**⚠ CAUTION**

- Check the nozzle injection pressure and condition after confirming that there is nobody standing in the direction the fume goes. If the fume from the nozzle directly contacts the human body, cells may be destroyed and blood poisoning may be caused.


**Nozzle Injection Pressure**

1. Set the injection nozzle to the nozzle tester.
2. Slowly move the tester handle to measure the pressure at which fuel begins jetting out from the nozzle.
3. If the measurement is not within the factory specifications, replace the injection nozzle assembly.

Fuel injection pressure	Factory spec.	13.73 to 14.71 MPa 140 to 150 kgf/cm ² 1991 to 2133 psi
-------------------------	---------------	--

(1) Adjusting Washer

W1037197


**Nozzle Spraying Condition**

1. Set the injection nozzle to a nozzle tester (Code No. 07909-31361), and check the nozzle spraying condition.
2. If the spraying condition is defective, replace the injection nozzle assembly.

(a) Good

(b) Bad

W1037394

**Valve Seat Tightness**

1. Set the injection nozzle to a nozzle tester (Code No. 07909-31361).
2. Raise the fuel pressure, and keep at 12.75 MPa (130 kgf/cm², 1849 psi) for 10 seconds.
3. If any fuel leak is found, replace the injection nozzle assembly.

Valve seat tightness	Factory spec.	No fuel leak at 12.75 MPa 130 kgf/cm ² 1849 psi
----------------------	---------------	---

W1088949


2 CLUTCH

MECHANISM

CONTENTS

1. FEATURE	2-M1
------------------	------

1. FEATURE





The dry single plate with diaphragm spring type clutch is adapted for all models.

This clutch is operated with the hanging type pedal, and the pedal (5) and release fork (3) have been linked as shown in figure.

- | | |
|-----------------------------|------------------------|
| (1) Clutch Disc | (8) Clutch Lever Shaft |
| (2) Pressure Plate Assembly | (9) Flywheel |
| (3) Release Fork | (10) Pressure Plate |
| (4) Clutch Pedal Rod | (11) Diaphragm Spring |
| (5) Clutch Pedal | (12) Main Shaft |
| (6) Release Bearing | (13) Clutch Cover |
| (7) Release Hub | (14) PTO Shaft |

W1012642



SERVICING

CONTENTS

1. TROUBLESHOOTING	2-S1
2. SERVICING SPECIFICATIONS	2-S2
3. TIGHTENING TORQUES	2-S3
4. CHECKING, DISASSEMBLING AND SERVICING.....	2-S4
[1] CHECKING AND ADJUSTING	2-S4
[2] DISASSEMBLING AND ASSEMBLING.....	2-S5
(1) Separating Clutch Housing and Engine	2-S5
(2) Removing Clutch Assembly	2-S14
[3] SERVICING	2-S15

1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
Clutch Drags	<ul style="list-style-type: none"> Clutch pedal free play excessive Dust on clutch disc generated from clutch disc facing Release fork broken Clutch disc or pressure plate warped Wire ring of the pressure plate worn or broken 	Adjust Remove rust Replace Replace Replace (Pressure Plate assembly)	2-S4 - 2-S15 2-S14 2-S14
Clutch Slips	<ul style="list-style-type: none"> Clutch pedal free play too small Clutch disc excessively worn Grease or oil on clutch disc facing Clutch disc or pressure plate warped Diaphragm spring weaken or broken Wiring of the pressure plate worn or broken 	Adjust Replace Replace Replace Replace Replace (Pressure Plate assembly)	2-S4 2-S14 2-S14 2-S14 2-S14 2-S14
Chattering	<ul style="list-style-type: none"> Grease or oil on clutch disc facing Clutch disc or pressure plate warped Clutch disc boss spline worn or rusted Gear shaft bent Pressure plate or flywheel face cracked or scored Clutch disc boss spline and gear shaft spline worn Diaphragm spring strength uneven or diaphragm spring broken 	Replace Replace Replace or remove rust Replace Replace Replace Replace	2-S14 2-S14 2-S14 3-S26, S62, S104 2-S14, 1-S39 2-S14, 3-S26, S62, S104 2-S14
Rattle During Running	<ul style="list-style-type: none"> Clutch disc boss spline worn Thrust ball bearing worn or sticking 	Replace Replace	2-S14 2-S15
Clutch Squeaks	<ul style="list-style-type: none"> Thrust ball bearing sticking or dry Clutch disc excessively worn 	Replace or lubricate Replace	2-S15 2-S14
Vibration	<ul style="list-style-type: none"> Gear shaft bent Clutch disc rivet worn or broken Clutch parts broken 	Replace Replace Replace	3-S26, S62, S104 2-S14 2-S14

W1014322

2. SERVICING SPECIFICATIONS

Item	Factory Specification	Allowable Limit
Clutch Pedal	Free play 20 to 30 mm 0.78 to 1.18 in.	—
Clutch Stopper Bolt	Height 18 to 22 mm 0.70 to 0.87 in.	—
Clutch Disc	Disc Surface to Rivet Top (Depth) —	0.3 mm 0.012 in.
Clutch Disc Boss to Gear Shaft	Backlash (Displacement Around Disc Edge) —	2.0 mm 0.079 in.
Pressure Plate	Flatness —	0.2 mm 0.008 in.
Diaphragm Spring	Mutual Difference —	0.5 mm 0.020 in.

W1013874

Item	Factory Specification	Allowable Limit
Clutch Pedal	Free play 20 to 30 mm 0.78 to 1.18 in.	—
Clutch Stopper Bolt	Height 18 to 22 mm 0.70 to 0.87 in.	—
Clutch Disc	Disc Surface to Rivet Top (Depth) —	0.3 mm 0.012 in.
Clutch Disc Boss to Gear Shaft	Backlash (Displacement Around Disc Edge) —	2.0 mm 0.079 in.
Pressure Plate	Flatness —	0.2 mm 0.008 in.
Diaphragm Spring	Mutual Difference —	0.5 mm 0.020 in.

3. TIGHTENING TORQUES


Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-9.)

Item	N·m	kgf·m	ft-lbs
ROPS lower connector mounting screw	103 to 118	10.5 to 12.0	75.9 to 86.8
ROPS plate mounting screw (M14 × 40)	138 to 147	14.0 to 15.0	102 to 108
(M14 × 30)	167 to 196	17.0 to 20.0	123 to 145
Step mounting bolt and nut	124 to 147	12.6 to 15.0	91.1 to 108
Floor seat mounting bolt and nut	196 to 225	20 to 23	145 to 166
Compressor mounting screw	24.5 to 29.4	2.5 to 3.0	18.1 to 21.7
Muffler mounting screw	31.4 to 37.2	3.2 to 3.8	23.1 to 27.5
Cabin mounting bolt and nut	124 to 147	12.6 to 15.0	91.1 to 108
Joint bolt for main delivery pipe 1	49 to 69	5.0 to 7.0	36.1 to 50.6
Joint bolt for PTO delivery pipe	34 to 39	3.5 to 4.0	25.3 to 28.9
Joint bolt for oil cooler pipe	34 to 39	3.5 to 4.0	25.3 to 28.9
Clutch mounting screw	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Release fork setting screw	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Engine and clutch housing mounting screw and nut	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Engine and clutch housing mounting stud bolt	39.2 to 49.0	4.0 to 5.0	28.9 to 36.2

W1012736

4. CHECKING, DISASSEMBLING AND SERVICING

[1] CHECKING AND ADJUSTING



Clutch Pedal Free Travel

⚠ CAUTION

• When checking, park the tractor on flat ground, apply the parking brake, stop the engine and remove the key.

1. Slightly depress the clutch pedal and measure free travel "L" at top of clutch pedal.
2. If the measurement is not within the factory specifications, loosen the lock nut (2), remove the clevis pin (3) adjust the length of rod (1) within acceptable limits.
3. Retighten the lock nut (2) and split the cotter pin (4).



Clutch pedal free travel on top of clutch pedal "L"	Factory spec.	20 to 30 mm 0.78 to 1.18 in.
---	---------------	---------------------------------

- | | |
|----------------------|------------------------|
| (1) Clutch Pedal Rod | (4) Cotter Pin |
| (2) Lock Nut | |
| (3) Clevis Pin | L : Free Travel |

W1018185

[2] DISASSEMBLING AND ASSEMBLING

(1) Separating Clutch Housing and Engine



Draining the Transmission Fluid

1. Place oil pans underneath the transmission case.
2. Remove the drain plugs (1).
3. Drain the transmission fluid.
4. Reinstall the drain plugs (1).

(When refilling)

- Fill up from filling port after removing the filling plug (2) until reaching the upper notch on the dipstick (3).
- After running the engine for few minutes, stop it and check the oil level again, add the fluid to prescribed level if it is not correct level.

Transmission fluid capacity	L3130 L3430	42 L 11.1 U.S.gals. 9.2 Imp.gals.
	L3830 L4330 L4630	43 L 11.4 U.S.gals. 9.5 Imp.gals.
	L5030	45 L 11.9 U.S.gals. 9.9 Imp.gals.

■ IMPORTANT

- Use only KUBOTA SUPER UDT fluid. Use of other oils may damage the transmission or hydraulic system. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7, 8.)
- Do not mix different brands of fluid together.

- (1) Drain Plugs
(2) Filling Plug
(3) Dipstick

(A) Oil level is acceptable within this range.

W1018004



Battery, Front Grill, Skirt and Bonnet

1. Open the bonnet and disconnect the battery negative cable.
2. Disconnect the head light connector and remove the front grill (4).
3. Remove the left and right side skirts (3).
4. Disconnect window washer hoses (2). (Cabin model only.)
5. Remove the bonnet (1).


■ NOTE

- When disconnecting the battery cords, disconnect the negative cord first, when connecting, positive cord first.

- (1) Bonnet
(2) Window Washer Hose

- (3) Skirt
(4) Front Grill

W1018348



ROPS

1. Remove the lower connector (2).
2. Remove the plate mounting screws (4), (8).
3. Remove the upper frame (1) from ROPS lower frame (5).

(When reassembling)




■ **NOTE**

- Do not firmly tighten all screws until most components are attached.

Tightening torque	Lower connector mounting screw (3)	103 to 118 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Plate mounting screw (4)	138 to 147 N·m 14.0 to 15.0 kgf·m 102 to 108 ft-lbs
	Plate mounting screw (8)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft-lbs

(Reference)

Tightening torque	Upper connector mounting screw (9)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft-lbs
	Fulcrum bolt and nut (11)	118 to 137 N·m 12.0 to 14.0 kgf·m 86.8 to 102 ft-lbs







- (1) Upper Frame
- (2) Lower Connector
- (3) Screw (M12 × 65)
- (4) Screw (M14 × 40)
- (5) Lower Frame
- (6) Plate
- (7) Connector
- (8) Screw (M14 × 30)

- (9) Screw (M14 × 30)
- (10) Upper Connector
- (11) Fulcrum Bolt and Nut
- (12) Lock Bolt

A : Rigid Type
B : Foldable Type

W1018522





Steering Joint, Heater Hoses and Electric Wiring

1. Remove the tank frame support (2).
2. Remove the universal joint bolt (10) and steering joint support (3), and then remove the steering joint (2).
3. Disconnect the hand accelerator wire and foot accelerator wire (7). (A foot accelerator is not equipped in HST model.)
4. Disconnect the wiring connectors for engine stop solenoid (8), engine tachometer sensor (9) and glow plug.
5. Disconnect the heater hoses (4), and then reconnect their hoses to make loop. (Cabin model only.)

NOTE

- Put a mark to the each heater hose before disconnecting.
6. Disconnect the wiring connector for window washer tank (5) and compressor 1P connector (6). (Cabin model only.)
 7. Disconnect the brake pedal rod.



(When reassembling)

- When accelerator wire is installed, adjust the wiring length as hit both the idling speed adjusting bolt and the maximum speed adjusting bolt by lever within the stroke of the accelerator lever.
- Set the steering joint (1) by the joint support (3) so that the steering wheel is turned lightly.
- Be sure to check and adjust the brake pedal free travel. (See page G-16.)

- (1) Steering Joint
- (2) Tank Frame Support
- (3) Steering Joint Support
- (4) Heater Hose
- (5) Window Washer Tank
- (6) 1P Connector

- (7) Accelerator Wire
 - (8) Engine Stop Solenoid
 - (9) Engine Tachometer Sensor
 - (10) Universal Joint Bolt
- [A] ROPS Model (HST)
[B] CABIN Model (GST)

W1018825



Clutch Rod, Brake Pedal Rod and Electric Wiring

1. Disconnect the brake pedal rod (5) and clutch rod (4).
2. Disconnect the wiring connectors for alternator (1), coolant temperature sensor (9), oil pressure switch (2), fuel unit (3), starter motor (6) and battery.
3. Remove the clamps and ground earth of wiring harness and collect wiring harness to the step or cabin.
4. Remove the clamps (7) of A/C hoses (8). (Cabin model only.)

(When reassembling)


- Be sure to check and adjust the clutch and brake pedal free travel. (See page G-16, 22.)





- (1) Alternator
- (2) Oil Pressure Switch
- (3) Fuel Unit
- (4) Clutch Rod
- (5) Brake Pedal Rod
- (6) Starter Motor

- (7) Clamps
- (8) A/C Hoses
- (9) Coolant Temperature Sensor

[A] ROPS Model
[B] Cabin Model

W1019114





Seat, Seat Bracket and Lever Grips

1. Remove the seat.
2. Disconnect the seat switch connector (3) and remove the seat bracket (1) with seat suspension (6).
3. Remove the front wheel drive lever (9).

(Manual Transmission Model)

4. Remove the lever grip for position control lever (2), range gear shift lever (4) and main gear shift lever (5).

(GST Model)

4. Remove the lever grip for position control lever (2) and creep shift lever (7) (if equipped).

(HST Model)

4. Remove the lever grip for position control lever (2), range gear shift lever (4) and cruise control lever (10).

- | | |
|----------------------------|-----------------------------|
| (1) Seat Bracket | (8) GST Lever |
| (2) Position Control Lever | (9) Front Wheel Drive Lever |
| (3) Seat Switch Connector | (10) Cruise Control Lever |
| (4) Range Gear Shift Lever | |
| (5) Main Gear Shift Lever | |
| (6) Seat Suspension | |
| (7) Creep Shift Lever | |

A : Manual Transmission Model
B : GST Model
C : HST Model

W1019332

Differential Lock Rod and Lowering Speed Adjusting Knob

1. Disconnect the differential lock rod (1).






(Reference)

- As for location of differential lock rod (1), it is at right side for manual transmission and GST model, and left side for HST model.

2. Remove the lowering speed adjusting knob (2).

- | | |
|---------------------------|-----------------------------------|
| (1) Differential Lock Rod | (2) Lowering Speed Adjusting Knob |
|---------------------------|-----------------------------------|

W1019603



Electric Connector for GST

1. Disconnect the ECU connector (1).
2. Disconnect the GST lever sensor connector (2).
3. Remove the GST valve cover.
4. Disconnect the pressure switch connector (4), proportional reducing valve connector (5), solenoid valve connector (6), oil temperature sensor connector (8) and ground cables (7).

(Reference)

- The ground cable (7) is at position where the manual transmission model is the same.

- | | |
|--|---|
| (1) ECU Connector | (5) Proportional Reducing Valve Connector |
| (2) GST Lever Sensor Connector | (6) Solenoid Valve Connector |
| (3) Wiring Harness of GST Lever Sensor | (7) Ground Cable |
| (4) Pressure Switch Connector | (8) Oil Temperature Sensor Connector |

W1019732

Electric Connector for HST

1. Remove the lowering speed adjusting knob (4).
2. Disconnect the differential lock rod (2).
3. Disconnect the range gear shift lever sensor connector (3).
4. Disconnect the cruise switch connector (1).
5. Disconnect the HST pedal neutral switch connector (5).
6. Disconnect the ground earth (a).

- | | |
|---|--|
| (1) Cruise Switch Connector | (4) Lowering Speed Adjusting Knob |
| (2) Differential Lock Pedal | (5) HST Pedal Neutral Switch Connector |
| (3) Range Gear Shift Lever Sensor Connector | (a) Ground earth is connected here |

W1019896

PTO Shift Wire and Electric Connector

1. Disconnect the PTO shift wire (2) at the PTO clutch valve lever (4).
2. Disconnect the traveling speed sensor connector (1).


(When reassembling)

- When connecting the PTO shift wire (2) to the lever (4), be sure to adjust the length of wire as follows.

1. Set the PTO shift lever to **OFF (Neutral)** position.
2. Loosen the lock nut (3) of wire, and connect wire to the clutch valve lever (4), and then place the wire to the hook.
3. Tighten the lock nut (3) clockwise (pull the wire), and lock the nut just before the lever moves.

- | | |
|--------------------------------------|----------------------------|
| (1) Traveling Speed Sensor Connector | (3) Lock Nut |
| (2) PTO Shift Wire | (4) PTO Clutch Valve Lever |

W1020066



Shuttle Switch Connector (Manual and GST Model)

1. Remove the panel cover and steering post cover.
2. Disconnect the shuttle switch connector (1).

(1) Shuttle Switch Connector

W1020239




Cruise Control Release Wire (HST Model)

1. Disconnect the cruise control release wire (1).
- (When reassembling)**

- Be sure to adjust the cruise control release wire (1). (See page 3-S95.)

(1) Cruise Control Release Wire

W1020333




Step and Floor Seat (ROPS Model)

1. Disconnect the panel frame connector (1) from fuel tank frame.
2. Remove the step and floor seat mounting bolt and nut.
3. Dismount the step, fender, floor seat and panel frame as a unit after checking whether there is forgetting to disconnect wiring.

(When reassembling)

- Be sure to set the washers and rubber plates of the floor seat and step mounting bolt at an original positions as shown in figure.
- Before mounting the floor seat and step, be sure to set both the shuttle lever rod and the shuttle arm to the neutral position, and then connect the shuttle lever rod securely. (Manual and GST model)







Tightening torque	Step mounting bolt and nut	124 to 147 N·m 12.6 to 15.0 kgf·m 91.1 to 108 ft·lbs
	Floor seat mounting bolt and nut	196 to 225 N·m 20 to 23 kgf·m 145 to 166 ft·lbs

- (1) Panel Frame Connector
- (2) Floor Seat
- (3) Bolt
- (4) Rubber Plate
- (5) Washer
- (6) Spring Washer

- (7) Nut
- (8) Step

F : Front Side
R : Rear Side

W1020698



Air Conditioner Parts (Cabin Model)

1. Remove the muffler (2).
2. Remove the air conditioner belt (4) and remove the compressor (1) mounting screw.
3. Remove the recovery tank (6) and window washer tank (7).
4. Disconnect the air cleaner hose (8).
5. Disconnect the recovery tank hose (5).
6. Disconnect the radiator upper hose (3).
7. Remove the oil cooler mounting screw. (HST model only)
8. Remove the battery (10).
9. Remove the battery stay mounting bolt.
10. Take out the compressor (1), condenser (11), receiver (12), hoses (13), battery stay (9) and etc. as a unit.

(When reassembling)

- After reassembling the compressor, be sure to adjust the air conditioner belt tension. (See page G-28.)

Tightening torque	Compressor mounting screw	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft·lbs
	Muffler mounting screw	31.4 to 37.2 N·m 3.2 to 3.8 kgf·m 23.1 to 27.5 ft·lbs

- | | |
|--------------------------|---------------------------|
| (1) Compressor | (8) Air Cleaner Hose |
| (2) Muffler | (9) Battery Stay |
| (3) Radiator Upper Hose | (10) Battery |
| (4) Air Conditioner Belt | (11) Condenser |
| (5) Recovery Tank Hose | (12) Receiver |
| (6) Recovery Tank | (13) Air Conditioner Hose |
| (7) Window Washer Tank | |

W1020914

Cabin Assembly

1. Remove the outer roof of cabin.
2. Support the cabin with nylon straps (1) and hoists.
3. Loosen and remove the cabin mounting bolts (2) and nuts (9).
4. Dismounting the cabin from tractor body.

NOTE

- Lift the cabin while making sure it does not catch on anything.



(When reassembling)

- Be sure to install the washers and mount rubbers, etc. in their original positions.
- Before mounting the cabin, be sure to set both the shuttle lever rod and the shuttle arm to the neutral position, and then connect the shuttle lever rod securely. (GST model)

Tightening torque	Cabin mounting bolt and nut	124 to 147 N·m 12.6 to 15.0 kgf·m 91.1 to 108 ft·lbs
-------------------	-----------------------------	--

- | | |
|------------------------|-------------------|
| (1) Nylon Straps | (7) Washer |
| (2) Bolt | (8) Spring Washer |
| (3) Plate | (9) Nut |
| (4) Mount Rubber | |
| (5) Collar | |
| (6) Plain Washer (M14) | |
- F : Front Side**
R : Rear Side

W1021215




Hydraulic Pipes

1. Remove the main delivery pipe 1 (2).
 2. Remove the PTO delivery pipe (3). (Manual and GST model)
 3. Disconnect the suction hose (1) from hydraulic pump.
 4. Remove the joint bolt (4) of oil cooler pipe (5). (HST model)
- (When reassembling)**

Tightening torque	Joint bolt for main delivery pipe 1 to front hydraulic block	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Joint bolt for PTO delivery pipe	34 to 39 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft-lbs
	Joint bolt for oil cooler pipe	34 to 39 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft-lbs

- (1) Suction Hose
 - (2) Main Delivery Pipe 1
 - (3) PTO Delivery Pipe
 - (4) Joint Bolt
 - (5) Oil Cooler Pipe
- [A] GST Model**
[B] HST Model

W1021456




Propeller Shaft (4WD Only)


1. Slide the propeller shaft cover (4) and (8) after removing the screws (7).
2. Tap out the spring pins (2), (6) and slide the couplings (1), (5) and then remove the propeller shaft with covers (4), (8).

(When reassembling)

- Apply grease to the splines of propeller shaft 1 (3).
- (1) Coupling
 - (2) Spring Pin
 - (3) Propeller Shaft 1
 - (4) Propeller Shaft Cover
 - (5) Coupling
 - (6) Spring Pin
 - (7) Screws
 - (8) Propeller Shaft Cover

W1021671





3TLABAB1P044A

Separating Engine and Clutch Housing

1. Place the disassembling stand under the engine and clutch housing case.
2. Remove the fuel tank support mounting screws.
3. Remove the engine and clutch housing mounting screws and nuts.
4. Separate the engine and clutch housing while lifting up the tank frame.

(When reassembling)

- Apply grease to the spline of clutch shaft.
- Apply liquid gasket (Three Bond 1211 or equivalent) to joint face of the flywheel housing and clutch housing.

Tightening torque	Engine and clutch housing mounting screw and nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Engine and clutch housing mounting stud bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs

W1021830

(2) Removing Clutch Assembly



3TLABAB2P004A

Clutch Assembly

1. Remove the clutch from the flywheel.

(When reassembling)

- Direct the shorter end of the clutch disc boss toward the flywheel.
- Apply molybdenum disulphide (Three Bond 1901 or equivalent) to the splines of clutch disc boss.
- Install the pressure plate, noting the position of straight pins.

■ IMPORTANT

- **Align the center of disc and flywheel by inserting the clutch center tool. (See page G-45.)**

■ NOTE


- **Do not allow grease and oil on the clutch disc facing.**

Tightening torque	Clutch mounting screws	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.5 to 20.3 ft-lbs
-------------------	------------------------	---

W1019957



3TLABAB2P005A



3TLABAB3P115B

Release Holder and Clutch Lever

1. Draw out the clutch release hub (6) and the release bearing (4) as a unit.
2. Remove the release fork setting screws (2).
3. Draw out the clutch lever (3) to remove the release fork (1).

(When reassembling)

- Make sure the direction of the release fork (1) is correct.
- Inject grease to the release hub (6).
- Be sure to set the snap pins (5).

Tightening torque	Release fork setting screws	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft-lbs
-------------------	-----------------------------	---

- | | |
|-------------------|---------------------|
| (1) Release Fork | (4) Release Bearing |
| (2) Setting Screw | (5) Snap Pin |
| (3) Clutch Lever | (6) Release Hub |

W1015118

[3] SERVICING



3TMABAB2P007A

Backlash between Clutch Disc Boss and Gear Shaft

1. Mount the clutch disc to the gear shaft.
2. Hold the gear shaft so that it may not turn.
3. Rotate disc lightly and measure the displacement around the disc edge.
4. If the measurement exceeds the allowable limit, replace the disc.

Displacement around disc edge	Allowable limit	2.0 mm 0.079 in.
-------------------------------	-----------------	---------------------

W1016866



3TMABAB2P008A


Thrust Ball Bearing

1. Remove the thrust ball bearing from release hub with a puller.
2. Check for abnormal wear on contact surface.
3. Hold bearing inner race and rotate outer race, while applying pressure to it.
4. If the bearing rotation is rough or noisy, replace the bearing.

NOTE

- Do not depress outer race, while installing thrust ball bearing

W1017028



3TMABAB2P009A




Clutch Disc Wear

1. Measure the depth from clutch disc surface to the top of rivet at least 10 points with a depth gauge.
2. If the depth is less than the allowable limit, replace the disc.
3. If oil is sticking to clutch disc, or disc surface is carbonized, replace the disc.

In this case, inspect transmission gear shaft oil seal, engine rear oil seal and other points for oil leakage.

Disc surface to rivet top (Depth)	Allowable limit	0.3 mm 0.012 in.
-----------------------------------	-----------------	---------------------

W1017162



Checking Pressure Plate Assembly and Flywheel

1. Wash the disassembling parts except clutch disc with a suitable cleaning solvent to remove dirt and grease before making inspection and adjustment.
2. Check friction surface of pressure plate and flywheel for scoring or roughness.
 - Slight roughness may be smoothed by using fine emery cloth.
 - If these parts have deep scores or grooves on their surface, they should be replaced.
3. Check the surface of the diaphragm spring for wear. If excessive wear is found, replace clutch cover assembly.
4. Inspect thrust rings (wire ring) for wear or damage. As these parts are invisible from outside, shake pressure plate assembly up and down to listen for chattering noise, or lightly hammer on rivets for a slightly cracked noise. Any of these noises indicates need of replace as a complete assembly.

Diaphragm spring mutual difference	Allowable limit	0.5 mm 0.020 in.
------------------------------------	-----------------	---------------------

W1017284

Pressure Plate Flatness

1. Place a straight edge on the pressure plate and measure clearance with a feeler gauge at several points.
2. If the clearance exceeds the allowable limit, replace it.
3. When the pressure plate is worn around its outside and its inside surface only is in contact with the straight edge, replace even if the clearance is within the allowable limit.

Clearance between pressure plate and straight edge	Allowable limit	0.2 mm 0.008 in.
--	-----------------	---------------------

A : inside

B : Outside

W1017439

3 TRANSMISSION


MECHANISM

CONTENTS

1. MANUAL TRANSMISSION MODEL	3-M1
[1] STRUCTURE	3-M1
[2] POWER TRAIN FOR TRAVELING GEAR	3-M2
(1) Main Gear Shift Section	3-M2
(2) Shuttle Shift Section	3-M2
(3) Range Gear Shift Section	3-M3
(4) Front Wheel Drive Section (For Four Wheel Drive Model)	3-M3
[3] SHIFT LINKAGE MECHANISM	3-M4
(1) Main Gear Shift Lever	3-M4
(2) Shuttle Lever	3-M4
(3) Range Gear Shift Lever	3-M5
(4) Front Wheel Drive Lever (For Four Wheel Drive Model)	3-M5
2. GLIDE SHIFT TRANSMISSION (GST) MODEL	3-M6
[1] STRUCTURE	3-M6
[2] CHARACTERISTIC AND SYSTEM OUTLINE	3-M7
[3] POWER TRAIN	3-M8
[4] ELECTRICAL CONTROL SYSTEM	3-M9
(1) Construction and Function of Components	3-M9
(2) Electrical Control	3-M12
[5] HYDRAULIC CONTROL SYSTEM	3-M13
(1) Hydraulic Circuit and System Outline	3-M13
(2) Construction and Function of Components	3-M15
[6] SHIFT LINKAGE MECHANISM	3-M22
3. HYDROSTATIC TRANSMISSION (HST) MODEL	3-M23
[1] STRUCTURE	3-M23
[2] POWER TRAIN	3-M24
(1) Hydrostatic Transmission (HST)	3-M24
(2) Range Gear Shift Section	3-M34
(3) Front Wheel Drive Section	3-M34
[3] SHIFT LINKAGE MECHANISM	3-M35
(1) Range Gear Shift Lever	3-M35
4. PTO SYSTEM	3-M36
[1] STRUCTURE	3-M36
[2] PTO CLUTCH	3-M37
(1) Shift Linkage	3-M37
(2) Oil Flow	3-M37
(3) Operation	3-M38
[3] MID PTO (OPTION)	3-M39
(1) Power Train	3-M39
(2) Shift Linkage	3-M39
5. CREEP SPEED SYSTEM (OPTION)	3-M40
[1] POWER TRAIN	3-M40
[2] SHIFT LINKAGE	3-M40

1. MANUAL TRANSMISSION MODEL

[1] STRUCTURE



(1) Main Gear Shift Section
(2) PTO Clutch Section

(3) Shuttle Shift Section

(4) Range Gear Shift Section


(5) Front Wheel Drive Shift Section

[2] POWER TRAIN FOR TRAVELING GEAR

The transmission consists of a series of gears and shafts as shown in previous page.

The traveling system consists of main gear shift section, shuttle shift section, range gear shift section and front wheel drive section.

(1) Main Gear Shift Section




The main gear shift section is located in the clutch housing, and it uses a synchromesh.

Power which is transmitted from the engine to the gear shaft (1) via the clutch is changed in four ways by operating the main shift lever to shift the shifters, and transmits to the counter shaft (3).

- | | |
|-------------------------------------|-------------------------------------|
| (1) Gear Shaft (Input) | (8) Gear for 2nd |
| (2) Main Shaft | (9) Synchromesh Gears (1st and 2nd) |
| (3) Counter Shaft | (10) Gear for 1st |
| (4) Shuttle Shaft | a : 4th Speed |
| (5) Gear for 4th | b : 3rd Speed |
| (6) Synchromesh Gears (3rd and 4th) | c : 2nd Speed |
| (7) Gear for 3rd | d : 1st Speed |

W1012742


(2) Shuttle Shift Section



The shuttle shift section is located in the mid case, and it uses a double cone type synchromesh. It allows the operator to change forward and reverse for each speed from the first to eighth with single shift lever.

The double cone type synchromesh is characterized by its light operating force and durability because it engages with the gear in reverse rotation when the speed is changed from forward to reverse position or vice versa.


Two synchronizing rings (7), (9) are installed on one side, and the center ring (8) is provided between the synchronizing rings. This construction doubles the ground contact area of the synchronizer rings (7), (9) and improves the durability as compared with the ordinary key type synchromesh.



- | | |
|--|-----------------------------|
| (1) Shuttle Shaft (Connected to Counter Shaft) | (7) Outer Synchronizer Ring |
| (2) Shuttle Gear Shaft (Connected to Range Gear Shaft) | (8) Center Ring |
| (3) Gear for Forward | (9) Inner Synchronizer Ring |
| (4) Double Cone Type Synchromesh | (10) Synchronizer Key |
| (5) Gear for Reverse | (11) Synchronizer Spring |
| (6) Reverse Gear Shaft | (12) Hub |
| | (13) Shifter |
- F : Forward**
R : Reverse

W1012964

(3) Range Gear Shift Section




The range gear shift section is located in the differential gear case, and it uses constant mesh.

- (1) Shuttle Gear Shaft
 - (2) Gear for Low
 - (3) Shifter
 - (4) Gear for High
 - (5) Range Gear Shaft
 - (6) Counter Gear
 - (7) Spiral Bevel Pinion
- L : Low Speed**
H : High Speed

W1013209


(4) Front Wheel Drive Section (For Four Wheel Drive Model)



Front wheel drive shift section is located in the differential gear case. 2 wheel drive or 4 wheel drive is selected by operating the front wheel drive lever to shift the shifter gear (4).


- (1) Spiral Bevel Pinion
 - (2) Gear
 - (3) Front Wheel Drive Gear
 - (4) Shifter Gear
 - (5) Front Wheel Drive Shaft
(Connected to Propeller Shaft)
- a : 4 Wheel Drive Position**

W1013518



[3] SHIFT LINKAGE MECHANISM

(1) Main Gear Shift Lever



The links are connected from the shift lever (6) to the shift forks (1), (2) as shown in the figure. Each speed from the 1st to 4th can be changed by a single shift lever (6).


When the shift lever (6) is moved to the left, the shift arm (3) is engaged with the 1-2 shift fork (1), allowing the operator to change the 1st or the 2nd speed.

When the shift lever (6) is moved to the right, the shift arm (3) is engaged with the 3-4 shift fork (2), allowing the operator to change the 3rd or the 4th speed.

- | | |
|---------------------------|---------------------------|
| (1) 1-2 Shift Fork | R : Right Movement |
| (2) 3-4 Shift Fork | L : Left Movement |
| (3) Shift Arm | 1 : 1st Shift |
| (4) Shift Rod 1 | 2 : 2nd Shift |
| (5) Shift Rod 2 | 3 : 3rd Shift |
| (6) Main Gear Shift Lever | 4 : 4th Shift |

W1013619

(2) Shuttle Lever




The links are connected from the shift lever (1) to the shift fork (7) as shown in the figure.

When the shift lever (1) is moved to the **F** side, the shift fork (7) is moved toward the **F** side, allowing the operator to shift to forward by means of the shuttle universal joint (2), shuttle shift shaft (3), shift arm (6), and shuttle fork rod (5).

When the shift lever (1) is moved to the **R** side, the shift fork (7) is shifted to reverse position.

- | | |
|-----------------------------|--------------------------|
| (1) Shuttle Shift Lever | (6) Shift Arm |
| (2) Shuttle Universal Joint | (7) Shift Fork |
| (3) Shuttle Shift Shaft | |
| (4) Shuttle Switch | F : Forward Shift |
| (5) Shuttle Fork Rod | R : Reverse Shift |

W1013763

(3) Range Gear Shift Lever


The links from the shift lever (1) to the shift fork (5) are connected as shown in the figure.

When the shift lever (1) is moved to the **A** side, the shift fork (5) is moved to the **A** side by means of the rod (2), sub-arm (3), and shift arm (4), changing the shift arm to the Lo-speed side. When the shift lever (1) is moved to the **B** side, the shift fork (5) is moved to the Hi-speed side.

- (1) Shift Lever
- (2) Rod
- (3) Sub-arm
- (4) Shift Arm
- (5) Shift Fork

A : Lo-speed Shift
B : Hi-speed Shift

W1013899

(4) Front Wheel Drive Lever (For Four Wheel Drive Model)

The shift lever (1) is connected directly to the shift fork (2).

When the shift lever (1) is moved to the **A** side, the shift fork (2) is also moved to the **A** side, then the front wheel drive is "**Engaged**".

When the shift lever (1) is moved to the **B** side, the front wheel drive is "**Disengaged**".


- (1) Shift Lever
- (2) Shift Fork
- (3) Shifter Gear

A : Engaged
B : Disengaged

W1014303

2. GLIDE SHIFT TRANSMISSION (GST) MODEL

[1] STRUCTURE



3TLABAB3P011A


(1) Main Gear Shift Section
 (2) Clutch Pack for GST

(3) PTO Shift Section
 (4) Shuttle Shift Section

(5) Range Gear Shift Section

(6) Front Wheel Drive Shift Section

[2] CHARACTERISTIC AND SYSTEM OUTLINE



3TLABAB3P012A

The GST of a new version is adapted in the L30 series tractor. In addition to the former GST system that controls the gear shifting and clutch operation hydraulically, this new GST has the function to control these operations electrically.


12 forward and 8 reverse speeds can shift only by operating the main shift lever (GST lever) (4) and shuttle shift lever (3) without the clutch operation as well as the former GST system. In addition, the movement and gear shifting according to the oil temperature and the traveling speed can be achieved by having electronically controlled the GST system, and a smoother operation can be done.

Moreover, because the selected speed and the traveling speed can be confirmed by the liquid crystal display (LCD) (1) of electronic instrument panel (IntelliPanel) (2), it can do a comfortable tractor operation. And it is excellent in service because it can confirm the error indication with an electronic instrument panel (2) when the electric wiring is disconnected or short-circuited.

- (1) Liquid Crystal Display (LCD)
- (2) Electronic Instrument Panel (IntelliPanel)
- (3) Shuttle Lever
- (4) Main Shift Lever (GST Lever)

W1014583

[3] POWER TRAIN



(1) Main Shift Section (2) GST Clutch Pack (3) Sub-range Shift Section (4) Shuttle Shift Section (5) Main Range Shift Section

The transmission is composed of the fully synchronized gear shifting and the hydraulic clutch as shown above figure. And the double cone type synchromesh is adapted on the 4th speed side of main shift section (1), shuttle shift section (4) and L side of main range shift section (5).

As for the speed changing, only by operating the GST lever, the shifter of the gear changing is moved by hydraulic operation which is electrically controlled. And as for each gear changing, each shift is moved according to the shift pattern input to the electric control unit (ECU). The shift pattern is shown in the table below.

Regarding a double cone type synchromesh system and front wheel drive section, these are basically similar to manual transmission model and refer to page 3-M2 and 3-M3.

(Forward shift pattern)

Lever Location at Lever Guide	1	2	3	4	5	6	7	8	9	10	11	12
Display on LCD	1	2	3	4	5	6	7	8	9	10	11	12
(1) Main Shift	1	2	3		4		1		2		3	4
(3) Sub-range Shift	Hi		Lo	Hi	Lo	Hi	Lo	Hi	Lo	Hi		
(5) Main Range Shift	L						H					

(Reverse shift pattern)


Lever Location at Lever Guide	1	2	3	4	5	6	7	8	9	10	11	12
Display on LCD	1	2	3		4		5		6		7	8
(1) Main Shift	1	2	3		4		1		2		3	4
(5) Main Range Shift	L						H					

[4] ELECTRICAL CONTROL SYSTEM

■ NOTE


- Only the electrical control system concerning the GST operation has been described in this section. Therefore, refer to "ELECTRICAL SYSTEM" section (Section 9) for a general electrical control system.

(1) Construction and Function of Components



- | | | | |
|------------------------------|----------------------------|--|---------------------------------|
| (1) Traveling Speed Sensor | (4) Shuttle Switch | (7) GST Valve
(Solenoid Valve and
Proportional Reducing Valve) | (8) Electric Control Unit (ECU) |
| (2) Engine Tachometer Sensor | (5) Pressure Switch | | (9) Electronic Instrument Panel |
| (3) GST Lever Sensor | (6) Oil Temperature Sensor | | (10) Battery |

The electric control of the GST system is composed by parts shown in the above figure.




■ Electric Control Unit (ECU)

This unit incorporates an electronic circuit for various control of GST system and it is equipped on the left under of the platform.

The ECU processes and judges the input data from various switches and sensors and send the signal to various solenoid valves (solenoid valves and proportional reducing valve). At the same time, it also sends the communication data to display the selected-speed and several messages in electronic instrument panel.

- (1) Electric Control Unit

W1015703




3TLABAB3P016A

■ Electronic Instrument Panel (IntelliPanel)

The 8 bits CPU is built into this panel.

The electronic instrument panel has functions to receive several data of GST control from the ECU, and output them to the liquid crystal display and the monitor lamps. Moreover, it transmits the model data and the sensor data, etc. also to the ECU.

W1015755



3TLABAB3P017A


■ GST Lever Sensor

This sensor has function to detect the GST lever position, and it is equipped on the bottom of the GST lever (2).

This sensor is a variable resistor of the rotation displacement type, and all resistance is 2 k Ω , and electrically effective angle is 140 degrees. Then, the lever position from **N** to 12 speed is output within the range from about 0.7 to 4.2 voltages.

(1) GST Lever Sensor (2) GST Lever

W1015847



3TLABAB3P018A


■ Shuttle Switch

This switch has function to detect the shuttle lever position, and it is equipped on the bottom of the shuttle lever rod (2).

This switch has three contact points, which is **Forward**, **Neutral** and **Reverse**, and detects their position. As for GST control, it judges the shuttle start condition.

(1) Shuttle Switch (2) Shuttle Lever Rod

W1015891




3TLABAB3P019A

■ Engine Tachometer Sensor

This sensor is to detect the engine rotating speed, and it is equipped on the left side of the engine gear case. This sensor perceives tooth of the fuel camshaft gear and emits the pulse. This pulse is sent to the electronic instrument panel, and converted at the engine speed. The data of engine speed is always sent to the ECU.

(1) Engine Tachometer Sensor

W1015946




■ **Pressure Switch**

This switch is to detect the gear change completion and hydraulic clutch operation, and it is equipped on the GST valve.

This switch is turned **ON** when the pressure in the GST valve becomes higher than 0.49 MPa (5 kgf/cm², 71 psi) of the pilot pressure, and it is turned **OFF** at a pressure lower than 0.34 MPa (3.5 kgf/cm², 50 psi).

(1) Pressure Switch

W1015998



■ **Oil Temperature Sensor**

This sensor is to detect the temperature of transmission fluid, and it is equipped on the GST valve.

This is provided to make correction for driving time and current of proportional reducing valve in accordance with the oil temperature. This is used to thermistor, and it has such characteristics that its resistance decreases at high temperature and increases at low temperature.

(1) Oil Temperature Sensor

W1016064






■ **Traveling Speed Sensor**

This sensor is to detect the traveling speed, and it is equipped on the right bottom side of the differential case. This sensor perceives tooth of the front wheel drive gear (3) on the PTO drive shaft (2) and emits pulse. This pulse is sent to the electronic instrument panel, and the traveling speed is calculated by the coefficient which is set according to the tire size. The data of traveling speed is always sent to the ECU.

(1) Traveling Speed Sensor (3) Front Wheel Drive Gear
(2) PTO Drive Shaft

W1015587



(2) Electrical Control

An electrical control of GST system is as follows.

1. Shift the GST lever and shuttle lever to desired position.
2. The output voltage of selected gear shift position is output to microcomputer of the ECU by lever sensor.
3. The ECU detects the gear shift position with GST lever sensor and shuttle switch, and excites various solenoid valves in accordance with selected position.
4. When the desired solenoid is excited, oil is sent to the desired shift piston.
5. A pressure in the circuit is raised because the movement of shift piston shuts the shift check pin. When the pressure in the circuit reaches 0.49 MPa (5 kgf/cm², 71 psi), the pressure switch becomes **ON**.
6. By means of the pressure switch's **ON**, the ECU detects the present condition (traveling speed, engine speed and oil temperature) from various sensors, and pressure in the hydraulic clutch is raised according to the respective condition.

■ **NOTE**

- **By means of speed increasing, speed decreasing, traveling speed, engine speed and oil temperature, the indicated pressure period from c to d is controlled at appropriate pressure respectively.**
7. A pressurizing to hydraulic clutch has been done until it reaches the system pressure, and pressure in the clutch is maintained at this state.


P : Pressure
 H : Time
 a : Starting of clutch engaging
 b : Low-pas pressure

c : Starting of pressurized
 c to d :Specified pressure from ECU
 e : Gear shifting completion

W1016324

[5] HYDRAULIC CONTROL SYSTEM

(1) Hydraulic Circuit and System Outline



3TLABAB3P025A

- | | | | |
|--|--|---|--|
| (1) Regulating Valve Assembly | (11) Solenoid Valve 5
(Sub-range Shift) | (19) 3-4 Shift Check Valve | a : To Steering Controller |
| (2) Hydraulic Pump | (12) Shift Piston
(Main Range Shift) | (20) 1-2 Shift Check Valve | b : From Steering Controller |
| (3) Hydraulic Oil Filter | (13) 3-4 Shift Piston | (21) Shift Check Valve
(Sub-range Shift) | c : To PTO Clutch Valve |
| (4) Regulating Valve | (14) Solenoid Valve 4 | (22) Shift Check Valve, Shuttle | d : Check port for pilot
pressure |
| (5) Pressure Reducing Valve | (15) 1-2 Shift Piston | (23) Pressure Switch | e : Check port for clutch
pressure |
| (6) Check Valve | (16) Solenoid Valve 2 | (24) Clutch Valve | f : Check port for Low-pass
pressure |
| (7) Oil Temperature Sensor | (17) Shift Piston (Sub-range Shift) | (25) Low-pass Valve | g : Check port for system
pressure |
| (8) Solenoid Valve 6
(Main Range Shift) | (18) Shift Check Valve
(Main Range Shift) | (26) Proportional Reducing Valve | |
| (9) Solenoid Valve 3 | | (27) GST Clutch | |
| (10) Solenoid Valve 1 | | (28) GST Valve Assembly | |

No.	Solenoid	Color of wiring
(1)	Solenoid 1	Black
(2)	Solenoid 2	White
(3)	Solenoid 3	Red
(4)	Solenoid 4	Green
(5)	Solenoid 5 (Sub-range)	Blue
(6)	Solenoid 6 (Main range)	Yellow



- Oil is supplied from the power steering hydraulic pump (2) while running the engine.
- The oil entering the regulating valve assembly (1) flows through the pressure reducing valve (5) to the GST circuit. This oil pressure is maintained at a fixed level by the pressure reducing valve (5).
- When the GST lever is operated, the desired shift solenoids (8), (9), (10), (11), (14) or (16) are excited according to the output voltage from the GST lever sensor.
- When the solenoid valve is operated, oil is supplied to corresponded shift pistons (12), (13), (15) or (17), and the shift piston is moved. The shift arm that is moved by the shift piston moves shifter of synchromesh to shift the gear. At this time, GST clutch (27) has been disengaging until gear shifting is completed. The GST clutch (27) is engaging except where the condition is neutral, is gear shifting and is engine stopping.
- Pressure in the pilot circuit rises because the shift check valves (18), (21) and (19) or (20) are shut by the movements of shift pistons at the same time as completing gear shifting.
- By means of pressure rising of the circuit, the clutch valve (24) is actuated. And, oil flows through the low-pass valve (25) and the proportional reducing valve (26) to the GST clutch (27). This oil flows until becoming the compound pressure which is both of setting pressure for closing of low-pass valve, and controlled indication pressure of the proportional reducing valve.

(Reference)


- Setting pressure for closing of low-pass valve : 0.24 MPa (2.5 kgf/cm², 34.1 psi)
- Because pressure in the GST clutch (27) is gradually pressurized by function of proportional reducing valve (26), clutch is able to engage without shock and smoothly.
 - When the pressure in the circuit rises to the system pressure, pressure is maintained. And the GST clutch is maintained at engaging condition until the next gear shifting.

State of energizing of solenoid**(Forward)**

	N	1st	2nd	3rd	4th	5th	6th	7th	8th	9th	10th	11th	12th
Solenoid 1(10)		ON						ON	ON				
Solenoid 2 (16)			ON							ON	ON		
Solenoid 3 (9)				ON	ON							ON	
Solenoid 4 (14)						ON	ON						ON
Solenoid 5 (11)	(ON)			ON		ON		ON		ON			
Solenoid 6 (8)	(ON)	ON	ON	ON	ON	ON	ON						

(Reverse)

	N	1st	2nd	3rd	4th	5th	6th	7th	8th
Solenoid 1 (10)		ON				ON			
Solenoid 2 (16)			ON				ON		
Solenoid 3 (9)				ON				ON	
Solenoid 4 (14)					ON				ON
Solenoid 5 (11)	(ON)	ON	ON	ON	ON	ON	ON	ON	ON
Solenoid 6 (8)	(ON)	ON	ON	ON	ON				




No.	Solenoid	Color of wiring
(10)	Solenoid 1	Black
(16)	Solenoid 2	White
(9)	Solenoid 3	Red
(14)	Solenoid 4	Green
(11)	Solenoid 5, Sub-range Lo-Hi	Blue
(8)	Solenoid 6, Main range L-H	Yellow

3TLABAB3P026A


W1019092

(2) Construction and Function of Components


(A) Regulating Valve



3TLABAB3P027A



3TLABAB3P028A



3TLABAB3P029A

The oil from the hydraulic pump for the power steering system flows to the GST circuit to set the pressure of the circuit. Other oil flows to the power steering circuit.





The oil from the power steering hydraulic pump (2) flows through the pressure reducing valve (5) to the GST circuit. When the oil is filled into the circuit, the pressure reducing valve (5) is closed to maintain the pressure in the GST system circuit to 2.45 MPa (25.0 kgf/cm², 356 psi).

The oil from the power steering pump passes through the regulating valve (3) and check valve (4), and then it flows to power steering circuit. The regulating valve (3) is provided to maintain 2.94 MPa (30.0 kgf/cm², 427 psi) at inlet pressure of the pressure reducing valve (5) except when the power steering is operated. Thereby getting 2.45 MPa (25.0 kgf/cm², 356 psi) of the GST circuit pressure.

- (1) Regulating Valve Assembly
 - (2) Hydraulic Pump
 - (3) Regulating Valve
 - (4) Check Valve
 - (5) Pressure Reducing Valve
- A : To Power Steering Circuit
 - B : To GST Circuit and PTO Clutch Valve
 - C : From Power Steering Circuit
 - D : From Hydraulic Pump

W1019304

(B) GST Valve



■ GST Valve Assembly

The GST valve assembly is installed at the left side of the transmission mid case. In the GST valve assembly, many parts comprising the system are installed, including the solenoid valves, shift pistons, shift check valves, low-pass valve, proportional reducing valve, clutch valve, check valves, sensor and switches. The GST valve assembly functions as the central unit of the GST system.

- | | |
|-----------------------------------|--|
| (1) GST Valve Assembly | (6) Connector for Oil Temperature Sensor |
| (2) Clutch Valve | (7) Connector for Solenoid Valve |
| (3) Low-pass Valve | (8) Solenoid Valves Switch |
| (4) Connector for Pressure Switch | |
| (5) Proportional Reducing Valve | a : Oil From Regulating Valve |

W1019626

■ Solenoid Valve




When the GST lever is operated, the solenoid valve controls the flow of oil according to the gear shifting operation.

When the solenoid is not excited, oil flows to the shift piston through the surrounding of the ball in the valve. When the solenoid is excited, it presses the ball against the valve seat to open the unload passage, and drain the oil.

When the solenoid is not excited, oil from regulating valve flows to the shift piston through the surrounding of the ball (10) in the valve. When the solenoid is excited, plunger (9) presses the ball against the valve seat (11) to open the unload passage (12), and drain the oil.

- | | |
|---|----------------------------|
| (1) Solenoid Valve 4 | (9) Plunger |
| (2) Solenoid Valve 3 | (10) Ball |
| (3) Solenoid Valve 6 (Main Range Shift) | (11) Valve Passage |
| (4) Solenoid Valve 5 (Sub-range Shift) | (12) Unload Passage |
| (5) Solenoid Valve 2 | |
| (6) Solenoid Valve 1 | T : Drain Port |
| (7) Solenoid | R : IN Port |
| (8) Solenoid Valve | P : To Shift Piston |

W1019949







■ Shift Piston

The shift pistons (1), (2), (3), (4) are actuated by the oil distributed by the each solenoid valve. At the tip of these shift pistons (1), (2), (3) are installed the shifters (5), which are connected to each shift rod and shift the gear.

There are neutral positions in 1-2 shift piston (2) and 3-4 shift piston (1).

- (1) 3-4 Shift Piston
 - (2) 1-2 Shift Piston
 - (3) Main Range Shift Piston
 - (4) Sub-range Shift Piston
 - (5) Shifter
 - (6) Valve Body
 - (7) Cover
 - (8) Piston
 - (9) Ball for Check Valve
 - (10) Spring
 - (11) Check Pin
 - (12) Ball for Detent
 - (13) Neutral Piston
- A : Shift Piston for Main Range Shift**
B : 1-2 and 3-4 Shift Piston

W1020109



■ Shift Check Valve

The shift check valves (2), (3), (4), (5), (6) are provided on each shift piston and the shuttle shift rod.

From the start to the end of gear shifting, the shift check valves (2), (4), (5), (6) of the shift pistons are opened because the ball (9) of the check pin (18) is on the straight portion, the oil in the pilot circuit of the clutch valve passes through the shift check valves (2), (3), (4), (5), (6) to be drained into the tank, causing the GST clutch to be disengaged.




When the gear shifting is completed, the ball (9) of the check pin (18) enters the groove of the shift piston; the check valve is closed, causing the pilot circuit pressure to rise and the clutch valve to open. Thus, the oil flows into the GST clutch to engage it. The 1-2 shift check valve (6) and 3-4 shift check valve (5) compose a serial circuit. When either valve is closed, the oil in the pilot circuit will not be drained into the tank.

In case of the shuttle shifting, the shift check valve (3) is opened and closed by the groove of the shuttle shift rod.

Note that the shuttle shift fork rod has a slot into which the shift fork mounting bolt is inserted. Therefore, when the shuttle shift lever is moved, the shuttle shift fork rod is moved before the shuttle shift fork is moved, disengaging the clutch pack and thus moving the shuttle shift fork.

- | | |
|----------------------------------|-------------------------------------|
| (1) GST Valve Cover | (10) Sub-range Check Pin |
| (2) Main Range Shift Check Valve | (11) Shuttle Check Pin |
| (3) Shuttle Shift Check Valve | (12) 3-4 Check Pin |
| (4) Sub-range Shift Check Valve | (13) Pin |
| (5) 3-4 Shift Check Valve | (14) 1-2 Check Pin |
| (6) 1-2 Shift Check Valve | (15) Shift Piston (Sub-range Shift) |
| (7) GST Valve Body | (16) Ball |
| (8) Main Range Check Pin | (17) Spring |
| (9) Ball for Detent | (18) Check Pin |

W1020427



Low-pass Valve




After completion of the gear shifting, the low-pass valve (8) opens immediately to flow oil into the GST clutch (9), to promote the engagement of the clutch.

When the gear shifting starts, the oil in the GST clutch (9) passes the clutch valve (7) to be drained into the tank. So prior to beginning of the GST clutch connection and after completion of gear shifting, it is necessary to flow oil to the GST clutch quickly. It is the low-pass valve that does this operation with the proportional reducing valve (10) simultaneously.

The oil from the regulating valve flows in from the **IN-port (A)**, passes through the low-pass valve poppet (4), flows out from **OUT-port (B)**, and flows to the clutch valve (7) and clutch (9). When the pressure on the side of the **OUT-port (B)** reaches setting pressure, the poppet (4) pushes the spring (3) to close the circuit.

- (1) Nut
 - (2) Adjuster
 - (3) Spring
 - (4) Poppet
 - (5) Plug
 - (6) Stopper Plate
 - (7) Clutch Valve
 - (8) Low-pass Valve
 - (9) GST Clutch
 - (10) Proportional Reducing Valve
- (A) IN-Port
(B) OUT-Port

W1020861






■ Proportional Reducing Valve

After the gear shifting is completed, this valve has function which gradually rises the pressure in the clutch (4) in order to make a clutch engaging for without shock and smoothly.

When the gear shifting is completed, the pressure switch is turned **ON**. By means of turning on the pressure switch, the microcomputer of ECU calculates and judges the charging of pressure and its time according to the oil temperature sensor and gear shifting period, and the traveling speed and speed acceleration according to the traveling speed sensor. By these instructions from microcomputer of ECU, the proportional reducing valve adjusts pressure in the clutch to become a appropriate acceleration.

- (1) Proportional Reducing Valve P : IN Port (From Regulating Valve)
- (2) GST Valve Assembly
- (3) Clutch Valve C : OUT Port (To Clutch Valve)
- (4) GST Clutch T : DRAIN Port (To Tank)
- (5) Filter

W1021268



■ Clutch Valve




The clutch valve (5) changes the flow of the oil flowing to the GST clutch to carry out “ENGAGE” / “DISENGAGED” of the clutch.

Except for during gear shifting, the oil of the pilot circuit flows in from the **A**-port to push the spool to the right when the pilot circuit is pressurized. Therefore, the oil from the low-pass valve (7) and proportional reducing valve (8) flows in from **B** and **C**-port, flows out from the **D**-port, and flows to the GST clutch (6).

When the pilot circuit pressure is zero, that is, from the start to the left with the spring (3) to cut the oil flow of **B** and **C**-port, and stopping the oil flow to the GST clutch (6). Furthermore, the oil of the GST clutch flows in from **D**-port, and is drained from **E**-port, and then the GST clutch is disengaged.

- | | |
|---------------------------------|--|
| (1) Plug | A : A-Port (From Pilot Circuit) |
| (2) Spool | B : B-Port (From Low-pass Valve) |
| (3) Spring | C : C-Port (From Proportional Reducing Valve) |
| (4) Stopper Plate | D : D-Port (To GST Clutch) |
| (5) Clutch Valve | E : E-Port (To Tank) |
| (6) GST Clutch | |
| (7) Low-pass Valve | |
| (8) Proportional Reducing Valve | |

W1021514

(C) GST Clutch

The GST clutch is hydraulic multiple plate type and is provided between the counter shaft (3) and the shuttle shaft (8), and it “engages” and “disengages” the power from the engine. This is controlled by the operation of clutch valve (2).

■ **Engaging (When the shift gear is at desired position while engine is running)**

The oil from clutch valve (2) flows in to push the return spring (9) and the piston (6). The piston is pushed to the left by the oil, thereby pushing the clutch discs (4) and the plates (5) to transmit the power.

■ **Disengaging (When the engine stop, the shift levers are neutral position, between from start to end of the gear shifting)**

The oil of the GST clutch (1) is pushed out with return spring (9) and piston (6), and flowed to the tank.

- | | |
|-------------------|------------------------|
| (1) GST Clutch | (7) Clutch Case |
| (2) Clutch Valve | (8) Shuttle Shaft |
| (3) Counter Shaft | (9) Return Spring |
| (4) Clutch Disc | (10) Clutch Output Hub |
| (5) Plate | (11) Clutch Input Hub |
| (6) Piston | |


W1021896

[6] SHIFT LINKAGE MECHANISM

For shift linkage mechanism of “Shuttle Lever” and “Front Wheel Drive Lever”, refer to page 3-M4, M5.

3. HYDROSTATIC TRANSMISSION (HST) MODEL

[1] STRUCTURE



3TLABAB3P051A

(1) Hydrostatic Transmission Section

(2) PTO Clutch Section

(3) Range Gear Shift Section


(4) Front Wheel Drive Shift Section

[2] POWER TRAIN

The transmission of this model consists of a series of gears and shafts as shown in previous page. The traveling system is chiefly composed of hydrostatic transmission section, range gear shift section and front wheel drive section.


(1) Hydrostatic Transmission (HST)

(A) Structure




- (1) Output Shaft (Motor Shaft)
- (2) Case Relief Valve
- (3) Bypass Pipe (Servo Pipe)
- (4) HST Case (Clutch Housing)
- (5) Port Block Cover
- (6) Servo Piston
- (7) Servo Regulator
- (8) Control Lever (Connect to HST Pedal)
- (9) Input Shaft (Pump Shaft)
- (10) Charge Relief Valve
- (11) Outlet Port (To Oil Cooler)
- (12) Check and High Pressure Relief Valve (Reverse)
- (13) Check and High Pressure Relief Valve (Forward)
- (14) Charge Relief Valve

W1022595




The HST of L30 series tractor is a built-in type to the clutch housing, and HST with the servomechanism is adapted. The servomechanism controls the pedal operation of HST hydraulically. As a result, the HST pedal feels extremely light and smoother pedal operation can be done.

HST assembly is chiefly composed of HST case (clutch housing), variable displacement piston pump, fixed displacement piston motor, charge pump, servo-regulator and various valves. Refer to the next page for detailed parts in the HST.



- | | | |
|-------------------------|---------------------------------|---|
| (1) Fixed Swashplate | (7) Regulator Assembly | (13) Cylinder Block (Motor) |
| (2) Variable Swashplate | (8) Port Block Cover | (14) Bypass Pipe (Servo Pipe) |
| (3) Charge Pump | (9) Cylinder Block (Pump) | (15) Case Relief Valve |
| (4) Servo Piston | (10) Input Shaft (Pump Shaft) | (16) Check and High Pressure Relief Valve |
| (5) Feedback Rod | (11) Piston | (17) Charge Relief Valve |
| (6) Control Shaft | (12) Output Shaft (Motor Shaft) | |

- A : Sectional View W-W**
- B : Sectional View X-X**
- C : Sectional View Y-Y**
- D : Sectional View Z-Z**

(B) Oil Flow


- | | | | |
|-------------------------------|-------------------------------|---|--|
| (1) HST Assembly | (8) Hydraulic Pump | (14) Check and High Pressure Relief Valve | C : From Steering Controller |
| (2) Servo Regulator Assembly | (9) Filter | (15) Charge Pump | D : To PTO Clutch Valve |
| (3) Regulator Valve | (10) Oil Cooler | (16) Motor Cylinder Block | a : a-port (In from suction line) |
| (4) Control Lever (HST Pedal) | (11) Input Shaft (Pump Shaft) | (17) Output Shaft (Motor Shaft) | b : b-port (Out by charge pump) |
| (5) Case Relief Valve | (12) Pump Cylinder Block | A : To Hydraulic Block | c : c-port (In from charge pump) |
| (6) Charge Relief Valve | (13) Servo Piston | B : To Steering Controller | d : d-port (Out from HST circuit) |
| (7) Filter | | | |

Oil flows in HST case from **a**-port, and is sent to **b**-port with the charge pump (15). Oil from **b**-port is sent to the HST circuit and the PTO clutch circuit through the filter (7). Moreover, the oil of the HST circuit sent to **c**-port is flowed into the servo regulator (2) and HST main circuit. At this time, the pressure in the regulator, HST main circuit (closed circuit) and PTO clutch circuit is controlled with the charge relief valve (6). The oil in regulator is used for the movement of servo piston (13) which is operated by the regulator valve (3) and HST pedal (4). And the oil in the HST main circuit gets circulated between the variable displacement piston pump (12) and the fixed displacement piston motor (16), which forms a closed circuit.

On the other hand, surplus oil with the charge relief valve (6) flows out from **d**-port, and is sent to the suction line through the oil cooler (10). And the case relief valve (5) controls pressure in the HST case.

(C) Function of Components

■ Servomechanism



- | | | | |
|--|--------------------|-------------------------------------|--|
| (1) Control Lever (Connected to HST Pedal) | (4) Feedback Lever | (8) Piston Adjusting Screw | A : Slit for Connection of Swashplate |
| (2) Regulator Valve Assembly | (5) Control Arm | (9) Orifice | P : IN Port (From Bypass Pipe) |
| (3) Spool | (6) Servo Piston | (10) Pin A (Fixed with Control Arm) | |
| | (7) Spring | (11) Pin B (Fixed with Spool) | |

As for the servomechanism, the regulator (2) and servo piston (6) are chiefly composed. The regulator is connected to the HST pedal through linkages, and controls the flow of oil to the servo piston by the pedal operation.

The servo piston moved by hydraulic force, is connected to the pump cylinder swashplate. Therefore, a tilt angle of swashplate is varied by servo piston movement.

As for the regulator and the servo piston, it is connected with feedback lever (4), and the movement of the piston is restricted according to the amount of depressing of the HST pedal.


Refer to Workshop Manual of **"TRACTOR MECHANISM" (Code No. 97897-18200)** for the operation of the servomechanism, that is, the operation of regulator and servo piston.

■ Valves

As for the mechanism and function of check and high pressure relief valve, charge relief valve and case relief valve, refer to Workshop Manual of **"TRACTOR MECHANISM" (Code No. 97897-18200)**.

(D) Operation

■ **Neutral**




- | | | | |
|-------------------------|------------------------------|--|---|
| (1) Transmission Case | (7) Regulator Valve Assembly | (13) HST Assembly | (18) Charge Relief Valve |
| (2) Filter | (8) Servo Piston | (14) Main Circuit and Steering Circuit | (19) PTO Clutch Valve Circuit |
| (3) Input Shaft | (9) Feedback Lever | (15) Oil Cooler | (20) Motor Cylinder |
| (4) Charge Pump | (10) HST Pedal | (16) Filter | (21) Output Shaft |
| (5) Pump Cylinder | (11) Regulator Valve | (17) Case Relief Valve | (22) Check and High Pressure Relief Valve |
| (6) Variable Swashplate | (12) Bypass Pipe | | |

The sucked oil from the transmission case (1) by the charge pump (4) flows into the HST housing (13) and regulator valve (7) through the oil filter (16) and charge relief valve (18). Overflow oil from HST housing (13) flows to the suction line through the oil cooler (15).

When the HST pedal (10) is in neutral, regulator valve (7) is not activated, so the variable swashplate (6) is at right angle to the pump pistons and they only rotate with cylinder (5) without reciprocation. Since the oil is not being pumped to motor, the cylinder block in the motor (20) is stationary and the output shaft (21) does not rotate.

■ Forward



3TLABAB3P058A

- | | | | |
|------------------------------|--|---|-------------------------|
| (1) Transmission Case | (9) Feedback Lever | (16) Filter | A : Pump Port A |
| (2) Filter | (10) HST Pedal | (17) Case Relief Valve | B : Pump Port B |
| (3) Input Shaft | (11) Regulator Valve | (18) Charge Relief Valve | C : Motor Port C |
| (4) Charge Pump | (12) Bypass Pipe | (19) PTO Clutch Valve Circuit | D : Motor Port D |
| (5) Pump Cylinder | (13) HST Assembly | (20) Motor Cylinder | |
| (6) Variable Swashplate | (14) Main Circuit and Steering Circuit | (21) Output Shaft | |
| (7) Regulator Valve Assembly | (15) Oil Cooler | (22) Check and High Pressure Relief Valve | |
| (8) Servo Piston | | | |


When the HST pedal (10) is stepped on and in forward, so the variable swashplate (6) is tilted by the servo piston (8) and regulator valve (11) as shown in figure above.

As the pump cylinder block (5) rotates with the input shaft (3), oil is forced out of pump port A at high pressure. As pressure oil enters motor port D, the pistons, which align with port D, are pushed against the thrust plate and slide down inclined surface.

Then the output shaft (21) rotates with the motor cylinder block (20). This drives the machine forward and the angle of pump swashplate determines the output shaft speed.

As the motor cylinder block continues to rotate, oil is forced out of motor port C at low pressure and returns to the pump port B.

■ Reverse




- | | | | |
|------------------------------|--|---|-------------------------|
| (1) Transmission Case | (9) Feedback Lever | (16) Filter | A : Pump Port A |
| (2) Filter | (10) HST Pedal | (17) Case Relief Valve | B : Pump Port B |
| (3) Input Shaft | (11) Regulator Valve | (18) Charge Relief Valve | C : Motor Port C |
| (4) Charge Pump | (12) Bypass Pipe | (19) PTO Clutch Valve Circuit | D : Motor Port D |
| (5) Pump Cylinder | (13) HST Assembly | (20) Motor Cylinder | |
| (6) Variable Swashplate | (14) Main Circuit and Steering Circuit | (21) Output Shaft | |
| (7) Regulator Valve Assembly | (15) Oil Cooler | (22) Check and High Pressure Relief Valve | |
| (8) Servo Piston | | | |

When the HST pedal (10) is stepped on and in reverse, the variable swashplate (6) is tilted by servo piston (8) and regulator valve (11) as shown in figure above.

As the pump cylinder block (5) rotates with the input shaft (3), oil is forced out of pump port B at high pressure. As pressure oil enters motor port C, the pistons, which align with port C, are pushed against the thrust plate and slide down inclined surface.

Then the output shaft (21) rotates with the motor cylinder block (20). This drives the machine rearward and the angle of pump swashplate determines the output shaft speed.

As the motor cylinder block continues to rotate, oil is forced out of motor port D at low pressure and returns to the pump port A.

(E) Control Linkage


3TLABAB3P021A

- | | | | |
|-----------------------|----------------------|--------------------|-------------------------|
| (1) HST Assembly | (4) HST Pedal | (7) Neutral Rod | (10) Neutral Holder Arm |
| (2) HST Control Lever | (5) Pedal Bracket | (8) Neutral Holder | (11) Neutral Spring |
| (3) HST Control Rod | (6) Connecting Shaft | (9) Ball Bearing | (12) Damper |

The speed control pedal (HST pedal) (4) and the HST control lever (servo control lever) (2) are linked with the pedal bracket (5) and HST control rod (3). And HST pedal (4) and the neutral holder arm (10) are linked with pedal bracket (5) and neutral rod (7) through connecting shaft (6).

As the HST pedal (4) is depressed to forward, the HST control lever (2) is rotated, then the swashplate is tilted by servomechanism and forward travelling speed increases. Then, the swashplate is returned to neutral with the neutral holder arm (10), when the pedal is released. The ball bearing (9) on the neutral holder (8) pulled with the neutral spring (11) seats the detent of the neutral holder arm (10) so that the neutral holder arm returns to neutral.

The damper (12) is connected to the HST pedal (4) through connecting shaft (6), neutral rod (7) and neutral holder arm (10), restricts the movement of the linkage to prevent abrupt operation or reversing.

(F) Cruise Control**■ Speed Set**

3TLABAB3P060A

- | | | | |
|-------------------|--------------------|--------------------------|---------------------------|
| (1) HST Pedal | (4) Plate | (7) Lever Rod | (10) Cruise Adjusting Rod |
| (2) Release Lever | (5) Rubber | (8) Cruise Control Lever | (11) Connecting Shaft |
| (3) Cruise Spring | (6) Cruise Lever 2 | (9) Cruise Lever 1 | |


The cruise control lever (8) and HST pedal (1) are linked with the lever rod (7), cruise lever 1 (9), cruise lever 2 (6), cruise adjusting rod (10) and connecting shaft (11).

When the cruise control lever (8) is moved to forward direction, cruise lever 2 (6) is moved to arrow direction by the lever rod (7). The cruise lever 1 (9) is moved forward by being pushed to the cruise lever 2 (6), and cruise adjusting rod (10) is pulled backward. Because cruise adjusting rod (10) and the HST pedal (1) are connected by the connecting shaft (11), the HST pedal is moved and HST becomes forward position.

On the other hand, because the plate (4) and the rubber (5) are suppressed outside by the release lever (2) and the cruise spring (3), cruise lever 1 (9) and cruise lever 2 (6) are fixed at the position. As a result, cruise control lever position can be infinitely set.

In addition, because the movement of the cruise lever 1 (9) is restricted by the cruise lever 2 (6), the backward pedal operation cannot be done while the cruise control lever (8) is operating.

■ Release



(1) Brake Pedal
(2) Brake Lever
(3) Bracket

(4) Release Lever
(5) Release Spring
(6) Plate

(7) Rubber
(8) Cruise Control Lever
(9) Cruise Lever 2

(10) Release Wire
(11) Cruise Spring
(12) Groove

The cruise control can be returned to neutral automatically when brake pedals (1) are depressed.


The cruise control lever (8) is set with plates (6) and rubbers (7) by the release lever (4) and cruise spring (11). When brake pedals (1) are depressed, brake lever (2) to pull the release lever (4) via release wire (10). The release lever (4) is moved along grooves (12).

As a result, the holding force of cruise control lever (8) is lost and the cruise control lever (8) returns to neutrality by force of the release spring (5).

■ NOTE

- The cruise control will release when both brake pedals are depressed.
- The cruise control does not release when the individual right or left brake is applied.

(2) Range Gear Shift Section




The range gear shift section is located in the differential gear case.

It changes the speed to five positions (L, N, M, N and H) by shifting of shifter gear (3) in the straight line on bevel pinion shaft (7).

- | | |
|-------------------------------|----------------------------------|
| (1) Counter Shaft | L : Low Speed Position |
| (2) Gear (for L) | N : Neutral Position |
| (3) Shifter Gear (for M) | M : Middle Speed Position |
| (4) Range Gear Shaft | H : High Speed Position |
| (5) Spline Boss | |
| (6) Gear (for H) | |
| (7) Spiral Bevel Pinion Shaft | |

W1024698

(3) Front Wheel Drive Section



Front wheel drive section is located in the differential gear case.

2 wheel drive or 4 wheel drive is selected by operating the front wheel drive lever to shift the shifter gear (6).


- | | |
|-----------------------------------|-----------------------------------|
| (1) Spiral Bevel Pinion Shaft | (5) Front Wheel Drive Gear |
| (2) Front Wheel Drive Output Gear | (6) Shifter Gear |
| (3) PTO Drive Shaft | a : 4 Wheel Drive Position |
| (4) Front Wheel Drive Shaft | |

W1024918

[3] SHIFT LINKAGE MECHANISM

The shift linkage mechanism of "Front Wheel Drive Lever", refer to page 3-M5.

(1) Range Gear Shift Lever




The links are connected from the shift lever (3) to the shift fork (1) as shown in figure.

- (1) Shift Fork
- (2) Shift Arm
- (3) Range Gear Shift Lever
- (4) Rod
- (5) Sub-arm

W1025045

4. PTO SYSTEM

[1] STRUCTURE



3TLABAB3P065A

- | | | | |
|----------------------|-----------------------|--------------------------------|--|
| (1) PTO Gear Shaft 1 | (4) PTO Counter Shaft | (7) Output Shaft (Motor Shaft) | [A] Manual Transmission and GST Model |
| (2) PTO Gear Shaft 2 | (5) PTO Drive Shaft | (8) PTO Gear Shaft 1 | [B] HST Model |
| (3) PTO Clutch Pack | (6) PTO Shaft | (9) PTO Gear Shaft 2 | |

The independent PTO operated by hydraulic clutch (3) is adapted for all models. PTO is “ENGAGED” or “DISENGAGED” by operating the shift lever of the PTO clutch valve. And, mid-PTO is adapted in option.

The power train from the clutch to the PTO shaft is composed as shown in figure above.

(Reference)

- PTO speed of each model is as shown in the table below.

Manual Transmission and GST Model


Rear PTO	All Model	540 min ⁻¹ (rpm) at 2550 min ⁻¹ (rpm) engine speed
Mid PTO	All Model	2000 min ⁻¹ (rpm) at 2580 min ⁻¹ (rpm) engine speed

HST Model

Rear PTO	L3130, L3430, L3830, L4630	540 min ⁻¹ (rpm) at 2640 min ⁻¹ (rpm) engine speed
	L4330	540 min ⁻¹ (rpm) at 2440 min ⁻¹ (rpm) engine speed
	L5030	540 min ⁻¹ (rpm) at 2660 min ⁻¹ (rpm) engine speed
Mid PTO	L3130, L3430, L3830, L4630	2000 min ⁻¹ (rpm) at 2670 min ⁻¹ (rpm) engine speed
	L4330	2000 min ⁻¹ (rpm) at 2470 min ⁻¹ (rpm) engine speed
	L5030	2000 min ⁻¹ (rpm) at 2690 min ⁻¹ (rpm) engine speed

[2] PTO CLUTCH

(1) Shift Linkage




The shift lever (1) and the PTO clutch valve (4) are connected by the shift cable (3) as shown in the left figure.

When the shift lever is moved to the **B** side, the PTO clutch valve (4) is set at **“ENGAGED”** position. Then the oil flows to clutch pack through the PTO clutch valve (4), and the clutch pack is engaged and the PTO shaft rotates. When the shift lever is moved to the **A** side, the PTO clutch valve (4) is set at the **“DISENGAGED”** position.

- (1) Shift Lever
- (2) Lever Guide
- (3) Shift Cable
- (4) PTO Clutch Valve

W1025261

(2) Oil Flow




Oil flows into the clutch valve (2) after it is regulated to the system pressure. As for the system pressure of the PTO clutch valve, it is controlled by the regulating valve for GST and Manual Transmission model, and it is controlled by the HST charge relief valve for HST model. When the PTO lever is at the **“DISENGAGED”** position, the oil does not flow through the PTO clutch valve (2) to the clutch pack. When the PTO lever is at the **“ENGAGED”** position, the oil flows through the PTO clutch valve (2) to the accumulator (4) and the PTO clutch pack (3) to engage it.

- (1) Check Valve
(Except HST Model)
 - (2) PTO Clutch Valve
 - (3) PTO Clutch Pack
 - (4) Accumulator
- A** : From Regulating Valve (For Manual Transmission and GST Model)
From HST Charge Pump (For HST Model)
- B** : Pressure Check Port

W1025366

(3) Operation



The oil flows into the clutch valve and opens the check valve (1). When the shift lever is set at the **“ENGAGED”** position, the spool (2) is turned to **(a)** position, then the oil flows through the spool (2) into the accumulator and the clutch pack. Oil entering the clutch pack pushes the piston (4) to engage the clutch pack. The accumulator absorbs the engaging shock of the clutch pack.


When the shift lever is set at the **“DISENGAGED”** position, the spool (2) is turned to **(b)** position, then the oil is stopped by the spool (2) and the oil in the PTO clutch pack and accumulator is drained into the transmission case. Thus the piston (4) is pushed back, the brake plate (7) is also moved to contact the brake disc (6) so as to stop the rotation and the drag of the PTO shaft.

- (1) Check Valve
(Except HST Model)
 - (2) Spool
 - (3) Plate
 - (4) Piston
 - (5) Brake Spring
 - (6) Brake Disc
 - (7) Brake Plate
 - (8) Return Spring
 - (9) Clutch Disc
 - (10) Back Plate
 - (11) Clutch Hub
 - (12) Accumulator Piston
 - (13) Bearing Case
- (a) ENGAGED Position**
 - (b) DISENGAGED Position**
 - (c) From Regulator Valve or HST Charge Pump**
 - (d) Drain (To the Transmission Case)**
- A : PTO Clutch Valve**
B : Accumulator
C : PTO Clutch Pack

W1025465

[3] MID PTO (OPTION)

(1) Power Train



The power can be taken out from the differential gear case by installing the Mid-PTO case assembly (8).


The power is transmitted to the Mid-PTO shaft (6) from the rear PTO drive shaft (1). Therefore the Mid-PTO is rotated, while the rear PTO is engaged.

Mid-PTO shaft can be rotated by operating the Mid-PTO shift lever to shift the shifter (5).

- | | |
|-----------------------------|---------------------------|
| (1) PTO Drive Shaft | (5) Shifter |
| (2) Mid-PTO Idle Gear | (6) Mid-PTO Shaft |
| (3) Mid-PTO Output Gear | (7) Gear |
| (4) Front Wheel Drive Shaft | (8) Mid-PTO Case Assembly |

W1026018

(2) Shift Linkage



It is shifted "Engaged" or "Disengaged" position semi-independently by the Mid-PTO shift lever (1).


The links are connected from the Mid-PTO shift lever (1) to the shift fork (5) as shown in figure.

- | | |
|-------------------------|----------------|
| (1) Mid-PTO Shift Lever | A : Engaged |
| (2) Rod | B : Disengaged |
| (3) Shift Arm | |
| (4) Shift Lever 2 | |
| (5) Shift Fork | |

W1026129

5. CREEP SPEED SYSTEM (OPTION)

[1] POWER TRAIN



The creep speed section is located under the H-L range gear shift section to reduce a travelling speed. It is shifted by the creep shift lever to shift the shifter (3).

The power train of creep speed is as shown in figure.


■ NOTE

- The creep gear is adapted in the L4630GST-CAB model by the standard.

- | | |
|-------------------------------|-------------------------------|
| (1) Creep Output Gear | H : High Speed (Normal Speed) |
| (2) Range Gear Shaft | L : Low Speed (Creep Speed) |
| (3) Shifter | |
| (4) Low Speed Counter Gear | |
| (5) Spiral Bevel Pinion Shaft | |
| (6) Creep Gear Shaft | |
| (7) Creep Gear | |

W1026304

[2] SHIFT LINKAGE



The links are connected from the shift lever (3) to the shift fork (1) as shown in the left figure.

When the shift lever (3) is moved to the A side, the shift fork (1) is moved to the A side by means of the rod (4), sub-arm (5), and shift arm (2), thereby causing the creep shift.

When the shift lever (3) is moved to the B side, the shift fork (1) is moved to the B side to cause the normal shift.

- | | |
|-----------------|------------------------|
| (1) Shift Fork | A : Creep Speed Shift |
| (2) Shift Arm | B : Normal Speed Shift |
| (3) Shift Lever | |
| (4) Rod | |
| (5) Sub-arm | |

W1026459

SERVICING

CONTENTS

1. TROUBLESHOOTING	3-S1
[1] GENERAL	3-S1
[2] GST SYSTEM	3-S2
[3] HST SYSTEM	3-S8
[4] PTO SYSTEM	3-S10
2. SERVICING SPECIFICATIONS	3-S11
[1] GENERAL	3-S11
[2] PTO CLUTCH	3-S12
[3] GST	3-S13
[4] HST	3-S14
3. TIGHTENING TORQUES	3-S15
4. CHECKING, DISASSEMBLING AND SERVICING	3-S17
[1] MANUAL TRANSMISSION MODEL	3-S17
(1) Checking and Adjusting	3-S17
(2) Disassembling and Assembling	3-S18
(3) Servicing	3-S41
[2] GLIDE SHIFT TRANSMISSION (GST) MODEL	3-S47
(1) Checking and Adjusting	3-S47
(2) Disassembling and Assembling	3-S53
(3) Servicing	3-S87
[3] HYDROSTATIC TRANSMISSION (HST) MODEL	3-S89
(1) Checking and Adjusting	3-S89
(2) Disassembling and Assembling	3-S95
(3) Servicing	3-S120


1. TROUBLESHOOTING

[1] GENERAL


Symptom	Probable Cause	Solution	Reference Page
Excessive Transmission Noise	<ul style="list-style-type: none"> Transmission fluid insufficient Gear worn or backlash improper Bearing worn or broken Shift fork worn Spline worn Snap rings on the shaft come off Spiral bevel pinion lock nut improperly tightened Improper backlash between spiral bevel pinion and spiral bevel gear Improper backlash between differential pinion and differential side gear 	Replenish Replace Replace Replace Replace Repair or replace Tighten Adjust Adjust	G-7, 8 3-S44 to S46 3-S41 3-S41 3-S41 – 3-S36 3-S45 3-S46
Gear Slip Out of Mesh	<ul style="list-style-type: none"> Shift linkages rusted Shifter or shift fork worn or damaged Shift fork interlock ball spring weaken or damaged Interlock ball fallen Synchronizer unit damaged Gears worn or broken 	Repair Replace Replace Reassemble Replace Replace	– – 3-S26, S63 3-S26, S63 3-S42 –
Hard Shifting	<ul style="list-style-type: none"> Shifter or shift fork worn or damaged Shift fork bent Shift linkage rusted Shaft part of shift arms rusted Synchronizer unit damaged 	Replace Replace Repair Repair Replace	– – – – 3-S42
Gears Clash When Shifting	<ul style="list-style-type: none"> Clutch does not release Gears worn or damaged Synchronizer unit damaged 	Adjust or repair Replace Replace	G-22 – 3-S42
Differential Lock Can Not Be Set	<ul style="list-style-type: none"> Differential lock shift fork damaged Differential lock shift fork mounting clevis pin damaged Differential lock shifter pin bent or damaged Differential lock fork shaft bent or damaged 	Replace Replace Replace Replace	3-S38 3-S38 3-S38 3-S38
Differential Lock Pedal Does Not Return	<ul style="list-style-type: none"> Differential lock pedal return spring weaken or damaged Differential lock shifter pin bent or damaged Differential lock fork shaft bent 	Replace Replace Replace	– 3-S38 3-S38
Excessive or Unusual at All Time	<ul style="list-style-type: none"> Improper backlash between spiral bevel pinion and spiral bevel gear Improper backlash between differential pinion and differential side gear Bearings worn Insufficient or improper type of transmission fluid used 	Adjust Adjust Replace Replenish or replace	3-S45 3-S46 – G-7, 8
Noise While Turning	<ul style="list-style-type: none"> Differential pinion or differential side gears worn or damaged Differential lock binding (does not disengage) Bearing worn 	Replace Replace Replace	3-S40 3-S38 –

[2] GST SYSTEM

■ Electrical Diagnosis by Electronic Instrument Panel (IntelliPanel)








■ Error Display

Display on LCD Screen	Trouble Item	Probable Cause	Solution	Reference Page
				
ERROR-20	Communication error between ECU and electronic instrument panel	<ul style="list-style-type: none"> • Fuse blown out • Communication line between ECU and electronic instrument panel is broken or short-circuited • No signals from ECU for longer than 5 seconds (error cleared if signal sent and received later) • ECU defective 	<ul style="list-style-type: none"> • Check fuse • Check ECU connector • Check communication line between ECU and electronic instrument panel at ECU connector • Replace ECU 	9-S27 9-S27 9-S31 9-S28
ERROR-30	ECU memory device has failed	<ul style="list-style-type: none"> • ECU memory device failure 	<ul style="list-style-type: none"> • Replace ECU 	9-S28
ERROR-40	Input voltage to lever sensor from ECU is failed	<ul style="list-style-type: none"> • Lever sensor input voltage drop below 2.6 V for 0.1 second or more • Ground wire of lever sensor short-circuited 	<ul style="list-style-type: none"> • Check ground wire • Check input voltage at ECU connector • Check sensor connector 	9-S27 9-S29 -
ERROR-50	GST lever sensor is failed	<ul style="list-style-type: none"> • Lever sensor output terminal is out of adjustment • Lever sensor output wire terminal broken or short-circuited • Input line broken • Lever sensor defective 	<ul style="list-style-type: none"> • It is possible to run at its selected speed position until engine is stopped. • Check sensor connector • Check sensor voltage by Test mode (Mode A) • Check lever sensor wire connector (voltage) or check sensor resistance • Replace lever sensor 	- - 9-S13 9-S29, S31 9-M20
ERROR-60	Proportional reducing valve failure	<ul style="list-style-type: none"> • Output voltage of proportional reducing valve terminal or return current is out of specification • Valve wire broken or short-circuited • Proportional reducing valve defective 	<ul style="list-style-type: none"> • Check connector of proportional reducing valve • Check proportional reducing valve resistance at valve or ECU connector • Check grounding wire • Connect emergency connector and move 	- 9-S30, S32 9-S27 9-M22

Display on LCD Screen	Trouble Item	Probable Cause	Solution	Reference Page
	Solenoid 1 failure (At forward or neutral)	<ul style="list-style-type: none"> Solenoid output terminal's voltage is out of specification Solenoid broken or short-circuited Wiring harness broken or short-circuited 	<ul style="list-style-type: none"> Able to travel at speeds other than 1, 7 and 8 (Forward) or 1 and 5 (Reverse) Check the wiring connector of solenoid 	—
	Solenoid 1 failure (At reverse)	<ul style="list-style-type: none"> Grounding plate of solenoid is poor contact with chassis 	<ul style="list-style-type: none"> Check a resistance between solenoid and GND Replace GST valve 	9-S30, S32 3-S82
	Solenoid 2 failure (At forward or neutral)		<ul style="list-style-type: none"> Able to travel at speeds other than 2, 9 and 10 (Forward) or 2 and 6 (Reverse) Check the wiring connector of solenoid 	—
	Solenoid 2 failure (At reverse)		<ul style="list-style-type: none"> Check a resistance between solenoid and GND Replace GST valve 	9-S30, S32 3-S82
	Solenoid 3 failure (At forward or neutral)		<ul style="list-style-type: none"> Able to travel at speeds other than 3, 4 and 11 (Forward) or 3 and 7 (Reverse) Check the wiring connector of solenoid 	—
	Solenoid 3 failure (At reverse)		<ul style="list-style-type: none"> Check a resistance between solenoid and GND Replace GST valve 	9-S30, S32 3-S82


W1011845

Display on LCD Screen	Trouble Item	Probable Cause	Solution	Reference Page
	Solenoid 4 failure (At forward or neutral)	<ul style="list-style-type: none"> • Solenoid output terminal's voltage is out of specification • Solenoid broken or short-circuited • Wiring harness broken or short-circuited • Grounding plate of solenoid is poor contact with chassis 	<ul style="list-style-type: none"> • Able to travel at speeds other than 5, 6 and 12 (Forward) or 4 and 8 (Reverse) • Check the wiring connector of solenoid • Check a resistance between solenoid and GND • Replace GST valve 	—
	Solenoid 4 failure (At reverse)			9-S30, S32 3-S82
	Solenoid 6 (Main range gear shift) failure (At forward or neutral)	<ul style="list-style-type: none"> • Solenoid output terminal's voltage is out of specification • Solenoid broken or short-circuited • Wiring harness broken or short-circuited • Grounding plate of solenoid is poor contact with chassis 	<ul style="list-style-type: none"> • Able to travel at speeds other than 1 to 6 (Forward) or 1 to 4 (Reverse) • Check the wiring connector of solenoid • Check a resistance between solenoid and GND • Replace GST valve 	—
	Solenoid 6 (Main range gear shift) failure (At reverse)			9-S30, S32 3-S82
	Solenoid 5 (Sub-range gear shift) failure	<ul style="list-style-type: none"> • Solenoid output terminal's voltage is out of specification • Solenoid broken or short-circuited • Wiring harness broken or short-circuited • Grounding plate of solenoid is poor contact with chassis 	<ul style="list-style-type: none"> • Able to travel at speeds other than 3, 5, 7 and 9 (Forward) • Check the wiring connector of solenoid • Check a resistance between solenoid and GND • Replace GST valve 	— — 9-S30, S32 3-S82

W1087197

■ Error Message Does not Indicate on LCD

1. The tractor does not move while shifted.



Checking points	Solution or defect portions	Reference Page	
1			
Measure the GST clutch pressure.		3-S52	
Correct pressure	Pressure is below the factory spec.	Defect the pressure switch.	9-S31
		Clogged the filter of proportional reducing valve.	3-S86
		Defect the clutch valve.	3-S85
		Defect the GST clutch.	3-S68
		Defect the GST clutch pack.	3-S68
		Defect the synchronizer units.	1-S64, S69
		Defect the gears, on the shaft.	—


2. The time needed to start the tractor.


Check the transmission fluid level and quality.	Insufficient	Replenish correct fluid and correct level.	G-7, 8
Check the * mark onwards of "1. The tractor does not move while shifted".	Sufficient	Improperly adjusted GST valve.	3-S48
		Improperly adjusted shifting shock.	3-S49
		Defect oil temperature sensor.	9-S32

3. Quick engagement while starting or large shock while shifting.

Check the transmission fluid level and quality.	Insufficient	Replenish correct fluid and correct level.	G-7, 8
Check the * mark onwards of "1. The tractor does not move while shifted".	Sufficient	Improperly adjusted GST valve.	3-S48
		Improperly adjusted shifting shock.	3-S49
		Defect oil temperature sensor.	9-S32
		Defect pressure switch.	9-S31

[3] HST SYSTEM





[4] PTO SYSTEM

PTO CLUTCH

Symptom	Probable Cause	Solution	Reference Page
PTO Clutch Slip	<ul style="list-style-type: none"> Operating pressure is low PTO clutch valve malfunctioning Clutch disc or drive plate excessively worn Deformation of piston or return plate 	Adjust Repair or replace Replace Replace	3-S17, S92 3-S29 3-S31 3-S32
PTO Shaft Does Not Rotate	<ul style="list-style-type: none"> PTO clutch malfunctioning PTO propeller shaft coupling disengaged 	Repair or replace Engage	3-S31 -
PTO Clutch Operating Pressure is Low	<ul style="list-style-type: none"> Transmission oil improper or insufficient Relief valve malfunctioning 	Replenish or change Adjust or replace	G-7, 8 3-S17, S92
PTO Clutch Drags	<ul style="list-style-type: none"> Brake plate excessively worn Return spring weaken or broken Accumulator valve malfunctioning Deformation or return plate or steal plate 	Replace Replace Repair or replace Replace	3-S32 3-S32 3-S31 3-S32

W10137180



2. SERVICING SPECIFICATIONS

[1] GENERAL

Item		Factory Specification	Allowable Limit
Gear to Spline	Clearance	0.030 to 0.078 mm 0.00118 to 0.00307 in.	0.2 mm 0.008 in.
Shift Fork to Shifter Gear Groove	Clearance	0.20 to 0.40 mm 0.008 to 0.016 in.	0.8 mm 0.031 in.
Gear to Shaft	Clearance	0.021 to 0.054 mm 0.00083 to 0.00213 in.	0.1 mm 0.004 in.
Shift Fork to Shifter Groove	Clearance (Shuttle)	0.20 to 0.45 mm 0.0079 to 0.0177 in.	0.8 mm 0.031 in.
	(Others)	0.15 to 0.40 mm 0.0059 to 0.0157 in.	0.8 mm 0.031 in.
Synchronizer Ring to Gear (In Contact)	Side Clearance	—	0.35 mm 0.0138 in.
Spiral Bevel Gear	Turning Torque	3.92 to 6.37 N·m 0.40 to 0.65 kgf·m 2.89 to 4.70 ft-lbs	
Spiral Bevel Pinion to Spiral Bevel Gear	Backlash	0.15 to 0.30 mm 0.006 to 0.012 in.	—
	Tooth Contact	—	More than 35 %
	Center to Tooth Contact	—	1/3 to 1/2 of the entire width from the small end
Differential Case Bore (Differential Case Cover Bore) to Differential Side Gear Boss	Clearance	0.050 to 0.151 mm 0.00197 to 0.00594 in.	0.35 mm 0.0138 in.
Differential Case Bore	I.D.	40.500 to 40.550 mm 1.59449 to 1.59646 in.	—
Differential Case Cover Bore	I.D.	40.500 to 40.550 mm 1.59449 to 1.59646 in.	—
Differential Side Gear Boss	O.D.	40.338 to 40.450 mm 1.59008 to 1.59252 in.	—
Differential Pinion Shaft to Differential Pinion	Clearance	0.060 to 0.102 mm 0.00236 to 0.00402 in.	0.25 mm 0.0098 in.
Differential Pinion Shaft	O.D.	19.959 to 19.980 mm 0.78579 to 0.78661 in.	—
Differential Pinion	I.D.	20.040 to 20.061 mm 0.78898 to 0.78980 in.	—

W1013874

Item		Factory Specification	Allowable Limit
Differential Pinion to Differential Side Gear	Backlash	0.15 to 0.30 mm 0.006 to 0.012 in.	0.40 mm 0.016 in.
Differential Side Gear Washer 1	Thickness	1.5 mm 0.059 in.	—
Differential Side Gear Washer 2	Thickness	1.6 mm 0.063 in.	—
Differential Side Gear Washer 3	Thickness	1.7 mm 0.067 in.	—

W1013874

[2] PTO CLUTCH

PTO Clutch Valve Condition • Engine Speed : Idling • Oil Temperature : 40 to 60 °C 104 to 140 °F	Operating Pressure [Manual and GST Model]	2.30 to 2.50 MPa 23.5 to 25.5 kgf/cm ² 334 to 363 psi	—
	[HST Model]	2.21 to 2.40 MPa 22.5 to 24.5 kgf/cm ² 320 to 348 psi	—
PTO Clutch Disc	Thickness	1.70 to 1.90 mm 0.067 to 0.075 in.	1.55 mm 0.061 in.
PTO Steel Plate	Thickness	1.15 to 1.25 mm 0.045 to 0.049 in.	1.10 mm 0.043 in.
PTO Piston	Flatness	—	0.15 mm 0.006 in.
PTO Steel Plate	Flatness	—	0.30 mm 0.012 in.
PTO Return Spring	Free Length	40.5 mm 1.59 in.	37.5 mm 1.48 in.
PTO Brake Spring	Free Length	20.3 mm 0.80 in.	18.0 mm 0.71 in.
Seal Ring	Thickness	2.45 to 2.50 mm 0.096 to 0.098 in.	2.0 mm 0.079 in.

W1277262

[3] GST

Item	Factory Specification	Allowable Limit
GST System Pressure Condition <ul style="list-style-type: none"> • Engine Speed : Idling • Oil Temperature : 40 to 60 °C 104 to 140 °F 	Setting Pressure 2.40 to 2.55 MPa 24.5 to 26.0 kgf/cm ² 348 to 370 psi	—
Regulating Pressure Condition <ul style="list-style-type: none"> • Engine Speed : Maximum • Oil Temperature : 40 to 60 °C 104 to 140 °F 	Setting Pressure 2.74 to 2.94 MPa 28.0 to 30.0 kgf/cm ² 398 to 427 psi	—
GST Pilot Pressure Condition <ul style="list-style-type: none"> • Engine Speed : Maximum • Oil Temperature : 40 to 60 °C 104 to 140 °F • GST Lever : 1st • Shuttle Lever : Forward or Reverse 	Operating Pressure 2.30 to 2.50 MPa 23.5 to 25.5 kgf/cm ² 334 to 363 psi	—
GST Clutch Pressure Condition <ul style="list-style-type: none"> • Engine Speed : Idling • Oil Temperature : 40 to 60 °C 104 to 140 °F • GST Lever : Neutral to 12th or 8th • Shuttle Lever : Neutral to Forward and Reverse 	Operating Pressure 2.30 to 2.50 MPa 23.5 to 25.5 kgf/cm ² 334 to 363 psi	—
GST Clutch Disc	Thickness 2.55 to 2.65 mm 0.100 to 0.104 in.	2.50 mm 0.098 in.
GST Steel Plate	Thickness 1.55 to 1.65 mm 0.061 to 0.065 in.	1.50 mm 0.059 in.
GST Steel Plate	Flatness —	0.30 mm 0.012 in.
GST Clutch Piston	Flatness —	0.15 mm 0.006 in.
GST Clutch Piston Return Spring	Free Length 19.9 to 20.1 mm 0.78 to 0.79 in.	18.0 mm 0.71 in.
GST Clutch Seal Ring	Thickness 2.45 to 2.50 mm 0.096 to 0.098 in.	2.0 mm 0.079 in.

W1277262

[4] HST

Item	Factory Specification	Allowable Limit
Check and High Pressure Relief Valve Condition <ul style="list-style-type: none"> • Engine Speed : Maximum • Oil Temperature : 40 to 60 °C 104 to 140 °F • Range Gear Shift Lever : H Position • HST Pedal : Depress Forward or Reverse with Brake 	Setting Pressure	33.3 to 36.3 MPa 340 to 370 kgf/cm ² 4836 to 5262 psi
Charge Relief Valve Condition <ul style="list-style-type: none"> • Engine Speed : Maximum • Oil Temperature : 40 to 60 °C 104 to 140 °F • HST Pedal : Neutral 	Setting Pressure	2.26 to 2.45 MPa 23 to 25 kgf/cm ² 327 to 355 psi
Cruise Control Lever	Operating Force (Forward Direction)	54 to 64 N 5.5 to 6.5 kgf 12.1 to 14.3 lbs

W1277262

W1277262

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-9.)

Item	N·m	kgf·m	ft-lbs
(General)			
ROPS lower connector mounting screw	103 to 118	10.5 to 12.0	75.9 to 86.8
ROPS plate mounting screw (M14 × 40)	138 to 147	14.0 to 15.0	102 to 108
(M14 × 30)	167 to 196	17.0 to 20.0	123 to 145
ROPS upper connector mounting screw (Rigid)	167 to 196	17.0 to 20.0	123 to 145
ROPS fulcrum bolt and nut (Foldable)	118 to 137	12.0 to 14.0	86.8 to 102
ROPS lower frame mounting screw	167 to 196	17.0 to 20.0	123 to 145
Step mounting bolt and nut	124 to 147	12.6 to 15.0	91.1 to 108
Floor seat mounting bolt and nut	196 to 225	20 to 23	145 to 166
Joint bolt for main delivery pipe 1 to front hydraulic block	49 to 69	5.0 to 7.0	36.1 to 50.6
Joint bolt for main delivery pipe 2 to rear hydraulic block	49 to 69	5.0 to 7.0	36.1 to 50.6
Cap nut for return pipe to mid case	49 to 69	5.0 to 7.0	36.1 to 50.6
Joint bolt for PTO delivery pipe	34 to 39	3.5 to 4.0	25.3 to 28.9
Engine and clutch housing mounting screw and nut	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Engine and clutch housing mounting stud bolt	39.2 to 49.0	4.0 to 5.0	28.9 to 36.2
Clutch housing and mid case mounting nut	102.9 to 117.6	10.5 to 12.0	75.9 to 86.8
Clutch housing and mid case mounting screw	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Clutch housing and mid case mounting stud bolt	38.2 to 45.1	3.9 to 4.6	28.2 to 33.3
Release fork mounting screw	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Mid case and transmission case mounting screw	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Mid case and transmission case mounting nut	102.9 to 117.6	10.5 to 12.0	75.9 to 86.8
Mid case and transmission case mounting stud bolt	39.2 to 49.0	4.0 to 5.0	28.9 to 36.2
PTO clutch valve mounting screw	23.5 to 27.4	2.4 to 2.8	17.4 to 20.2
Mid case bearing holder mounting screw	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2
Brake plate mounting screw (PTO clutch)	9.8 to 11.3	1.00 to 1.15	7.2 to 8.3
Rear wheel mounting nut	215	22	160
Rear wheel mounting stud bolt	98.1 to 112.8	10.0 to 11.5	72.3 to 83.2
Lift arm pin mounting nut	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Lift arm pin lock nut	62.8 to 72.6	6.4 to 7.4	46.3 to 53.5
Drawbar frame mounting screw (M12)	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
(M14)	167 to 196	17.0 to 20.0	123 to 145
Hydraulic cylinder hose	34.3 to 48.1	3.5 to 4.9	25.3 to 35.4
Rear axle case mounting screw and nut			
M10 screw and nut (7T)	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2
Stud bolt	24.5 to 31.4	2.5 to 3.2	18.1 to 23.1
M10 nut (9T)	60.8 to 70.6	6.2 to 7.2	44.9 to 52.1
M12 screw	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Brake case mounting stud bolt	29.4 to 49.0	3.0 to 5.0	21.7 to 36.1
Brake case mounting screw and nut	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Lever fulcrum screw	62.8 to 72.5	6.4 to 7.4	46.3 to 53.5
Lock nut	147 to 196	15 to 20	108 to 145
Pinion bearing case mounting screw	39.2 to 44.1	4.0 to 4.5	28.9 to 32.5
Transmission bearing holder mounting screw	48.1 to 55.9	4.9 to 5.7	35.5 to 41.2
Lock nut	147 to 196	15 to 20	108 to 145
Bearing case mounting screw	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Differential support mounting screw	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2
Differential case cover mounting screw	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2
Spiral bevel gear UBS screw	68.6 to 88.3	7.0 to 9.0	50.6 to 65.1
Muffler mounting screw	31.4 to 37.2	3.2 to 3.8	23.1 to 27.5


Item	N·m	kgf·m	ft-lbs
(Cabin)			
Compressor mounting screw	24.5 to 29.4	2.5 to 3.0	18.1 to 21.7
Cabin mounting bolt and nut	124 to 147	12.6 to 15.0	91.1 to 108
(Manual Transmission)			
Main shift base mounting screw	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Main shift arm setting screw	9.8 to 11.3	1.00 to 1.15	7.2 to 8.3
Clutch housing bearing holder mounting screw	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2
Stopper screw	34.3 to 44.1	3.5 to 4.5	25.3 to 32.5
(GST)			
Joint bolt for GST delivery pipe	34 to 39	3.5 to 4.0	25.3 to 28.9
Shift pin mounting screw	12.7 to 14.7	1.3 to 1.5	9.4 to 10.8
GST valve mounting screw	42.2 to 48.1	4.3 to 4.9	31.1 to 35.4
Clutch housing bearing holder mounting screw	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2
Stopper screw	34.3 to 44.1	3.5 to 4.5	25.3 to 32.5
Joint bolt for GST delivery pipe and regulating valve	34.3 to 39.2	3.5 to 4.0	25.3 to 28.9
Joint bolt for power steering hose and regulating valve	49.0 to 68.6	5.0 to 7.0	36.2 to 50.6
Joint bolt for delivery pipe and hydraulic pump	39.3 to 49.0	4.0 to 5.0	29.0 to 36.2
Regulating valve mounting screw	17.6 to 20.6	1.8 to 2.1	13.0 to 15.2
Joint bolt	49.0 to 58.8	5.0 to 6.0	36.2 to 43.4
Plate	9.8	1.0	7.2
Regulating valve case and support mounting screw	9.8	1.0	7.2
Lower body mounting hex. socket head cap screw	9.8 to 10.8	1.0 to 1.1	7.2 to 8.0
(HST)			
HST control lever setting hex. head screw	6.86 to 8.33	0.70 to 0.85	5.06 to 6.15
Joint bolt for oil cooler pipe	34 to 39	3.5 to 4.0	25.3 to 28.9
Joint bolt for charge delivery pipe to filter bracket	39 to 49	4.0 to 5.0	28.9 to 36.1
Joint bolt for PTO pipe to PTO clutch valve	34 to 39	3.5 to 4.0	25.3 to 28.9
Cap nut for charge delivery pipe	49 to 59	5.0 to 6.0	36.1 to 43.4
Port block mounting hex. head screw	98 to 123	10 to 12.5	72.3 to 90.4
Swashplate setting hex. head screw	28 to 35	2.9 to 3.6	21 to 26
Cradle bearing bracket mounting hex. head screw	28 to 35	2.9 to 3.6	21 to 26
Charge pump case mounting screw	28 to 35	2.9 to 3.6	21 to 26
Hex. head plug	30 to 37	3.1 to 3.8	22.4 to 27.5
Hex. head plug	56 to 68	5.5 to 7.0	39.8 to 50.6
Regulator mounting hex. head screw	6.9 to 8.3	0.7 to 0.85	5.1 to 6.1
Servo piston and cover mounting hex. head screw	28 to 35	2.9 to 3.6	21 to 26

W1012736

4. CHECKING, DISASSEMBLING AND SERVICING

[1] MANUAL TRANSMISSION MODEL

(1) Checking and Adjusting




Operating Pressure of PTO Clutch Valve

1. Start the engine and warm up the transmission fluid, and then stop the engine.
2. Remove the plug (1) (PT 1/8) on the PTO valve spool (2).
3. Set the pressure gauge.
4. Start the engine and measure the pressure.
5. For adjustment use the pressure reducing valve adjustor (3) of the regulating valve assembly (5).

■ IMPORTANT

- Do not connect the universal joint of the implement to the tractor PTO shaft while testing.



PTO operating pressure	When PTO shift lever is "ENGAGED" position	2.30 to 2.50 MPa 23.5 to 25.5 kgf/cm ² 334 to 363 psi
	When PTO shift lever is "DISENGAGED" position	No pressure


Condition

- Engine speed Idling speed
- Oil temperature 40 to 60 °C
104 to 140 °F



(Reference)

- Turn to clockwise direction → Pressure is increased
- Turn to counterclockwise direction → Pressure is decreased

- (1) Plug (PT 1/8)
- (2) Spool
- (3) Pressure Reducing Valve Adjustor
- (4) Regulating Valve Adjustor
- (5) Regulating Valve Assembly



W1012774

(2) Disassembling and Assembling**(A) Clutch Housing****Draining the Transmission Fluid**

1. Place oil pans underneath the transmission case.
2. Remove the drain plugs (1).
3. Drain the transmission fluid.
4. Reinstall the drain plugs (1).

(When refilling)

- Fill up from filling port after removing the filling plug (2) until reaching the upper notch on the dipstick (3).
- After running the engine for few minutes, stop it and check the oil level again, add the fluid to prescribed level if it is not correct level.

Transmission fluid capacity	L3130 L3430	42 L 11.1 U.S.gals. 9.2 Imp.gals.
	L3830 L4330 L4630	43 L 11.4 U.S.gals. 9.5 Imp.gals.

■ IMPORTANT

- Use only KUBOTA SUPER UDT fluid. Use of other oils may damage the transmission or hydraulic system. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7, 8.)
- Do not mix different brands of fluid together.

- (1) Drain Plugs
- (2) Filling Plug
- (3) Dipstick

(A) Oil level is acceptable within this range.

W1012748

Battery, Front Grill, Skirt and Bonnet

1. Open the bonnet (1) and disconnect the battery negative cable.
2. Disconnect the head light connector and remove the front grill (3).
3. Remove the left and right side skirts (2).
4. Remove the bonnet (1).


■ NOTE


- When disconnecting the battery cords, disconnect the negative cord first, when connecting, positive cord first.

- (1) Bonnet
- (2) Skirt

(3) Front Grill

W1013500






ROPS

1. Remove the lower connector (2).
2. Remove the plate mounting screws (4), (8).
3. Remove the upper frame (1) from ROPS lower frame (5).

(When reassembling)

■ **NOTE**


- Do not firmly tighten all screws until most components are attached.



Tightening torque	Lower connector mounting screw (3)	103 to 118 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft·lbs
	Plate mounting screw (4)	138 to 147 N·m 14.0 to 15.0 kgf·m 102 to 108 ft·lbs
	Plate mounting screw (8)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft·lbs

(Reference)


Tightening torque	Upper connector mounting screw (9)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft·lbs
	Fulcrum bolt and nut (11)	118 to 137 N·m 12.0 to 14.0 kgf·m 86.8 to 102 ft·lbs








- (1) Upper Frame
- (2) Lower Connector
- (3) Screw (M12 × 65)
- (4) Screw (M14 × 40)
- (5) Lower Frame
- (6) Plate
- (7) Connector
- (8) Screw (M14 × 30)

- (9) Screw (M14 × 30)
- (10) Upper Connector
- (11) Fulcrum Bolt and Nut
- (12) Lock Bolt

A : Rigid Type
B : Foldable Type



W1097399



Steering Joint, Brake Pedal Rod and Electric Wiring

1. Remove the tank frame support (1).
2. Remove the universal joint bolt (7) and steering joint support (3), and then remove the steering joint (2).
3. Disconnect the hand accelerator wire and foot accelerator wire (4).
4. Disconnect the wiring connectors for engine stop solenoid (5) engine tachometer sensor (6) and glow plug.
5. Disconnect the brake pedal rod.

(When reassembling)

- When accelerator wire is installed, adjust the wire length as hit both the idling speed adjusting bolt and the maximum speed adjusting bolt by lever within the stroke of the accelerator lever.
- Set the steering joint (2) by the joint support (3) so that the steering wheel is turned lightly.
- Be sure to check and adjust the brake pedal free travel. (See page G-16.)

- | | |
|----------------------------|------------------------------|
| (1) Tank Frame Support | (5) Engine Stop Solenoid |
| (2) Steering Joint | (6) Engine Tachometer Sensor |
| (3) Steering Joint Support | (7) Universal Joint Bolt |
| (4) Accelerator Wire | |

W1014002

Clutch Rod, Brake Pedal Rod and Electric Wiring

1. Disconnect the brake pedal rod (5) and clutch pedal rod (4).
2. Disconnect the wiring connectors for alternator (1), coolant temperature sensor (7), oil pressure switch (2), fuel unit (3), starter motor (6) and battery.
3. Remove the clamps and ground earth of wiring harness and collect wiring harness to the step.

(When reassembling)

- Be sure to check and adjust the clutch and brake pedal free travel. (See page G-16, 22.)

- | | |
|-------------------------|--------------------------------|
| (1) Alternator | (5) Brake Pedal Rod |
| (2) Oil Pressure Switch | (6) Starter Motor |
| (3) Fuel Unit | (7) Coolant Temperature Sensor |
| (4) Clutch Pedal Rod | |

W1014368




Shuttle Switch Connector

1. Remove the panel cover and steering post cover.
2. Disconnect the shuttle switch connector (1).

(1) Shuttle Switch Connector

W1014526




Seat, Seat Bracket, Lever Grips, PTO Shift Wire and Connectors

1. Remove the seat.
2. Disconnect the seat switch connector (3) and remove the seat bracket (1) with seat suspension.
3. Remove the lever grip for main shift lever (5), position control lever (2), range gear shift lever (4) and front wheel drive lever (4WD only).
4. Disconnect the differential lock rod (7).
5. Remove the lowering speed adjusting knob (6).
6. Disconnect the PTO shift wire (9) at the PTO clutch valve (11).
7. Disconnect the traveling speed sensor connector (8).

(When reassembling)

- When connecting the PTO shift wire (9) to the clutch valve lever, be sure to adjust the length of wire as follows.


1. Set the PTO shift lever to **OFF (Neutral)** position.
2. Loosen the lock nut (10) of wire, and connect wire to the clutch valve lever, and then place the wire to the hook.
3. Tighten the lock nut (10) clockwise (pull the wire), and lock the nut just before the lever moves.




- (1) Seat Bracket
- (2) Position Control Lever
- (3) Seat Switch Connector
- (4) Range Gear Shift Lever
- (5) Main Gear Shift Lever
- (6) Lowering Speed Adjusting Knob

- (7) Differential Lock Rod
- (8) Traveling Speed Sensor Connector
- (9) PTO Shift Wire
- (10) Lock Nut
- (11) PTO Clutch Valve

W1014626






3TLABAB3P106A

Step and Floor Seat

1. Disconnect the ground cable which is attached on left side of transmission case.
2. Disconnect the panel frame connector (1) from fuel tank frame.
3. Remove the step and floor seat mounting bolt and nut.
4. Dismount the step, fender, floor seat and panel frame as a unit after checking whether there is forgetting to disconnect wiring.

(When reassembling)

- Be sure to set the washers and rubber plates of the floor seat and step mounting bolt at an original positions as shown in figure.
- Before mounting the floor seat and step, be sure to set both the shuttle lever rod and the shuttle arm to the neutral position, and then connect the shuttle lever rod securely.




3TLABAB3P107A

Tightening torque	Step mounting bolt and nut	124 to 147 N·m 12.6 to 15.0 kgf·m 91.1 to 108 ft-lbs
	Floor seat mounting bolt and nut	196 to 225 N·m 20 to 23 kgf·m 145 to 166 ft-lbs

- | | |
|---------------------------|----------|
| (1) Panel Frame Connector | (7) Nut |
| (2) Floor Seat | (8) Step |
| (3) Bolt | |
| (4) Rubber Plate | |
| (5) Washer | |
| (6) Spring Washer | |

F : Front Side
R : Rear Side

W1015069



3TLABAB3P108A

Hydraulic Pipes


1. Remove the main delivery pipe 1 (8).
2. Disconnect the main delivery pipe 2 (2) at the rear hydraulic block (1) and return pipe (6) at the mid case, and then remove the front hydraulic block (7) with pipes and bracket as a unit.
3. Remove the suction pipe (4) with oil filter (3).
4. Remove the PTO delivery pipe (5).

(When reassembling)

Tightening torque	Joint bolt for main delivery pipe 1 to front hydraulic block	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Joint bolt for main delivery pipe 2 to rear hydraulic block	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Cap nut for return pipe to mid case	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Joint bolt for PTO delivery pipe	34 to 39 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft-lbs

- | | |
|--------------------------|---------------------------|
| (1) Rear Hydraulic Block | (5) PTO Delivery Pipe |
| (2) Main Delivery Pipe 2 | (6) Return Pipe |
| (3) Hydraulic Oil Filter | (7) Front Hydraulic Block |
| (4) Suction Pipe | (8) Main Delivery Pipe 1 |

W1015283



3TMABAB1P011A


Propeller Shaft (4WD Only)

1. Slide the propeller shaft cover (4) and (8) after removing the screws (7).
2. Tap out the spring pins (2), (6) and slide the couplings (1), (5) and then remove the propeller shaft with covers (4), (8).

(When reassembling)

- Apply grease to the splines of propeller shaft 1 (3).

- | | |
|---------------------------|---------------------------|
| (1) Coupling | (5) Coupling |
| (2) Spring Pin | (6) Spring Pin |
| (3) Propeller Shaft 1 | (7) Screws |
| (4) Propeller Shaft Cover | (8) Propeller Shaft Cover |



3TLABAB3P109A



3TLABAB3P110A

Separating Engine and Clutch Housing





1. Place the disassembling stand under the engine and clutch housing case.
2. Remove the fuel tank support mounting bolts.
3. Remove the engine and clutch housing mounting screws and nuts.
4. Separate the engine and clutch housing while lifting up the tank frame.

(When reassembling)

- Apply grease to the spline of clutch shaft.
- Apply liquid gasket (Three Bond 1211 or equivalent) to joint face of the flywheel housing and clutch housing.

Tightening torque	Engine and clutch housing mounting screw and nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Engine and clutch housing mounting stud bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs

W1015876



Shift Levers

1. Disconnect the brake rods (6).
2. Tap out the spring pins (2) of main shift rod 1 (3).
3. Remove the shuttle shift arm stopper mounting screw, and then pull the shuttle shift shaft (1) with arm (4) up.

(When reassembling)

- Tap in the spring pins (2) so that their split portion may face forward.
- When reassembling the shuttle shift arm (4) to the shuttle fork rod (5), be sure to install it to the groove **A**.

- (1) Shuttle Shift Shaft
- (2) Spring Pin
- (3) Main Shift Rod 1
- (4) Shuttle Shift Arm

- (5) Shuttle Fork Rod
- (6) Brake Rod

A : Fork Rod Groove

W1016127

Separating Clutch Housing and Mid Case

1. Remove the clutch housing and mid case mounting screws and nuts.
2. Separate the clutch housing and mid case.

(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the clutch housing and mid case.

Tightening torque	Clutch housing and mid case mounting nut	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft·lbs
	Clutch housing and mid case mounting screw	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft·lbs
	Clutch housing and mid case mounting stud bolt	38.2 to 45.1 N·m 3.9 to 4.6 kgf·m 28.2 to 33.3 ft·lbs

W10134850

Main Shift Base

1. Remove the main shift base mounting screws.
2. Take out the main shift base (1) and main shift arm (3) as a unit.

(When reassembling)


- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the clutch housing case and main shift base.
- The main shift arm should be fitted on to the shift fork grooves (2) after setting the shift forks to neutral position.

Tightening torque	Main shift base mounting screw	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft·lbs
	Main shift arm setting screw	9.8 to 11.3 N·m 1.00 to 1.15 kgf·m 7.2 to 8.3 ft·lbs

- (1) Main Shift Base
- (2) Shift Fork Grooves

- (3) Main Shift Arm

W1016861



Clutch Lever, Release Fork and Release Bearing

1. Remove the release fork mounting screws (2).
2. Draw out the clutch lever (3) to remove the release fork (1).
3. Remove the release bearing and release hub (4) together.


(When reassembling)

- Apply grease to the sliding surface of the clutch release hub.
- Apply grease to the clutch lever.

Tightening torque	Release fork mounting screw	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft·lbs
-------------------	-----------------------------	---

- (1) Release Fork (3) Clutch Lever
(2) Release Fork Mounting Screw (4) Release Hub

W10126560



Shaft Case

1. Remove the shaft case mounting screws.
2. Screw down the two M6 screws (1) into the shaft case (2) and pull it out.
3. Take out the shaft case (2).

(When reassembling)


- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the shaft case and clutch housing case.

(When replacing oil seal in shaft case)





- Install the oil seal (3) as shown in the figure, noting its direction.
- Apply grease to the oil seal (3).

- (1) M6 Screw (3) Oil Seal
(2) Shaft Case

W10128390



Clutch housing bearing holder mounting screw	18 to 20 N·m 1.9 to 2.1 kgf·m 13 to 15 ft·lb
Clutch housing bearing holder	24 to 26 N·m 2.5 to 2.8 kgf·m 17 to 19 ft·lb



23T (24T) Gear Shaft, 27T (26T) Gear and Front Axle Drive Shaft

1. Remove the 23T (24T) gear shaft (3).
2. Remove the external snap ring (1) and 27T (26T) gear (2).
3. Pull out the front axle drive shaft (4) to the rear side (4WD only).

(When reassembling)

- Install the oil seal (7) on the 18T gear shaft (5), noting the direction of the oil seal (7) as shown in the figure.
- Direct the boss side of the gear (2) to the bearing side.
- Apply small amount of the grease to the oil seal (6), (7).
- Install the front axle drive shaft (4) from front side after assembling the clutch housing case and mid case. Then install the bearing (10), sleeve (11), oil seal (9), collar (12) and internal snap ring (8) in order.

- | | |
|---|------------------------|
| (1) External Snap Ring | (7) Oil Seal |
| (2) 27T Gear (Except L4330)
26T Gear (L4330) | (8) Internal Snap Ring |
| (3) 23T Gear Shaft (Except L4330)
24T Gear Shaft (L4330) | (9) Oil Seal |
| (4) Front Axle Drive Shaft | (10) Bearing |
| (5) 18T Gear Shaft | (11) Sleeve |
| (6) Oil Seal | (12) Collar |

F : Front Side

W1017151

Clutch Housing Bearing Holder

1. Remove the three interlock balls (2) after removing the stopper screw (1).
2. Pull out the clutch housing bearing holder (5) with using two jack bolts (6).

NOTE

- Take care not to fly out the balls (3) and springs (4) when pull out the bearing holder (1).


(When reassembling)

- Tap in the clutch housing bearing holder (5) with plastic hammer until contact to clutch housing case, and then tighten the screws to specified torque.
- Install the three interlock balls (2) with a small amount of grease to the clutch housing bearing holder (5) after setting the shift forks and shift rods to the neutral position.

Tightening torque	Clutch housing bearing holder mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft-lbs
	Stopper screw	34.3 to 44.1 N·m 3.5 to 4.5 kgf·m 25.3 to 32.5 ft-lbs

- | | |
|--------------------|-----------------------------------|
| (1) Stopper Screw | (4) Spring |
| (2) Interlock Ball | (5) Clutch Housing Bearing Holder |
| (3) Ball | (6) Jack Bolt |

W1017551



3TLABAB3P121A


Shaft Assemblies

1. Remove the external snap ring (1) and collar (2).
2. Draw out the shaft assemblies (3), (5), (6), (7), (8).

- | | |
|----------------------------|--------------------------------|
| (1) External Snap Ring | (5) 18T Gear Shaft Assembly |
| (2) Collar | (6) Idle Shaft Assembly |
| (3) Counter Shaft Assembly | (7) PTO Counter Shaft Assembly |
| (4) Shift Rods | (8) Main Gear Shaft Assembly |

W1017774

Counter Shaft



3TLABAB3P122A

- | | | | |
|------------------------|-------------------------|---------------------|---------------------|
| (1) Internal Snap Ring | (6) Synchronizer Ring | (10) Shifter | (14) Needle Bearing |
| (2) Bearing | (7) Synchronizer Spring | (11) 29T Gear (3rd) | (15) 37T Gear (1st) |
| (3) Needle Bearing | (8) Hub | (12) Counter Shaft | (16) Bearing |
| (4) 24T Gear (4th) | (9) Synchronizer Key | (13) 34T Gear (2nd) | (17) Bearing Holder |
| (5) External Snap Ring | | | |

1. Remove the internal snap ring (1) and remove both side of the bearings (2), (16).
2. Remove the gears on the counter shaft (12) and external snap rings (5).


(When reassembling)

- Reinstall the synchronizer keys (9) in the key grooves of the synchronizer rings (6) firmly.

(B) Mid Case

■ **NOTE**

- For the disassembling procedure from “Draining the Transmission Fluid” to “Propeller Shaft”, refer to page 3-S18 to 3-S23.



Main Shift Lever and Brake Rods

1. Tap out the spring pins (2) of main shift rod (1).
2. Remove the main gear shift lever (4) with the support (3).

(When reassembling)

- Tap in the spring pins (2) so that their split portion may face forward.

- (1) Spring Pin
- (2) Main Shift Rod
- (3) Support
- (4) Main Gear Shift Lever

W1018477



Separating Mid Case and Transmission Case


1. Separate the mid case and transmission case after removing their mounting screws.

(When reassembling)

- Confirm to insert the PTO shaft to PTO clutch firmly, turning the PTO shaft.
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the mid case and transmission case.

Tightening torque	Mid case and transmission case mounting screw	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Mid case and transmission case mounting nut	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Mid case and transmission case mounting stud bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs

W1018604



Separating Mid Case

1. Lift up the shuttle shift arm (1).
2. Separate the mid case from the clutch housing after removing their mounting screws.

(When reassembling)


- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of clutch housing and mid case.
- When reassembling the shuttle shift arm (1) to the shuttle fork rod (2), be sure to install it to the groove **A**.


Tightening torque	Clutch housing and mid case mounting screw	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Clutch housing and mid case mounting nut	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Clutch housing and mid case mounting stud bolt	38.2 to 45.1 N·m 3.9 to 4.6 kgf·m 28.2 to 33.3 ft-lbs

- (1) Shuttle Shift Arm
- (2) Shuttle Fork Rod

A : Fork Rod Groove

W1018779





PTO Clutch Valve

1. Remove the PTO clutch valve (2) as a unit.
2. Pull out the pipe (1).


(When reassembling)

- Apply small amount of grease for the O-ring (3).
- Install the pipe (1) to the hole (4) of the PTO clutch valve (2) firmly.
- Replace the pipe (1) with new one.

Tightening torque	PTO clutch valve mounting screw	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft-lbs
-------------------	---------------------------------	---

- (1) Pipe
- (2) PTO Clutch Valve
- (3) O-ring
- (4) Hole

W1019328



Mid Case Bearing Holder

1. Remove the PTO drive shaft (3).
2. Remove the mid case bearing holder mounting screws, and then take out the bearing holder (2) with PTO clutch (1) as a unit.

■ NOTE

- Take care not to fly out the ball (5) and spring (4) when pull out the bearing holder (2).


(When reassembling)

- Tap in the mid case bearing holder (2) with plastic hammer until contact to mid case, and then tighten the screws to specified torque.

Tightening torque	Mid case bearing holder mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft-lbs
-------------------	--	---

- (1) PTO Clutch
- (2) Mid Case Bearing Holder
- (3) PTO Drive Shaft
- (4) Spring
- (5) Ball

W1019191






Shaft Assemblies

1. Remove the external snap ring (5).
2. Draw out the shaft assemblies (1), (2), (3) and shuttle fork rod (4).

- (1) Reverse Gear Shaft
- (2) Shuttle Gear Shaft
- (3) Shuttle Shaft Assembly
- (4) Shuttle Fork Rod
- (5) External Snap Ring

W1019826



Shuttle Shaft

1. Remove the external snap ring (17) and collar (16).
2. Draw out the bearing (15) by the bearing puller.
3. Remove the gears, collars and etc..
4. Remove the external snap ring (12), and then remove the hub (10) and other parts.

(When reassembling)


- Apply enough transmission fluid to the synchronizer portion, needle bearings (3) and thrust collar (14).
- Direct the grooved side of the thrust collar (14) to the needle bearing (3) side.
- Install the protrusion portions (B) of the center rings (6) to the holes (A) of the gears (4), (13) firmly.
- Install the protrusion portions (D) of the outer synchronizer rings (7) to the grooves (C) of the inner synchronizer rings (5).
- Install the external snap ring (12) to the groove of the shuttle shaft (2) firmly.
- Install the synchronizer keys (8) in the key grooves of the outer synchronizer rings (7) firmly.




- (1) Bearing
- (2) Shuttle Shaft
- (3) Needle Bearing
- (4) 22T Gear (Forward)
- (5) Inner Synchronizer Ring
- (6) Center Ring
- (7) Outer Synchronizer Ring
- (8) Synchronizer Key
- (9) Synchronizer Spring
- (10) Hub
- (11) Shifter
- (12) External Snap Ring
- (13) 18T Gear (Reverse)

- (14) Thrust Collar
- (15) Bearing
- (16) Collar
- (17) External Snap Ring

- A : Holes of the Gear
- B : Protrusion Portion of the Center Ring
- C : Groove of the Inner Synchronizer Ring
- D : Protrusion Portion of the Outer Synchronizer Ring

W1019932






Clutch Hub and Clutch Discs of PTO Clutch

1. Remove the internal snap ring (8), and then take out the clutch discs (5), the back plate (7), the steel plates(4) and (6), the hub (3) and the bearing (2).


(When reassembling)

- Install the clutch discs (5) and steel plates (4) and (6) mutually. (Refer to figure below.)
- Do not confuse the two types steel plates. The steel plates with the plug rubbers (10) are (6) and without plug rubbers are (4).
- Do not confuse the back plate (7) and steel plates. The back plate (7) is thicker than the steel plates.
- Assemble the plug rubbers portion of the three steel plates (6) are same positions while assembling them. (Refer to figure below.)
- Apply enough transmission fluid to the discs (5).
- Confirm the moving of the piston (11) smoothly when pressure air at 0.29 to 0.39 MPa (3 to 4 kgf/cm², 42 to 57 psi) is sent to clutch pack. (Refer to the figure left.)



- | | |
|---------------------------------------|------------------------|
| (1) Clutch Case | (7) Back Plate |
| (2) Bearing | (8) Internal Snap Ring |
| (3) Hub | (9) Bearing Holder |
| (4) Steel Plate (without Plug Rubber) | (10) Plug Rubber |
| (5) Clutch Disc | (11) Piston |
| (6) Steel Plate (with Plug Rubber) | |

W10159250




Accumulator Valve of PTO Clutch

1. Remove the internal snap ring (1).
2. Remove the spring seat (2).
3. Draw out the spring (4) and piston (3).

- | | |
|------------------------|------------|
| (1) Internal Snap Ring | (3) Piston |
| (2) Spring Seat | (4) Spring |

W10163300



Clutch Case



1. Remove the external snap ring (1).
2. Remove the clutch case (7) and brake disc (5).

(When reassembling)

- Direct the contact part of the brake disc (5) to the brake plate (6).
- Apply small amount of the grease to the seal rings (8).

- | | |
|------------------------|-----------------|
| (1) External Snap Ring | (5) Brake Disc |
| (2) Collar | (6) Brake Plate |
| (3) Bearing Holder | (7) Clutch Case |
| (4) Collar | (8) Seal Ring |

W10164510



Brake Plate

1. Remove the brake plate mounting screws (3) and then take out the brake plate (4) and the springs (2).


(When reassembling)

- Apply liquid lock (Three Bond 1372 or equivalent) to the brake plate mounting screws (3).
- Apply grease to the O-rings (5), and be sure to install the three O-rings (5).

Tightening torque	Brake plate mounting screw	9.8 to 11.3 N·m 1.00 to 1.15 kgf·m 7.2 to 8.3 ft·lbs
-------------------	----------------------------	--

- | | |
|--------------------------------|-----------------|
| (1) Clutch Case | (4) Brake Plate |
| (2) Spring | (5) O-ring |
| (3) Brake Plate Mounting Screw | |

W10167880



Piston

1. Press the washer (7) lightly by the hand press, using the hand made jig. (Refer to the figure left.)
2. Remove the external snap ring (3), washer (7) and spring (6).
3. Draw out the piston (5).


(When reassembling)

- Apply enough transmission fluid to seal rings (4) and (8).

- | | |
|------------------------|---------------|
| (1) Clutch Case | (6) Spring |
| (2) Jig | (7) Washer |
| (3) External Snap Ring | (8) Seal Ring |
| (4) Seal Ring | |
| (5) Piston | |

A : 41 mm (1.6 in.)

W10169240



(C) Transmission Case

■ **NOTE**

- For the disassembling procedure from “Draining the Transmission Fluid” to “Step and Floor Seat”, refer to page 3-S18 to 3-S22.




Rear Wheel

1. Place disassembling stand under the transmission case, and support it with a jack.
2. Remove the rear wheels.
3. After removing the rear wheels, support it at both sides of rear axle by stands.

(When reassembling)

Tightening torque	Rear wheel mounting screw and nut	215 N·m 22 kgf·m 160 ft·lbs
	Rear wheel mounting stud bolt	98.1 to 112.8 N·m 10.0 to 11.5 kgf·m 72.3 to 83.2 ft·lbs

W1021882




ROPS, 3 Point Linkages, Hydraulic Cylinders and Others


1. Remove the top link.
2. Remove the lift rods (2), lower links (6) and stabilizers (1) as a unit.
3. Remove the ROPS lower frames (3).
4. Remove the PTO shaft cover (5).
5. Remove the drawbar frame (7).
6. Disconnect the hydraulic cylinder hoses (8) and return hoses (10) at the rear hydraulic block (9).
7. Remove the two pins and remove the hydraulic cylinders (4).
8. Remove the main gear shift lever (11).
9. Disconnect the brake rods (12).

(When reassembling)

- Apply grease to the lower link pins and hydraulic cylinder pins.




Tightening torque	Lift arm pin mounting nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft·lbs
	Lift arm pin lock nut	62.8 to 72.6 N·m 6.4 to 7.4 kgf·m 46.3 to 53.5 ft·lbs
	Drawbar frame mounting screw (M12)	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft·lbs
	Drawbar frame mounting screw (M14)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft·lbs
	Hydraulic cylinder hose	34.3 to 48.1 N·m 3.5 to 4.9 kgf·m 25.3 to 35.4 ft·lbs
	ROPS lower frame mounting screw	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft·lbs



- | | |
|-----------------------------|--------------------------------|
| (1) Stabilizer | (9) Rear Hydraulic Block |
| (2) Lift Rod | (10) Return Hose |
| (3) ROPS Lower Frame | (11) Main Gear Shift Lever |
| (4) Hydraulic Cylinder | (12) Brake Rod |
| (5) PTO Shaft Cover | (13) Screw (M14 × 155) |
| (6) Lower Link | (14) Screw (M14 × 30) |
| (7) Drawbar Frame | A : L3130, L3430 |
| (8) Hydraulic Cylinder Hose | B : L3830, L4330, L4630 |

W1142329



Rear Hydraulic Block and Lift Arm Support

1. Loosen the main delivery pipe support screw and disconnect the main delivery pipe (1) at the rear hydraulic block (2).
2. Remove the rear hydraulic block (2), cover (4) and lift arm support (3) as a unit.


(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the differential case and cover (4).

Tightening torque	Joint bolt for main delivery pipe	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs

- (1) Main Delivery Pipe
- (2) Rear Hydraulic Block
- (3) Lift Arm Support
- (4) Cover

W1022601



Mid PTO Case (If equipped)


1. Remove the mid PTO lever (1).
2. Remove the mid PTO gear case assembly (3) with lever rod (2).

(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the mid PTO case and transmission case.

- (1) Mid PTO Lever
- (2) Lever Rod
- (3) Mid PTO Gear Case

W1023596



Rear Axle

1. Separate the rear axle case from brake case.

(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the rear axle and brake case.

Tightening torque	Rear axle case mounting screw and nut	M10 screw and nut (7T)	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft-lbs
		Stud bolt	24.5 to 31.4 N·m 2.5 to 3.2 kgf·m 18.1 to 23.1 ft-lbs
		M10 nut (9T) (Except L3130, L3430)	60.8 to 70.6 N·m 6.2 to 7.2 kgf·m 44.9 to 52.1 ft-lbs
		M12 screw (Except L3130, L3430)	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs

W1022886



3TLABAB3P140A

Brake Case


1. Remove the range gear shift lever and its fulcrum screw.
2. Remove the brake case mounting screws and nuts.
3. Separate the brake case, tapping the brake case lever lightly.

(When reassembling)

- Apply grease to the steel ball seats. (Do not grease excessively.)
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the brake case and transmission case.
- Be sure to apply liquid gasket to **A** position.
- Be sure to fix the brake cam and cam plate.
- Before installing the brake case to the transmission case, install the cam plate to the transmission case.

Tightening torque	Brake case mounting stud bolt	29.4 to 49.0 N·m 3.0 to 5.0 kgf·m 21.7 to 36.1 ft-lbs
	Brake case mounting screw and nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Lever fulcrum screw	62.8 to 72.5 N·m 6.4 to 7.4 kgf·m 46.3 to 53.5 ft-lbs

W10194530



3TLABAB3P141A

Separating Mid Case and Transmission Case


1. Separate the mid case and transmission case after removing their mounting screws and nut.

(When reassembling)

- Confirm to insert the PTO shaft to PTO clutch firmly, turning the PTO shaft.
- Confirm to insert the front wheel drive shaft to coupling firmly.
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the mid case and transmission case.

Tightening torque	Mid case and transmission case mounting screw	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Mid case and transmission case mounting nut	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Mid case and transmission case mounting stud bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs

W1023310



3TLABAB3P142A

Pinion Bearing Cover

1. Remove the stake of lock nut (5).
2. Lock the turning of spiral bevel pinion and remove the lock nut (5).
3. Remove the pinion bearing case mounting screws.
4. Take out the pinion bearing cover (4) and shims (1).


(When reassembling)

- Make sure of the number of shims in the pinion bearing case.
- Replace the lock nut (5) with a new one, and stake the lock nut firmly after installing the parts on the shaft.

Tightening torque	Lock nut	147 to 196 N·m 15 to 20 kgf·m 108 to 145 ft·lbs
	Pinion bearing case mounting screw	39.2 to 44.1 N·m 4.0 to 4.5 kgf·m 28.9 to 32.5 ft·lbs

- (1) Shim
- (2) Pinion Bearing Case
- (3) Spiral Bevel Pinion Shaft
- (4) Pinion Bearing Cover
- (5) Lock Nut

W1022792



3TLABAB3P143A

Transmission Bearing Holder

1. Remove the transmission bearing holder mounting screws.
2. Tap out the spring pin (8) on the shift fork rod (3).
3. Jack up the bearing holder (1) by using the two jack screws (5) until the taper roller bearing (7) can be removed.

NOTE

- Jack up the bearing holder while hitting the two shafts (2) (4) by copper hammer or soft hammer.
- 4. Jack up more and remove the transmission bearing holder (1).


(When reassembling)

- Tap in the transmission bearing holder with soft hammer until contact to transmission case, and then tighten the screws to specified torque.
- Tap in the spring pin (8) so that its split portion may face forward. (Refer to figure.)


Tightening torque	Transmission bearing holder mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.5 to 41.2 ft·lbs
-------------------	--	---

- (1) Transmission Bearing Holder
- (2) Spiral Bevel Pinion Shaft
- (3) Shift Fork Rod for Range Gear Shift
- (4) PTO Drive Shaft
- (5) Jack Screw
- (6) Pinion Bearing Case
- (7) Taper Roller Bearing
- (8) Spring Pin
- (9) Range Gear Shaft
- (10) Front Wheel Drive Shaft





W1023062



3TLABAB3P144A



3TLABAB3P145A




Shaft Assemblies

1. Remove the traveling speed sensor (1).
2. Take out the spiral bevel pinion shaft assembly (4), range gear shaft assembly (5) with shift fork (6) and PTO drive shaft assembly (3).
3. Take out the front wheel drive shaft (2).

- | | |
|--|---|
| (1) Traveling Speed Sensor | (11) 20T-49T Gear |
| (2) Front Wheel Drive Shaft | (12) 27T Gear (L3130, L3430, L3830) |
| (3) PTO Drive Shaft | (13) 29T Gear (L3130, L3430) |
| (4) Spiral Bevel Pinion Shaft | 29T-31T Gear (L3830) |
| (5) Range Gear Shaft | 29T-30T Gear (L4330, L4630) |
| (6) Shift Fork | 29T-32T Gear (L5030) |
| (7) 17T Gear | (14) 24T Shifter Gear (4WD Only) |
| (8) Needle Bearing | (15) 26T-60T Gear (L3130, L3430, L3830) |
| (9) 34T Gear (L3130, L3430, L4330) | |
| 35T Gear (L3830, L4630) | |
| (10) 18T Gear (L3130, L3430, L4330, L4630) | |
| 17T Gear (L3830) | |

W1024207



Differential Lock Shift Fork


1. Tap out the left side spring pin (4).
2. Remove the cotter pin and take out the clevis pin (3).
3. Draw out the differential lock fork shaft (1) and take out the differential lock shift fork (2).

(When reassembling)

- Apply grease to the left and right oil seals on the transmission case.
- Insert the clevis pin (3) from the top and install the washer and cotter pin.
- Tap in the spring pin (4) so that its split portion **a** may face outward as shown in the figure.

- (1) Differential Lock Fork Shaft
- (2) Differential Lock Shift Fork
- (3) Clevis Pin
- (4) Spring Pin

a : Split Portion




PTO Shaft

1. Remove the PTO shaft cover.
2. Remove the bearing case mounting screws, and draw out the PTO shaft (1) with bearing case (2).
3. Remove the internal snap ring (3).
4. Top out the PTO shaft (1) to the front.

(When reassembling)

- If the lock nut (6) was removed, replace it with a new one. After replacing, be sure to stake it firmly.
- Install the slinger (7) firmly.
- Apply grease to the oil seal (4) and install it, noting its direction.




Tightening torque	Lock nut	147 to 196 N·m 15 to 20 kgf·m 108 to 145 ft·lbs
	Bearing case mounting screw	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft·lbs


- (1) PTO Shaft
- (2) Bearing Case
- (3) Internal Snap Ring
- (4) Oil Seal
- (5) Oil Seal Collar

- (6) Lock Nut
- (7) Slinger

[A] L3130, L3430
[B] L3830, L4330, L4630



W10242030



Differential Gear Assembly


1. Remove the differential support, noting the number of left shims.
2. Take out the differential gear assembly, noting the number of right shims.

(When reassembling)

- Check the spiral bevel gear for wear or damage. If it is no longer serviceable, replace it. Then, also replace the spiral bevel pinion.
- Use same number of shims as before disassembling.

Tightening torque	Differential support mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft·lbs
-------------------	-------------------------------------	---


W10245370



Bearing and Differential Lock Shifter

1. Secure the differential gear in a vise.
2. Remove the differential lock shifter and taper roller bearing as a unit with a puller.

W10246640



Differential Case Cover and Differential Side Gear

1. Remove the differential case cover (3).
2. Remove the differential side gear (1) and differential side gear washer (2).

(When reassembling)


- Apply molybdenum disulfide (Three Bond 1901 or equivalent) to the inner circumferential surface of the differential side gear boss.

Tightening torque	Differential case cover mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft·lbs
-------------------	--	---

- (1) Differential Side Gear
(2) Differential Side Gear Washer

- (3) Differential Case Cover

W10247220



Spiral Bevel Gear


1. Remove the spiral bevel gear.

(When reassembling)


- Check the spiral bevel gear for wear or damage. If it is no longer serviceable, replace it. Then, also replace the spiral bevel pinion shaft.
- Apply liquid lock (Three Bond 1372 or equivalent) to the spiral bevel gear UBS screws.

Tightening torque	Spiral bevel gear UBS screw	68.6 to 88.3 N·m 7.0 to 9.0 kgf·m 50.6 to 65.1 ft·lbs
-------------------	-----------------------------	---


W10249330




3TMABAB3P035A



3TMABAB3P036A



3TMABAB3P037A



3TMABAB3P038A

Differential Pinion Shaft and Differential Pinion

1. Draw out the differential pinion shaft 2 (5), and take out the differential pinion (3) and differential pinion washer (4).
2. Draw out the differential pinion shaft 1 (1), and take out the differential pinion (2) and differential pinion washer.

■ **NOTE**

- **Arrange the parts to know their original position.**

(When reassembling)

- Check the differential pinions (2) and (3), and pinion shaft (1) and (5) for excessive wear. If these parts are damaged or excessively worn, replace their parts they are in mesh with, or they sliding on.
- Apply molybdenum disulfide (Three Bond 1901 or equivalent) to the inner circumferential surface of the differential pinions.
- Install the parts to their original position.
- Install the differential pinion washer (4), noting its groove position.

- (1) Differential Pinion Shaft
- (2) Differential Pinion
- (3) Differential Pinion
- (4) Differential Pinion Washer
- (5) Differential Pinion Shaft 2

- (6) Differential Side Gear
- (7) Differential Side Gear Washer
- (8) Differential Case

A : Fit Groove

W10250420

Differential Side Gear


1. Take out the differential side gear (2) and differential side gear washer (1).

(When reassembling)

- Check the thrust and bearing surface of both differential side gears (2). If they are worn or damaged, bores in the differential case may also be damaged. Be sure to replace their parts.

- (1) Differential Side Gear Washer
- (2) Differential Side Gear

W10252580


(3) Servicing**(A) Bearing, Gear and Shaft**

3TMABAB3P015A

Checking Bearing

1. Hold the inner race, and push and pull the outer race in all directions to check for wear and roughness.
2. Apply transmission fluid to the bearing, and hold the inner race. Then turn the outer race to check rotation.
3. If there is any defect, replace it.

W10222940




3TMABAB3P016A

Clearance between Gear and Spline

1. Secure the gear with a vise.
2. Set a dial indicator (lever type) with its finger on the spline.
3. Move the shaft to measure the clearance.
4. If the clearance exceeds the allowable limit, replace them.

Clearance between gear and spline	Factory spec.	0.030 to 0.078 mm 0.0018 to 0.00307 in.
	Allowable limit	0.2 mm 0.008 in.

W10258480




3TMABAB3P017A

Clearance between Shift Fork and Shift Gear Groove

1. Place for in the groove to check clearance with feeler gauge.
2. If the clearance exceeds allowable limit, replace.

Clearance between shift fork and shift gear groove	Factory spec.	0.20 to 0.40 mm 0.008 to 0.016 in.
	Allowable limit	0.8 mm 0.031 in.

W10269970




3TLABAB3P152A

Clearance between Gear and Shaft

1. Measure the shaft O.D. (rubbing surface).
2. Measure the gear I.D. (rubbing surface).
3. Measure the O.D. of the two needles installed diagonally in the needle bearing.
4. Calculate the clearance
(Clearance = Gear I.D. - {(2 × needle O.D.) + shaft O.D.})
5. If the clearance exceeds the allowable limit, replace them.

Clearance between gear and shaft	Factory spec.	0.021 to 0.054 mm 0.00083 to 0.00213 in.
	Allowable limit	0.1 mm 0.004 in.

W1026299

(B) Synchronized Gear


3TLABAB3P154A

Clearance between Shift Fork and Shifter Groove

1. Measure the width of shift fork.
2. Measure the shifter groove width, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace them.

Clearance between shift fork and shifter groove	Factory spec.	Shuttle F-R	0.20 to 0.45 mm 0.0079 to 0.0177 in.
		Other	0.15 to 0.40 mm 0.0059 to 0.0157 in.
	Allowable limit	Shuttle F-R	0.80 mm 0.031 in.
		Other	0.80 mm 0.031 in.

W1020704




3TLABAB3P155A

Checking Contact between Coupling and Shifter

1. Check to see if there is flaw or wear on the spline of the coupling and shifter, and the key groove on the coupling.
2. Engage the shifter with the coupling, and check that they slide smoothly.
3. Similarly, check that there is any flaw or wear on the gear splines.
4. If there is any defect, replace them.

W1020860




3TLABAB3P156A

Flaw on Synchronizer Key and Spring

1. Check the projection in the center of the synchronizer key for wear.
2. Check the spring for fatigue or wear on the area where the spring contacts with the keys.
3. If there is any defect, replace them.

W1021026




3TLABAB3P153A

Side Clearance between Synchronizer Ring and Gear (In Contact)

1. Press the synchronizer ring against the tapered portion of the gear, and measure the side clearance.
2. Apply thin film of red lead to the tapered portion, press the ring against it by hand, rub them together a few times, and check the contact.
3. Check the tooth surface and key grooves of the ring for wear.
4. If the side clearance exceeds the allowable limit or if there is any defect, replace the synchronizer ring.

Side clearance	Allowable limit	0.35 mm 0.0138 in.
Contact condition of tapered portion	Allowable limit	More than 80 %

W1026696

(C) PTO Clutch


3TMABAB2P034A

PTO Clutch Disc Wear

1. Measure the thickness of PTO clutch disc with vernier calipers.
2. If the thickness is less than the allowable limit, replace it.

Thickness of PTO clutch disc	Factory spec.	1.70 to 1.90 mm 0.067 to 0.075 in.
	Allowable limit	1.55 mm 0.061 in.

W1021195




3TMABAB2P035A

PTO Steel Plate Wear

1. Measure the thickness of PTO steel plate with vernier calipers.
2. If the thickness is less than the allowable limit, replace it.

Thickness of PTO steel plate	Factory spec.	1.15 to 1.25 mm 0.045 to 0.049 in.
	Allowable limit	1.10 mm 0.043 in.

W1021446



3TMABAB2P036A


Flatness of PTO Piston and PTO Steel Plate

1. Place the part on a surface plate.
2. Check it unable to insert a feeler gauge (allowable limit size) underneath it at least four points.
3. If the gauge can be inserted, replace it.

Flatness of PTO piston	Allowable limit	0.15 mm 0.006 in.
------------------------	-----------------	----------------------

Flatness of PTO steel plate	Allowable limit	0.30 mm 0.012 in.
-----------------------------	-----------------	----------------------

W1021557



3TMABAB2P037A


Piston Return Spring Free Length

1. Measure the free length of spring with vernier calipers.
2. If the measurement is less than the allowable limit, replace it.

PTO return spring free length	Factory spec.	40.5 mm 1.59 in.
	Allowable limit	37.5 mm 1.48 in.

PTO brake spring free length	Factory spec.	20.3 mm 0.80 in.
	Allowable limit	18.0 mm 0.71 in.

W1021677




Thickness of Seal Ring

1. Measure the thickness of seal rings (1) with an outside micrometer.
2. If the measurement is less than the allowable limit, replace it.


Thickness of seal ring	Factory spec.	2.45 to 2.50 mm 0.096 to 0.098 in.
	Allowable limit	2.0 mm 0.0079 in.

(1) Seal Ring

W1021804



(D) Differential Gears




Spiral Bevel Gear Turning Torque

■ **NOTE**

• It is necessary to adjust the spiral bevel gear turning torque, when replacing the differential gears, transmission case or other relative parts.

1. Assemble the differential gears to transmission case. At this time, install the some shims (3) to the spiral bevel gear side.
2. Check the turning torque by using turning torque tool (1).
Turning Torque Tool : Weld socket on the brake shaft
(Brake shaft Part No. TA040-26710)
3. Add or reduce the thickness of shims (3) to make the specified turning torque.
4. After getting the specified turning torque, divide the thickness of shims to left and right side.
5. Assemble the transmission case and adjust the backlash and tooth contact with spiral bevel pinion. (See next page.)




Turning torque of 37T spiral bevel gear	Factory spec.	3.92 to 6.37 N·m 0.40 to 0.65 kgf·m 2.89 to 4.70 ft·lbs
---	---------------	---


- (1) Turning Torque Tool
(2) 37T Spiral Bevel Gear

- (3) Adjusting Shim
(4) Differential Support

W10277520



3TMABAB3P041A



3TMABAB3P042A

Backlash and Tooth Contact between Spiral Bevel Gear and Spiral Bevel Pinion Shaft

1. Set the dial indicator (lever type) with its finger on the tooth surface.
2. Measure the backlash by fixing the spiral bevel pinion shaft (3) and moving the spiral bevel gear (4) by hand.
3. When the backlash is too large, decrease the number of shims (6) in the side of the spiral bevel gear, and insert the shims (5) of the same thickness as the removed ones to the opposite side. When the backlash is too small, do the opposite way to increase backlash.
4. Adjust the backlash properly by repeating the above procedure.
5. Apply red lead lightly over several teeth at three positions equally spaced on the spiral bevel gear.
6. Turn the spiral bevel pinion shaft, while pressing a wooden piece against the periphery on the spiral bevel gear.
7. Check the tooth contact. If not proper, adjust according to the instructions below.

Backlash between spiral bevel gear and spiral bevel pinion shaft	Factory spec.	0.15 to 0.30 mm 0.006 to 0.012 in.
	Allowable limit	0.4 mm 0.016 in.

(Reference)

- Thickness of shims (2) :
0.1 mm (0.004 in.) 0.2 mm (0.008 in.) 0.5 mm (0.020 in.)
- Thickness of shims (5) :
0.4 mm (0.016 in.) 0.7 mm (0.028 in.) 1.0 mm (0.039 in.)
0.5 mm (0.020 in.) 0.8 mm (0.031 in.) 1.2 mm (0.047 in.)
0.6 mm (0.024 in.) 0.9 mm (0.035 in.) 1.4 mm (0.055 in.)
- Thickness of shims (6)
0.4 mm (0.016 in.) 0.8 mm (0.031 in.) 1.2 mm (0.047 in.)
0.6 mm (0.024 in.) 1.0 mm (0.039 in.) 1.6 mm (0.063 in.)

- (1) Pinion Bearing Case
- (2) Shim
- (3) Spiral Bevel Pinion
- (4) Spiral Bevel Gear
- (5) Shim
- (6) Shim
- (7) Differential Support

W10279260

More than 35 % red lead contact area on the gear tooth surface.
The center of tooth contact at 1/3 of the entire width from the small end.




3TMABAB3P043A

(A) Proper Contact

W10187470

Replace the adjusting shim (2) with thicker one to move the spiral bevel pinion shaft backward.



3TMABAB3P044A


For move the spiral bevel gear rightward, reduce right side shim (5) and add shim (6) of the same thickness as the right side to left side.

(B) Shallow Contact

(C) Heel Contact

W10189000

Replace the shim (5) with a thinner one to move the spiral bevel pinion shaft forward.



3TMABAB3P045A


For move the spiral bevel gear leftward, reduce left side shim (6) and add shim (5) of the same thickness as the left side to right side.

Repeat above until the proper tooth contact and backlash are achieved.

(D) Deep Contact

(E) Toe Contact

W10189730



Clearance between Differential Case Bore (Differential Case Cover Bore) and Differential Side Gear Boss

1. Measure the bore I.D. of the differential case and differential case cover.
2. Measure the differential side gear boss O.D. and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace them.


Clearance between differential case bore and differential side gear boss	Factory spec.	0.050 to 0.151 mm 0.00197 to 0.00594 in.
	Allowable limit	0.35 mm 0.0138 in.

Differential case bore I.D.	Factory spec.	40.500 to 40.550 mm 1.59449 to 1.59646 in.
Differential side gear boss O.D.	Factory spec.	40.388 to 40.450 mm 1.59008 to 1.59252 in.

Clearance between differential case cover bore and differential side gear boss	Factory spec.	0.050 to 0.151 mm 0.00197 to 0.00594 in.
	Allowable limit	0.35 mm 0.0138 in.

Differential case cover bore I.D.	Factory spec.	40.500 to 40.550mm 1.59449 to 1.59646 in.
Differential side gear boss O.D.	Factory spec.	40.388 to 40.450 mm 1.59008 to 1.59252 in.

W10284030




Clearance between Differential Pinion Shaft and Differential Pinion

1. Measure the differential pinion shaft O.D.
2. Measure the differential pinion I.D. and calculate the clearance.
3. If the clearance exceed the allowable limit, replace them.

Clearance between differential pinion shaft and differential pinion	Factory spec.	0.060 to 0.102 mm 0.00236 to 0.00402 in.
	Allowable limit	0.25 mm 0.0098 in.

Differential pinion shaft O.D.	Factory spec.	19.959 to 19.980 mm 0.78579 to 0.78661 in.
Differential pinion I.D.	Factory spec.	20.040 to 20.061 mm 0.78898 to 0.78980in.

W10287600



Backlash between Differential Pinion and Differential Side Gear

1. Set a dial indicator (lever type) on the tooth of the differential pinion.
2. Hold the differential side gear and move the differential pinion to measure the backlash.
3. If the measurement is not within the factory specifications, adjust with the differential side gear washer.

Backlash between differential pinion and differential side gear	Factory spec.	0.15 to 0.30 mm 0.0059 to 0.0118 in.
	Allowable limit	0.4 mm 0.016 in.

(Reference)

- Thickness of differential side gear washer :
1.5 mm (0.059 in.) 1.7 mm (0.067 in.)
1.6 mm (0.063 in.)

W10289200

[2] GLIDE SHIFT TRANSMISSION (GST) MODEL


(1) Checking and Adjusting

(A) Electrical Adjusting [GST Fine-adjustment with Electronic Instrument Panel (IntelliPanel)]

■ NOTE

- Before executing the following fine-adjustment, refer to “Testing, Setting and Adjusting by Electronic Instrument Panel” of an Electrical System. (Refer to page 9-S12.)

The fine-adjustment function is a function to update the data of the memory device in the ECU when a sensor, a valve, and an electronic instrument panel which relates to the GST system are repaired or are re-installed. There are three kinds of fine-adjustment functions in the GST system.



GST Lever Sensor Fine-adjustment

(Setting the GST lever's neutral position with its sensor)

■ IMPORTANT

- As for this fine-adjustment, be sure to set it correctly because the set state becomes the standard of the control thereafter.

■ NOTE


- When the GST lever sensor, the ECU or the electronic instrument panel is replaced, this adjustment is required.

1. Set the GST shift lever to **Neutral** position.
2. Push down both the display mode switch (2) and the travel speed switch (3) at once, continue holding switches, and then turn the main switch to **ON** position.
3. The “**Mode Selection Display**” (a) is indicated on the LCD (1). And release the switches.
4. Press the display mode switch (2) to move the flashing part, and flash the “**E**”.
5. Hold down the display mode switch (2) for more than 2 seconds at this condition, and the buzzer rings and Mode **E** is selected.
6. “**LEVER**” is displayed (b) and “**PUSH SW**” is displayed (c) for five seconds.
7. Hold down the display mode switch for more than 2 seconds. (This preserve the adjusted value to the ECU.)
8. “**OK**” is displayed (d) on LCD screen to tell that preserving to ECU has been made correctly. Turn off the main switch to end the mode.
9. If “**NG**” is displayed (f), it means the preserving has not been made correctly (4). Turn off the main switch and repeat the procedure.
10. If “**LEVER**” is displayed (b) first and then “**ERROR-70**” shows up (e), it means the lever sensor voltage is out of specification. In this case;
 - Check to see that GST lever is at the **Neutral** position.
 - Check the lever sensor voltage in the Test Mode (Mode “**A**”) (see page 9-S13). If out of specification, replace the sensor itself.

- (1) Liquid Crystal Display (LCD)
 (2) Display Mode Switch
 (3) Travel Speed Switch

- (a) Mode Selection Display
 (b) Information Display
 (c) Adjusting Display
 (d) Correct Preserving Display
 (e) Error Display
 (f) Incorrect Preserving Display

W1029305



GST Valve Fine-adjustment
(Setting the function of proportional reducing valve)

■ **NOTE**

• **When the ECU or GST valve is replaced, this adjustment is required.**

1. Push down both the display mode switch and the travel speed switch at once, continue holding switches, and then start the engine.
2. Select Mode F by the procedure from 3 to 5 which has been described to previous page.
3. "P-VALVE" is displayed (b) and STEP-01 (c) is displayed the three seconds after.

■ **NOTE**



• **To make this adjustment, follow these steps in the exact order described. (Otherwise the switch does not work to go to next step. At "STEP-01" and "STEP-03", however, the next step can be moved without their settings.)**

- **Push the display mode switch to move to the next step.**
4. **STEP-01 (c)** : Release parking brake.
 5. **STEP-02 (d)** : Set the engine speed at 1000 to 1400 min⁻¹ (rpm).
 6. **STEP-03 (e)** : Set front tires straight ahead.
 7. **STEP-04 (f)** : Operate the speed selection lever (GST lever) as follows ; disengaged the clutch, select "forward" with the shuttle lever, and shift the GST lever from 1 thru 12 several times. Set the GST lever at the positions other than neutr.
 8. **STEP-05 (g)** : Set the GST lever to **Neutral** position.
 9. **STEP-06 (h)** : Set shuttle lever to forward and engage clutch.
 10. **PUSH SW (i)** : Push the display mode switch for more than three seconds.
 11. **STEP-07 (j)** : To perform this function the operator must be seated on the tractor. After a short delay the tractor will begin to move slowly. And then, after it moves a little, the tractor stops automatically. (Fine-adjustment is being executed.)
 12. **OK is displayed (k)** : The setting has been preserved correctly to the ECU.
 13. **NG is displayed (l)** : The setting has not been correctly saved in the ECU. Repeat the entire procedure.

- (a) Mode Selection Display
- (b) Information Display
- (c) Setting Display-1
- (d) Setting Display-2
- (e) Setting Display-3
- (f) Setting Display-4

- (g) Setting Display-5
- (h) Setting Display-6
- (i) Adjusting Display
- (j) Setting Display-7
- (k) Correct Preserving Display
- (l) Incorrect Preserving Display

W1029611



Checking Regulating Valve Setting Pressure

1. Start the engine and warm up the transmission fluid, and then stop the engine.
2. Remove the pressure checking port (5) plug (PT 1/8).
3. Install the adaptor "7" to checking port (5) and then install the adaptor "D", the threaded joint, cable and pressure gauge.
4. Start the engine and set the maximum engine speed. Set the shift levers to "Neutral".
5. Measure the pressure. (Do not turn the steering wheel.)
6. If the measurement is not within factory specifications, adjust the regulating valve adjuster (4) on the regulating valve assembly (1).

Regulating valve setting pressure	Factory spec.	2.74 to 2.94 MPa 28.0 to 30.0 kgf/cm ² 398 to 427 psi
-----------------------------------	---------------	--

Condition



- Engine speed : Maximum
- Oil temperature : 40 to 60 °C
104 to 140 °F

(Reference)

- Turn to clockwise direction → Pressure is increased
- Turn to counterclockwise direction → Pressure is decreased

- (1) Regulating Valve Assembly (4) Regulating Valve Adjustor
 (2) Adaptor D (5) Checking Port (PT 1/8)
 (3) Adaptor 7

W1031426



Checking Pilot Pressure

1. Start the engine and warm up the transmission fluid, and then stop the engine.
2. Remove the pilot pressure checking port plug (PT 1/8) on the GST valve (2).
3. Install the adaptor "D" or GST valve adaptor (3) to the checking port (1), and then install the threaded joint, cable and pressure gauge.
4. Start the engine and set the maximum speed.
5. Disengage the main clutch and shift the GST lever to "1st" position, shuttle shift lever to "Forward" or "Reverse" position.
6. Measure the pressure.
7. When the pilot pressure is not within factory specifications :
Check the pilot orifice is clogged, movement of the shift forks, shift pistons and shift check valves.

■ IMPORTANT

- Do not engage the main clutch while checking.



Pilot pressure	Factory spec.	2.30 to 2.50 MPa 23.5 to 25.5 kgf/cm ² 334 to 363 psi
----------------	---------------	--

Condition

- Engine speed : Maximum
- Oil temperature : 40 to 60 °C
104 to 140 °F
- Shifting : GST lever to be "1st"
Shuttle shift lever to be "Forward" or "Reverse"

- (1) Pilot Pressure Checking Port (PT 1/8) (2) GST Valve
 (3) Adaptor

W1031829



Checking Clutch Pack Pressure

1. Start the engine and warm up the transmission fluid, and then stop the engine.
2. Remove the clutch pack pressure checking port plug (PT 1/8) on the GST valve (2).
3. Install the adaptor "D" or GST valve adaptor to the checking port (1), and then install the threaded joint, cable and pressure gauge.
4. Start the engine and set the idling speed.
5. Disengage the main clutch and shift the GST lever to "1st" position, shuttle shift lever to "Forward" position.
6. Measure the pressure.
7. When the clutch pack pressure is not within factory specifications:
Check the clutch valve and clutch pack.
8. Check the pressure changes while shifting the shuttle shift lever "Reverse" to "Forward" and shifting the GST lever from "Neutral" to "12th" or "8th".
9. If the pressure does not change correctly, check the modulating check valve and modulating valve.

■ **IMPORTANT**

- Do not engage the main clutch while checking.

Clutch pack pressure	Factory spec.	2.30 to 2.50 MPa 23.5 to 25.5 kgf/cm ² 334 to 363 psi
Pressure changing while shifting the shuttle shift lever and main shift lever		It drops on 0.29 MPa (3 kgf/cm ² , 43 psi) once, and it rises to factory specification quickly.

Condition

- Engine speed : Maximum
- Oil temperature : 40 to 60 °C
104 to 140 °F
- Shifting : GST lever "Neutral" to "1st" to "12th" or "8th"
Shuttle shift lever "Neutral" to "Forward" or "Reverse"

- (1) Clutch Pack Pressure Checking Port (2) GST Valve (PT 1/8)
(3) Adaptor


W1032163

(C) Others

Operating Pressure of PTO Clutch Valve

1. See page 3-S17.

W1032841



GST Shift Shock Fine-adjustment Mode (Adjusting the clutch engaging interval)

■ NOTE

- When the sense of shifting shock is not suitable, shifting shock can be changed by this adjustment.

1. Push down both the display mode switch and the travel speed switch at once, continue holding switches, and then start the engine.
2. Select Mode G by the procedure from 3 to 5 which has been described to page 3-S47.
3. "SHOCK" is displayed (b) first and then the numerical code setting is displayed (c).

The number "-9" through "+9" can be displayed. This has been factory-adjusted to "0".

4. Setting;

- For lighter shifting shock;
Press the display mode switch to reduce the number.
- For higher shifting shock;
Press the travel speed switch to increase the number.

5. Move the tractor to confirm the shifting shock.
6. Turn off the key. Then setting will be put in memory.




■ NOTE

- If the shift shock has been adjusted but no remarkable effect can be felt, keep the setting at "0".

- (a) Mode Selection Display
(b) Information Display

- (c) Setting Number Display

W1030354

(B) Hydraulic Checking**Checking GST System Pressure**

1. Start the engine and warm up the transmission fluid, and then stop the engine.
2. Remove the GST system pressure checking port (1) plug (PT 1/8) on the GST valve (2).
3. Install the GST valve adaptor (see page G-51) to checking port (1), and then install the threaded joint, cable and pressure gauge.
4. Start the engine and set the idling speed. Set the shift levers to "Neutral".
5. Measure the pressure.
6. If the measurement is not within factory specifications, adjust the pressure reducing valve adjustor (4) on the regulating valve assembly (5).

GST system pressure	Factory spec.	2.40 to 2.55 MPa 24.5 to 26.0 kg/cm ² 348 to 370 psi

Condition

- Engine speed : Idling speed
- Oil temperature : 40 to 60 °C
104 to 140 °F

(Reference)



- Turn to clockwise direction → Pressure is increased
- Turn to counterclockwise direction → Pressure is decreased

- | | |
|--|--------------------------------------|
| (1) GST System Pressure Checking Port (PT 1/8) | (3) GST Valve Adaptor |
| (2) GST Valve | (4) Pressure Reducing Valve Adjustor |
| | (5) Regulating Valve Assembly |

W1030916

(2) Disassembling and Assembling

(A) Clutch Housing



Draining the Transmission Fluid

1. Place oil pans underneath the transmission case.
2. Remove the drain plugs (1).
3. Drain the transmission fluid.
4. Reinstall the drain plugs (1).

(When refilling)

- Fill up from filling port after removing the filling plug (2) until reaching the upper notch on the dipstick (3).
- After running the engine for few minutes, stop it and check the oil level again, add the fluid to prescribed level if it is not correct level.

Transmission fluid capacity	L3130 L3430	42 L 11.1 U.S.gals. 9.2 Imp.gals.
	L3830 L4330 L4630	43 L 11.4 U.S.gals. 9.5 Imp.gals.
	L5030	45 L 11.9 U.S.gals. 9.9 Imp.gals.

■ IMPORTANT

- Use only KUBOTA SUPER UDT fluid. Use of other oils may damage the transmission or hydraulic system. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7, 8.)
- Do not mix different brands of fluid together.

- (1) Drain Plugs
(2) Filling Plug
(3) Dipstick

(A) Oil level is acceptable within this range.

W1166268



Battery, Front Grill, Skirt and Bonnet

1. Open the bonnet and disconnect the battery negative cable.
2. Disconnect the head light connector and remove the front grill (4).
3. Remove the left and right side skirts (3).
4. Disconnect window washer hoses (2). (Cabin model only.)
5. Remove the bonnet (1).


■ NOTE

- When disconnecting the battery cords, disconnect the negative cord first, when connecting, positive cord first.

- (1) Bonnet
(2) Window Washer Hose

- (3) Skirt
(4) Front Grill

W1033112



ROPS (ROPS Model)


1. Remove the lower connector (2).
2. Remove the plate mounting screws (4), (8).
3. Remove the upper frame (1) from ROPS lower frame (5).

(When reassembling)

■ **NOTE**


- Do not firmly tighten all screws until most components are attached.

Tightening torque	Lower connector mounting screw (3)	103 to 118 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Plate mounting screw (4)	138 to 147 N·m 14.0 to 15.0 kgf·m 102 to 108 ft-lbs
	Plate mounting screw (8)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft-lbs



(Reference)


Tightening torque	Upper connector mounting screw (9)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft-lbs
	Fulcrum bolt and nut (11)	118 to 137 N·m 12.0 to 14.0 kgf·m 86.8 to 102 ft-lbs



- (1) Upper Frame
- (2) Lower Connector
- (3) Screw (M12 × 65)
- (4) Screw (M14 × 40)
- (5) Lower Frame
- (6) Plate
- (7) Connector
- (8) Screw (M14 × 30)






- (9) Screw (M14 × 30)
- (10) Upper Connector
- (11) Fulcrum Bolt and Nut
- (12) Lock Bolt

A : Rigid Type
B : Foldable Type



W1168342





Steering Joint, Brake Pedal Rod and Electric Wiring

1. Remove the tank frame support (2).
2. Remove the universal joint bolt (10) and steering joint support (6), and then remove the steering joint (1).
3. Disconnect the hand accelerator wire and foot accelerator wire (7).
4. Disconnect the wiring connectors for engine stop solenoid (8), engine tachometer sensor (9) and glow plug.
5. Disconnect the heater hoses (3), and then reconnect their hoses to make loop. (Cabin model only.)

NOTE

- Put a mark to the each heater hose before disconnecting.
6. Disconnect the wiring connector for window washer tank (4) and compressor 1P connector (5). (Cabin model only.)
 7. Disconnect the brake pedal rod.

(When reassembling)

- When accelerator wire is installed, adjust the wiring length as hit both the idling speed adjusting bolt and the maximum speed adjusting bolt by lever within the stroke of the accelerator lever.
- Set the steering joint (1) by the joint support (6) so that the steering wheel is turned lightly.
- Be sure to check and adjust the brake pedal free travel. (See page G-16.)

- (1) Steering Joint
- (2) Tank Frame Support
- (3) Heater Hose
- (4) Window Washer Tank
- (5) 1P Connector

- (6) Steering Joint Support
- (7) Accelerator Wire
- (8) Engine Stop Solenoid
- (9) Engine Tachometer Sensor
- (10) Universal Joint Bolt

W1033546

Clutch Rod, Brake Pedal Rod and Electric Wiring

1. Disconnect the brake pedal rod (6) and clutch rod (4).
2. Disconnect the wiring connectors for alternator (1), coolant temperature sensor (9), oil pressure switch (2), fuel unit (3), starter motor (7) and battery.
3. Remove the clamps and ground earth of wiring harness and collect wiring harness to the step or cabin.
4. Remove the clamps (8) of A/C hoses (5). (Cabin model only.)




(When reassembling)

- Be sure to check and adjust the clutch and brake pedal free travel. (See page G-16, 22.)

- (1) Alternator
- (2) Oil Pressure Switch
- (3) Fuel Unit
- (4) Clutch Rod
- (5) A/C Hoses

- (6) Brake Pedal Rod
- (7) Starter Motor
- (8) Clamps
- (9) Coolant Temperature Sensor

W1033897



Air Conditioner Parts (Cabin Model)

1. Remove the muffler (1).
2. Remove the air conditioner belt (4) and remove the compressor (1) mounting screw.
3. Remove the recovery tank (6) and window washer tank (7).
4. Disconnect the air cleaner hose (8).
5. Disconnect the recovery tank hose (5).
6. Disconnect the radiator upper hose (3).
7. Remove the battery (10).
8. Remove the battery stay mounting bolt.
9. Take out the compressor (1), condenser (11), receiver (12), hoses (13), battery stay (9) and etc. as a unit.

(When reassembling)

- After reassembling the compressor, be sure to adjust the air conditioner belt tension. (See page G-28.)

Tightening torque	Compressor mounting screw	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft·lbs
	Muffler mounting screw	31.4 to 37.2 N·m 3.2 to 3.8 kgf·m 23.1 to 27.5 ft·lbs

- | | |
|--------------------------|---------------------------|
| (1) Compressor | (8) Air Cleaner Hose |
| (2) Muffler | (9) Battery Stay |
| (3) Radiator Upper Hose | (10) Battery |
| (4) Air Conditioner Belt | (11) Condenser |
| (5) Recovery Tank Hose | (12) Receiver |
| (6) Recovery Tank | (13) Air Conditioner Hose |
| (7) Window Washer Tank | |






W1034133

Shuttle Switch Connector

1. Remove the panel cover and steering post cover.
2. Disconnect the shuttle switch connector (1).

- (1) Shuttle Switch Connector

W1172874



Seat, Seat Bracket and Lever Grips

1. Remove the seat.
2. Disconnect the seat switch connector (3) and remove the seat bracket (1) with seat suspension (7).
3. Remove the lever grips for position control lever (2), front wheel drive lever (6) and creep shift lever (4) (if equipped).
4. Disconnect the differential lock rod (9).
5. Remove the lowering speed adjusting knob (8).

- | | |
|----------------------------|-----------------------------------|
| (1) Seat Bracket | (6) Front Wheel Drive Lever |
| (2) Position Control Lever | (7) Seat Suspension |
| (3) Seat Switch Connector | (8) Lowering Speed Adjusting Knob |
| (4) Creep Shift Lever | (9) Differential Lock Rod |
| (5) GST Lever | |

W1046526

Electric Connector for GST

1. Disconnect the ECU connector (1).
2. Disconnect the GST lever sensor connector (2).
3. Remove the GST valve cover.
4. Disconnect the pressure switch connector (4), proportional reducing valve connector (5), solenoid valve connector (6), oil temperature sensor connector (8) and ground cables (7).

- | | |
|--|---|
| (1) ECU Connector | (5) Proportional Reducing Valve Connector |
| (2) GST Lever Sensor Connector | (6) Solenoid Valve Connector |
| (3) Wiring Harness of GST Lever Sensor | (7) Ground Cable |
| (4) Pressure Switch Connector | (8) Oil Temperature Sensor Connector |

W1046759

PTO Shift Wire and Electric Connector


1. Disconnect the PTO shift wire (2) at the PTO clutch valve (4).
2. Disconnect the traveling speed sensor connector (1).

(When reassembling)

- When connecting the PTO shift wire (2) to the clutch valve (4), be sure to adjust the length of wire as follows.
 1. Set the PTO shift lever to **OFF (Neutral)** position.
 2. Loosen the lock nut (3) of wire, and connect wire to the clutch valve lever, and then place the wire to the hook.
 3. Tighten the lock nut (3) clockwise (pull the wire), and lock the nut just before the lever moves.

- | | |
|--------------------------------------|----------------------|
| (1) Traveling Speed Sensor Connector | (3) Lock Nut |
| (2) PTO Shift Wire | (4) PTO Clutch Valve |

W1046922




3TLABAB3P106A

Step and Floor Seat

1. Disconnect the panel frame connector (1) from fuel tank frame.
2. Remove the step and floor seat mounting bolt and nut.
3. Dismount the step, fender, floor seat and panel frame as a unit after checking whether there is forgetting to disconnect wiring.

(When reassembling)

- Be sure to set the washers and rubber plates of the floor seat and step mounting bolt at an original positions as shown in figure.
- Before mounting the floor seat and step, be sure to set both the shuttle lever rod and the shuttle arm to the neutral position, and then connect the shuttle lever rod securely.



3TLABAB3P107A

Tightening torque	Step mounting bolt and nut	124 to 147 N·m 12.6 to 15.0 kgf·m 91.1 to 108 ft-lbs
	Floor seat mounting bolt and nut	196 to 225 N·m 20 to 23 kgf·m 145 to 166 ft-lbs

- (1) Panel Frame Connector
- (2) Floor Seat
- (3) Bolt
- (4) Rubber Plate
- (5) Washer
- (6) Spring Washer
- (7) Nut
- (8) Step

F : Front Side
R : Rear Side

W1175106



3TLABAB3P174A

Cabin Assembly


1. Remove the outer roof of cabin.
2. Support the cabin with nylon straps (1) and hoists.
3. Loosen and remove the cabin mounting bolts (2) and nuts (9).
4. Dismounting the cabin from tractor body.

NOTE

- Lift the cabin while making sure it does not catch on anything.

(When reassembling)

- Be sure to install the washers and mount rubbers, etc. in their original positions.
- Before mounting the cabin, be sure to set both the shuttle lever rod and the shuttle arm to the neutral position, and then connect the shuttle lever rod securely.





3TLABAB3P175A

Tightening torque	Cabin mounting bolt and nut	124 to 147 N·m 12.6 to 15.0 kgf·m 91.1 to 108 ft-lbs
-------------------	-----------------------------	--

- (1) Nylon Straps
- (2) Bolt
- (3) Plate
- (4) Mount Rubber
- (5) Collar
- (6) Plain Washer (M14)
- (7) Washer
- (8) Spring Washer
- (9) Nut

F : Front Side
R : Rear Side

W1047429



Hydraulic Pipes


1. Remove the main delivery pipe 1 (5).
2. Disconnect the main delivery pipe 2 (2) at the rear hydraulic block (1) and return pipe (3) at the mid case, and then remove the front hydraulic block (4) with pipes and bracket as a unit.
3. Remove the suction pipe (8) with oil filter (7).
4. Remove the PTO delivery pipe (9) and GST pipe (6) as a unit.

(When reassembling)

Tightening torque	Joint bolt for main delivery pipe 1 to front hydraulic block	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Joint bolt for main delivery pipe 2 to front hydraulic block	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Cap nut for return pipe to mid case	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Joint bolt for PTO / GST delivery pipe	34 to 39 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft-lbs

- | | |
|---------------------------|--------------------------|
| (1) Rear Hydraulic Block | (6) GST Pipe |
| (2) Main Delivery Pipe 2 | (7) Hydraulic Oil Filter |
| (3) Return Pipe | (8) Suction Pipe |
| (4) Front Hydraulic Block | (9) PTO Delivery Pipe |
| (5) Main Delivery Pipe 1 | |

W1047928




Propeller Shaft

1. Slide the propeller shaft cover (4) and (8) after removing the screws (7).
2. Tap out the spring pins (2), (6) and slide the couplings (1), (5) and then remove the propeller shaft with covers (4), (8).

(When reassembling)

- Apply grease to the splines of propeller shaft 1 (3).
- | | |
|---------------------------|---------------------------|
| (1) Coupling | (5) Coupling |
| (2) Spring Pin | (6) Spring Pin |
| (3) Propeller Shaft 1 | (7) Screws |
| (4) Propeller Shaft Cover | (8) Propeller Shaft Cover |

W1176284





Separating Engine and Clutch Housing


1. Place the disassembling stand under the engine and clutch housing case.
2. Remove the fuel tank support mounting screws.
3. Remove the engine and clutch housing mounting screws and nuts.
4. Separate the engine and clutch housing while lifting up the tank frame.

(When reassembling)

- Apply grease to the spline of clutch shaft.
- Apply liquid gasket (Three Bond 1211 or equivalent) to joint face of the flywheel housing and clutch housing.

Tightening torque	Engine and clutch housing mounting screw and nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Engine and clutch housing mounting stud bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs

W1048295



Clutch Lever, Release Fork and Release Bearing

1. Remove the release fork mounting screws (2).
2. Draw out the clutch lever (3) to remove the release fork (1).
3. Remove the release bearing and release hub (4) together.




(When reassembling)

- Apply grease to the sliding surface of the clutch release hub.
- Apply grease to the clutch lever.

Tightening torque	Release fork mounting screw	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft-lbs
-------------------	-----------------------------	---

- (1) Release Fork
- (2) Release Fork Mounting Screw
- (3) Clutch Lever
- (4) Release Hub

W11766950



Shuttle Shift Arm and GST Valve Assembly

1. Disconnect the brake rod (3).
2. Remove the shuttle shift arm stopper screw, and then pull the shuttle shift shaft (1) with arm up.
3. Remove the GST valve (2) with using two jack bolts.
4. Remove the shift pins (6), (7).

■ **NOTE**

- Do not fall down the shuttle check pin (9) while disassembling.

(When reassembling)

- When reassembling the shuttle shift arm (4) to the shuttle fork rod (5), be sure to install it to the groove **A**.
- Place the 1-2 shift pin (6) and the 3-4 shift pin (7) at **neutral** position, main range shift pin (9) at **L** position (forward) and sub-range shift pin (10) at **Hi** position (rearward), and then assemble the GST valve.
- Be sure to match the each shift pin and shift piston.
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the GST valve assembly.
- Install the GST valve (2) by hand, and then tighten the screws. Do not use the hummer.
- Replace the pipe (8) with new one, if damaged.

Tightening torque	Shift pin mounting screws	12.7 to 14.7 N·m 1.3 to 1.5 kgf·m 9.4 to 10.8 ft-lbs
	GST valve mounting screws	42.2 to 48.1 N·m 4.3 to 4.9 kgf·m 31.1 to 35.4 ft-lbs

- | | |
|-----------------------|--------------------------|
| (1) Stopper Screw | (7) 3-4 Shift Pin |
| (2) GST Valve | (8) Pipe |
| (3) Brake Rod | (9) Main Range Shift Pin |
| (4) Shuttle Shift Arm | (10) Sub-range Shift Pin |
| (5) Shuttle Fork Rod | |
| (6) 1-2 Shift Pin | |
- A : Fork Rod Groove**

W1048476

Separating Clutch Housing and Mid Case


1. Remove the clutch housing and mid case mounting screws and nuts.
2. Separate the clutch housing and mid case.

(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the clutch housing and mid case.

Tightening torque	Clutch housing and mid case mounting nut	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Clutch housing and mid case mounting screw	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Clutch housing and mid case mounting stud bolt	38.2 to 45.1 N·m 3.9 to 4.6 kgf·m 28.2 to 33.3 ft-lbs

W10489710



Shaft Case


1. Remove the shaft case mounting screws.
2. Screw down the two M6 screws (1) into the shaft case (2) and pull it out.
3. Take out the shaft case (2).

(When reassembling)



- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the shaft case and clutch housing case.

(When replacing oil seal in shaft case)

- Install the oil seal (3) as shown in the figure, noting its direction.
- Apply grease to the oil seal (3).



- (1) M6 Screw
- (2) Shaft Case




23T (24T) Gear Shaft and 27T (26T) Gear


1. Remove the 23T (24T) gear shaft (1).
2. Remove the external snap ring (3) and 27T (26T) gear (2).

(When reassembling)

- Install the oil seal (4) on the 18T gear shaft (6), noting the direction of the oil seal (4) as shown in the figure.
- Direct the boss side of the gear (2) to the bearing side.
- Apply small amount of the grease to the oil seal (4), (5).

- (1) 23T Gear Shaft (L3130, L3430, L3830, L4630)
- (2) 27T Gear (L3130, L3430, L3830, L4630)
- (3) External Snap Ring
- (4) Oil Seal
- (5) Oil Seal
- (6) 18T Gear Shaft





Clutch Housing Bearing Holder

1. Remove the three interlock balls (2) after removing the stopper screw (1).
2. Pull out the clutch housing bearing holder (4) with using two jack bolts (3).

(When reassembling)


- Tap in the clutch housing bearing holder (4) with plastic hammer until contact to clutch housing case, and then tighten the screws to specified torque.
- Install the three interlock balls (2) with a small amount of grease to the clutch housing bearing holder (4) after setting the shift forks and shift rods to the neutral position.

Tightening torque	Clutch housing bearing holder mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft-lbs
	Stopper screw	34.3 to 44.1 N·m 3.5 to 4.5 kgf·m 25.3 to 32.5 ft-lbs

- (1) Stopper Screw
(2) Interlock Ball

- (3) Jack Bolt
(4) Clutch Housing Bearing Holder

W1049879



Shaft Assemblies

1. Remove the external snap ring (1) and thrust collar (2).
2. Draw out the shaft assemblies (4), (5), (6), (7), (9) and shift forks (10) and rods.
3. Pull out the front axle drive shaft (8) to the rear side.


(When reassembling)

- Install the front axle drive shaft (8) from front side after assembling the clutch housing case and mid case. Then install the bearing (13), sleeve (14), oil seal (12), collar (15) and internal snap ring (11) in order.

- (1) External Snap Ring
(2) Collar
(3) Shuttle Shift Arm
(4) 18T Gear Shaft Assembly
(5) Idle Shaft Assembly
(6) PTO Counter Shaft Assembly
(7) Main Gear Shaft Assembly
(8) Front Axle Drive Shaft
(9) Counter Shaft Assembly


- (10) Shift Fork
(11) Internal Snap Ring
(12) Oil Seal
(13) Bearing
(14) Sleeve
(15) Collar

F : Front Side



W1050076


Counter Shaft



- (1) Internal Snap Ring
- (2) Bearing
- (3) Needle Bearing
- (4) 24T Gear (4th)
- (5) External Snap Ring
- (6) Synchronizer Ring
- (7) Synchronizer Spring
- (8) Hub
- (9) Synchronizer Key
- (10) Shifter
- (11) 29T Gear (3rd)
- (12) Counter Shaft
- (13) 34T Gear (2nd)
- (14) Needle Bearing
- (15) 37T Gear (1st)
- (16) Bearing
- (17) Bearing Holder
- (18) Inner Synchronizer Ring
- (19) Center Ring
- (20) Outer Synchronizer Ring

[A] L3130, L3430
 [B] L3830, L4330, L4630, L5030

W1050216



1. Remove the internal snap ring (1) and remove both side of the bearings (2), (16).
2. Remove the gears on the counter shaft (12) and external snap rings (5).

(When reassembling)


- Reinstall the synchronizer keys (9) in the key grooves of the synchronizer rings (6) or (20) firmly.
- Be sure to install the synchronizer rings (18), (19), (20) with referring to page 3-S30.

W1050447

(B) Mid Case

■ **NOTE**

- For the disassembling procedure from “Draining the Transmission Fluid” to “Propeller Shaft”, refer to page 3-S53 to 3-S56.




GST Valve Assembly

1. Disconnect the brake rods (2).
2. Remove the GST valve (1) with using two jack bolts.
3. Remove the shift pin (3), (4) and (6).

■ **NOTE**

- **Do not fall down the shuttle check pin while disassembling.**
(When reassembling)


- Place the 1-2 (3) and 3-4 shift pins (4) at **neutral** position, sub-range shift pin (7) at **Hi** position (rearward) and main range shift pin (6) at **L** position (forward), and then assemble the GST valve.
- Be sure to match the each shift pin and shift piston.
- Install the GST valve (1) by hand, and then tighten the screws. Do not use the hummer.
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the GST valve assembly.
- Replace the pipe (5) with new one, if damaged.



Tightening torque	GST valve mounting screws	42.2 to 48.1 N·m 4.3 to 4.9 kgf·m 31.1 to 35.4 ft-lbs
	Shift pin mounting screw	12.7 to 14.7 N·m 1.3 to 1.5 kgf·m 9.4 to 10.8 ft-lbs

- (1) GST Valve
- (2) Brake Rod
- (3) 1-2 Shift Pin
- (4) 3-4 Shift Pin
- (5) Pipe
- (6) Main Range Shift Pin
- (7) Sub-range Shift Pin

W1050592



Separating Mid Case and Transmission Case


1. Separate the mid case and transmission case after removing their mounting screws.

(When reassembling)

- Confirm to insert the PTO shaft to PTO clutch firmly, turning the PTO shaft.
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the mid case and transmission case.

Tightening torque	Mid case and transmission case mounting screw	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Mid case and transmission case mounting nut	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Mid case and transmission case mounting stud bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs

W1050879




Separating Mid Case

1. Lift up the shuttle shift arm (1).
2. Separate the mid case from the clutch housing after removing their mounting screws.

(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of clutch housing and mid case.
- When reassembling the shuttle shift arm (1) to the shuttle fork rod (2), be sure to install it to the groove (A).




Tightening torque	Clutch housing and mid case mounting screw	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Clutch housing and mid case mounting nut	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Clutch housing and mid case mounting stud bolt	38.2 to 45.1 N·m 3.9 to 4.6 kgf·m 28.2 to 33.3 ft-lbs

- (1) Shuttle Shift Arm
- (2) Shuttle Fork Rod

A : Fork Rod Groove

W1051037



PTO Clutch Valve

1. Remove the PTO clutch valve (2) as a unit.
2. Pull out the pipe (1).

(When reassembling)





- Apply small amount of grease for the O-ring (3).
- Install the pipe (1) to the hole (4) of the PTO clutch valve (2) firmly.
- Replace the pipe (1) with new one.

Tightening torque	PTO clutch valve mounting screw	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft-lbs
-------------------	---------------------------------	---

- (1) Pipe
- (2) PTO Clutch Valve

- (3) O-ring
- (4) Hole

W1180630



Mid Case Bearing Holder

1. Remove the internal snap ring (9) and remove the disc spring (8) and clutch input hub (7).
2. Remove the external snap ring (6) and remove the GST clutch case (5).
3. Remove the mid case bearing holder mounting screws, and then take out the bearing holder (2) with PTO clutch (10) by using two jack bolts.

NOTE

- Take care not to fly out the ball (4) and spring (3) when pull out the bearing holder (2).

(When reassembling)

- Tap in bearing holder (2) with plastic hammer until contact to case, and then tighten the screws to specified torque.
- Assemble the disc spring (8) as shown in the figure.
- Install the internal snap ring (9) to the clutch case (5) as shown in the figure.
- Confirm the moving of the piston smoothly when pressure air at 0.29 to 0.39 MPa (3 to 4 kgf/cm², 42 to 57 psi) is sent to clutch pack. (Air must be sent from hole A.)

Tightening torque	Mid case bearing holder mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft·lbs
-------------------	--	---

- | | |
|-----------------------------|------------------------|
| (1) PTO Clutch Pipe | (8) Disc Spring |
| (2) Mid Case Bearing Holder | (9) Internal Snap Ring |
| (3) Spring | (10) PTO Clutch |
| (4) Ball | (11) Clutch Disc |
| (5) Clutch Case | (12) Steel Plate |
| (6) External Snap Ring | |
| (7) Clutch Input Hub | |

A : Oil Inlet Port for GST Clutch

W1180845

Shaft Assemblies

1. Pull out the sub-range shift rod (4) and remove the shift fork (3).
2. Remove the external snap ring (2) which is located at rear side of the mid case.
3. Draw out the shaft assemblies (1), (5), (6) and shuttle fork rod (7).


- | | |
|------------------------------|------------------------|
| (1) Reverse Gear Shaft | (5) Shuttle Gear Shaft |
| (2) External Snap Ring | (6) Shuttle Shaft |
| (3) Shift Fork | (7) Shuttle Fork Rod |
| (4) Sub-range Shift Fork Rod | |

W1183161

Disassembling PTO Clutch

1. See page 3-S31, S32.

W1289718



GST Clutch Discs


1. Take out the clutch hub (2), clutch disc (3) and steel plate (5), (6) from clutch case (1).

(When reassembling)

- Assemble the two (L3130, L3430) or three (L3830, L4330, L4630, L5030) steel plates (6) with plug rubbers (4) to the front side, one steel plate (5) without plug rubber to the piston side. (Steel plate (5), (6) are used same part.)
- Do not pile up the plug rubber (4) portion on steel plates (6) while reassembling as shown in the figure.

- | | |
|--------------------------------------|---------------------------------------|
| (1) Clutch Case | (5) Steel Plate without Plug Rubber |
| (2) Clutch Hub | (6) Steel Plate with Plug Rubber |
| (3) Clutch Disc | (Two pieces for L3130, L3430, |
| (Three pieces for L3130, L3430, | three pieces for L3830, L4330, |
| four pieces for L3830, L4330, L4630, | L4630, L5030) |
| L5030) | |
| (4) Plug Rubber | [A] L3130, L3430 |
| | [B] L3830, L4330, L4630, L5030 |

W1051729



Clutch Case and GST Clutch Piston


1. Remove the external snap ring (1) while pushing the spring retainer (2) by hand press.
2. Take out the spring retainer (2), springs (3) and piston (4).

(When reassembling)


- Apply small amount of the grease to the seal rings (8) when assemble the clutch case (7).
- Apply enough transmission fluid to the O-ring (6) and D-ring (5).

- | | |
|------------------------|--------------------|
| (1) External Snap Ring | (6) O-ring |
| (2) Spring Retainer | (7) Clutch Case |
| (3) Spring | (8) Seal Ring |
| (4) Piston | (9) Needle Bearing |
| (5) D-ring | |

W1052192




Shuttle Shift Gears (L3130, L3430)



- (1) External Snap Ring
- (2) Thrust Collar
- (3) Bearing
- (4) Thrust Collar
- (5) External Snap Ring
- (6) Thrust Collar
- (7) External Snap Ring
- (8) Hub
- (9) Needle Bearing
- (10) 20T Gear
- (11) 22T Gear
- (12) Needle Bearing
- (13) Thrust Collar
- (14) Shuttle Forward Shaft
- (15) Needle Bearing
- (16) Shuttle Shaft
- (17) Hub
- (18) External Snap Ring
- (19) 18T Gear
- (20) Needle Bearing
- (21) Thrust Collar
- (22) Bearing
- (23) Collar
- (24) External Snap Ring

W1052711

3TLABAB3P196A




3TLABAB3P197A

1. Remove the external snap ring (1) and thrust collar (2).
2. Remove the bearing (3) and remove the thrust collar (4), 20T gear (10) and synchronizer ring.
3. Remove the external snap ring (7) and remove the hub (8) with shifter, synchronizer ring and 22T gear (11).
4. Remove the external snap rings (5) and remove the needle bearings, thrust collars (6), (13) and shuttle forward shaft (14).
5. Remove the external snap ring (24) and collar (23) and remove the bearing (22), thrust collar (21), 18T gear (19) and synchronizer rings.
6. Remove the external snap ring (18) and remove the hub (17) with shifter and synchronizer rings.

(When reassembling)


- Direct the groove side of the thrust collars (4), (21) to the gear side.
- Reinstall the synchronizer keys in the key grooves of the synchronizer rings.
- Direct the groove side of the hub (8) and shuttle forward shaft (14) as shown in figure.
- Apply enough transmission fluid to the needle bearings (9), (12), (15), (20).



3TLABAB3P198A

W1052955


Shuttle Shift Gears (L3830, L4330, L4630, L5030)




- (1) External Snap Ring
- (2) Thrust Collar
- (3) Bearing
- (4) Thrust Collar
- (5) External Snap Ring
- (6) Thrust Collar
- (7) External Snap Ring
- (8) Hub
- (9) Needle Bearing
- (10) 20T Gear
- (11) 22T Gear
- (12) Needle Bearing
- (13) Thrust Collar
- (14) Shuttle Forward Shaft
- (15) Needle Bearing
- (16) Shuttle Shaft
- (17) Hub
- (18) External Snap Ring
- (19) 18T Gear
- (20) Needle Bearing
- (21) Thrust Collar
- (22) Bearing
- (23) Collar
- (24) External Snap Ring
- (25) External Snap Ring
- (26) Synchronizer Ring

W1186507

3TLABAB3P199A



3TLABAB3P200A



3TLABAB3P198A

1. Remove the external snap ring (1) and thrust collar (2).
2. Remove the bearing (3) and remove the thrust collar (4), 20T gear (10) and synchronizer ring.
3. Remove the external snap ring (7) and remove the hub (8) with shifter, synchronizer ring and 22T gear (11).
4. Remove the external snap rings (5) and remove the needle bearings, thrust collars (6), (13) and shuttle forward shaft (14).
5. Remove the external snap ring (24) and collar (23) and remove the bearing (22), thrust collar (21), 18T gear (19) and synchronizer rings.
6. Remove the external snap ring (25) and remove the needle bearing (20).
7. Remove the external snap ring (18) and remove the hub (17) with shifter and synchronizer rings.

(When reassembling)

- Direct the groove side of the thrust collars (4), (21) to the gear side.
- Reinstall the synchronizer keys in the key grooves of the synchronizer rings.
- Install the synchronizer rings (26) securely, referring to page 3-S30.
- Direct the groove side of the hub (8) and shuttle forward shaft (14) as shown in figure.

W1186665

(C) Transmission Case

■ **NOTE**

- For the disassembling procedure from “Draining the Transmission Fluid” to “Cabin Assembly”, refer to page 3-S53 to 3-S55.



Rear Wheel

1. Place disassembling stand under the transmission case, and support it with a jack.
2. Remove the rear wheels.
3. After removing the rear wheels, support it at both sides of rear axle by stands.

(When reassembling)


Tightening torque	Rear wheel mounting screw and nut	215 N·m 22 kgf·m 160 ft·lbs
	Rear wheel mounting stud bolt	98.1 to 112.8 N·m 10.0 to 11.5 kgf·m 72.3 to 83.2 ft·lbs





W1187806

52.8 to 73.5 N·m 5.4 to 7.4 kgf·m 40.2 to 53.6 ft·lb	Front pin lock nut
7.5 to 90.5 N·m 0.8 to 9.2 kgf·m 5.7 to 66.5 ft·lb	Clutch frame mounting screw (M12)
187 to 195 N·m 19 to 20 kgf·m 137 to 142 ft·lb	Clutch cover mounting screw (M14)
24.3 to 36.1 N·m 2.5 to 3.8 kgf·m 18.2 to 26.4 ft·lb	Hydraulic cylinder pin
187 to 195 N·m 19 to 20 kgf·m 137 to 142 ft·lb	Front cover frame

- (B) Rear Hydraulic Jack
- (10) Hub Nut
- (11) Drive Shaft (13)
- (12) Drive Shaft (20)
- A. ROPS Model
- B. CABIN Model
- C. L3130, L3430
- D. L3830, L4330, L4630, L5030

- (1) Drive Shaft
- (2) Drive Shaft
- (3) Drive Shaft
- (4) Hydraulic Cylinder
- (5) ROPS Lower Frame
- (6) ROPS Lower Frame
- (7) ROPS Lower Frame
- (8) Hydraulic Cylinder
- (9) Hub Nut
- (10) Hub Nut
- (11) Drive Shaft (13)
- (12) Drive Shaft (20)





ROPS, 3 Point Linkages, Hydraulic Cylinders and Others

1. Remove the top link.
2. Remove the lift rods (2), lower links (6) and stabilizers (1) as a unit.
3. Remove the ROPS lower frames (3). (ROPS Model only)
4. Remove the PTO shaft cover (5).
5. Remove the drawbar frame (7).
6. Disconnect the hydraulic cylinder hoses (8) and return hoses (10) at the rear hydraulic block (9).
7. Remove the two pins and remove the hydraulic cylinders (4).
8. Disconnect the brake rods.


(When reassembling)

- Apply grease to the lower link pins and hydraulic cylinder pins.

Tightening torque	Lift arm pin mounting nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Lift arm pin lock nut	62.8 to 72.6 N·m 6.4 to 7.4 kgf·m 46.3 to 53.5 ft-lbs
	Drawbar frame mounting screw (M12)	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Drawbar frame mounting screw (M14)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft-lbs
	Hydraulic cylinder hose	34.3 to 48.1 N·m 3.5 to 4.9 kgf·m 25.3 to 35.4 ft-lbs
	ROPS lower frame mounting screw	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft-lbs

- | | |
|---|--|
| (1) Stabilizer
(2) Lift Rod
(3) ROPS Lower Frame
(4) Hydraulic Cylinder
(5) PTO Shaft Cover
(6) Lower Link
(7) Drawbar Frame
(8) Hydraulic Cylinder Hose | (9) Rear Hydraulic Block
(10) Return Hose
(11) Screw (M14 × 155)
(12) Screw (M14 × 30)
A : ROPS Model
B : CABIN Model
C : L3130, L3430
D : L3830, L4330, L4630, L5030 |
|---|--|

W1189095



Rear Hydraulic Block and Lift Arm Support

1. Remove the GST delivery pipe. (Refer to 3-S59.)
2. Loosen the main delivery pipe support screw and disconnect the main delivery pipe at the rear hydraulic block (1). (Refer to 3-S59.)
3. Remove the rear hydraulic block (1), cover (2) and lift arm support (3) as a unit.


(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the differential case and cover (2).

Tightening torque	Joint bolt for main delivery pipe to rear hydraulic block	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Joint bolt for GST delivery pipe	34 to 39 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft-lbs

- (1) Rear Hydraulic Block (2) Cover (3) Lift Arm Support

W1054122



Mid PTO Case (If equipped)

1. Remove the mid PTO lever (1).
2. Remove the mid PTO gear case assembly (3) with lever rod (2).

(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the mid PTO case and transmission case.

- (1) Mid PTO Lever (2) Lever Rod (3) Mid PTO Gear Case

W1193061



Rear Axle


1. Separate the rear axle case from brake case.

(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the rear axle and brake case.

Tightening torque	Rear axle case mounting screw and nut	M10 screw and nut (7T)	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft-lbs
		Stud bolt	24.5 to 31.4 N·m 2.5 to 3.2 kgf·m 18.1 to 23.1 ft-lbs
		M10 nut (9T) (Except L3130, L3430)	60.8 to 70.6 N·m 6.2 to 7.2 kgf·m 44.9 to 52.1 ft-lbs
		M12 screw (Except L3130, L3430)	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs

W1054206



Brake Case


1. Remove the creep gear shift lever and its fulcrum screw. (If equipped.)
2. Remove the brake case mounting screws and nuts.
3. Separate the brake case, tapping the brake case lever lightly.

(When reassembling)

- Apply grease to the steel ball seats. (Do not grease excessively.)
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the brake case and transmission case.
- Be sure to apply liquid gasket to **A** position.
- Be sure to fix the brake cam and cam plate.
- Before installing the brake case to the transmission case, install the cam plate to the transmission case.

	Brake case mounting stud bolt	29.4 to 49.0 N·m 3.0 to 5.0 kgf·m 21.7 to 36.1 ft-lbs
Tightening torque	Brake case mounting screw and nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Lever fulcrum screw	62.8 to 72.5 N·m 6.4 to 7.4 kgf·m 46.3 to 53.5 ft-lbs

W10543450



GST Valve Assembly

1. Remove the GST valve assembly with using two jack bolts.
2. Remove the shift pin (4).

NOTE


- Do not fall down the shuttle check pin while disassembling.
- (When reassembling)**

- Place the 1-2 (1) and 3-4 (2) shift pins at **neutral** position, sub-range shift pin (5) at **Hi** position (rearward) and main range shift pin (4) at **L** position (forward), and then assemble the GST valve.
- Be sure to match the each shift pin and shift piston.
- Install the GST valve by hand, and then tighten the screws. Do not use the hummer.
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the GST valve assembly.
- Replace the pipe (3) with new one, if damaged.

	GST valve mounting screw	42.2 to 48.1 N·m 4.3 to 4.9 kgf·m 31.1 to 35.4 ft-lbs
Tightening torque	Shift pin mounting screw	12.7 to 14.7 N·m 1.3 to 1.5 kgf·m 9.4 to 10.8 ft-lbs

- (1) 1-2 Shift Pin
- (2) 3-4 Shift Pin
- (3) Pipe
- (4) Main Range Shift Pin
- (5) Sub-range Shift Pin

W1194627



Separating Mid Case and Transmission Case


1. Separate the mid case and transmission case after removing their mounting screws and nut.

(When reassembling)

- Confirm to insert the PTO shaft to PTO clutch firmly, turning the PTO shaft.
- Confirm to insert the front wheel drive shaft to coupling firmly.
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the mid case and transmission case.

Tightening torque	Mid case and transmission case mounting screw	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Mid case and transmission case mounting nut	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Mid case and transmission case mounting stud bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs

W1054481



Pinion Bearing Cover

1. Remove the stake of lock nut (5).
2. Lock the turning of spiral bevel pinion and remove the lock nut (5).
3. Remove the pinion bearing case mounting screws.
4. Take out the pinion bearing cover (4) and shims (1).

(When reassembling)


- Make sure of the number of shims in the pinion bearing case.
- Replace the lock nut (5) with a new one, and stake the lock nut firmly after installing the parts on the shaft.

Tightening torque	Lock nut	147 to 196 N·m 15 to 20 kgf·m 108 to 145 ft-lbs
	Pinion bearing case mounting screw	39.2 to 44.1 N·m 4.0 to 4.5 kgf·m 28.9 to 32.5 ft-lbs

- (1) Shim
- (2) Pinion Bearing Case
- (3) Spiral Bevel Pinion Shaft

- (4) Pinion Bearing Cover
- (5) Lock Nut

W1054717



Transmission Bearing Holder

1. Remove the transmission bearing holder mounting screws.
2. Jack up the bearing holder (7) by using the two jack screws until the taper roller bearing (9) can be removed.

■ **NOTE**

- Jack up the bearing holder while hitting the two shafts (2) (5) by copper hammer or soft hammer.


3. Jack up more and remove the transmission bearing holder (7).
(When reassembling)

- Tap in the transmission bearing holder with soft hammer until contact to transmission case, and then tighten the screws to specified torque.

Tightening torque	Transmission bearing holder mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.5 to 41.2 ft-lbs
-------------------	--	---

- | | |
|---|---------------------------------|
| (1) Creep Gear Shaft (Creep Gear Type) | (6) Front Wheel Drive Shaft |
| (2) Spiral Bevel Pinion Shaft | (7) Transmission Bearing Holder |
| (3) Range Gear Shaft | (8) Pinion Bearing Case |
| (4) Shift Fork Rod for Range Gear Shift | (9) Taper Roller Bearing |
| (5) PTO Drive Shaft | |

W1054992





Shaft Assemblies

1. Remove the traveling speed sensor (1).
2. Remove the external snap ring (3) of the creep gear shaft (4) to the rear. (Creep gear type only)
3. Take out the range gear shaft assembly (8) with the shift fork rod (9).
4. Take out the creep shaft assembly (4) and spiral bevel pinion shaft assembly (7) with shift fork (10) and shift fork rod (11).
5. Take out the PTO drive shaft assembly (6) and front wheel drive shaft assembly (5).


- | | |
|-----------------------------|-------------------------------|
| (1) Traveling Speed Sensor | (7) Spiral Bevel Pinion Shaft |
| (2) Creep Gear | (8) Range Gear Shaft |
| (3) External Snap Ring | (9) Shift Fork Rod |
| (4) Creep Gear Shaft | (10) Shift Fork |
| (5) Front Wheel Drive Shaft | (11) Shift Fork Rod |
| (6) PTO Drive Shaft | |

W1198652





Disassembling Shaft Assemblies


1. Disassemble the each shaft referring to the figure.




- (1) 49T-20T Gear
49T-19T-20T Gear
(Creep Model Only)
 - (2) Range Gear Shaft
 - (3) 17T Gear
 - (4) 34T Gear (L3130, L3430, L4330)
35T Gear (L3830, L4630, L5030)
 - (5) 50T Gear (Creep Model Only)
 - (6) 18T Gear
(L3130, L3430, L4330, L4630)
17T Gear (L3830, L5030)
 - (7) Spiral Bevel Pinion Shaft
 - (8) 44T Gear (Creep Model Only)
 - (9) Shifter for Creep Shift
(Creep Model Only)
 - (10) Creep Shaft
(Creep Model Only)
 - (11) 27T Gear
 - (12) 29T Gear (L3130, L3430)
29T-31T Gear (L3830)
29T-30T Gear (L4330, L4630)
29T-32T Gear (L5030)
 - (13) 24T Shifter Gear
 - (14) 26T-60T Gear
 - (15) Front Wheel Drive Shaft
 - (16) PTO Drive Shaft
- [A] L3130, L3430, L3830, L4630 (CABIN)**
[B] L4330, L5030



W1055343



3TMABAB3P027A



3TMABAB3P028A

Differential Lock Shift Fork


1. Tap out the left side spring pin (4).
2. Remove the cotter pin and take out the clevis pin (3).
3. Draw out the differential lock fork shaft (1) and take out the differential lock shift fork (2).

(When reassembling)


- Apply grease to the left and right oil seals on the transmission case.
- Insert the clevis pin (3) from the top and install the washer and cotter pin.
- Tap in the spring pin (4) so that its split portion **a** may face outward as shown in the figure.


- (1) Differential Lock Fork Shaft
- (2) Differential Lock Shift Fork
- (3) Clevis Pin
- (4) Spring Pin

a : Split Portion



W12034180






PTO Shaft

1. Remove the PTO shaft cover.
2. Remove the bearing case mounting screws, and draw out the PTO shaft (1) with bearing case (2).
3. Remove the internal snap ring (3).
4. Top out the PTO shaft (1) to the front.

(When reassembling)

- If the lock nut (6) was removed, replace it with a new one. After replacing, be sure to stake it firmly.
- Install the slinger (7) firmly.
- Apply grease to the oil seal (4) and install it, noting its direction.




Tightening torque	Lock nut	147 to 196 N·m 15 to 20 kgf·m 108 to 145 ft-lbs
	Bearing case mounting screw	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft-lbs

- (1) PTO Shaft
- (2) Bearing Case
- (3) Internal Snap Ring
- (4) Oil Seal
- (5) Oil Seal Collar
- (6) Lock Nut
- (7) Slinger

- [A] L3130, L3430
- [B] L3830, L4330, L4630
- [C] L5030

W12044640



Differential Gear Assembly

1. Remove the differential support, noting the number of left shims.
2. Take out the differential gear assembly, noting the number of right shims.

(When reassembling)

- Check the spiral bevel gear for wear or damage. If it is no longer serviceable, replace it. Then, also replace the spiral bevel pinion.
- Use same number of shims as before disassembling.

Tightening torque	Differential support mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft-lbs
-------------------	-------------------------------------	---


W12055450

Disassembling Differential Gears

1. See page 3-S39, S40.

W1056552

(D) Regulating Valve



3TLABAB7P013B


Front Grille, Skirt and Battery Cable

1. Open the bonnet and disconnect the battery negative cable.
2. Disconnect the head light connector and remove the front grille (3).
3. Remove the skirt RH (2).

- (1) Bonnet
- (2) Skirt RH

- (3) Front Grille

W1056678




3TLABAB7P015B

Hydraulic Pipes and Regulating Valve Assembly

1. Disconnect the GST delivery pipe (5), power steering return hose (3) and power steering delivery pipe (4) from regulating valve assembly (2).
2. Remove the delivery pipe (1).
3. Loosen and remove the regulating valve mounting screws.
4. Take out the regulating valve assembly (2) from the power steering hydraulic pump (7).

(When reassembling)

- Install the copper washers firmly.
- Apply grease to the O-ring (6) and take care not to damage it.





3TLABAB3P213A

Tightening torque	Joint bolt for GST delivery pipe (3) and regulating valve	34.3 to 39.2 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft·lbs
	Joint bolt for power steering delivery hose (2) and regulating valve	49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 ft·lbs
	Joint bolt for delivery pipe (5) and hydraulic pump	39.3 to 49.0 N·m 4.0 to 5.0 kgf·m 29.0 to 36.2 ft·lbs
	Regulating valve mounting screws	17.6 to 20.6 N·m 1.8 to 2.1 kgf·m 13.0 to 15.2 ft·lbs

- (1) Delivery Pipe
- (2) Regulating Valve Assembly
- (3) Power Steering Return Hose
- (4) Power Steering Delivery Pipe

- (5) GST Delivery Pipe
- (6) O-ring
- (7) Power Steering Hydraulic Pump

W1056783



Disassembling Regulating Valve

■ **NOTE**

• The regulating valve has been precisely machined and assembled. It is advisable not to disassemble it as long as there is no necessary.

1. Remove the plate (8) and take out reducing spool (11), spring retainer (5) and spring (10).
2. Separate the regulating valve case (12) and support (4).
3. Take out the bush (6) and poppet (7).
4. Remove the joint bolt (14), and then take out the spring (13) and the poppet (9).
5. Take out the spring retainer (5) and spring (10).

(When reassembling)

• Take care not to damage the O-rings.

Tightening torque	Joint bolt (14)	49.0 to 58.8 N·m 5.0 to 6.0 kgf·m 36.2 to 43.4 ft-lbs
	Plate (8)	9.8 N·m 1.0 kgf·m 7.2 ft-lbs
	Regulating valve case and support mounting screws	9.8 N·m 1.0 kgf·m 7.2 ft-lbs

- | | |
|------------------------|----------------------------|
| (1) Nut | (8) Plate |
| (2) Adjustor | (9) Poppet |
| (3) Washer with Rubber | (10) Spring |
| (4) Support | (11) Reducing Spool |
| (5) Spring Retainer | (12) Regulating Valve Case |
| (6) Bush | (13) Spring |
| (7) Poppet | (14) Joint Bolt |

W1057149

(E) GST Valve Assembly

■ **NOTE**



• The GST valve has been precisely machined and assembled. It is advisable not to disassemble it. If unavoidably necessary to do it, take the following precautions.

1. Tighten up the screws and nuts to their specified torques.
2. Be sure to clean the disassembled parts and dry them up with compressed air.
3. Do not wear any gloves other than rubber ones not use waste cloth. This is important for keeping the parts clean and free from rust.
4. Be careful not to drop the parts on the floor or workbench. Check any part, if dropped, for hit mark, scratch and burr.
5. Be sure to use a rubber or plastic hammer for reassembling.
6. Do not use a wire brush nor polish any part with sandpaper.
7. Apply super UDT oil to the O-rings and oil seals before reassembling. Do not use any metal-cleaning liquid.

Draining Transmission Fluid

1. See page 3-S53.

W1057749



GST Valve Assembly

1. Remove the GST valve cover.
2. Disconnect the pressure switch connector (1), proportional reducing valve connector (2) solenoid connector (4) and oil temperature sensor connector (5).
3. Disconnect the GST delivery pipe (3).
4. Remove the GST valve assembly (6) with using two jack bolts.



■ **NOTE**

- **Do not fall down the shuttle check pin while assembling. (When reassembling)**
- Place the 1-2 shift pin (7) and the 3-4 shift pin (8) at **neutral** position, main range shift pin (10) at **L** position (forward) and sub-range pin (11) at **Hi** position (rearward), and then assemble the GST valve.
- Be sure to match the each shift pin and shift piston.
- Install the GST valve assembly (6) by hand, and then tighten the screws. Do not use the hummer.
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the GST valve assembly.

Tightening torque	GST valve assembly mounting screw	42.2 to 48.1 N·m 4.3 to 4.9 kgf·m 31.1 to 35.4 ft·lbs
	Joint bolt for GST delivery pipe to GST valve	34.3 to 39.2 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft·lbs

- | | |
|---|---------------------------|
| (1) Pressure Switch Connector | (6) GST Valve Assembly |
| (2) Proportional Reducing Valve Connector | (7) 1-2 Shift Pin |
| (3) GST Delivery Pipe | (8) 3-4 Shift Pin |
| (4) Oil Temperature Sensor Connector | (9) Pipe |
| (5) Solenoid Valve Connector | (10) Main Range Shift Pin |
| | (11) Sub-range Shift Pin |

W1057795



Solenoid Valve


1. Remove the cover (7).
 2. Disconnect the connector (8) and remove the solenoid valves.
- (When reassembling)**

- Be sure to install the each solenoid valve to their original positions as shown in the photo and table below.

No.	Solenoid Name	Color of wiring
(6)	Shift Solenoid 1 (1st shift)	Black
(1)	Shift Solenoid 2 (2nd shift)	White
(3)	Shift Solenoid 3 (3rd shift)	Red
(2)	Shift Solenoid 4 (4th shift)	Green
(5)	Shift Solenoid 5 (Sub-range shift)	Blue
(4)	Shift Solenoid 6 (Main range shift)	Yellow

- | | |
|----------------|----------------|
| (1) Solenoid 2 | (5) Solenoid 5 |
| (2) Solenoid 4 | (6) Solenoid 1 |
| (3) Solenoid 3 | (7) Cover |
| (4) Solenoid 6 | (8) Connector |

W1058270




Shift Check Valve


1. Remove the lower body mounting hex. socket head cap screws (1).
2. Separate the upper body (2) and lower body (4).
3. Take out the 1-2, 3-4 shift check pin (10), (11), sub-range shift check pin (6), main range shift check pin (7), shuttle shift check pin (8), balls (5) and pin (9) from lower body (4).
4. Take out the springs (13), balls (12) and filter (14) from upper body (2).

(When reassembling)




- Take care so that only the main range shift check pin (7) is short length.







Tightening torque	Lower body mounting hex. socket head cap screw	9.8 to 10.8 N·m 1.0 to 1.1 kgf·m 7.2 to 8.0 ft·lbs
-------------------	--	--



- | | |
|--------------------------------|--------------------------|
| (1) Hex. Socket Head Cap Screw | (9) Shuttle Shift Pin |
| (2) Upper Body | (10) 3-4 Shift Check Pin |
| (3) Plate | (11) 1-2 Shift Check Pin |
| (4) Lower Body | (12) Ball |
| (5) Ball | (13) Spring |
| (6) Sub-range Shift Check Pin | (14) Filter |
| (7) Main Range Shift Check Pin | (15) Shift Piston |
| (8) Shuttle Shift Check Pin | |



W1058592



Shift Piston

1. Separate the upper body, and lower body. (See page 3-S83.)
2. Tap out the spring pins (6), and remove the shifters (5).
(For 1-2, 3-4 and sub-range shift piston)
3. Remove the internal snap ring (1) and cover (2), and then take out the shift piston (4), (9) with neutral piston (3).
(For 1-2 and 3-4 shift piston)
4. Remove the internal snap ring (12) and cover (8), and then take out the shift piston (7), (11).
(For main range and sub-range shift piston)

(When reassembling)


- Take care not to damage the O-ring (13) and piston seal (14).

- (1) Internal Snap Ring
- (2) Cover
- (3) Neutral Piston
- (4) 3-4 Shift Piston
- (5) Shifter
- (6) Spring Pin
- (7) Sub-range Shift Piston
- (8) Cover
- (9) 1-2 Shift Piston


- (10) Lower Body
- (11) Main Range Shift Piston
- (12) Internal Snap Ring
- (13) O-ring
- (14) Piston Seal

- A : 1-2 and 3-4 Shift Piston**
- B : Sub-range Shift Piston**
- C : Main Range Shift Piston**


W1059069




3TLABAB3P225A



3TLABAB3P226A



3TLABAB3P227A



3TLABAB3P228A

Low-pass Valve

■ IMPORTANT

- Do not adjust or remove the adjustor (2), otherwise the GST clutch engagement feeling will be changed.
- If this valve is disassembled, be sure to check and adjust the low-pass pressure.

- Separate the upper body and lower body. (See page 3-S83.)
- Remove the plug (5).
- Remove the stopper plate (6) and remove the low-pass poppet (4) and spring (3).

- (1) Lock Nut
- (2) Adjustor
- (3) Spring

- (4) Low-pass Poppet
- (5) Plug
- (6) Stopper Plate

W1059505

Clutch Valve

- Separate the upper body and lower body. (See page 3-S83.)
- Remove the stopper plate (4) while pushing the plug (1).
- Take out the spool (2) and spring (3).


(When reassembling)

- Be careful about the direction of the spool (2) and the plugs (1) referring to the figure.

- (1) Plug
- (2) Spool

- (3) Spring
- (4) Stopper Plate

W1059735



Proportional Reducing Valve and Filter


1. Remove the valve mounting hex. socket head cap screws.
2. Remove the proportional reducing valve (2).
3. Remove the cover (6).
4. Take out the plug (3) and orifice support (4) with filter (5).

(When reassembling)

- Take care not to damage the O-ring.

- | | |
|---------------------------------|---------------------|
| (1) Hex. Socket Head Cap Screw | (4) Orifice Support |
| (2) Proportional Reducing Valve | (5) Filter |
| (3) Plug | (6) Cover |

W1059897



Check Valve, Oil Temperature Sensor, Orifice and Filter




1. Remove the oil temperature sensor (3) and take out the spring (2) and ball (1).
2. Remove the plug (6), and take out the spring (5) and orifice plug (4) with filter (7).

(When reassembling)

- Be careful about the direction of the orifice support (4) and filter (7).

- | | |
|----------------------------|------------|
| (1) Ball | (5) Spring |
| (2) Spring | (6) Plug |
| (3) Oil Temperature Sensor | (7) Filter |
| (4) Orifice Support | |

W1060139



(3) Servicing

(A) Bearing, Gear and Shaft

See page 3-S41.

(B) Synchronizer Gear

See page 3-S42.

(C) PTO Clutch

See page 3-S43.

(D) Differential Gears

See page 3-S44 to 3-S46.

(E) GST Clutch




Clutch Disc Wear

1. Measure the thickness of GST clutch disc with vernier calipers.
2. If the thickness is less than the allowable limit, replace it.

Thickness of GST clutch disc	Factory spec.	2.55 to 2.65 mm 0.100 to 0.104 in.
	Allowable limit	2.50 mm 0.098 in.

W1060836



Steel Plate Wear

1. Measure the thickness of GST steel plate with vernier calipers.
2. If the thickness is less than the allowable limit, replace it.

Thickness of GST steel plate	Factory spec.	1.55 to 1.65 mm 0.061 to 0.065 in.
	Allowable limit	1.50 mm 0.059 in.

W1061099




Flatness of Piston and Steel Plate

1. Place the part on a surface plate.
2. Check it unable to insert a feeler gauge (allowable limit size) underneath it at least four points.
3. If the gauge can be inserted, replace it.

Flatness of GST piston	Allowable limit	0.15 mm 0.006 in.
------------------------	-----------------	----------------------

Flatness of GST steel plate	Allowable limit	0.30 mm 0.012 in.
-----------------------------	-----------------	----------------------

W1061290




Piston Return Spring Free Length

1. Measure the free length of spring with vernier calipers.
2. If the measurement is less than the allowable limit, replace it.

Piston return spring free length	Factory spec.	19.9 to 20.1 mm 0.78 to 0.79 in.
	Allowable limit	18.0 mm 0.71 in.

W1060662




Thickness of Seal Ring

1. Measure the thickness of seal rings (1) with an outside micrometer.
2. If the measurement is less than the allowable limit, replace it.

Thickness of seal ring	Factory spec.	2.45 to 2.50 mm 0.096 to 0.098 in.
	Allowable limit	2.0 mm 0.0079 in.

(1) Seal Ring




[3] HYDROSTATIC TRANSMISSION (HST) MODEL

(1) Checking and Adjusting

(A) Electrical Adjusting [Adjustment with Electronic Instrument Panel (IntelliPanel)]

■ NOTE

- Before executing the following fine-adjustment, refer to “Testing, Setting and Adjusting by Electronic Instrument Panel” of an Electrical System. (Refer to page 9-S12.)



Adjustment of HST Range Gear Shift Lever Sensor

■ NOTE

- When the electronic instrument panel or range gear shift sensor was replaced, this adjustment is required.

1. Set the range gear shift lever to the **M** position.
2. Push down both the display mode switch (2) and the travel speed switch (3) at once, continue holding switches, and then turn the main switch to **ON** position.
3. The “**Mode Selection Display**” (a) is indicated on the LCD (1). And release the switches.
4. Press the display mode switch (2) to move the flashing part, and flash the “**I**”.
5. Hold down the display mode switch (2) for more than 2 seconds at this condition, and the buzzer rings and Mode I is selected.
6. “**MHG**” is displayed (b), and the existing symbol setting is flashing.
7. Press the display mode switch (2) to move the flashing part, and flash the “**H**” of the HST model.
8. Hold down the display mode switch (2) for more than 2 seconds at this condition, and the buzzer rings.
9. “**OK**” is displayed (c) : Lever sensor voltage is as specified.
10. “**ERROR 71**” is displayed (d) : Lever sensor voltage is not specified.


In this case;

- Check to see that the range gear shift lever is at **M** position.
- Check the lever sensor voltage in the Test Mode (Mode “**A**”) (see page 9-S13). If out of specification, replace the sensor.

- (1) Liquid Crystal Display (LCD)
 (2) Display Mode Switch
 (3) Travel Speed Switch

- (a) **Mode Selection Display**
 (b) **Information Display**
 (c) **Correct Preserving Display**
 (d) **Error Display**

W1061720

(B) Hydraulic Checking and Adjusting**Checking High Pressure Relief Valve Pressure****CAUTION**

- **When checking, park the machine on flat ground, apply the parking brake.**
1. Remove the hex. socket head plug from **P1** or **P2** port. (**P2** is for forward and **P1** is for reverse.)
 2. Assemble adaptor **C** (07916-50371) and threaded joint (07916-50341) with the gasket between them.
 3. Install the assemble adaptor **C** and threaded joint to **P2** (forward) or **P1** (reverse) port.
 4. Install the cable, threaded joint in relief valve set pressure tester and high pressure gauge to threaded joint in order.
 5. Check to see that parking brake is applied.
 6. Run the engine at maximum speed.
 7. Place the range gear shift lever in **H** position.
 8. Depress the HST pedal, and measure the check and high pressure relief valve pressure.
 9. If the measurement is not within the factory specification, check the check and high relief valve assembly. (See page 3-S107.)

Check and high relief pressure (Oil temperature at 40 to 60 °C (104 to 140 °F))	Factory spec.	33.3 to 36.3 MPa 340 to 370 kgf/cm ² 4836 to 5262 psi
---	---------------	--

IMPORTANT

- **Measure quickly so that the relief valve may not be in operation more than 10 seconds.**

NOTE



- **High pressure gauge is 40 MPa (400 kgf/cm², 5800 psi) full scale.**

(When reassembling)

- Install the hex. socket head plug to the port with O-ring.

(1) **P1** Port (for Reverse)(2) **P2** Port (for Forward)

W1012199



Checking Charge Relief Pressure

⚠ CAUTION

- When checking, park the machine on flat ground, apply the parking brake.

■ NOTE

- Use a new transmission oil filter.
1. Remove the hex. socket head plug from P2 (or P1) port.
 2. Assemble adaptor 58 (07916-52391) and thread joint (07916-50341) with the gasket between them.
 3. Install the assembled adaptor 58 and thread joint to P2 port.
 4. Install the cable, thread joint in relief valve set pressure tester and low pressure gauge to threaded joint in order.
 5. Place the range gear shift lever in neutral.
 6. Run the engine at maximum speed.
 7. Release the HST pedal to set in neutral, and measure the charge pressure.
 8. If the measurement is not within the factory specifications, check charge relief valve (3) (See page 3-S107) or adjust with adjusting shim.

■ NOTE

- Adjusting shim is located on between spring guide (6) and plug (7).

(Reference)

- Thickness of adjusting shim : 0.5 mm (0.02 in.)
- Pressure change per 0.5 mm (0.02 in.) of shim :
 Approx. 61.8 kPa
 0.68 kgf/cm²
 8.97 psi

Charge pressure (oil temperature at 50 to 60 °C (122 to 140 °F))	Factory spec.	2.26 to 2.45 MPa 23 to 25 kgf/cm ² 327 to 355 psi
--	---------------	--

■ NOTE

- Low pressure gauge is 5 MPa (50 kgf/cm², 711 psi) full scale.

- | | |
|-------------------------|------------------|
| (1) P1 Port | (5) Spring |
| (2) P2 Port | (6) Spring Guide |
| (3) Charge Relief Valve | (7) Plug |
| (4) Poppet | |

W1012608




Operating Pressure of PTO Clutch Valve

1. Start the engine and warm up the transmission fluid, and then stop the engine.
2. Remove the plug (1) (PT 1/8) on the PTO valve spool (2).
3. Set the pressure gauge.
4. Start the engine and measure the pressure.
5. For adjustment use the adjusting shim (4) of HST charge relief valve (3).

■ IMPORTANT

- Do not connect the universal joint of the implement to the tractor PTO shaft while testing.



Independent PTO pressure	When PTO shift lever is "ENGAGED" position	2.21 to 2.40 MPa 22.5 to 24.5 kgf/cm ² 320 to 348 psi
	When PTO shift lever is "DISENGAGED" position	No pressure

Condition

- Engine speed Idling speed
- Oil temperature 40 to 60 °C
104 to 140 °F


(Reference)

- Thickness of adjusting shim : 0.5 mm (0.02 in.)
- Pressure change per 0.5 mm (0.02 in.) of shim :
Approx. 61.8 kPa
0.68 kgf/cm²
8.97 psi

- (1) Plug (PT 1/8)
- (2) Spool

- (3) Charge Relief Valve
- (4) Adjusting Shim

W1224108





(C) HST Linkages

Checking Neutral

1. Disengage the front wheel drive lever. (Drive only rear wheels.)
2. Lift the rear of the tractor so that the rear wheels are off the ground and run the engine at low idling and drive only rear wheels.
3. Depress the one end of speed control pedal and release, and do the same at the other end.
4. If the rear wheels do not stop turning, adjust as following procedure of next page.

W1011525



Adjusting Neutral

■ **NOTE**

• **Stop the engine when adjusting the HST neutral.**

1. Set the cruise control lever to "OFF" position. (HST pedal is in **Neutral** position.)
2. Check to see that the length **a** of HST control rod (2) and the length **b** of neutral rod (6) are specified length. If not, adjust as follows.
Length **a** : 196.5 to 197.5 mm (7.74 to 7.78 in.)
Length **b** : 139.5 to 140.5 mm (5.49 to 5.53 in.)
3. Loosen the hex. head screw (3) to make situation that HST control lever (4) moves freely.
4. Tighten the hex. head screw (3) so that the HST control lever (4) does not turn.

■ **NOTE**

• **Be sure to tighten the hex. head screw with specified torque.**

Tightening torque	HST control lever setting hex. head screw	6.86 to 8.33 N·m 0.70 to 0.85 kgf·m 5.06 to 6.15 ft·lbs
-------------------	---	---

- (1) HST Pedal
- (2) HST Control Rod
- (3) Hex. Head Screw
- (4) HST Control Lever
- (5) Connecting Shaft
- (6) Neutral Rod


[A] Right Side View

[B] Left Side View

a : Length of HST Control Rod

b : Length of Neutral Rod


W1011601



Cruise Lever Operating Force

1. Measure the force to move the cruise control lever (1) at lever grip (2).
Put the cruise control lever near a maximum speed position, and measure the operating force to the increasing direction.
2. If the force is not within the factory specifications, loosen the lock nut (4) and adjust the tension of cruise spring (3).
3. Retighten the lock nut securely.



Cruise control lever operating force	Factory spec.	54 to 64 N 5.5 to 6.5 kgf 12.1 to 14.3 lbs
--------------------------------------	---------------	--



- (1) Cruise Control Lever
- (2) Lever Grip

- (3) Cruise Spring
- (4) Lock Nut

W1063742



Cruise Control Linkage and Maximum Travel Speed

■ **NOTE**

- Stop the engine when adjusting the cruise control linkage and pedal stroke.
- Be sure to adjust the HST neutral position (see page 3-S92).
- Be sure to check whether the “traveling speed coefficient” is suitable for tire size. If not, input the appropriate code number. (Refer to page 9-S14.)

1. Loosen the HST pedal mounting screws (4) and tighten the screws (4) while pulling up the front of HST pedal (1).
2. Adjust the height **a** of the pedal stopper bolt F (3) to 35 to 40 mm (1.38 to 1.57 in.).
3. Run the tractor actually and confirm whether traveling speed is a factory specification. (See table below.)
If not, adjust by height of stopper bolt F (3).

Traveling speed at rated engine speed	Factory spec.	L3130	27.0 km/h
		L3430	16.8 mph
		L3830	25.3 km/h
			15.7 mph
		L4330	26.4 km/h
			16.4 mph
	L4630	25.3 km/h	
		15.7 mph	
	L5030	26.1 km/h	
		16.2 mph	

Condition


- Engine Speed : Rated speed
 - Range Gear Shift Lever : H position
 - HST Pedal : Fully depressed forward
4. Set the cruise control lever to fully forward (Maximum position). HST pedal also tilts.
 5. Measure the clearance **b** of between bottom of HST pedal and tip of pedal stopper bolt F (3).

Length b of between HST pedal and stopper bolt F	Factory spec.	3 to 7 mm 0.12 to 0.28 in.
---	---------------	-------------------------------

6. If the measurement is not within factory specification, adjust by the cruise adjusting rod (5). (Cruise Linkage Adjustment)
7. Shorten the pedal stopper bolt R (2) to the position where the length of the bolt is not touched to the HST pedal (1) even if the HST pedal is fully depressed rearward.
8. Lengthen the length of the pedal stopper bolt R (2) gradually with the HST pedal fully depressed rearward and lengthen the three turn from the position where the head of the stopper bolt touches the HST pedal further.

- (1) HST Pedal
- (2) Pedal Stopper Bolt R
- (3) Pedal Stopper Bolt F
- (4) HST Pedal Mounting Screw
- (5) Cruise Adjusting Rod

W1230914





Adjusting Cruise Control Release Linkage

1. Adjust the brake pedals play first.
2. Depress one of the brake pedals to make sure the cruise control is not released. Also depress both the brake pedals coupled together to make sure that the cruise control is released.
3. If the cruise control does not work as above adjust with release wire (1) as follows.
 - Check to see that the threaded portion of the wire (1) rear side is set at the end position. If not, set by lock nuts (2).
 - Adjust by lock nuts (4) for the center of the threaded portion of the release wire front side to come to the hook position.
 - Confirm whether to move as above-mentioned 2.
 - If not, adjust by lock nut (4).

- (1) Release Wire
- (2) Lock Nut (Rear)
- (3) Damper Stay
- (4) Lock Nut (Front)

W1013375

(2) Disassembling and Assembling
(A) Separating Clutch Housing and Engine



Draining the Transmission Fluid

1. Place oil pans underneath the transmission case.
2. Remove the drain plugs (1).
3. Drain the transmission fluid.
4. Reinstall the drain plugs (1).

(When refilling)

- Fill up from filling port after removing the filling plug (2) until reaching the upper notch on the dipstick (3).
- After running the engine for few minutes, stop it and check the oil level again, add the fluid to prescribed level if it is not correct level.

Transmission fluid capacity	L3130 L3430	42 L 11.1 U.S.gals. 9.2 Imp.gals.
	L3830 L4330 L4630	43 L 9.5 11.4 U.S.gals. Imp.gals.
	L5030	45 L 11.9 U.S.gals. 9.9 Imp.gals.


■ IMPORTANT

- Use only KUBOTA SUPER UDT fluid. Use of other oils may damage the transmission or hydraulic system. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7, 8.)
- Do not mix different brands of fluid together.

- (1) Drain Plugs
- (2) Filling Plug
- (3) Dipstick

(A) Oil level is acceptable within this range.

W1242305



Battery, Front Grill, Skirt and Bonnet


1. Open the bonnet and disconnect the battery negative cable.
2. Disconnect the head light connector and remove the front grill (4).
3. Remove the left and right side skirts (3).
4. Disconnect window washer hoses (2). (Cabin model only.)
5. Remove the bonnet (1).

■ **NOTE**

- When disconnecting the battery cords, disconnect the negative cord first, when connecting, positive cord first.

- | | |
|------------------------|-----------------|
| (1) Bonnet | (3) Skirt |
| (2) Window Washer Hose | (4) Front Grill |

W1242861



ROPS

1. Remove the lower connector (2).
2. Remove the plate mounting screws (4), (8).
3. Remove the upper frame (1) from ROPS lower frame (5).

(When reassembling)




■ **NOTE**

- Do not firmly tighten all screws until most components are attached.

Tightening torque	Lower connector mounting screw (3)	103 to 118 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft·lbs
	Plate mounting screw (4)	138 to 147 N·m 14.0 to 15.0 kgf·m 102 to 108 ft·lbs
	Plate mounting screw (8)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft·lbs

(Reference)




Tightening torque	Upper connector mounting screw (9)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft·lbs
	Fulcrum bolt and nut (11)	118 to 137 N·m 12.0 to 14.0 kgf·m 86.8 to 102 ft·lbs



- | | |
|----------------------|---------------------------|
| (1) Upper Frame | (9) Screw (M14 × 30) |
| (2) Lower Connector | (10) Upper Connector |
| (3) Screw (M12 × 65) | (11) Fulcrum Bolt and Nut |
| (4) Screw (M14 × 40) | (12) Lock Bolt |
| (5) Lower Frame | |
| (6) Plate | |
| (7) Connector | |
| (8) Screw (M14 × 30) | |

A : Rigid Type
B : Foldable Type

W1243191



Steering Joint, Brake Pedal Rod and Electric Wiring

1. Remove the tank frame support (2).
2. Remove the universal joint bolt (10) and steering joint support (3), and then remove the steering joint (1).
3. Disconnect the hand accelerator wire (7).
4. Disconnect the wiring connectors for engine stop solenoid (8), engine tachometer sensor (9) and glow plug.
5. Disconnect the heater hoses (4), and then reconnect their hoses to make loop. (Cabin model only.)

NOTE

- Put a mark to the each heater hose before disconnecting.
6. Disconnect the wiring connector for window washer tank (5) and compressor 1P connector (6). (Cabin model only.)
 7. Disconnect the brake pedal rod.



(When reassembling)

- When accelerator wire is installed, adjust the wiring length as hit both the idling speed adjusting bolt and the maximum speed adjusting bolt by lever within the stroke of the accelerator lever.
- Set the steering joint (1) by the joint support (3) so that the steering wheel is turned lightly.
- Be sure to check and adjust the brake pedal free travel. (See page G-16.)

- (1) Steering Joint
 (2) Tank Frame Support
 (3) Steering Joint Support
 (4) Heater Hose
 (5) Window Washer Tank
 (6) 1P Connector

- (7) Accelerator Wire
 (8) Engine Stop Solenoid
 (9) Engine Tachometer Sensor
 (10) Universal Joint Bolt
[A] ROPS Model
[B] Cabin Model

W1065071



Clutch Rod, Brake Pedal Rod and Electric Wiring

1. Disconnect the brake pedal rod (5) and clutch rod (4).
2. Disconnect the wiring connectors for alternator (1), coolant temperature sensor (9), oil pressure switch (2), fuel unit (3), starter motor (6) and battery.
3. Remove the clamps and ground earth of wiring harness and collect wiring harness to the step or cabin.
4. Remove the clamps (7) of A/C hoses (8). (Cabin model only.)

(When reassembling)





- Be sure to check and adjust the clutch and brake pedal free travel. (See page G-16, 22.)

- (1) Alternator
- (2) Oil Pressure Switch
- (3) Fuel Unit
- (4) Clutch Rod
- (5) Brake Pedal Rod
- (6) Starter Motor

- (7) Clamps
- (8) A/C Hoses
- (9) Coolant Temperature Sensor

[A] ROPS Model
[B] Cabin Model

W1065311



Air Conditioner Parts (Cabin Model)

1. Remove the muffler (1).
2. Remove the air conditioner belt (4) and remove the compressor (1) mounting screw.
3. Remove the recovery tank (6) and window washer tank (7).
4. Disconnect the air cleaner hose (8).
5. Disconnect the recovery tank hose (5).
6. Disconnect the radiator upper hose (3).
7. Remove the oil cooler mounting screw.
8. Remove the battery (10).
9. Remove the battery stay mounting bolt.
10. Take out the compressor (1), condenser (11), receiver (12), hoses (13), battery stay (9) and etc. as a unit.

(When reassembling)

- After reassembling the compressor, be sure to adjust the air conditioner belt tension. (See page G-28.)

Tightening torque	Compressor mounting screw	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft·lbs
	Muffler mounting screw	31.4 to 37.2 N·m 3.2 to 3.8 kgf·m 23.1 to 27.5 ft·lbs

- | | |
|--------------------------|---------------------------|
| (1) Compressor | (8) Air Cleaner Hose |
| (2) Muffler | (9) Battery Stay |
| (3) Radiator Upper Hose | (10) Battery |
| (4) Air Conditioner Belt | (11) Condenser |
| (5) Recovery Tank Hose | (12) Receiver |
| (6) Recovery Tank | (13) Air Conditioner Hose |
| (7) Window Washer Tank | |

W1248025

Cruise Control Release Wire

1. Disconnect the cruise control release wire (1).

(When reassembling)

- Be sure to adjust the cruise control release wire (1). (See page 3-S95.)

- (1) Cruise Control Release Wire


W1065983

Seat, Seat Bracket and Lever Grips

1. Remove the seat.
2. Disconnect the seat switch connector (3) and remove the seat bracket (1) with seat suspension (7).
3. Remove the lever grips for position control lever (2), front wheel drive lever (6), range gear shift lever (5) and cruise control lever (4).

- | | |
|----------------------------|-----------------------------|
| (1) Seat Bracket | (5) Range Gear Shift Lever |
| (2) Position Control Lever | (6) Front Wheel Drive Lever |
| (3) Seat Switch Connector | (7) Seat Suspension |
| (4) Cruise Control Lever | |

W1066109




3TLABAB3P253A

Electric Connector for HST


1. Remove the lowering speed adjusting knob (4).
2. Disconnect the differential lock rod (2).
3. Disconnect the range gear shift lever sensor connector (3).
4. Disconnect the cruise switch connector (1).
5. Disconnect the HST pedal neutral switch connector (5).
6. Disconnect the ground earth (a).

- | | |
|---|--|
| (1) Cruise Switch Connector | (4) Lowering Speed Adjusting Knob |
| (2) Differential Lock Pedal | (5) HST Pedal Neutral Switch Connector |
| (3) Range Gear Shift Lever Sensor Connector | (a) Ground earth is connected here |

W1066282



3TLABAB3P254A



3TLABAB3P255A

PTO Shift Wire and Electric Connector


1. Disconnect the PTO shift wire (2) at the PTO clutch valve lever (4).
2. Disconnect the traveling speed sensor connector (1).

(When reassembling)

- When connecting the PTO shift wire (2) to the lever (4), be sure to adjust the length of wire as follows.
 1. Set the PTO shift lever to **OFF (Neutral)** position.
 2. Loosen the lock nut (3) of wire, and connect wire to the clutch valve lever (4), and then place the wire to the hook.
 3. Tighten the lock nut (3) clockwise (pull the wire), and lock the nut just before the lever moves.

- | | |
|--------------------------------------|----------------------------|
| (1) Traveling Speed Sensor Connector | (3) Lock Nut |
| (2) PTO Shift Wire | (4) PTO Clutch Valve Lever |

W1066431



3TLABAB3P106A


Step and Floor Seat (ROPS Model)

1. Disconnect the panel frame connector (1) from fuel tank frame.
2. Remove the step and floor seat mounting bolt and nut.
3. Dismount the step, fender, floor seat and panel frame as a unit.

(When reassembling)

- Be sure to set the washers and rubber plates of the floor seat and step mounting bolt at an original positions as shown in figure.

Tightening torque	Step mounting bolt and nut	124 to 147 N·m 12.6 to 15.0 kgf·m 91.1 to 108 ft-lbs
	Floor seat mounting bolt and nut	196 to 225 N·m 20 to 23 kgf·m 145 to 166 ft-lbs



3TLABAB3P107A

- | | |
|---------------------------|----------|
| (1) Panel Frame Connector | (7) Nut |
| (2) Floor Seat | (8) Step |
| (3) Bolt | |
| (4) Rubber Plate | |
| (5) Washer | |
| (6) Spring Washer | |
- F : Front Side**
R : Rear Side

W1252564



Cabin Assembly


1. Remove the outer roof of cabin.
2. Support the cabin with nylon straps (1) and hoists.
3. Loosen and remove the cabin mounting bolts (2) and nuts (9).
4. Dismounting the cabin from tractor body.

NOTE

- Lift the cabin while making sure it does not catch on anything.

(When reassembling)


- Be sure to install the washers and mount rubbers, etc. in their original positions.



Tightening torque	Cabin mounting bolt and nut	124 to 147 N·m 12.6 to 15.0 kgf·m 91.1 to 108 ft-lbs
-------------------	-----------------------------	--

- | | |
|------------------------|-------------------|
| (1) Nylon Straps | (7) Washer |
| (2) Bolt | (8) Spring Washer |
| (3) Plate | (9) Nut |
| (4) Mount Rubber | |
| (5) Collar | |
| (6) Plain Washer (M14) | |
- F : Front Side**
R : Rear Side


W1252841



Hydraulic Pipes

1. Remove the main delivery pipe 1 (5).
2. Disconnect the main delivery pipe 2 (1) at the rear hydraulic block (6) and return pipe (2) at the mid case, and then remove the front hydraulic block (4) with pipes and bracket as a unit.
3. Remove the suction pipe (3) with oil filter (7).
4. Disconnect the oil cooler pipe (8) at the clutch housing.
5. Remove the brake rods (9).


(When reassembling)




Tightening torque	Joint bolt for main delivery pipe 1 to front hydraulic block	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Joint bolt for main delivery pipe 2 to rear hydraulic block	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Cap nut for return pipe to mid case	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Joint bolt for oil cooler pipe	34 to 39 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft-lbs

- | | |
|---------------------------|--------------------------|
| (1) Main Delivery Pipe 2 | (6) Rear Hydraulic Block |
| (2) Return Pipe | (7) Hydraulic Oil Filter |
| (3) Suction Pipe | (8) Oil Cooler Pipe |
| (4) Front Hydraulic Block | (9) Brake Rod |
| (5) Main Delivery Pipe 1 | |

W1067018





Propeller Shaft


1. Slide the propeller shaft cover (4) and (8) after removing the screws (7).
2. Tap out the spring pins (2), (6) and slide the couplings (1), (5) and then remove the propeller shaft with covers (4), (8).

(When reassembling)

- Apply grease to the splines of propeller shaft 1 (3).

- | | |
|---------------------------|---------------------------|
| (1) Coupling | (5) Coupling |
| (2) Spring Pin | (6) Spring Pin |
| (3) Propeller Shaft 1 | (7) Screws |
| (4) Propeller Shaft Cover | (8) Propeller Shaft Cover |

W1254425



Separating Engine and Clutch Housing

1. Place the disassembling stand under the engine and clutch housing case.
2. Remove the fuel tank support mounting screws.
3. Remove the engine and clutch housing mounting screws and nuts.
4. Separate the engine and clutch housing while lifting up the tank frame.




(When reassembling)

- Apply grease to the spline of clutch shaft.
- Apply liquid gasket (Three Bond 1211 or equivalent) to joint face of the flywheel housing and clutch housing.



Tightening torque	Engine and clutch housing mounting screw and nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Engine and clutch housing mounting stud bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs

W1067479



HST Linkage and Hydraulic Pipes

1. Disconnect the HST control rod (1) with the control lever (2).
2. Remove the charge delivery pipe 1 (3).
3. Remove the joint bolt (4) and disconnect the charge delivery pipe 2 (5) at the HST side.

(When reassembling)

- Be sure to adjust the HST neutral position. (See page 3-S92.)
- Install the copper washer securely.

Tightening torque	HST control lever setting hex. head screw	6.86 to 8.33 N·m 0.70 to 0.85 kgf·m 5.06 to 6.15 ft-lbs
	Joint bolt for charge delivery pipes to filter bracket	39 to 49 N·m 4.0 to 5.0 kgf·m 28.9 to 36.1 ft-lbs
	Cap nut for charge delivery pipe	49 to 59 N·m 5.0 to 6.0 kgf·m 36.1 to 43.4 ft-lbs

- (1) HST Control Rod
 (2) HST Control Lever
 (3) Charge Delivery Pipe 1

- (4) Joint Bolt
 (5) Charge Delivery Pipe 2

W1067625

Separating Clutch Housing and Mid Case


1. Remove the clutch housing and mid case mounting screws and nuts.
2. Separate the clutch housing (1) and mid case (2).

(When reassembling)

- Be sure to install the gasket.
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the clutch housing and mid case.

Tightening torque	Clutch housing and mid case mounting nut	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Clutch housing and mid case mounting screw	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Clutch housing and mid case mounting stud bolt	38.2 to 45.1 N·m 3.9 to 4.6 kgf·m 28.2 to 33.3 ft-lbs

W10679060



Clutch Lever, Release Fork and Release Bearing

1. Remove the release fork mounting screws (2).
2. Draw out the clutch lever (3) to remove the release fork (1).
3. Remove the release bearing and release hub (4) together.


(When reassembling)

- Apply grease to the sliding surface of the clutch release hub.
- Apply grease to the clutch lever.

Tightening torque	Release fork mounting screw	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft·lbs
-------------------	-----------------------------	---

- (1) Release Fork (3) Clutch Lever
(2) Release Fork Mounting Screw (4) Release Hub

W12561710



Shaft Case, Input Shaft, Gear and Front Axle Drive Shaft

1. Remove the shaft case mounting screws.
2. Screw down the two M6 screws into the shaft case (4) and pull it out.
3. Take out the shaft case (4).
4. Take out the 23T (24T) gear shaft (3).
5. Take out the 27T (26T) gear (2).
6. Pull out the front axle drive shaft (1) to the rear side.

(When reassembling)

- Be sure to install the gasket.


(When replacing oil seal in shaft case)

- Install the oil seal (5) as shown in the figure, noting its direction.
- Apply grease to the oil seal (5).
- Install the front axle drive, shaft (1) from front side after assembling the clutch housing case (HST unit) and mid case. Then install the bearing (8), sleeve (9), oil seal (7), collar (10) and internal snap ring (6) in order.


- (1) Front Axle Drive Shaft (5) Oil Seal
(2) 27T Gear (6) Internal Snap Ring
(L3130, L3430, L3830, L4630) (7) Oil Seal
26T Gear (L4330, L5030) (8) Bearing
(3) 23T Gear Shaft (9) Sleeve
(L3130, L3430, L3830, L4630) 24T Gear Shaft (L4330, L5030) (10) Collar
(4) Shaft Case

F : Front Side


W10682690



3TMABAB3P008C



3TLABAB3P119C




HST Servo Pipe (Bypass Pipe)

1. Remove the servo pipe (1).

- (1) Servo Pipe (3) HST Servo Regulator
(2) UST Unit (Clutch Housing)

W1257288



Port Block

1. Remove the port block mounting hex. head screws.
2. Pull and remove the port block (1) from the HST housing.

(When reassembling)

- Install port block with O-ring (5), valve plates and gasket in place.



■ IMPORTANT

- **Valve plates (2), (3) may stick to the port block but they are not fixed. Take care not to drop them.**
- **And these valve plates are not interchangeable**

Tightening torque	Port block mounting hex. head screw	98 to 123 N·m 10 to 12.5 kgf·m 72.3 to 90.4 ft-lbs
-------------------	-------------------------------------	--

- | | |
|--------------------------|------------|
| (1) Port Block | (4) Gasket |
| (2) Valve Plate of Pump | (5) O-ring |
| (3) Valve Plate of Motor | |

W1018180



Cylinder Block Assemblies

1. Remove both motor and pump cylinders (1), (2) with pistons.
- (When reassembling)**


- Apply clean hydrostatic transmission oil to cylinder blocks.

■ NOTE

- **Take care not to damage the surface of cylinder blocks and pistons.**
- **Do not interchange pistons between pump and motor cylinder block.**

- | | |
|--------------------------|-------------------------|
| (1) Motor Cylinder Block | (2) Pump Cylinder Block |
|--------------------------|-------------------------|

W1018501



Motor Shaft

1. Remove the motor swashplate setting hex. head screw (1).
2. Remove the motor swashplate (3) and motor shaft (4).


(When reassembling)


- Be sure to install the thrust plate to swashplate (3).
- When installing the swashplate to clutch housing (HST body), be sure to align the hole (2) of swashplate and straight pin (5).
- Apply clean transmission oil to the thrust plate.

Tightening torque	Swashplate setting hex. head screw	28 to 35 N·m 2.9 to 3.6 kgf·m 21 to 26 ft-lbs
-------------------	------------------------------------	---

- | | |
|----------------------|------------------|
| (1) Hex. Head Screw | (4) Motor Shaft |
| (2) Hole | (5) Straight Pin |
| (3) Motor Swashplate | |

W1069209





Swashplate and Pump Shaft

1. Remove the swashplate (1).
2. Remove the cradle bearing bracket mounting hex. head screws (6).
3. Tap the pump shaft (3) with a plastic hammer slightly to slide out it with cradle bearing bracket (5) to the rear side.




(When reassembling)

- Place the swashplate (1) into the housing, align the slot guide (4) of swashplate and groove (2) of servo piston.
- Apply clean transmission oil to the surface of swashplate and cradle bearing.

Tightening torque	Cradle bearing bracket mounting hex. head screw	28 to 35 N·m 2.9 to 3.6 kgf·m 21 to 26 ft-lbs
-------------------	---	---

- | | |
|----------------|----------------------------|
| (1) Swashplate | (4) Slot Guide |
| (2) Groove | (5) Cradle Bearing Bracket |
| (3) Pump Shaft | (6) Hex. Head Screw |

W1018971



Charge Pump

1. Remove the charge pump mounting hex. head screws, and remove the charge pump cover (3).
2. Tap out the rotors (1), (2) with soft hummer slightly, and take out the rotors.

(When reassembling)


■ **NOTE**


- **Align the each alignment mark of rotors.**
- **Alignment mark should be rear side.**

Tightening torque	Charge pump case mounting screw	28 to 35 N·m 2.9 to 3.6 kgf·m 21 to 26 ft-lbs
-------------------	---------------------------------	---

- | | |
|-----------------|-----------------------|
| (1) Inner Rotor | (3) Charge Pump Cover |
| (2) Outer Rotor | (4) Alignment Mark |

W1017976





Charge Relief Valve

1. Remove the hex. head plug (1).
2. Remove the spring guide (3), shim (2), spring (4) and valve poppet (5).

(When reassembling)


■ **NOTE**

- Install valve component, noting the number of shims (2) in the charge relief valve.
- Take care not to damage the O-ring.
- When replacing the valves, check and adjust the setting pressure. (Refer to page 3-S91.)

Tightening torque	Hex. head plug	30 to 37 N·m 3.1 to 3.8 kgf·m 22.4 to 27.5 ft-lbs
-------------------	----------------	---

- | | |
|--------------------|------------------|
| (1) Hex. Head Plug | (4) Spring |
| (2) Shim | (5) Valve Poppet |
| (3) Spring Guide | |

W1019266



Check and High Pressure Relief Valve

1. Remove the hex. head plug (1) and remove the spring (2) and relief valve assembly (3), (4).


(When reassembling)

- Take care not to damage the O-ring on the plug.

Tightening torque	Hex. head plug	54 to 68 N·m 5.5 to 7.0 kgf·m 39.8 to 50.6 ft-lbs
-------------------	----------------	---

- | | |
|---|---|
| (1) Plug | (4) Check and High Pressure Relief Valve Assembly (Reverse) |
| (2) Spring | |
| (3) Check and High Pressure Relief Valve Assembly (Forward) | |

W1018316



Servo Regulator Assembly

1. Remove the regulator mounting hex. head screw.
2. Remove the servo regulator assembly (1).

(When reassembling)

- Place a new gasket on the housing.
- Install the servo regulator assembly to the housing, align the feedback lever (2) of regulator and groove of servo piston.


■ **NOTE**

- Do not disassemble the regulator assembly, since it has been factory-adjusted.

Tightening torque	Regulator mounting hex. head screw	6.9 to 8.3 N·m 0.7 to 0.85 kgf·m 5.1 to 6.1 ft-lbs
-------------------	------------------------------------	--

- | | |
|------------------------------|--------------------|
| (1) Servo Regulator Assembly | (2) Feedback Lever |
|------------------------------|--------------------|

W1019454



3TLABAB3P277A



3TLABAB3P278A

Servo Piston Assembly

1. Remove the servo piston under cover (1).
2. Remove the servo piston assembly mounting hex. head screw.
3. Push the piston from bottom side slightly and pull out the servo piston assembly (2).

(When reassembling)

■ **NOTE**


- Take care not to do damage the surface of servo piston.
- Do not disassemble the servo piston assembly, since it has been factory-adjusted.

Tightening torque	Servo piston and cover mounting hex. head screw	28 to 35 N·m 2.9 to 3.6 kgf·m 21 to 26 ft·lbs
-------------------	---	---

(1) Servo Piston Under Cover





(2) Servo Piston Assembly

W1019685



(B) Mid Case**NOTE**

- For the disassembling procedure from "Draining the Transmission Fluid" to "Step and Floor Seat" or "Cabin Assembly", refer to page 3-S95 to 3-S101.

**Hydraulic Pipes**

- Remove the HST control rod (4).
- Remove the brake rods (2), (13).
- Remove the main delivery pipe 1 (6).
- Disconnect the main delivery pipe 2 (1) at the rear hydraulic block (9) and return pipe (3) at the mid case, and then remove the front hydraulic block (8) with pipes and bracket as a unit.
- Remove the suction pipes (7) with oil filter (11).
- Remove the charge delivery pipe 1 (12).
- Remove the charge delivery pipe 2 (10).

(When reassembling)


- Install the copper washer securely.

Tightening torque	Joint bolt for main delivery pipe 1 to front hydraulic block	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Joint bolt for main delivery pipe 2 to rear hydraulic block	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Cap nut for return pipe to mid case	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft-lbs
	Joint bolt for charge delivery pipes to filter bracket	39 to 49 N·m 4.0 to 5.0 kgf·m 28.9 to 36.1 ft-lbs
	Joint bolt for charge delivery pipe 2 to PTO clutch valve	34 to 39 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft-lbs
	Cap nut for charge delivery pipes	49 to 59 N·m 5.0 to 6.0 kgf·m 36.1 to 43.4 ft-lbs

- Main Delivery Pipe 2
- Brake Rod RH
- Return Pipe
- HST Control Rod
- HST Control Lever
- Main Delivery Pipe 1
- Suction Pipe

- Front Hydraulic Block
- Rear Hydraulic Block
- Charge Delivery Pipe 2
- Oil Filter
- Charge Delivery Pipe 1
- Brake Rod LH

W1071129



HST Linkages


1. Remove the cruise adjusting rod (3).
2. Disconnect the neutral rod (5) from connecting shaft (2).
3. Disconnect the damper (6) from neutral holder arm (9).
4. Remove the neutral rod (5), neutral holder (9) and neutral holder arm (10) as a unit.
5. Disconnect the cruise spring (8), and remove the damper stay (7) with damper (6).
6. Remove the cruise release wire (1).

(When reassembling)

- When installing the cruise wire (1) to the damper bracket (7) set the lock nuts (4) so that the threaded position of wire (1) becomes end.
- Be sure to check the cruise wire releasing. (See page 3-S95.)
- Be sure to adjust the HST neutral position. (See page 3-S92.)

- | | |
|--------------------------|-------------------------|
| (1) Cruise Release Wire | (6) Damper |
| (2) Connecting Shaft | (7) Damper Stay |
| (3) Cruise Adjusting Rod | (8) Cruise Spring |
| (4) Lock Nut | (9) Neutral Holder |
| (5) Neutral Rod | (10) Neutral Holder Arm |

W1260145



Separating Mid Case and Transmission Case

1. Separate the mid case and transmission case after removing their mounting screws.

(When reassembling)

- Confirm to insert the PTO shaft to PTO clutch firmly, turning the PTO shaft.
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the mid case and transmission case.



Tightening torque	Mid case and transmission case mounting screw	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Mid case and transmission case mounting nut	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Mid case and transmission case mounting stud bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs


W1071622

Separating Mid Case

1. Separate the mid case from the clutch housing after removing their mounting screws.


(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of clutch housing and mid case.
- Be sure to install the gasket.



Tightening torque	Clutch housing and mid case mounting screw	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Clutch housing and mid case mounting nut	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Clutch housing and mid case mounting stud bolt	38.2 to 45.1 N·m 3.9 to 4.6 kgf·m 28.2 to 33.3 ft-lbs

W1071785



PTO Clutch Valve

1. Remove the PTO clutch valve (2) as a unit.
2. Pull out the pipe (1).


(When reassembling)

- Apply small amount of grease for the O-ring (3).
- Install the pipe (1) to the hole (4) of the PTO clutch valve (2) firmly.
- Replace the pipe (1) with new one.

Tightening torque	PTO clutch valve mounting screw	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft·lbs
-------------------	---------------------------------	---

- (1) Pipe (3) O-ring
(2) PTO Clutch Valve (4) Hole

W1260974



Mid Case Bearing Holder with Gears

1. Remove the mid case bearing holder 1 (5).
2. Take out the gear shafts (4), (8), (7), (6).
3. Remove the PTO drive shaft (1).
4. Remove the mid case bearing holder 2 (2) with PTO clutch (10).

(When reassembling)

- Tap in the mid case bearing holder (2), (5) with plastic hammer until contact to mid case, and then tighten the screws to specified torque.

Tightening torque	Mid case bearing holder mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft·lbs
-------------------	--	---

- (1) PTO Drive Shaft (6) 25T Gear Shaft
(2) Mid Case Bearing Holder 2 (7) 15T Gear Shaft
(3) Mid Case (8) 22T Gear Shaft
(4) 21T Gear Shaft (9) PTO Clutch Valve
(5) Mid Case Bearing Holder 1 (10) PTO Clutch

W1072101

Disassembling PTO Clutch

1. See page 3-S31, S32.

W1294451

(C) Transmission Case

NOTE

- For the disassembling procedure from “Draining the Transmission Fluid” to “Step and Floor Seat” or “Cabin Assembly”, refer to page 3-S95 to 3-S101.







Rear Wheel

1. Place disassembling stand under the transmission case, and support it with a jack.
2. Remove the rear wheels.
3. After removing the rear wheels, support it at both sides of rear axle by stands.

(When reassembling)

Tightening torque	Rear wheel mounting screw and nut	215 N·m 22 kgf·m 160 ft·lbs
	Rear wheel mounting stud bolt	98.1 to 112.8 N·m 10.0 to 11.5 kgf·m 72.3 to 83.2 ft·lbs

W1261766



ROPS, 3 Point Linkages, Hydraulic Cylinders and Others

1. Remove the top link.
2. Remove the lift rods (2), lower links (6) and stabilizers (1) as a unit.
3. Remove the ROPS lower frames (3). (ROPS Model only)
4. Remove the PTO shaft cover (5).
5. Remove the drawbar frame (7).
6. Disconnect the hydraulic cylinder hoses (8) and return hoses (10) at the rear hydraulic block (9).
7. Remove the two pins and remove the hydraulic cylinders (4).
8. Disconnect the brake rods.


(When reassembling)

- Apply grease to the lower link pins and hydraulic cylinder pins.

Tightening torque	
Lift arm pin mounting nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
Lift arm pin lock nut	62.8 to 72.6 N·m 6.4 to 7.4 kgf·m 46.3 to 53.5 ft-lbs
Drawbar frame mounting screw (M12)	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
Drawbar frame mounting screw (M14)	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft-lbs
Hydraulic cylinder hose	34.3 to 48.1 N·m 3.5 to 4.9 kgf·m 25.3 to 35.4 ft-lbs
ROPS lower frame mounting screw	167 to 196 N·m 17.0 to 20.0 kgf·m 123 to 145 ft-lbs

- | | |
|---|--|
| <ul style="list-style-type: none"> (1) Stabilizer (2) Lift Rod (3) ROPS Lower Frame (4) Hydraulic Cylinder (5) PTO Shaft Cover (6) Lower Link (7) Drawbar Frame (8) Hydraulic Cylinder Hose | <ul style="list-style-type: none"> (9) Rear Hydraulic Block (10) Return Hose (11) Screw (M14 × 155) (12) Screw (M14 × 30) <p>A : ROPS Model
 B : CABIN Model
 C : L3130, L3430
 D : L3830, L4330, L4630, L5030</p> |
|---|--|

W1261978



Hydraulic Pipes

1. Remove the brake rods (1).
2. Remove the charge delivery pipe 2 (2).
3. Remove the joint bolt (3) for main delivery pipe 2.


(When reassembling)

- Install the copper washer securely.

Tightening torque	Joint bolt for main delivery pipe 2 to rear hydraulic block	49 to 69 N·m 5.0 to 7.0 kgf·m 36.1 to 50.6 ft·lbs
	Joint bolt for charge delivery pipe 2 to filter bracket	39 to 49 N·m 4.0 to 5.0 kgf·m 28.9 to 36.1 ft·lbs
	Joint bolt for charge delivery pipe 2 to PTO clutch valve	34 to 39 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft·lbs

- (1) Brake Rod (3) Joint Bolt for Main Delivery Pipe 2
 (2) Charge Delivery Pipe 2

W1073148



HST Linkages


1. Remove the cruise adjusting rod (3).
2. Disconnect the neutral rod (5) from connecting shaft (2).
3. Disconnect the damper (6) from neutral holder arm (9).
4. Remove the neutral rod (5), neutral holder (9) and neutral holder arm (10) as a unit.
5. Disconnect the cruise spring (8), and remove the damper stay (7) with damper (6).
6. Remove the cruise release wire (1).


(When reassembling)

- When installing the cruise wire (1) to the damper bracket (7) set the lock nuts (4) so that the threaded position of wire (1) becomes end.
- Be sure to check the cruise wire releasing. (See page 3-S95.)
- Be sure to adjust the HST neutral position. (See page 3-S92.)

- (1) Cruise Release Wire (6) Damper
 (2) Connecting Shaft (7) Damper Stay
 (3) Cruise Adjusting Rod (8) Cruise Spring
 (4) Lock Nut (9) Neutral Holder
 (5) Neutral Rod (10) Neutral Holder Arm

W1263843





Cruise Linkage, Rear Hydraulic Block and Lift Arm Bracket



1. Remove the cruise lever rod (7) and release spring (8).
2. Remove the cruise assembly mounting screws (Three screws) and remove the cruise assembly (1).
3. Remove the range gear shift lever rod and remove the range gear shift lever sensor (2) with stay.
4. Remove the external snap ring and remove the range gear shift lever (5) and cruise control lever (4).
5. Remove the rear hydraulic block (3), cover and lift arm support (6) as a unit.

(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the differential case and cover.
- Be sure to check cruise lever operation force and cruise control linkage. (See page 3-S93.)

- | | |
|-----------------------------------|----------------------------|
| (1) Cruise Assembly | (5) Range Gear Shift Lever |
| (2) Range Gear Shift Lever Sensor | (6) Lift Arm Support |
| (3) Rear Hydraulic Block | (7) Cruise Lever Rod |
| (4) Cruise Control Lever | (8) Return Spring |

W1264120



Mid PTO Case (If equipped)

1. Remove the mid PTO lever (1).
2. Remove the mid PTO gear case assembly (3) with lever rod (2).

(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the mid PTO case and transmission case.

- | | |
|-------------------|-----------------------|
| (1) Mid PTO Lever | (3) Mid PTO Gear Case |
| (2) Lever Rod | |

W1266062



Rear Axle

1. Separate the rear axle case from brake case.

(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the rear axle and brake case.

Tightening torque	Rear axle case mounting screw and nut	M10 screw and nut (7T)	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft-lbs
		Stud bolt	24.5 to 31.4 N·m 2.5 to 3.2 kgf·m 18.1 to 23.1 ft-lbs
		M10 nut (9T) (Except L3130, L3430)	60.8 to 70.6 N·m 6.2 to 7.2 kgf·m 44.9 to 52.1 ft-lbs
		M12 screw (Except L3130, L3430)	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs

W1266378



3TLABAB3P140A

Brake Case


1. Remove the range gear shift lever and its fulcrum screw.
2. Remove the brake case mounting screws and nuts.
3. Separate the brake case, tapping the brake case lever lightly.

(When reassembling)

- Apply grease to the steel ball seats. (Do not grease excessively.)
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the brake case and transmission case.
- Be sure to apply liquid gasket to A position.
- Be sure to fix the brake cam and cam plate.
- Before installing the brake case to the transmission case, install the cam plate to the transmission case.

Tightening torque	Brake case mounting stud bolt	29.4 to 49.0 N·m 3.0 to 5.0 kgf·m 21.7 to 36.1 ft-lbs
	Brake case mounting screw and nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Lever fulcrum screw	62.8 to 72.5 N·m 6.4 to 7.4 kgf·m 46.3 to 53.5 t-lbs

W12666170



3TLABAB3P287A

Separating Mid Case and Transmission Case


1. Separate the mid case and transmission case after removing their mounting screws and nut.

(When reassembling)

- Confirm to insert the PTO shaft to PTO clutch firmly, turning the PTO shaft.
- Confirm to insert the front wheel drive shaft to coupling firmly.
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the mid case and transmission case.

Tightening torque	Mid case and transmission case mounting screw	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Mid case and transmission case mounting nut	102.9 to 117.6 N·m 10.5 to 12.0 kgf·m 75.9 to 86.8 ft-lbs
	Mid case and transmission case mounting stud bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs

W1073847



3TLABAB3P288A

Pinion Bearing Cover

1. Remove the stake of lock nut (5).
2. Lock the turning of spiral bevel pinion and remove the lock nut (5).
3. Remove the pinion bearing case mounting screws.
4. Take out the pinion bearing cover (4) and shims (1).


(When reassembling)

- Make sure of the number of shims in the pinion bearing case.
- Replace the lock nut (5) with a new one, and stake the lock nut firmly after installing the parts on the shaft.

Tightening torque	Lock nut	147 to 196 N·m 15 to 20 kgf·m 108 to 145 ft-lbs
	Pinion bearing case mounting screw	39.2 to 44.1 N·m 4.0 to 4.5 kgf·m 28.9 to 32.5 ft-lbs

- (1) Shim
- (2) Pinion Bearing Case
- (3) Spiral Bevel Pinion Shaft
- (4) Pinion Bearing Cover
- (5) Lock Nut

W1267146



3TLABAB3P289A

Transmission Bearing Holder

1. Remove the transmission bearing holder mounting screws.
2. Tap out the spring pin (8) on the shift fork rod (3).
3. Jack up the bearing holder (1) by using the two jack screws (5) until the taper roller bearing (7) can be removed.

NOTE

- Jack up the bearing holder while hitting the two shafts (2) (4) by copper hammer or soft hammer.

4. Jack up more and remove the transmission bearing holder (1).


(When reassembling)

- Tap in the transmission bearing holder with soft hammer until contact to transmission case, and then tighten the screws to specified torque.
- Tap in the spring pin (8) so that its split portion may face forward. (Refer to figure.)


Tightening torque	Transmission bearing holder mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.5 to 41.2 ft-lbs
-------------------	--	---

- (1) Transmission Bearing Holder
- (2) Spiral Bevel Pinion Shaft
- (3) Shift Fork Rod for Range Gear Shift
- (4) PTO Drive Shaft
- (5) Jack Screw
- (6) Pinion Bearing Case
- (7) Taper Roller Bearing
- (8) Spring Pin
- (9) Range Gear Shaft
- (10) Front Wheel Drive Shaft


W1267434




3TLABAB3P144A




3TLABAB3P290A




3TLABAB3P146A



3TLABAB3P291A



3TLABAB3P292A



3TLABAB3P293A

Shaft Assemblies



1. Remove the traveling speed sensor (1).
2. Take out the spiral bevel pinion shaft assembly (4) with shift fork (6), range gear shaft assembly (5) and PTO drive shaft assembly (3).
3. Take out the front wheel drive shaft (2).

(When reassembling)

- Apply transmission fluid to needle bearings (12).

- | | |
|-------------------------------|--|
| (1) Traveling Speed Sensor | (11) 18T Gear (L3130, L3430, L4330, L4630) |
| (2) Front Wheel Drive Shaft | 17T Gear (L3830, L5030) |
| (3) PTO Drive Shaft | (12) Needle Bearing |
| (4) Spiral Bevel Pinion Shaft | (13) 27T Gear |
| (5) Range Gear Shaft | (14) 29T Gear (L3130, L3430) |
| (6) Shift Fork | 29T-31T Gear (L3830) |
| (7) 49T Gear | 29T-30T Gear (L4330, L4630) |
| (8) 32T Shifter Gear | 29T-32T Gear (L5030) |
| (9) Spline Boss | (15) 24T Shifter Gear |
| (10) 18T Gear | (16) 26T-60T Gear |

W1268230



Differential Lock Shift Fork

1. Tap out the left side spring pin (4).
2. Remove the cotter pin and take out the clevis pin (3).
3. Draw out the differential lock fork shaft (1) and take out the differential lock shift fork (2).


(When reassembling)

- Apply grease to the left and right oil seals on the transmission case.
- Insert the clevis pin (3) from the top and install the washer and cotter pin.
- Tap in the spring pin (4) so that its split portion **a** may face outward as shown in the figure.

- (1) Differential Lock Fork Shaft
- (2) Differential Lock Shift Fork
- (3) Clevis Pin
- (4) Spring Pin

a : Split Portion

W10744620




PTO Shaft

1. Remove the PTO shaft cover.
2. Remove the bearing case mounting screws, and draw out the PTO shaft (1) with bearing case (2).
3. Remove the internal snap ring (3).
4. Top out the PTO shaft (1) to the front.

(When reassembling)



- If the lock nut (6) was removed, replace it with a new one. After replacing, be sure to stake it firmly.
- Install the slinger (7) firmly.
- Apply grease to the oil seal (4) and install it, noting its direction.



Tightening torque	Lock nut	147 to 196 N·m 15 to 20 kgf·m 108 to 145 ft·lbs
	Bearing case mounting screw	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft·lbs

- (1) PTO Shaft
- (2) Bearing Case
- (3) Internal Snap Ring
- (4) Oil Seal
- (5) Oil Seal Collar
- (6) Lock Nut
- (7) Slinger

- [A] L3130, L3430
- [B] L3830, L4330, L4630
- [C] L5030



Differential Gear Assembly

1. Remove the differential support, noting the number of left shims.
2. Take out the differential gear assembly, noting the number of right shims.

(When reassembling)

- Check the spiral bevel gear for wear or damage. If it is no longer serviceable, replace it. Then, also replace the spiral bevel pinion.
- Use same number of shims as before disassembling.

Tightening torque	Differential support mounting screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft·lbs
-------------------	-------------------------------------	---

W10750520

(3) Servicing

(A) Bearing, Gear and Shaft

See page 3-S41.


(B) PTO Clutch

See page 3-S43.

(C) Differential Gears

See page 3-S44 to 3-S46.

(D) HST




Charge Pump

1. Check the charge pump housing and the rotor (1), (2) for scratches and wear.
2. If scratch or worn, replace the charge pump complete assembly.

- (1) Inner Rotor
- (2) Outer Rotor
- (3) Pump Cover

W1025956




Pump Shaft and Motor Shaft

1. Check the seal surface (4) and the bearing surface (3).
2. If the shaft is rough or groove, replace it.

- (1) Motor Shaft
- (2) Pump Shaft
- (3) Bearing Surface
- (4) Seal Surface

W1026037



Cylinder Block Bore and Pistons


1. Lift the pistons gently with the retainer plate (1).
2. Check the pistons for their free movement in the cylinder block bores.
3. If the piston or the cylinder block bore is scored, replace cylinder block assembly.

■ IMPORTANT

- **Do not interchange pistons between pump and motor cylinder block.**

- (1) Retainer Plate
- (2) Piston
- (3) Cylinder Block

W1026142



Piston Slipper


1. Check the slipper (1) for flatness.
2. If rounded, replace.
3. Measure the thickness of piston slipper.
4. If the measurement is less than the allowable limit, replace.
5. Check the lubricant hole (2) for clogging.

■ IMPORTANT

- **Do not interchange pistons between pump and motor cylinder block.**

- (1) Piston Slipper
- (2) Lubricant Hole

W1026561




Cylinder Block Face

1. Check the polished face (1) of cylinder block for scoring.
2. If scored, replace cylinder block assembly.
3. Check the spring (2) for breakage.
4. If broken, replace cylinder block assembly.

(1) Polished Face

(2) Spring

W1026700



Valve Plate

1. Check the engagement of the valve plate (2), (3) and the anchor pin (1).
2. Pushing the valve plate against the anchor pin, lift it to remove.
3. Check the valve plate for foreign particles.
4. Clean the valve plate and dry with compressed air.
5. Check the valve plate for scratches, wear and erosion. (Run a finger nail across the valve plate surface. If worn, it will be felt.)
6. If worn or scored, replace.

NOTE


- After checking, coat them with transmission oil.
- Valve plates are not interchangeable.

(1) Anchor Pin

(3) Valve Plate (Motor)

(2) Valve Plate (Pump)

W1026799



Thrust Plate, Swashplate and Cradle Bearing

1. Check the thrust plate (1) for scratches and excessive wear.
2. If worn or scored, replace
3. Check the piston contact face of swashplate (2) for scratched and excessive wear and check the holes (3) of swashplate (2) for clogged.
4. If worn or scored, replace and if holes are clogged, clean them.
5. Check the surface of cradle bearings (4) for scratches and excessive wear.
6. If worn or scored, replace.

(1) Thrust Plate



(4) Cradle Bearing

(2) Swashplate

(5) Cradle Bearing Bracket

(3) Hole

W1026952



Oil Seals and Bearing for Shaft

1. Remove the internal snap ring and check the oil seals (2) for damage.
2. Check the bearings (1) for wear.
3. If the bearings are worn, replace.


NOTE

- After checking, coat the bearing with transmission oil and the oil seal lip with grease.

(1) Needle Bearing

(2) Oil Seal


W1027176



Check and High Pressure Relief Valve

1. Check the valve plug (1) and valve (3), (4) for scratches and damage.
2. Check the valve seat in the port block for damage.
3. Check the spring (2) for breakage and wear.
4. If anything unusual, replace the check and high pressure relief valve assembly.

- (1) Valve Plug
- (2) Spring
- (3) Check and High Pressure Relief Valve Assembly (Forward)
- (4) Check and High Pressure Relief Valve Assembly (Reverse)




Charge Relief Valve

1. Check the spring guide (3), spring (2) and valve poppet (1) for scratches, breakage and damage.
2. If anything unusual, replace.

NOTE

- When re-installing the charge relief valve, never change the number of shims.
- If replace with new one, be sure to check and adjust the setting pressure. (See page 3-S91.)

- (1) Valve Poppet
- (2) Spring
- (3) Spring Guide
- (4) Plug for Charge Relief Valve



Servo Piston

1. Check the surface of servo piston for scratches and excessive wear.
2. If worn or scored, replace the servo piston assembly.

- (1) Servo Piston Assembly

4 REAR AXLE


MECHANISM

CONTENTS

1. STRUCTURE	4-M1
--------------------	------

1. STRUCTURE

[L3130, L3430, L3830, L4330, L4630]



3TLABAB4P001A


- | | | | |
|--------------------|-----------------------------|-------------------------|--------------------------------|
| (1) Ball Bearing | (4) Differential Gear Shaft | (7) Differential Pinion | (10) Differential Lock Shifter |
| (2) Rear Axle | (5) Brake Case | (8) Ring Gear | (11) Differential Case |
| (3) Rear Axle Case | (6) Brake Disc | (9) Final Gear | (12) Differential Side Gear |

The final gear (9) are final reduction mechanism which further reduces the speed of rotation. The direction of power transmitted is changed by the differential gear.

The rear axles (2) are the final transmission mechanism which transmit the power from the transmission to the rear wheels. The rotation speed is reduced by the final gears (5).

The rear axles are the semi-floating type with the ball bearing (1) between the rear axle (2) and rear axle case (3), which support the rear wheel load besides transmitting power to the rear wheel. The rear axles also support the weight of the tractor.

[L5030]



3TLABAB4P002A

- | | | | |
|---------------------|-----------------------------|-------------------------|--------------------------------|
| (1) Rear Axle Cover | (5) Differential Gear Shaft | (8) Differential Pinion | (11) Differential Lock Shifter |
| (2) Ball Bearing | (6) Brake Case | (9) Ring Gear | (12) Differential Case |
| (3) Rear Axle | (7) Brake Disc | (10) Final Gear | (13) Differential Side Gear |
| (4) Rear Axle Case | | | |

SERVICING

CONTENTS

1. TROUBLESHOOTING	4-S1
2. TIGHTENING TORQUES	4-S2
3. CHECKING, DISASSEMBLING AND SERVICING.....	4-S3
[1] DISASSEMBLING AND ASSEMBLING.....	4-S3
(1) Separating Rear Axle Case from Brake Case	4-S3
(2) Disassembling Rear Axle	4-S6

1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
Excessive or Unusual Noise at All Time	<ul style="list-style-type: none"> Improper backlash between differential gear shaft and final gear Bearing worn Insufficient or improper type of transmission fluid used 	Replace Replace Replenish or change	4-S6 — G-7, 8
Noise while Turning	<ul style="list-style-type: none"> Differential gear shaft and final gear worn or damaged 	Replace	4-S6

W10122140

2. TIGHTENING TORQUES

Tightening torques of screws and nuts on the table below are especially specified.
(For general use screws and nuts : See page G-9.)


Item	N·m	kgf·m	ft-lbs
Rear wheel mounting screw and nut	215	22	160
Rear wheel mounting stud bolt	98.1 to 112.8	10.0 to 11.5	72.3 to 83.2
ROPS lower frame mounting screw	166.7 to 196.1	17 to 20	123 to 144
Cabin mounting bolt and nut	124 to 147	13.0 to 15.0	91.0 to 108.0
Cabin mount bracket mounting screw	166.7 to 196.1	17 to 20	123 to 144
Rear axle case mounting screw (M10)	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2
Rear axle case mounting nut (M10, 9T)	60.8 to 70.5	6.2 to 7.2	44.9 to 52.1
Rear axle case mounting screw (M12)	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Rear axle case mounting stud bolt	24.5 to 31.4	2.5 to 3.2	18.1 to 23.1
Rear axle lock nut	196 to 245	20 to 25	145 to 181

W10127360

3. CHECKING, DISASSEMBLING AND SERVICING

[1] DISASSEMBLING AND ASSEMBLING

(1) Separating Rear Axle Case from Brake Case




Draining the Transmission Fluid

1. Place oil pans underneath the transmission case.
2. Remove the drain plugs (1).
3. Drain the transmission fluid.
4. Reinstall the drain plugs (1).

(When refilling)

- Fill up from filling port after removing the filling plug (2) until reaching the upper notch on the dipstick (3).
- After running the engine for few minutes, stop it and check the oil level again, add the fluid to prescribed level if it is not correct level.



Transmission fluid capacity	L3130	42 L
	L3430	11.1 U.S.gals. 9.2 Imp.gals.
	L3830	43 L
	L4330	11.4 U.S.gals.
	L4630	9.5 Imp.gals.
	L5030	45 L 11.9 U.S.gals. 9.9 Imp.gals.

■ IMPORTANT

- Use only KUBOTA SUPER UDT fluid. Use of other oils may damage the transmission or hydraulic system. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7, 8.)
- Do not mix different brands of fluid together.


- (1) Drain Plugs
- (2) Filling Plug
- (3) Dipstick



(A) Oil level is acceptable within this range.

W1012666

Tightening torque	Part	Value
	Rear wheel mounting nut	218 N·m 160 ft-lbs
	Rear wheel mounting bolt	98.1 to 113.8 N·m 7.2 to 8.5 kgf·m
	Cabin mounting nut and nut	134 to 147 N·m 10.0 to 11.0 kgf·m

- (1) Top Link
- (2) Lift Rod
- (3) Lower Link
- (4) Stabilizer
- (5) Block of Wood
- (6) Lift Arm
- (7) Cabin Mount Bracket
- (8) Bolt (M14 × 90)
- (9) Spring Washer
- (10) Pin Washer
- (11) Plate
- (12) Mount Rubber
- (13) Collar
- (14) Nut





Rear Wheel and ROPS (ROPS Model)

1. Place the disassembling stand under the transmission case.
2. Remove the rear wheel mounting screws and nuts.
3. Remove the rear wheels.
4. Remove the top link (2) and lift rod (4).
5. Disconnect the stabilizer (6) and remove the lower link (5).
6. Remove the ROPS lower frame mounting screws (7), (8).
7. Dismount the ROPS assembly (1), (3).

(When reassembling)



Tightening torque	Rear wheel mounting screw and nut	215 N·m 22 kgf·m 160 ft·lbs
	Rear wheel mounting stud bolt	98.1 to 112.8 N·m 10.0 to 11.5 kgf·m 72.3 to 83.2 ft·lbs
	ROPS lower frame mounting screw	166.7 to 196.1 N·m 17 to 20 kgf·m 123 to 144 ft·lbs

- (1) ROPS Upper Frame
- (2) Top Link
- (3) ROPS Lower Frame
- (4) Lift Rod
- (5) Lower Link
- (6) Stabilizer

- (7) Screw (M14 × 155)
- (8) Screw (M14 × 30)

A : L3130, L3430
B : L3830, L4330, L4630, L5030

W10110430



Rear Wheel and Cabin Mount Screw (Cabin Model)

1. Place the disassembling stand under the transmission case.
2. Remove the rear wheel mounting screws and nuts.
3. Remove the rear wheels.
4. Remove the top link (1) and lift rod (2).
5. Disconnect the stabilizer (4) and remove the lower link (3).
6. Place a block of wood (5) between cabin and lift arm (6) to support the cabin.
7. Remove the cabin mount bracket mounting bolt (8) and nut.

(When reassembling)


- Be sure to install the washers, plate and mount rubbers, etc. in their original positions.

Tightening torque	Rear wheel mounting screw and nut	215 N·m 22 kgf·m 160 ft·lbs
	Rear wheel mounting stud bolt	98.1 to 112.8 N·m 10.0 to 11.5 kgf·m 72.3 to 83.2 ft·lbs
	Cabin mounting bolt and nut	124 to 147 N·m 13.0 to 15.0 kgf·m 91.0 to 108.0 ft·lbs

- (1) Top Link
- (2) Lift Rod
- (3) Lower Link
- (4) Stabilizer
- (5) Block of Wood
- (6) Lift Arm
- (7) Cabin Mount Bracket

- (8) Bolt (M14 × 90)
- (9) Spring Washer
- (10) Plain Washer
- (11) Plate
- (12) Mount Rubber
- (13) Collar
- (14) Nut

W1011906



Cabin Mount Bracket (Cabin Model)

1. Remove the cabin mount bracket (3), (4) or (6).
- (When reassembling)**

Tightening torque	Cabin mount bracket mounting screw	166.7 to 196.1 N·m 17 to 20 kgf·m 123 to 144 ft-lbs
-------------------	------------------------------------	---

- | | |
|-------------------------------|---------------------------------------|
| (1) Screw (M14 × 155) | (6) Cabin Mount Bracket |
| (2) Collar | |
| (3) Cabin Mount Lower Bracket | A : L3130, L3430 |
| (4) Cabin Mount Upper Bracket | B : L3830, L4330, L4630, L5030 |
| (5) Screw (M14 × 30) | |

W1013640



Rear Axle Case


1. Disconnect the brake rod.
2. Place the disassembling stand under the rear axle case.
3. Remove the rear axle mounting screws and nuts.
4. Separate the rear axle case from brake case.

(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the rear axle case and brake case.

Tightening torque	Rear axle case mounting screw and nut	M10 screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft-lbs
		M10 nut (9T) (Except L3130, L3430)	60.8 to 70.5 N·m 6.2 to 7.2 kgf·m 44.9 to 52.1 ft-lbs
		M12 screw (Except L3130, L3430)	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
		Stud bolt	24.5 to 31.4 N·m 2.5 to 3.2 kgf·m 18.1 to 23.1 ft-lbs

W10113490




Tightening torque	Lock nut	145 to 181 ft·lb 19 to 25 kgf·m
-------------------	----------	------------------------------------

W1011881W

(2) Disassembling Rear Axle

Rear Axle




- (1) Rear Axle
- (2) Oil Seal
- (3) Internal Snap Ring
- (4) Ball Bearing
- (5) Spacer
- (6) Rear Axle Case
- (7) Gear
- (8) Lock Nut
- (9) Ball Bearing
- (10) Ball Bearing
- (11) Rear Axle Cover
- (12) O-ring

[A] L3130, L3430, L3830,
L4330, L4630
[B] L5030

W10115940

3TLABAB4P009A




3TMABAB4P005B

1. Remove the ball bearing (9) with a puller.
2. Remove the stake of lock nut (8).
3. Secure the rear axle (1) in a vise and remove the lock nut.
4. Take out the gear (7) and spacer (5).
5. Tap out the rear axle (1).
6. Remove the rear axle cover (11). (L5030 only)

(When reassembling)

- Apply grease to the oil seal (2) and install it.
- Replace the lock nut with new one, and after tightening it to specified torque, stake it firmly.
- Assemble the oil seal (2) with correct direction. (See figure.)

Tightening torque	Lock nut	196 to 245 N·m 20 to 25 kgf·m 145 to 181 ft·lbs
-------------------	----------	---



3TLABAB4P010A

W10116810


5 BRAKES

MECHANISM

CONTENTS

1. STRUCTURE	5-M1
2. OPERATION	5-M2

1. STRUCTURE




This is used hanging type brake pedals to have wider space of the platform.

Independent mechanical wet disc brakes are used for the right and left travelling brakes. They are operated by the brake pedals through the mechanical linkages.

The parking brake is a mechanical type which is designed to actuate the travelling brakes. Pulling the parking brake lever (3) results in the same state as that obtained when the brake pedals are pressed.

2. OPERATION



3TLBAB5P001A

- | | | | |
|----------------|----------------|---------------------|-----------------|
| (1) Brake Case | (3) Cam Plate | (5) Brake Cam Lever | (7) Brake Cam |
| (2) Brake Disc | (4) Steel Ball | (6) Plate | (8) Brake Shaft |

The brakes are provided on the power transmitting shafts (brake shafts (8)) through which power is transmitted to the final reduction system. The brakes are incorporated in the brake case (1) filled with transmission oil. They are designed to brake when the brake discs (2), spline-coupled and rotating with the brake shaft, are pressed against the brake case by cam plate (3) with the cam mechanism incorporating steel balls (4). For greater braking force, two brake discs are provided respectively, and the plate (6) fixed to the brake case are arranged between the brake discs.

■ During Braking

When the brake pedal is pressed, the force causes the brake cam lever (5) to move in the direction of arrow through the brake rod. At the same time, the brake cam (7) spline-couples with the brake cam lever also moves. Due to this force, cam plate (3) moves in the direction of arrow. Since the steel balls (4) are set in the grooves of differential case, cam plate (3) is pushed out against the brake discs (2), causing braking with the friction force created.

SERVICING

CONTENTS

1. TROUBLESHOOTING	5-S1
2. SERVICING SPECIFICATIONS	5-S2
3. TIGHTENING TORQUES	5-S3
4. CHECKING, DISASSEMBLING AND SERVICING.....	5-S4
[1] BRAKE PEDAL	5-S4
(1) Checking and Adjusting	5-S4
(2) Disassembling and Assembling	5-S4
(3) Servicing	5-S7
[2] BRAKE CASE	5-S7
(1) Disassembling and Assembling	5-S7
(2) Servicing	5-S11

1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
Uneven Braking Force	<ul style="list-style-type: none"> • Brake pedal play unevenly adjusted • Brake disc worn • Cam plate warped 	Adjust Replace Replace	5-S4 5-S10 5-S10
Brake Drags	<ul style="list-style-type: none"> • Brake pedal play too small • Ball holes of cam plate for uneven wear • Brake pedal return spring weaken or broken • Brake cam rusted 	Adjust Replace Replace Repair	5-S4 5-S10 5-S6 5-S10
Poor Braking Force	<ul style="list-style-type: none"> • Brake pedal play excessive • Brake disc worn • Cam plate warped • Brake cam or lever damaged • Transmission fluid improper 	Adjust Replace Replace Replace Change	5-S4 5-S10 5-S10 5-S10 G-7, 8

W10143220

2. SERVICING SPECIFICATIONS

Item		Factory Specification	Allowable Limit
Brake Pedal	Free Travel	15 to 20 mm 0.6 to 0.8 in.	—
Brake Lever Link Shaft to Bushing	Clearance	0.12 to 0.25 mm 0.0047 to 0.0098 in.	1.0 mm 0.039 in.
Brake Lever Link Shaft	O.D.	19.90 to 19.98 mm 0.7835 to 0.7866 in.	—
Brake Lever Link Bushing	I.D.	20.10 to 20.15 mm 0.7913 to 0.7933 in.	—
Cam Plate	Flatness	—	0.3 mm 0.012 in.
Cam Plate and Ball	Height	20.9 to 21.1 mm 0.823 to 0.831 in.	20.5 mm 0.8071 in.
Brake Disc	Thickness	4.6 to 4.8 mm 0.181 to 0.189 in.	4.2 mm 0.165 in.
Plate	Thickness	2.54 to 2.66 mm 0.1000 to 0.1047 in.	2.1 mm 0.0827 in.

W10138740

3. TIGHTENING TORQUES

Tightening torques of screws and nuts in the table below are especially specified.
 (For general use screws and nuts: See page G-9.)

Item	N·m	kgf·m	ft-lbs
Rear wheel mounting screw and nut	215	22	166
Rear wheel mounting stud bolt	98.1 to 112.8	10.0 to 11.5	72.3 to 83.2
Floor seat mounting bolt and nut	196 to 225	20 to 23	145 to 166
Cabin mounting bolt and nut	124 to 147	13.0 to 15.0	91.0 to 108.0
Cabin mount bracket mounting screw	166.7 to 196.1	17 to 20	123 to 144
ROPS lower frame mounting screw	166.7 to 196.1	17 to 20	123 to 144
Rear axle case mounting screw (M10)	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2
Rear axle case mounting nut (M10, 9T)	60.8 to 70.5	6.2 to 7.2	44.9 to 52.1
Rear axle case mounting screw (M12)	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Rear axle case mounting stud bolt	24.5 to 31.4	2.5 to 3.2	18.1 to 23.1
Brake case mounting screw and nut	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Brake case mounting stud bolt	38.2 to 45.1	3.9 to 4.6	28.2 to 33.3
Brake case lever mounting screw	62.8 to 72.5	6.4 to 7.4	46.3 to 53.5

W10127360


(S) Disassembly and Assembly



4. CHECKING, DISASSEMBLING AND SERVICING

[1] BRAKE PEDAL

(1) Checking and Adjusting



Checking Brake Pedal Free Travel

CAUTION

• Stop the engine and chock the wheels before checking brake pedal.

1. Release the parking brake.
 2. Slightly depress the brake pedals and measure free travel (L) at top of pedal stroke.
 3. If the measurement is not within the factory specifications, loosen the lock nut (1) and turn the turnbuckle (2) to adjust the rod length within acceptable limits.
 4. Retighten the lock nut (1) securely.
- Keep the free travel in the right and left brake pedals equal.

Brake pedal free travel "L"	Factory spec.	15 to 20 mm 0.59 to 0.79 in.
--------------------------------	---------------	---------------------------------

- (1) Lock Nut
(2) Turnbuckle

L : Free Travel

W1015392

(2) Disassembling and Assembling




Panel Cover

1. Remove the combination switch (2).
2. Remove the panel cover (1).

(1) Panel Cover

(2) Combination Switch

W1017418



IntelliPanel (Electronic Instrument Panel)


1. Disconnect the panel connectors (3) and combination switch connector (4).
2. Disconnect the hazard connector, main switch connector (6) and mode switch connector (7).
3. Remove the electronic instrument panel (2) with panel frame (1) as a unit.

- | | |
|----------------------------------|---------------------------|
| (1) Panel Frame | (5) Hazard Switch |
| (2) Electronic Instrument Panel | (6) Main Switch Connector |
| (3) Panel Connector | (7) Mode Switch Connector |
| (4) Combination Switch Connector | |

W1017912



1. Remove the parking brake lever (1).
2. Remove the brake pedals (2), (8) and springs (8).
3. Tap out the spring pin (7) and pull out the brake pedal shaft (10) with clutch pedal (9).
4. Remove the external strap ring (5).
5. Disconnect the clutch pedal rod.
6. Remove the brake pedal rods (11), (13).
7. Remove the brake rods (12), (14).

Brake Pedal and Brake Rod


- (1) Parking Brake Lever
- (2) External Snap Ring
- (3) Oil Seal
- (4) Needle Bearing
- (5) Brake Pedal RH
- (6) Spring
- (7) Spring Pin
- (8) Brake Pedal LH
- (9) Clutch Pedal
- (10) Brake Pedal Shaft
- (11) Brake Pedal Rod RH
- (12) Brake Rod RH
- (13) Brake Pedal Rod LH
- (14) Brake Rod LH

W1012974

3TLABAB5P005A

1. Remove the brake rods (12), (14).
2. Remove the brake pedal rods (11), (13).
3. Disconnect the clutch pedal rod.
4. Remove the external snap ring (2).
5. Tap out the spring pin (7) and pull out the brake pedal shaft (10) with clutch pedal (9).
6. Remove the brake pedals (5), (8) and springs (6).
7. Remove the parking brake lever (1).

(3) Servicing



Clearance between Brake Lever Link Shaft and Bushing

1. Measure the brake lever link shaft O.D. with an outside micrometer.
2. Measure the brake lever link bushing I.D. with a cylinder gauge.
3. Calculate the clearance.
4. If the clearance exceeds the allowable limit, replace the bushing.

Clearance between brake lever link shaft and brake lever link bushing	Factory spec.	0.12 to 0.25 mm 0.0047 to 0.0098 in.
	Allowable limit	1.0 mm 0.039 in.

Brake lever link shaft O.D.	Factory spec.	19.90 to 19.98 mm 0.7835 to 0.7866 in.
Brake lever link bushing I.D.	Factory spec.	20.10 to 20.15 mm 0.7913 to 0.7933 in.


- (1) Brake Lever Link Shaft
(2) Brake Lever Link Bushing

(3) Brake Lever Link

W1013288

[2] BRAKE CASE

(1) Disassembling and Assembling




Draining the Transmission Fluid

1. Place oil pans underneath the transmission case.
2. Remove the drain plugs (1).
3. Drain the transmission fluid.
4. Reinstall the drain plugs (1).

(When refilling)

- Fill up from filling port after removing the filling plug (2) until reaching the upper notch on the dipstick (3).
- After running the engine for few minutes, stop it and check the oil level again, add the fluid to prescribed level if it is not correct level.



Transmission fluid capacity	L3130 L3430	42 L 11.1 U.S.gals. 9.2 Imp.gals.
	L3830 L4330 L4630	43 L 11.4 U.S.gals. 9.5 Imp.gals.
	L5030	45 L 11.9 U.S.gals. 9.9 Imp.gals.



■ IMPORTANT

- Use only KUBOTA SUPER UDT fluid. Use of other oils may damage the transmission or hydraulic system. Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7, 8.)
- Do not mix different brands of fluid together.

- (1) Drain Plugs
(2) Filling Plug
(3) Dipstick

(A) Oil level is acceptable within this range.

W1019291



Rear Wheel and ROPS (ROPS Model)



1. Place the disassembling stand under the transmission case.
2. Remove the rear wheel mounting screws and nuts.
3. Remove the rear wheels.
4. Remove the top link (2) and lift rod (4).
5. Disconnect the stabilizer (6) and remove the lower link (5).
6. Remove the ROPS lower frame mounting screws (7), (8).
7. Dismount the ROPS assembly (1), (3).

(When reassembling)

Tightening torque	Rear wheel mounting screw and nut	215 N·m 22 kgf·m 160 ft-lbs
	Rear wheel mounting stud bolt	98.1 to 112.8 N·m 10.0 to 11.5 kgf·m 72.3 to 83.2 ft-lbs
	ROPS lower frame mounting screw	166.7 to 196.1 N·m 17 to 20 kgf·m 123 to 144 ft-lbs

- | | |
|----------------------|---------------------------------------|
| (1) ROPS Upper Frame | (7) Screw (M14 × 155) |
| (2) Top Link | (8) Screw (M14 × 30) |
| (3) ROPS Lower Frame | |
| (4) Lift Rod | A : L3130, L3430 |
| (5) Lower Link | B : L3830, L4330, L4630, L5030 |
| (6) Stabilizer | |

W10195170



Rear Wheel and Cabin Mount Screw (Cabin Model)

1. Place the disassembling stand under the transmission case.
2. Remove the rear wheel mounting screws and nuts.
3. Remove the rear wheels.
4. Remove the top link (1) and lift rod (2).
5. Disconnect the stabilizer (4) and remove the lower link (3).
6. Place a block of wood (5) between cabin and lift arm (6) to support the cabin.
7. Remove the cabin mount bracket mounting bolt (8) and nut.

(When reassembling)

- Be sure to install the washers, plate and mount rubbers, etc. in their original positions.

Tightening torque	Rear wheel mounting screw and nut	215 N·m 22 kgf·m 160 ft-lbs
	Rear wheel mounting stud bolt	98.1 to 112.8 N·m 10.0 to 11.5 kgf·m 72.3 to 83.2 ft-lbs
	Cabin mounting bolt and nut	124 to 147 N·m 13.0 to 15.0 kgf·m 91.0 to 108.0 ft-lbs

- | | |
|-------------------------|---------------------|
| (1) Top Link | (8) Bolt (M14 × 90) |
| (2) Lift Rod | (9) Spring Washer |
| (3) Lower Link | (10) Plain Washer |
| (4) Stabilizer | (11) Plate |
| (5) Block of Wood | (12) Mount Rubber |
| (6) Lift Arm | (13) Collar |
| (7) Cabin Mount Bracket | (14) Nut |

W1019772



3TLABAB4P008A

Rear Axle Case

1. Disconnect the brake rod.
2. Place the disassembling stand under the rear axle case.
3. Remove the rear axle mounting screws and nuts.
4. Separate the rear axle case from brake case.

(When reassembling)

- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the rear axle case and brake case.



Tightening torque		Rear axle case mounting screw and nut	
M10 screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft-lbs		
M10 nut (9T) (Except L3130, L3430)	60.8 to 70.5 N·m 6.2 to 7.2 kgf·m 44.9 to 52.1 ft-lbs		
M12 screw (Except L3130, L3430)	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs		
Stud bolt	24.5 to 31.4 N·m 2.5 to 3.2 kgf·m 18.1 to 23.1 ft-lbs		

W10200480

Tightening torque		Rear axle case mounting screw and nut	
M10 screw	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft-lbs		
M10 nut (9T) (Except L3130, L3430)	60.8 to 70.5 N·m 6.2 to 7.2 kgf·m 44.9 to 52.1 ft-lbs		
M12 screw (Except L3130, L3430)	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs		
Stud bolt	24.5 to 31.4 N·m 2.5 to 3.2 kgf·m 18.1 to 23.1 ft-lbs		

- (7) Brake Case
- (8) Back of Wood
- (9) Floor Seat
- (10) Floor Steel Support
- (11) Brake Pin
- (12) Car Pin
- (13) Steel Nut

- (1) Brake Rod
- (2) Piston Shaft
- (3) Rear Steel Support
- (4) Floor Seat
- (5) Back of Wood
- (6) Oil Arm
- (7) Brake Case







Brake Cam and Brake Cam Lever

1. Remove the brake cam mounting nut and remove the brake cam.
- (When reassembling)**
- Apply grease to the O-ring (3) and take care not damage the O-ring.

- (3) O-ring
- (4) Brake Cam Lever

- (1) Brake Case
- (2) Brake Cam



Brake Case

1. Disconnect the brake rod (1).
2. Place a block of wood (5) between floor seat (4) and lift arm (6) to support the floor seat. (ROPS model)
3. Place the floor seat mounting bolts and nuts. (ROPS model)
4. Remove the floor seat support (3). (ROPS model)
5. Remove the fulcrum shaft (2) and disconnect the levers. (Left side only)
6. Remove the brake case mounting screws and nuts.
7. Remove the brake case (7).

(When reassembling)

- Place the brake discs (10) so that the hole "A" of brake discs should be overlapped 50 % or more.
- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the brake case and differential gear case.
- Be sure to apply the liquid gasket to a position.
- Apply grease to the steel ball seats. (Do not grease excessively.)
- Be sure to fix the brake cam (13) and cam plate (9).
- Before installing the brake case to the transmission case, install the cam plate (9) to the transmission case.

Tightening torque	Brake case mounting screw and nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft-lbs
	Floor seat mounting bolt and nut	196 to 225 N·m 20 to 23 kgf·m 145 to 166 ft-lbs

- | | |
|------------------------|------------------|
| (1) Brake Rod | (8) Steel Ball |
| (2) Fulcrum Shaft | (9) Cam Plate |
| (3) Floor Seat Support | (10) Brake Disc |
| (4) Floor Seat | (11) Plate |
| (5) Block of Wood | (12) Brake Shaft |
| (6) Lift Arm | (13) Brake Cam |
| (7) Brake Case | |

W1015647

Brake Cam and Brake Cam Lever

1. Remove the brake cam mounting nut and remove the brake cam (2) and brake cam lever (4).


(When reassembling)

- Apply grease to the O-ring (3) and take care not damage the O-ring.

- | | |
|----------------|---------------------|
| (1) Brake Case | (3) O-ring |
| (2) Brake Cam | (4) Brake Cam Lever |

W1014346

(2) Servicing




Brake Cam Lever Movement

1. Assemble the brake cam (1) and brake cam lever (2).
2. Move the brake cam lever by hand to check the movement.
3. If the movement is heavy, refine the brake cam lever or brake case with sandpaper.

(1) Brake Cam

(2) Brake Cam Lever

W10144750




Cam Plate Flatness

1. Place the cam plate on the surface plate.
2. Measure the flatness of cam plate with a feeler gauge at four points on a diagonal line.
3. If the measurement exceed the allowable limit, replace it.

Cam Plate Flatness	Allowable limit	0.3 mm 0.012 in.
--------------------	-----------------	---------------------

W10145650




Height of Cam Plate and Ball

1. Measure the dimension of the cam plate with the ball installed.
2. If the measurement is less than the allowable limit, replace the cam plate and balls.
3. Inspect the ball holes of cam plate for uneven wear. If the uneven wear is found, replace it.

Height of cam plate and ball	Factory spec.	20.9 to 21.1 mm 0.823 to 0.831 in.
	Allowable limit	20.5 mm 0.807 in.

W10147220



Brake Disc Wear

1. Measure the brake disc thickness with vernier calipers.
2. If the measurement is less than the allowable limit, replace it.

Brake disc thickness	Factory spec.	4.6 to 4.8 mm 0.181 to 0.189 in.
	Allowable limit	4.2 mm 0.165 in.

W10148530




Plate Wear

1. Measure the plate thickness with vernier calipers.
2. If the measurement is less than the allowable limit, replace it.

Plate thickness	Factory spec.	2.54 to 2.66 mm 0.1000 to 0.1047 in.
	Allowable limit	2.1 mm 0.083 in.

W10149690

6 FRONT AXLE

MECHANISM


CONTENTS

1. STRUCTURE	6-M1
[1] 2WD TYPE.....	6-M1
[2] 4WD TYPE.....	6-M2

1. STRUCTURE

The front axle supports the front of tractor and facilitates steering. There are two kinds of front axles. The two-wheel drive axle has free-running front wheels and the four-wheel drive axle has powered front wheels.

[1] 2WD TYPE




- | | | | |
|---------------------|-------------------------------|---------------------------|--------------------|
| (1) Slotted Nut | (6) Front Axle, Out | (10) Front Axle Frame | (14) Dust Cover |
| (2) Front Wheel Hub | (7) Front Axle Bracket, Front | (11) Front Wheel Cap | (15) Knuckle Shaft |
| (3) Oil Seal | (8) Front Axle Bracket, Rear | (12) Taper Roller Bearing | (16) Thrust Collar |
| (4) Knuckle Arm | (9) Front Axle, Middle | (13) Taper Roller Bearing | (17) Bushing |
| (5) Bushing | | | |

The front axle of the 2WD type is constructed as shown above. The shape of the front axle is relatively simple, and the front axle is supported at its center with the front axle brackets (7), (8) on the front axle frame (10), so that steering operation is stable even on an uneven grounds in a farm field.

[2] 4WD TYPE

(for L3130, L3430 and L3830)



3TLABAB6P002A

- | | | | |
|---------------------|--------------------------------|--------------------------------|-------------------------------|
| (1) Axle | (7) Bevel Gear | (13) Spiral Bevel Gear | (19) Differential Yoke Shaft |
| (2) Collar | (8) Differential Side Gear | (14) Spiral Bevel Pinion Shaft | (20) Differential Case |
| (3) Axle Flange | (9) Differential Pinion | (15) Bevel Gear | (21) Front Axle Bracket, Rear |
| (4) Bevel Gear | (10) Pinion Shaft | (16) Front Gear Case | (22) Coupling |
| (5) Bevel Gear | (11) Collar | (17) Bevel Gear Shaft | (23) Propeller Shaft |
| (6) Bevel Gear Case | (12) Front Axle Bracket, Front | (18) Front Axle Case | |


The front axle of the 4WD is constructed as shown above. Power is transmitted from the transmission through the propeller shaft (23) and to the bevel pinion shaft (14), then to the spiral bevel gear (13) after that to the differential gear.

The power through the differential is transmitted to the differential yoke shaft (19), and to the bevel gear shaft (17) in the bevel gear case (6).

The revolution is greatly reduced by the bevel gears (15), (4), then the power is transmitted to the axle (1).

The differential system allows each wheel to rotate at a different speed to make turning easier.

(for L4330, L4630 and L5030)



3TLABAB6P003A

- | | | | |
|-----------------------|----------------------------|--------------------------------|-------------------------------|
| (1) Axle | (7) Bevel Gear | (13) Front Axle Bracket, Front | (19) Front Axle Case |
| (2) Collar | (8) Bevel Gear Case | (14) Spiral Bevel Gear | (20) Differential Yoke Shaft |
| (3) Axle Flange | (9) Differential Side Gear | (15) Spiral Bevel Pinion Shaft | (21) Differential Case |
| (4) Bevel Gear | (10) Differential Pinion | (16) Front Gear Case | (22) Front Axle Bracket, Rear |
| (5) Bevel Gear | (11) Pinion Shaft | (17) Front Gear Case | (23) Coupling |
| (6) Axle Case Support | (12) Collar | (18) Bevel Gear Shaft | (24) Propeller Shaft |

SERVICING

CONTENTS

1. TROUBLESHOOTING	6-S1
2. SERVICING SPECIFICATIONS	6-S2
3. TIGHTENING TORQUES	6-S5
4. CHECKING, DISASSEMBLING AND SERVICING.....	6-S6
[1] CHECKING AND ADJUSTING	6-S6
[2] DISASSEMBLING AND ASSEMBLING.....	6-S8
(1) Separating Front Axle Assembly.....	6-S8
(2) Disassembling 2WD Type Front Axle	6-S10
(3) Disassembling 4WD Type Front Axle	6-S12
[3] SERVICING	6-S19
(1) 2WD Type	6-S19
(2) 4WD Type	6-S20

1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
Front Wheels Wander to Right or Left	• Tire pressure uneven	Adjust	G-53
	• Improper toe-in adjustment (improper alignment)	Adjust	6-S6
	• Clearance between front axle middle boss and front axle shaft bracket bushing excessive [2WD Type]	Replace	6-S19
	• Clearance between front axle case boss and front axle bracket (front, rear) bushing excessive [4WD Type]	Replace	6-S24
	• Knuckle shaft bushings worn [2WD Type]	Replace	6-S19
Front Wheels Can Not Be Driven [4WD Type]	• Front axle rocking force too small	Adjust	6-S7
	• Front wheel sway excessive	Replace	6-S6
	• Tie-rod end loose	Tighten	6-S10, S12
	• Air sucked in power steering circuit	Bleed	7-S14
	• Propeller shaft broken	Replace	6-S8
	• Front wheel drive gears in transmission broken	Replace	3-S37, S77, S117
	• Front differential gear broken	Replace	6-S18
Noise [4WD Type]	• Shift fork broken	Replace	-
	• Coupling displaced	Reassemble	6-S8
	• Gear backlash excessive	Adjust or replace	6-S20 to 23
	• Oil insufficient	Replenish	G-7, 8
	• Bearings damaged or broken	Replace	-
	• Gears damaged or broken	Replace	-
	• Spiral bevel pinion shaft turn force improper	Adjust	6-S21

W10143220

2. SERVICING SPECIFICATIONS

2WD TYPE

Item		Factory Specification	Allowable Limit
Front Wheel Alignment	Toe-in	2 to 8 mm 0.08 to 0.32 in.	—
Front Wheel	Axial Sway	Less than 5 mm 0.20 in.	—
Front Axle	Rocking Force	49.0 to 117.7 N 5.0 to 12.0 kgf 11.0 to 26.5 lbs	—
Knuckle Shaft to Bushing	Clearance	0.000 to 0.285 mm 0.00000 to 0.01122 in.	0.4 mm 0.016 in.
Knuckle Shaft	O.D.	27.880 to 27.900 mm 1.09764 to 1.09842 in.	—
Bushing	I.D.	27.900 to 28.165 mm 1.09842 to 1.10886 in.	—
Front Axle Middle Boss to Front Axle Shaft Bracket Bushing	Clearance	0.000 to 0.147 mm 0.00000 to 0.00579 in.	0.3 mm 0.012 in.
Front Axle Middle Boss	O.D.	39.938 to 40.000 mm 1.57236 to 1.57480 in.	—
Bushing	I.D.	40.000 to 40.085 mm 1.57480 to 1.57815 in.	—

W10138740

4WD TYPE

Item		Factory Specification	Allowable Limit
Front Wheel Alignment	Toe-in	2 to 8 mm 0.08 to 0.32 in.	—
Front Wheel	Steering Angle	0.925 to 0.960 rad. 53 to 55 °	—
	Axial Sway	5.0 mm 0.196 in.	—
	Radial Sway	5.0 mm 0.197 in.	—
(for L3130, L3430 and L3830) Differential Case, Differential Case Cover to Differential Side Gear	Clearance	0.050 to 0.151 mm 0.00197 to 0.00597 in.	0.20 mm 0.0079 in.
Differential Case	I.D.	32.000 to 32.062 mm 1.25984 to 1.26228 in.	—
Differential Case Cover	I.D.	32.000 to 32.025 mm 1.25984 to 1.26083 in.	—
Differential Side Gear	O.D.	31.911 to 31.950 mm 1.25634 to 1.25789 in.	—
(for L4330, L4630 and L5030) Differential Case, Differential Case Cover to Differential Side Gear	Clearance	0.050 to 0.114 mm 0.00197 to 0.00449 in.	0.20 mm 0.0079 in.
Differential Case	I.D.	32.000 to 32.025 mm 1.25984 to 1.26083 in.	—
Differential Case Cover	I.D.	32.000 to 32.025 mm 1.25984 to 1.26083 in.	—
Differential Side Gear	O.D.	31.911 to 31.950 mm 1.25634 to 1.25789 in.	—
Pinion Shaft to Differential Pinion	Clearance	0.064 to 0.100 mm 0.00252 to 0.00394 in.	0.25 mm 0.0096 in.
Pinion Shaft	O.D.	13.950 to 13.968 mm 0.54921 to 0.54992 in.	—
Differential Pinion	I.D.	14.032 to 14.050 mm 0.55244 to 0.55315 in.	—
Differential Pinion to Differential Side Gear	Backlash	0.2 to 0.3 mm 0.008 to 0.012 in.	0.4 mm 0.016 in.
Spiral Bevel Pinion Shaft	Turning Torque	0.98 to 1.18 N·m 0.10 to 0.12 kgf·m 0.72 to 0.87 ft·lbs	—

W10109890

4WD TYPE (Continued)

Item		Factory Specification	Allowable Limit
(for L3130, L3430, L3830) Spiral Bevel Pinion Shaft to Spiral Bevel Gear	Backlash	0.1 to 0.3 mm 0.004 to 0.012 in.	—
(for L4330, L4630, L5030) Spiral Bevel Pinion Shaft to Spiral Bevel Gear	Backlash	0.2 to 0.3 mm 0.008 to 0.012 in.	—
Bevel Gear to Bevel Gear	Backlash	0.2 to 0.3 mm 0.008 to 0.012 in.	0.6 mm 0.024 in.
Front Axle Case Boss (Front) to Bracket Bushing	Clearance	0.120 to 0.275 mm 0.00472 to 0.01083 in.	0.50 mm 0.19685 in.
Front Axle Case Boss (Front)	O.D.	49.950 to 49.975 mm 1.96653 to 1.96752 in.	—
Bushings	I.D.	50.095 to 50.225 mm 1.97224 to 1.97736 in.	—
(for L3130, L3430 and L3830) Front Axle Case Boss (Rear) to Bracket Bushing	Clearance	0.100 to 0.292 mm 0.00394 to 0.01150 in.	1.0 mm 0.03937 in.
Front Axle Case Boss (Rear)	O.D.	69.970 to 70.000 mm 2.75472 to 2.75590 in.	—
Bushings	I.D.	70.100 to 70.262 mm 2.75984 to 2.76622 in.	—
(for L4330, L4630 and L5030) Front Axle Case Boss (Rear) to Bracket Bushing	Clearance	0.025 to 0.195 mm 0.00098 to 0.00768 in.	0.5 mm 0.19685 in.
Front Axle Case Boss (Rear)	O.D.	80.000 to 80.035 mm 3.14961 to 3.15098 in.	—
Bushings	I.D.	80.060 to 80.195 mm 3.15197 to 3.15728 in.	—
(for L4330, L4630 and L5030) Bevel Gear Case Boss to Front Axle Support Bushing	Clearance	0.080 to 0.232 mm 0.00315 to 0.00913 in.	1.0 mm 0.03937 in.
Bevel Gear Case Boss	O.D.	54.970 to 55.000 mm 2.16417 to 2.16535 in.	—
Front Axle Support Bushing	I.D.	55.080 to 55.202 mm 2.16850 to 2.17331 in.	—

W10138740

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-9.)

2WD TYPE

Item	N·m	kgf·m	ft-lbs
Tie-rod clamp screw and nut	39.2 to 49.0	4.0 to 5.0	28.9 to 36.1
Slotted nut of tie-rod end	49.0 to 68.6	5.0 to 7.0	36.2 to 50.6
Front axle shaft brackets mounting screw	77.4 to 90.2	7.9 to 9.2	57.2 to 66.5
Front wheel mounting stud bolt	63.7 to 73.5	6.5 to 7.5	47.0 to 54.0
Front wheel mounting nut	137	14.0	100
Front wheel hub slotted nut	78.5 to 117.7	8.0 to 12.0	57.9 to 86.8
Knuckle arm mounting bolt and nut	77.5 to 90.2	7.9 to 9.2	57.2 to 66.5
Tie-rod joint lock nut	166.7 to 196.1	17.0 to 20.0	123 to 145
Locking force adjusting screw lock nut	34.3 to 39.2	3.5 to 4.0	25.3 to 28.9
Power steering hose retaining nut	24.5 to 29.4	2.5 to 3.0	18.1 to 21.7
Cylinder cover mounting screw	60.8 to 70.6	6.2 to 7.2	44.8 to 52.1
Front axle, out mounting bolt and nut	123 to 147	12.6 to 15.0	91.1 to 108.5

W10127360

4WD TYPE

Power steering hose retaining nut	24.5 to 29.4	2.5 to 3.0	18.1 to 21.7
Cylinder cover mounting screw	60.8 to 70.6	6.2 to 7.2	44.8 to 52.1
Tie-rod joint to steering cylinder	166.7 to 196.1	17.0 to 20.0	122.9 to 144.6
Front wheel mounting nut	166.7 to 196.1	17.0 to 20.0	122.9 to 144.6
Front bracket and rear bracket mounting screw and nut	77.5 to 90.1	7.9 to 9.2	57.2 to 66.5
Tie-rod end nut (L3130, L3430, L3830)	39.2 to 45.1	4.0 to 4.6	28.9 to 33.3
(L4330, L4630, L5030)	156.9 to 176.5	16.0 to 18.0	115.7 to 130.2
Bevel gear case mounting screw			
(L3130, L3430, L3830)	123 to 147	12.6 to 15.0	91.1 to 108.5
(L4330, L4630, L5030)	166.7 to 196.1	17.0 to 20.0	122.9 to 144.6
Front axle rocking force adjusting screw	19.6 to 29.4	2.0 to 3.0	14.5 to 21.7
Locking force adjusting screw lock nut			
(L3130, L3430, L3830)	39.2 to 58.8	4.0 to 6.0	28.9 to 43.4
(L4330, L4630, L5030)	58.8 to 98.1	6.0 to 10.0	43.4 to 72.3
Front wheel case support mounting screw	127 to 142	13.0 to 14.5	94.6 to 104.9
(L4330, L4630, L5030)			
Axle flange mounting screw and nut			
(L3130, L3430, L3830)	23.6 to 27.5	2.4 to 2.8	17.4 to 20.3
(L4330, L4630, L5030)	29.4 to 34.3	3.0 to 3.5	21.7 to 25.3
Differential case cover mounting screw			
(L3130, L3430, L3830)	48.0 to 58.8	4.9 to 6.0	35.4 to 43.4
(L4330, L4630, L5030)	60.8 to 70.6	6.2 to 7.2	44.8 to 52.1

W10117570


W1051351W

Axial Sway of Front Wheel

1. Jack up the front side of tractor.
2. Get a dial gauge on the outside of rim.
3. Turn the wheel slowly and read the turnout of rim.
4. If the measurement exceeds the factory specifications, check the bearing, tire and front wheel hub.


Item	Factory spec	Max. limit
Axial sway of front wheel	0.15 mm	0.25 mm

W1051351W




4. CHECKING, DISASSEMBLING AND SERVICING


[1] CHECKING AND ADJUSTING



3TMABAB0P042A



3TLABAB6P004A



3TLABAB0P029B

Toe-in

1. Park the tractor on the flat place.
2. Inflate the tires to the specified pressure.
3. Turn steering wheel so front wheels are in the straight ahead position.
4. Lower the implement, lock the parking brake and stop the engine.
5. Measure distance between tire beads at front of tire, hub height.
6. Measure distance between tire beads at rear of tire, hub height.
7. Front distance should be 2 to 8 mm (0.08 to 0.32 in.) less than rear distance.
8. If the measurement is not within the factory specifications, adjust by changing the tie-rod length.

Toe-in (B - A)	Factory spec.	2 to 8 mm 0.08 to 0.32 in.
----------------	---------------	-------------------------------

■ Adjusting

2WD

1. Detach the snap ring (3).
2. Loosen the tie-rod lock nut (1).
3. Turn the outer tube (2) to adjust the tie-rod length until the proper toe-in measurement is obtained.
4. Retighten the tie-rod lock nut (1) and rod mounting screw.
5. Attach the snap ring (3).

4WD

1. Detach the snap ring (6).
2. Loosen the tie-rod lock nut (4).
3. Turn the tie-rod joint (5) to adjust the rod length until the proper toe-in measurement is obtained.
4. Retighten the tie-rod lock nut (2).
5. Attach the snap ring (6).


Tightening torque	Tie-rod lock nut	166.7 to 196.1 N·m 17.0 to 20.0 kgf·m 123 to 145 ft-lbs
-------------------	------------------	---

■ IMPORTANT

- A right and left tie-rod joint is adjusted to the same length.

- | | |
|----------------------|--------------------------------------|
| (1) Tie-rod Lock Nut | (A) Wheel to Wheel Distance at front |
| (2) Outer Tube | (B) Wheel to Wheel Distance at rear |
| (3) Snap Ring | (C) Front |
| (4) Tie-rod Nut | (a) 2WD |
| (5) Tie-rod Joint | (b) 4WD |
| (6) Snap Ring | |

W10213280



3TMABAB6P008A

Axial Sway of Front Wheel

1. Jack up the front side of tractor.
2. Set a dial gauge on the outside of rim.
3. Turn the wheel slowly and rear the runout of rim.
4. If the measurement exceeds the factory specifications, check the bearing, rim and front wheel hub.

Axial sway of front wheel	Factory spec.	Less than 5.0 mm 0.197 in.
---------------------------	---------------	-------------------------------

W10120920




Front Axle Rocking Force (2WD)

1. Jack up the front side of tractor.
2. Set a spring balance to the front axle flange.
3. Measure the front axle rocking force.
4. If the measurement is not within the factory specifications, adjust with the adjusting screw (1).
5. Tighten the lock nut (2) firmly.

Front axle rocking force	Factory spec.	49.0 to 117.7 N 5.0 to 12.0 kgf·m 11.0 to 26.5 lbs
--------------------------	---------------	--

(When reassembling)

Tightening torque	Lock nut	34.3 to 39.2 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft-lbs
-------------------	----------	---



(1) Adjusting Screw

(2) Lock Nut

W1016647



Adjusting Front Axle Pivot (4WD)

1. Jack up the tractor body, then loosen the lock nut (2).
2. Measure the adjusting screw tightening torque.
3. If tightening torque is not within the factory specifications, adjust the adjusting screw (1).
4. After adjustment, tighten the lock nut firmly.


(When reassembling)

	Front axle adjusting screw	19.6 to 29.4 N·m 2.0 to 3.0 kgf·m 14.5 to 21.7 ft-lbs
Tightening torque	L3130	39.2 to 58.8 N·m
	L3430	4.0 to 6.0 kgf·m
Lock nut	L3830	28.9 to 43.4 ft-lbs
	L4330	58.8 to 98.1 N·m
	L4630	6.0 to 10.0 kgf·m
	L5030	43.4 to 72.3 ft-lbs

(1) Adjusting Screw



(2) Lock Nut

W1012030



Front Wheel Steering Angle (for L4330, L4630 and L5030)

1. Inflate the tires to the specified pressure.
2. Steer the wheels to the extreme right until the front gear case (1) contacts with the bevel gear case (2) at right hand side of the front axle.
3. If the front gear case (1) can not be contacted with the bevel gear case (2), shorten the length of stopper (3).
4. Keeping the front gear case (1) contact with the bevel gear case (2), make a specified clearance (A) as shown in the lower table.
5. After adjustment, secure the stopper with the lock nut (4).
6. For adjusting the left steering angle, perform the same procedure as mentioned in right steering angle.



Clearance (A) between bevel gear case and stopper	Factory spec.	1.0 to 3.0 mm 0.04 to 0.12 in.
---	---------------	-----------------------------------

- (1) Front Gear Case
- (2) Bevel Gear Case
- (3) Stopper
- (4) Lock Nut

(5) Front Gear Case

A : Clearance

W10126440

[2] DISASSEMBLING AND ASSEMBLING


(1) Separating Front Axle Assembly

Propeller Shaft (4WD Only)

1. Slide the propeller shaft cover (4) and (8) after removing the screws (7).
2. Tap out the spring pins (2), (6) and slide the couplings (1), (5) and then remove the propeller shaft with covers (4), (8).

(When reassembling)


- Apply grease to the splines of propeller shaft 1 (3).



- (1) Coupling
- (2) Spring Pin
- (3) Propeller Shaft 1
- (4) Propeller Shaft Cover

- (5) Coupling
- (6) Spring Pin
- (7) Screws
- (8) Propeller Shaft Cover

W1035934





Power Steering Hoses

1. Disconnect the power steering hoses (1), (2) from steering cylinder.
2. Remove the cylinder cover.

(When reassembling)

Tightening torque	Power steering hose retaining nut	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft·lbs
	Cylinder cover mounting screw	60.8 to 70.6 N·m 6.2 to 7.2 kgf·m 44.8 to 52.1 ft·lbs

- (1) Power Steering Hose, RH (with Red Tape)
 (2) Power Steering Hose, LH (with Blue Tape)
 (3) Cylinder Cover



Front Wheel and Front Axle Assembly


1. Check the front axle and engine are securely mounted on the disassembly stand.
2. Loosen the front wheel mounting nuts.
3. Lift the front axle and remove the front wheels.
4. Remove the bracket (front) mounting screws and nuts.
5. Remove the bracket (rear) mounting screws and nuts.
6. Separate the front axle from front axle bracket.

(When reassembling)





■ IMPORTANT

- Be sure to adjust the front axle rocking force. (See page 6-S7.)

Tightening torque	Front wheel mounting nut	137 N·m 14.0 kgf·m 100 ft·lbs
	Bracket mounting screw and nut	77.5 to 90.1 N·m 7.9 to 9.2 kgf·m 57.2 to 66.5 ft·lbs



(2) Disassembling 2WD Type Front Axle



Front Wheel Hub

1. Remove the front wheels.
2. Remove the cotter pin and remove the slotted nut (2).
3. Disconnect the knuckle arm (1) and tie-rod end (3).
4. Remove the front wheel cap (4).
5. Draw out the cotter pin.
6. Remove the slotted nut (5).
7. Remove the collar.
8. Remove the front wheel hub (6) with a puller.

(When reassembling)

- Replace cotter pin with a new one.
- Apply grease to the oil seal (8) in the front wheel hub.

■ IMPORTANT


- After tightening the slotted nut to the specified torque, insert a cotter pin and bend it as shown in the figure.
- Pack in the grease to the bearing in the front wheel hub.

	Front wheel mounting nut	137 N·m 14.0 kgf·m 100 ft-lbs
Tightening torque	Front wheel hub slotted nut	78.5 to 117.7 N·m 8.0 to 12.0 kgf·m 57.9 to 86.8 ft-lbs
	Tie-rod end slotted nut	49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 ft-lbs

- (1) Knuckle Arm
- (2) Slotted Nut
- (3) Front Wheel Hub
- (4) Front Wheel Cap
- (5) Slotted Nut

- (6) Front Wheel Hub
- (7) Knuckle Shaft
- (8) Oil Seal
- (9) Taper Roller Bearing
- (10) Taper Roller Bearing

W10141250




Knuckle Shaft and Front Axle, Out

1. Remove the knuckle arm (1) and draw out the knuckle shaft (2) from the front axle.
2. Remove the front axle, out (3).

(When reassembling)


- Apply grease to the knuckle shaft (2) and thrust collar (4), (5).
- Do not interchange right and left knuckle arms.
- Be sure to install the thrust collars (4), (5) so that groove side is downward.
- Be sure to align the hole of thrust collars (4), (5) and knock pin (6), (7).
- A large size thrust collar (5) must be lower side.



Tightening torque	Knuckle arm mounting bolt and nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.2 to 66.5 ft-lbs
	Front axle, out mounting bolt and nut	123 to 147 N·m 12.6 to 15.0 kgf·m 91.1 to 108.5 ft-lbs

- (1) Knuckle Arm
- (2) Knuckle Arm
- (3) Front Axle, Out
- (4) Thrust Collar
- (5) Thrust Collar
- (6) Knock Pin
- (7) Knock Pin

W10145970




Power Steering Hose

1. Remove the cylinder covers.
 2. Disconnect the power steering hoses from steering cylinder.
- (When reassembling)**

Tightening torque	Power steering hose retaining nut	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft-lbs
	Cylinder cover mounting screw	60.8 to 70.6 N·m 6.2 to 7.2 kgf·m 44.8 to 52.1 ft-lbs

- (1) Power Steering Hose

W1044808



Steering Cylinder

1. Remove the clamps (4) and remove the steering cylinder (2).
2. Remove the bracket mounting screw and nut and remove the front axle, middle (3).


(When reassembling)

Tightening torque	Bracket mounting screw and nut	77.5 to 90.1 N·m 7.9 to 9.2 kgf·m 57.2 to 66.5 ft-lbs
-------------------	--------------------------------	---

- (1) Bracket, Front
- (2) Steering Cylinder
- (3) Front Axle, Middle
- (4) Clamp
- (5) Bracket, Rear

W1046283

(3) Disassembling 4WD Type Front Axle



Draining Front Axle Case Oil

1. Place oil pans underneath the front axle case.
2. Remove the drain plug (3) both sides and filling port plug (2) to drain the oil.
3. After draining, reinstall the drain plugs (3) and filling port plug (2).

(When reassembling)

- Remove the filling port plug (2) and right and left check plugs (1).
- Fill with the new oil.
- After filling, reinstall the filling port plug (2).

Capacity	Front axle case oil	L3130	6.5 L
		L3430	6.9 U.S.qts.
		L3830	5.7 Imp.qts.
		L4330	9.0 L
		L4630	9.5 U.S.qts.
		L5030	7.9 Imp.qts.

■ IMPORTANT


- Use **KUBOTA SUPER UDT fluid or SAE80, 90 gear oil.** Refer to "LUBRICANTS, FUEL AND COOLANT". (See page G-7, 8.)

(3) Drain Plug

(2) Filling Port Plug

(1) Check Plug

W10128890



Propeller Shaft (4WD Only)

1. Slide the propeller shaft cover (4) and (8) after removing the screws (7).
2. Tap out the spring pins (2), (6) and slide the couplings (1), (5) and then remove the propeller shaft with covers (4), (8).

(When reassembling)

- Apply grease to the splines of propeller shaft 1 (3).

(1) Coupling

(2) Spring Pin

(3) Propeller Shaft 1

(4) Propeller Shaft Cover



(5) Coupling


(6) Spring Pin

(7) Screws

(8) Propeller Shaft Cover

W1048514





Tie-rods


1. Pull out the cotter pin and remove the tie-rod end slotted nuts.
2. Remove the tie-rod with a tie-rod end lifter (Code No. 07909-39051).

(When reassembling)

- After tightening the tie-rod end nut to the specified torques, install a cotter pin as shown in the figure left.

Tightening torque	Tie-rod end nut	L3130	39.2 to 45.1 N·m
		L3430	4.0 to 4.6 kgf·m
		L3830	28.9 to 33.3 ft-lbs
		L4330	156.9 to 176.5 N·m
		L4630	16.0 to 18.0 kgf·m
		L5030	115.7 to 130.2 ft-lbs

W10145200



Bevel Gear Case and Front Gear Case (for L3130, L3430 and L3830)

1. Remove the bevel gear case mounting screws.
2. Remove the bevel gear case (2) and front gear case (3) as a unit from the front axle case (1).


(When reassembling)

Tightening torque	Bevel gear case mounting screw	123 to 147 N·m 12.6 to 15.0 kgf·m 91.1 to 108.5 ft-lbs
-------------------	--------------------------------	--

(1) Front Axle Case
(2) Bevel Gear Case

(3) Front Gear Case

W10227940



Bevel Gear Case and Front Gear Case (for L4330, L4630 and L5030)

1. Remove the bevel gear case mounting screws.
2. Remove the bevel gear case (3) and front gear case (4) as a unit from the front axle case (1).

(When reassembling)


- Apply grease to the O-ring (2) and take care not to damage it.
- Do not interchange right and left bevel gear case assemblies.

Tightening torque	Bevel gear case mounting screw	166.7 to 196.1 N·m 17.0 to 20.0 kgf·m 122.9 to 144.6 ft-lbs
-------------------	--------------------------------	---

(1) Front Axle Case
(2) O-ring

(3) Bevel Gear Case
(4) Front Gear Case

W10155120



Axle Flange and Front Gear Case

1. Remove the axle flange mounting screws.
2. Remove the axle flange (1).

(When reassembling)


- Apply grease to the O-ring (2) of axle flange.
- Tighten the axle flange mounting screws and nuts diagonally in several steps.

Tightening torque	Axle flange mounting screw and nut	L3130	23.6 to 27.5 N·m
		L3430 L3830	2.4 to 2.8 kgf·m 1734 to 20.3 ft-lbs
		L4330	29.4 to 34.3 N·m
		L4630	3.0 to 3.5 kgf·m
		L5030	21.7 to 25.3 ft-lbs

(1) Axle Flange

(2) O-ring

W10156660




Bevel Gear and Bevel Gear Shaft

1. Remove the plug (5).
2. Remove the internal snap ring (4) and shim (3).
3. Tap out the bevel gear (2) with ball bearing.
4. Draw out the bevel gear shaft (1).

- (1) Bevel Gear Shaft
- (2) Bevel Gear
- (3) Shim

- (4) Internal Snap Ring
- (5) Plug

W10159240



Bevel Gear Case and Gears

1. Remove the axle case support (7). (L4330, L4630, L5030 only)
2. Remove the external snap ring (1).
3. Tap the bevel gear case (2) and separate it from the front gear case (3).
4. Remove the internal snap ring (4).
5. Take out the bevel gears (5), (6) with ball bearings, and shims (8).

(When reassembling)


- Install the shims (8) to their original position.
- Install the oil seal (9) of bevel gear case, noting its direction.

Tightening torque	Axle case support mounting screw	127 to 142 N·m 13.0 to 14.5 kgf·m 94.0 to 104.9 ft-lbs
-------------------	----------------------------------	--


- (1) External Snap Ring
- (2) Bevel Gear Case
- (3) Front Gear Case
- (4) Internal Snap Ring
- (5) Bevel Gear

- (6) Bevel Gear
- (7) Axle Case Support
- (8) Shim
- (9) Oil Seal

W10160540



3TMABAB6P026B



Axle




1. Remove the bearing with a special use puller set (Code No. 07916-09032).
2. Take out the bevel gear (2).
3. Take out the collar (1).
4. Tap out the axle (3).

(When reassembling)

- Install the oil seal (5) of axle flange (4), noting its direction as shown in the figure below.

- (1) Collar
- (2) Bevel Gear
- (3) Axle

- (4) Axle Flange
- (5) Oil Seal



Power Steering Hoses



1. Disconnect the power steering hoses (1), (2) from steering cylinder.
2. Remove the cylinder cover.

(When reassembling)

Tightening torque	Power steering hose retaining nut	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft·lbs
	Cylinder cover mounting screw	60.8 to 70.6 N·m 6.2 to 7.2 kgf·m 44.8 to 52.1 ft·lbs

- (1) Power Steering Hose, RH (with Red Tape)
- (2) Power Steering Hose, LH (with Blue Tape)
- (3) Cylinder Cover

W10517600



Steering Cylinder

1. Support the engine and front axle case by disassembling stand.
2. Remove the bracket mounting screw and nut, and remove the front axle case.
3. Remove the tie-rod joint (1) (right side).
4. Remove the cylinder set screw (3).
5. Remove the nipples (2) from steering cylinder.
6. Remove the internal snap ring (4).
7. Draw out the steering cylinder (5).

(When reassembling)


- Apply liquid lock (Three Bond 1324 or equivalent) to the tie-rod joint.

Tightening torque	Tie-rod joint to steering cylinder	166.7 to 196.1 N·m
		17.0 to 20.0 kgf·m
		122.9 to 144.6 ft·lbs

- (1) Tie-rod Joint
- (2) Nipple
- (3) Cylinder Set Screw

- (4) Internal Snap Ring
- (5) Steering Cylinder

W10165600



Power Steering Hoses

1. Disconnect the power steering hoses (1) (2) from steering cylinder.

2. Remove the cylinder cover.




(When reassembling)

Tightening torque	Power steering hose (1) (with fluid)	54.9 to 59.4 N·m 5.8 to 7.0 kgf·m 40.1 to 43.5 ft·lbs
	Cylinder cover mounting (2)	60.8 to 70.8 N·m 6.3 to 7.3 kgf·m 44.8 to 51.8 ft·lbs

(1) Power Steering Hose (RH) (with fluid) (2) Cylinder Cover (3) Cylinder Cover Mounting

(1) Power Steering Hose (LH) (with fluid) (2) Power Steering Hose (LH) (with fluid)

W10165600



Spiral Bevel Pinion Shaft and Differential Gear Assembly

1. Take out the differential yoke shaft (9), (10) both sides.
2. Remove the oil seal (6) and internal snap ring (5).
3. Remove the collar (4).
4. Remove the spiral bevel pinion shaft (3) by the pinion shaft remover (14).
5. Take out the differential gear assembly (2), ball bearing (7) and shim (8) from left side of front axle case (1).
6. Remove the stake of lock nut (11), and then remove the lock nut (11).
7. Remove the taper roller bearings (12).

(When reassembling)

- Replace the lock nut (11) and oil seal (6) with new ones.
- Apply grease to the oil seal (6).
- Install the shims and collars to their original position.
- Install the taper roller bearings correctly, noting their direction and apply gear oil to them.
- Tighten up the lock nut (11) until the turning force of the spiral bevel pinion shaft reaches the factory specification. (See page 6-S21.)
- When press-fitting an oil seal (6), observe the dimension "A" described in the figure.

■ IMPORTANT

- **After adjusting the turning torque stake the lock nut (11) firmly.**


Turning torque of spiral bevel pinion shaft	Factory spec.	0.98 to 1.18 N·m 0.10 to 0.12 kgf·m 0.72 to 0.89 ft-lbs

- (1) Front Axle Case
- (2) Differential Gear Assembly
- (3) Spiral Bevel Pinion Shaft
- (4) Adjusting Collar
- (5) Internal Snap Ring
- (6) Oil Seal
- (7) Ball Bearing
- (8) Shim
- (9) Differential Yoke Shaft R.H.

- (10) Differential Yoke Shaft L.H.
- (11) Lock Nut
- (12) Taper Roller Bearing
- (13) Collar
- (14) Pinion Shaft Remover

**A : Dimension A : 0.5 to 1 mm
(0.020 to 0.039 in.)**

W10168650



Differential Gear

1. Remove the differential case cover mounting screws (9) and then take out the differential case cover (5), ball bearing (6) and spiral bevel gear (7) as a unit.
2. Remove the external snap ring (8), and then remove the ball bearing (6) and spiral bevel gear (7) as a unit with a puller.
3. Remove the straight pin (13).
4. Pull out the pinion shaft (10) and take out the differential pinions (4) and differential side gears (12).

(When reassembling)

- Apply molybdenum disulfide (Three Bond 1901 or equivalent) to the inner circumferential surface of the differential side gears (12) and differential pinions (4).

Tightening torque	Differential case cover mounting screw	L3130	48.0 to 58.8 N·m
		L3430	4.9 to 6.0 kgf·m
	L3830	35.4 to 43.4 ft·lbs	
	L4330	60.8 to 70.6 N·m	
	L4630	6.2 to 7.2 kgf·m	
	L5030	44.8 to 52.1 ft·lbs	

- (1) Shim
- (2) Differential Case
- (3) Thrust Collar
- (4) Differential Pinion
- (5) Differential Case Cover
- (6) Ball Bearing
- (7) Spiral Bevel Gear

- (8) External Snap Ring
- (9) Differential Case Cover Mounting Screw
- (10) Pinion Shaft
- (11) Shim
- (12) Differential Side Gear
- (13) Straight Pin




[3] SERVICING


(1) 2WD Type



3TLABAB6P019A



3TLABAB6P020A



3TMABAB6P038A



3TLABAB6P021A

Clearance between Front Axle Middle Boss and Shaft Bracket Bushing

1. Measure the front axle middle boss O.D. at several points where it contacts with the bushing.
2. Measure the shaft bracket 1 bushing I.D. and bracket 2 bushing I.D. in the same method, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace them.

(When reassembling)

- Before press-fitting the bushing, install the new thrust collar.
- Install the oil seals, noting their direction. (Refer to figure left.)

■ IMPORTANT

- After replacing the bushing, be sure to adjust the front axle rocking force. (See page 6-S7.)

Clearance between front axle middle boss and bushing	Factory spec.	0.000 to 0.147 mm 0.00000 to 0.00579 in.
	Allowable limit	0.3 mm 0.012 in.

Front axle middle boss O.D.	Factory spec.	39.938 to 40.000 mm 1.57236 to 1.57480 in.
	Bushing I.D.	Factory spec.

(1) Thrust Collar
(2) Bushing

(3) Oil Seal

W10177400

Clearance between Knuckle Shaft (Kingpin) and Bushing

1. Measure the shaft O.D. at several points where it contacts with the bushings.
2. Measure the bushing I.D. in the same method, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace the bushing.


(When reassembling)

- Remove the bushing with a bushing puller.

Clearance between knuckle shaft (kingpin) and bushing	Factory spec.	0.000 to 0.285 mm 0.00000 to 0.01122 in.
	Allowable limit	0.4 mm 0.016 in.

Knuckle shaft O.D.	Factory spec.	27.880 to 27.900 mm 1.09764 to 1.09842 in.
	Bushing I.D.	Factory spec.

W10179760

(2) 4WD Type**Clearance between Differential Case (Differential Case Cover) and Differential Side Gear**

1. Measure the differential side gear O.D..
2. Measure the differential case bore I.D. and calculate the clearance.
3. Measure the differential case cover bore I.D. and calculate the clearance.
4. If the clearance exceeds the allowable limit, replace faulty parts. **(L3130, L3430 and L3830)**

Clearance between differential case (differential case cover) and differential side gear	Factory spec.	0.050 to 0.151 mm 0.00197 to 0.00594 in.
	Allowable limit	0.20 mm 0.0079 in.

Differential case bore I.D.	Factory spec.	32.000 to 32.062 mm 1.25984 to 1.26228 in.
Differential case cover bore I.D.	Factory spec.	32.000 to 32.025 mm 1.25984 to 1.26083 in.
Differential side gear O.D.	Factory spec.	31.911 to 31.950 mm 1.25634 to 1.25789 in.

(L4330, L4630 and L5030)

Clearance between differential case (differential case cover) and differential side gear	Factory spec.	0.050 to 0.114 mm 0.00197 to 0.00449 in.
	Allowable limit	0.20 mm 0.0079 in.

Differential case bore I.D.	Factory spec.	32.000 to 32.025 mm 1.25984 to 1.26083 in.
Differential case cover bore I.D.	Factory spec.	32.000 to 32.025 mm 1.25984 to 1.26083 in.
Differential side gear O.D.	Factory spec.	31.911 to 31.950 mm 1.25634 to 1.25789 in.

W10182040


Clearance between Pinion Shaft and Differential Pinion


1. Measure the pinion shaft O.D.
2. Measure the differential pinion I.D. and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace faulty parts.

Clearance between pinion shaft and differential pinion	Factory spec.	0.064 to 0.100 mm 0.00252 to 0.00394 in.
	Allowable limit	0.25 mm 0.0096 in.

Pinion shaft O.D.	Factory spec.	13.950 to 13.968 mm 0.54921 to 0.54992 in.
Differential pinion I.D.	Factory spec.	14.032 to 14.050 mm 0.55244 to 0.55315 in.

W10183690





Backlash between Differential Pinion and Differential Side Gear

1. Set a dial gauge (lever type) on a tooth of the differential pinion.
2. Fix the differential side gear and move the differential pinion to measure the backlash.
3. If the measurement exceeds the factory specifications, adjust with the differential side gears shims.


Backlash between differential pinion and differential side gear	Factory spec.	0.2 to 0.3 mm 0.008 to 0.012 in.
	Allowable limit	0.4 mm 0.016 in.

(Reference)

- Thickness of adjusting shims

0.4 mm (0.016 in.)	1.0 mm (0.039 in.)
0.6 mm (0.024 in.)	1.2 mm (0.047 in.)
0.8 mm (0.031 in.)	
- Tooth contact : More than 35 %

W10185110



Turning Torque of Spiral Bevel Pinion Shaft (Pinion Shaft Only)

1. Install the spiral bevel pinion shaft assembly only to the front axle case.
2. Measure the turning torque of spiral bevel pinion shaft.
3. If the turning torque is not within the factory specifications, adjust with the lock nut.
If the turning torque is not able to adjust by lock nut (2), change the thickness of collar (1) and adjust with lock nut (2) again.

(Reference)

- Standard size of collar (1) : 10.0 mm (0.394 in.) of thickness

Turning torque of spiral bevel pinion shaft	Factory spec.	0.98 to 1.18 N·m 0.10 to 0.12 kgf·m 0.72 to 0.87 ft-lbs
---	---------------	---


NOTE


- After turning torque adjustment, be sure to stake the lock nut.

(1) Collar

(2) Lock Nut

W10184540






Backlash between Spiral Bevel Pinion Shaft and Spiral Bevel Gear

1. Set a dial gauge (lever type) with its finger on the spline of spiral bevel pinion shaft.
2. Measure the backlash by moving the spiral bevel pinion shaft by hand lightly.
3. If the backlash is not within the factory specifications, change the adjusting collar (3), (4).

For example, when the backlash is too large, change the collar (3) to thinner one and change the collar (4) to thicker one. At this time, if the collar (3) is thinned by 1 mm, the collar (4) must be thickened by 1 mm.

(Reference)


- Standard size of adjusting collar (3), (4) : 6.0 mm (0.236 in.) of thickness (total 12.0 mm)
 - Standard size of adjusting shim (5) : 2.0 mm (0.079 in.) of thickness
4. Adjust the backlash properly by repeating the above procedures.



Backlash between spiral bevel pinion shaft and spiral bevel gear	Factory spec.	L3130 L3430 L3830	0.1 to 0.3 mm 0.004 to 0.012 in.
	Factory spec.	L4330 L4630 L5030	0.2 to 0.3 mm 0.008 to 0.012 in.

- (1) Spiral Bevel Gear
- (2) Spiral Bevel Pinion Shaft
- (3) Adjusting Collar
- (4) Adjusting Collar
- (5) Adjusting Shim

W10186900



Backlash between Bevel Gear and Bevel Gear

1. Stick a strip of fuse spots on the bevel gear (1) with grease.
2. Fix the front axle case, bevel gear case and front gear case.
3. Turn the axle.
4. Remove the bevel gear case from front axle case and measure the thickness of the fuses with an outside micrometer.
5. If the backlash is not within the factory specifications, adjust with shim (3).


Backlash between bevel gear (2) and bevel gear (1)	Factory spec.	0.2 to 0.3 mm 0.008 to 0.012 in.
	Allowable limit	0.6 mm 0.024 in.

(Reference)

- Thickness of adjusting shims
 - 0.4 mm (0.016 in.) 1.0 mm (0.039 in.)
 - 0.6 mm (0.024 in.) 1.2 mm (0.047 in.)
 - 0.8 mm (0.031 in.)
- Tooth contact : More than 35 %

- (1) Bevel Gear
- (2) Bevel Gear
- (3) Shim

W10190950



Backlash between Bevel Gear and Bevel Gear

1. Stick a strip of fuse to three spots on the bevel gear (1) with grease.
2. Fix the axle flange and front gear case.
3. Turn the axle.
4. Remove the axle flange from front gear case and measure the thickness of the fuse with an outside micrometer.
5. If the backlash is not within the factory specifications, adjust with shim (3).

Backlash between bevel gear (2) and bevel gear (1)	Factory spec.	0.2 to 0.3 mm 0.008 to 0.012 in.
	Allowable limit	0.6 mm 0.024 in.

(Reference)

- Thickness of adjusting shims
 0.4 mm (0.016 in.) 2.0 mm (0.079 in.)
 0.5 mm (0.020 in.)
- Tooth contact : More than 35 %

- (1) Bevel Gear
- (2) Bevel Gear

(3) Shim





0.100 to 0.152 mm 0.004 to 0.012 in.	Factory spec.	Front axle case bore (rear) O.D.
0.098 to 0.150 mm	Allowable limit	Backlash during (rear) I.D.
0.100 to 0.152 mm	Factory spec.	Front axle case bore (rear) O.D.
0.098 to 0.150 mm	Allowable limit	Backlash during (rear) I.D.
0.100 to 0.152 mm	Factory spec.	Front axle case bore (rear) O.D.
0.098 to 0.150 mm	Allowable limit	Backlash during (rear) I.D.

Press-fitting Bushing
 • When press-fitting a new bushing observe the dimension described in the figure.

12.0 to 13.2 mm 0.47 to 0.51 in.	Reference value	Press-fit depth of bushing (A)
-------------------------------------	-----------------	-----------------------------------

NOTE
 • After replacing the bushing, be sure to adjust the front axle locking force. (See page 8-27.)

(A) Depth of Bushing



Clearance between Front Axle Case Bosses and Bracket Bushings

1. Measure the front axle case bosses O.D. with an outside micrometer.
2. Measure the bracket bushing I.D. and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace the bracket bushing.

Clearance between front axle case boss (front) and bracket bushing (front)	Factory spec.	0.120 to 0.275 mm 0.00472 to 0.01083 in.
	Allowable limit	0.50 mm 0.01969 in.

Front axle case boss (front) O.D.	Factory spec.	49.950 to 49.975 mm 1.96653 to 1.96752 in.
Bracket bushing (front) I.D.	Factory spec.	50.095 to 50.225 mm 1.97224 to 1.97736 in.

(L3130, L3430 and L3830)

Clearance between front axle case boss (rear) and bracket bushing (rear)	Factory spec.	0.100 to 0.292 mm 0.00394 to 0.01150 in.
	Allowable limit	1.0 mm 0.03937 in.

Front axle case boss (rear) O.D.	Factory spec.	69.970 to 70.000 mm 2.75472 to 2.75590 in.
Bracket bushing (rear) I.D.	Factory spec.	70.100 to 70.262 mm 2.75984 to 2.76622 in.

(L4330, L4630 and L5030)

Clearance between front axle case boss (rear) and bracket bushing (rear)	Factory spec.	0.025 to 0.195 mm 0.00098 to 0.00768 in.
	Allowable limit	0.50 mm 0.01969 in.

Front axle case boss (rear) O.D.	Factory spec.	80.000 to 80.035 mm 3.14961 to 3.15098 in.
Bracket bushing (rear) I.D.	Factory spec.	80.060 to 80.195 mm 3.15197 to 3.15728 in.

■ Press-fitting Bushing

- When press-fitting a new bushing, observe the dimension described in the figure.

Press-fit depth of bushing (A)	Reference value	12.0 to 13.0 mm 0.47 to 0.51 in.
--------------------------------	-----------------	-------------------------------------


■ NOTE

- After replacing the bushing, be sure to adjust the front axle rocking force. (See page 6-S7.)

(1) Bushing

(A) Depth of Bushing

W10194290



Clearance between Bevel Gear Case Boss and Front Axle Support Bushing (for L4330, L4630 and L5030)

1. Measure the bevel gear case boss O.D. with an outside micrometer.
2. Measure the support bushing I.D. and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace it.

Clearance between bevel gear case boss and front axle support bushing	Factory spec.	0.080 to 0.232 mm 0.00315 to 0.00913 in.
	Allowable limit	1.0 mm 0.03937 in.

Bevel gear case boss O.D.	Factory spec.	54.970 to 55.000 mm 2.16417 to 2.16535 in.
Front axle support bushing I.D.	Factory spec.	55.080 to 55.202 mm 2.16850 to 2.17331 in.

W10198060


7 STEERING

MECHANISM

CONTENTS

1. STRUCTURE	7-M1
2. HYDRAULIC CIRCUIT	7-M2
3. HYDRAULIC PUMP	7-M3
4. STEERING CONTROLLER	7-M4
[1] CONTROL VALVE	7-M5
[2] METERING DEVICE (GEROTOR)	7-M5
[3] RELIEF VALVE (WITH CHECK VALVE)	7-M6
[4] OIL FLOW	7-M7
5. STEERING CYLINDER	7-M9

1. STRUCTURE



(1) Steering Wheel
(2) Steering Joint Shaft 1


(3) Hydraulic Pump
(4) Steering Cylinder

(5) Steering Controller
(6) Steering Joint Shaft 3

(7) Steering Joint Shaft 2
(8) Steering Shaft

The full hydrostatic type power steering is used on these tractors. This steering system is composed of steering wheel, steering joint shafts, steering controller, steering cylinder and other components shown in the figure.

2. HYDRAULIC CIRCUIT



When the engine starts, the hydraulic pump (8) pressure-feeds the oil, drawn from the transmission case (7) through the oil filter (6), to the steering controller (3).

The oil which has entered steering controller (3) is directed to control valve (10).

As the steering wheel is turned, control valve (10) operates and the oil passes through gerotor (1) and into steering cylinder (2). The cylinder rod then moves to control the directional movement of the front wheels.

Return oil from steering cylinder (2) passes through control valve (10) is sent to the PTO clutch valve, HST, GST valve, etc..

When the engine is not operating, and the steering wheel is turned, gerotor (1) rotates to supply oil to steering cylinder (2). Thus the machine can be steered manually.


- (1) Gerotor
- (2) Steering Cylinder
- (3) Steering Controller
- (4) Relief Valve
- (5) Check Valve
- (6) Oil Filter
- (7) Transmission Case
- (8) Hydraulic Pump

- (9) Steering Wheel
- (10) Control Valve

A : To Three Point Hydraulic System and Others
B : To PTO Clutch Valve, HST, GST Valve, etc.

W1012726

3. HYDRAULIC PUMP



The gear type hydraulic pump is adopted for these tractor. This pump is tandem type and it is composed two pair of gears, side plates, bushings and other components as shown in the figure.

The hydraulic pump pressure-fed the oil drawn from the transmission case through oil filter to power steering circuit and main hydraulic circuit.


- (1) Drive Gear 1
- (2) Coupling
- (3) Drive Gear 2
- (4) Driven Gear 1
- (5) Bushing
- (6) Bushing
- (7) Driven Gear 2
- (8) Side Plate

- A : From Power Steering Controller
- B : From Transmission Case
- C : To Power Steering Controller
- D : To Main Hydraulic Circuit

W1014335

The steering controller mainly consists of a control valve, a metering device and a relief valve with check valves. The metering device comprises a set of special gear called "Gerator".


4. STEERING CONTROLLER



- | | | | |
|-------------------------|------------------|-----------------|-----------------|
| (1) Port Cover | (4) Drive Plate | (6) Valve Plate | (8) Stator |
| (2) Hex. Drive Assembly | (5) Relief Valve | (7) Drive Link | (9) Upper Cover |
| (3) Rotor | | | |

The steering controller mainly consists of a control valve, a metering device and a relief valve with check valve. The metering device comprises a set of special gear called **"Gerotor"**.

[1] CONTROL VALVE




The control valve is a rotary plate type valve. When the steering wheel is not turned, the position of the valve plate (5) and the manifolds (1), (3) is kept neutral by the centering springs (2). This causes the forming of a **"Neutral"** oil circuit.

When the steering wheel is turned either clockwise or counterclockwise, the position of the valve plate (5) and manifolds (1), (3) changes against the centering spring. This allows the forming of a **"Right Turning"** or **"Left Turning"** oil circuit. At the same time, the gerotor rotates with the valve plate and sends the oil to the cylinder corresponding to the rotation of the steering wheel.

- | | |
|------------------------|-------------------------|
| (1) Isolation Manifold | (4) Hex. Drive Assembly |
| (2) Centering Spring | (5) Valve Plate |
| (3) Port Manifold | (6) Valve Ring |

W1013040

[2] METERING DEVICE (GEROTOR)




All oil directed from the hydraulic pump to the steering cylinder passes through the metering device (gerotor) on its way. This metering device is a trochoid pump. As the steering wheel is turned, the action is transmitted directly to stator (2) through drive plate (1). Thus, the gerotor sends the amount of oil corresponding to the turn of the steering wheel to the hydraulic cylinder, and the front wheels are moved through the angle corresponding to the turn of the steering wheel.

When the engine is not operating or the hydraulic pump fails. The gerotor serves as a manual pump, and thus the machine can be steered manually.

- | | |
|-----------------|----------------|
| (1) Drive Plate | (3) Rotor |
| (2) Stator | (4) Commutator |

W1013277

[3] RELIEF VALVE (WITH CHECK VALVE)






If the pressure in the hydraulic circuit rises above the set pressure of the relief valve, the relief valve will actuate to prevent the pressure from rising further and protect the hydraulic system. Also, if no oil is supplied from the hydraulic pump, the relief valve will act as a check valve and help draw oil from the return oil line to the drain hose, thus making it possible to steer the machine manually.


- (1) Outlet Port
- (2) Check Valve
- (3) Auxiliary Port
- (4) Inlet Port
- (5) R Port
- (6) L Port
- (7) Relief Valve

- [A] Normal Condition
- [B] Relief Valve in Operation
- [C] Check Valve in Operation
- a : From Hydraulic Pump
- b : To Control Valve
- c : From Control Valve
- d : To Drain Hose

W1013357



[4] OIL FLOW



■ Neutral Position

When the steering wheel (1) is not being turned, valve plate (2) is held in the neutral position by centering spring. Under this condition, an oil passage is formed between P port (from pump) and T port (to transmission case) in the control valve, and all oil from the hydraulic pump flows to T port.

- (1) Steering Wheel
- (2) Valve Plate
- (3) Gerotor
- (4) Steering Cylinder
- (5) Steering Controller
- (6) Relief Valve

- P : Pump Port
- T : Tank Port
- R : Cylinder Port R
- L : Cylinder Port L

W1013515

■ Right Turn

When the steering wheel is turned to the right, the action is transmitted through the drive plate, gerotor, and drive link to the control valve. Valve plate (2) then rotates to the right on manifolds, located on the opposite faces of the valve plate (2). Thus, the P port passage in the control valve is connected with gerotor (3).

The stator of gerotor (3) turns by the amount corresponding to the turn of the steering wheel (1), and the gerotor performs the metering function and lets oil through it, the amount of which corresponds to the turn of the steering wheel (1).


The oil which has passed through gerotor (3) flows back to the control valve, in which it is directed to cylinder port R to operate steering cylinder (4). Consequently, the front wheels are moved to the right through the angle corresponding to the amount of the oil.


When steering cylinder (4) operates, oil returning to cylinder port L flows back to the transmission case through the passage connected to T port in the control valve.

- (1) Steering Wheel
- (2) Valve Plate
- (3) Gerotor
- (4) Steering Cylinder
- (5) Steering Controller
- (6) Relief Valve

- P : Pump Port
- T : Tank Port
- R : Cylinder Port R
- L : Cylinder Port L

W1013646







■ Left Turn

The steering system operates in the same way at a left-turn as well, except that oil flows into and out of steering cylinder in the directions opposite to those at a right-turn.

- (1) Steering Wheel
- (2) Valve Plate
- (3) Gerotor
- (4) Steering Cylinder
- (5) Steering Controller
- (6) Relief Valve

- P : Pump Port
- T : Tank Port
- R : Cylinder Port R
- L : Cylinder Port L



■ Right Turn

When the steering wheel is turned to the right, the action is transmitted through the drive plate, gerotor, and valve plate to the control valve. The valve plate is turned to the right on the manifold, forcing the opposite faces of the valve plate (2). Thus, the R port passage in the control valve is connected with gerotor (3).

The rotor of gerotor (3) turns by the amount corresponding to the turn of the steering wheel (1), and the gerotor performs the metering function and lets oil through it, the amount of which corresponds to the turn of the steering wheel (1).


The oil which has passed through gerotor (3) flows back to the control valve, in which it is directed to cylinder port R to operate steering cylinder (4). Consequently, the front wheels are moved to the right through the angle corresponding to the amount of the oil.

When steering cylinder (4) operates, oil returning to cylinder port L flows back to the transmission case through the passage connected to T port in the control valve.

- (1) Steering Wheel
- (2) Valve Plate
- (3) Gerotor
- (4) Steering Cylinder
- (5) Steering Controller
- (6) Relief Valve
- P : Pump Port
- T : Tank Port
- R : Cylinder Port R
- L : Cylinder Port L

W1013826

5. STEERING CYLINDER



3TLABAB7P012A

- | | | | |
|----------------|-------------------|---------------------|------------------------|
| (1) Tie-rod | (3) Head Cover | (5) Head Cover | (7) Internal Snap Ring |
| (2) Piston Rod | (4) Cylinder Tube | (6) Front Axle Case | |

The steering cylinder is single piston both rod double-acting type. This steering cylinder is installed parallel to the front axle and connected to tie-rods. (The above figure is shown for 4 wheel drive model. Regarding 2 wheel drive model, please refer to TRACTOR MECHANISM workshop manual.)

The tie-rods connected to both knuckle arm guarantees equal steering movement to both front wheels.

The steering cylinder provides force in both directions. Depending upon direction the steering wheel is turned pressure oil enters at one end of the cylinder to extend, or the other end to retract it, thereby turning front wheel of the tractor.

SERVICING

CONTENTS

1. TROUBLESHOOTING	7-S1
2. SERVICING SPECIFICATIONS	7-S2
3. TIGHTENING TORQUES	7-S4
4. CHECKING, DISASSEMBLING AND SERVICING.....	7-S5
[1] HYDRAULIC PUMP	7-S5
(1) Checking	7-S5
(2) Disassembling and Assembling	7-S9
(3) Servicing	7-S11
[2] STEERING CONTROLLER	7-S13
(1) Checking	7-S13
(2) Disassembling and Assembling	7-S14
[3] STEERING CYLINDER.....	7-S15
(1) Disassembling and Assembling	7-S15
(2) Servicing	7-S17
[4] STEERING LINKAGE	7-S18
(1) Disassembling and Assembling	7-S18

1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
Tractor Can Not Be Steered	<ul style="list-style-type: none"> Steering controller broken Steering linkage broken Pipe broken 	Replace Replace Replace	7-S14 7-S18, S19 —
Front Wheels Vibrate	<ul style="list-style-type: none"> Improper toe-in adjustment Air in the hydraulic system Improperly mounted wheels Tie-rod end loose or worn Front wheel hub bearing worn Clearance between front axle center pivots and bracket bushing excessive Steering controller malfunctioning 	Adjust Bleed Retighten Retighten or replace Replace Replace Replace	6-S6 7-S14 7-S15, S16 7-S15, S16 6-S10 6-S19, S24 7-S14
Hard Steering	<ul style="list-style-type: none"> Steering linkage bushings sticking Hydraulic pump malfunctioning Overload Transmission fluid improper or insufficient Oil leak from pipe joint Insufficient tire pressure Steering controller malfunctioning Relief valve malfunctioning 	Replace Replace — Change or replenish Retighten Inflate Replace Replace	— 7-S10, S11 — G-7, 8 — G-53 7-S14 7-S14
Steering Force Fluctuates	<ul style="list-style-type: none"> Air sucked in pump due to leaking or missing of oil Air sucked in pump from suction circuit 	Replenish Repair	— —
Excessive Steering Wheel Play	<ul style="list-style-type: none"> Steering linkage worn 	Replace	7-S18, S19
Front Wheels Wander to Right or Left	<ul style="list-style-type: none"> Air sucked in pump due to leak of oil Air sucked in pump from suction circuit Tire pressure uneven Insufficient bleeding Improper toe-in adjustment Clearance between front axle center pivots and brackets bushings excessive Tie-rod end loose or worn Steering linkage worn Steering controller malfunctioning 	Replenish Repair Inflate Bleed Adjust Replace Retighten or replace Replace Replace	— — G-53 7-S14 6-S6 6-S19, S24 7-S15, S16 7-S18, S19 7-S14
Wheels Are Turned to a Direction Opposite to Steering Direction	<ul style="list-style-type: none"> Power steering hoses connected in reverse 	Repair	7-S14
Noise	<ul style="list-style-type: none"> Air sucked in pump due to lack of oil Air sucked in pump from suction circuit Pipe deformed 	Replenish Repair Replace	— — —

W10143220

STEERING CYLINDER

Item		Factory Specification	Allowable Limit
Steering Cylinder	I.D. [2WD]	50.000 to 50.062 mm 1.96850 to 1.97094 in.	50.100 mm 1.97244 in.
	I.D. [4WD]	55.000 to 55.074 mm 2.16535 to 2.16827 in.	55.100 mm 2.16929 in.
Rod to Bushing		Clearance	0.009 to 0.127 mm 0.00035 to 0.00500 in.

W10151200

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-9.)

Item	N·m	kgf·m	ft-lbs
Regulator delivery pipe joint bolt	39.2 to 49.0	4.0 to 5.0	28.9 to 36.2
Power steering delivery pipe joint bolt (HST model)	39.2 to 49.0	4.0 to 5.0	28.9 to 36.2
Power steering delivery pipe joint bolt (Except HST model)	49.0 to 68.6	5.0 to 7.0	36.2 to 50.6
GST/PTO delivery pipe joint bolt	34.3 to 39.2	3.5 to 4.0	25.3 to 28.9
Regulator valve mounting screw	17.7 to 20.6	1.8 to 2.1	13.0 to 15.2
Hydraulic pump assembly mounting screw and nut	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Pump cover mounting screw	39.2 to 44.1	4.0 to 4.5	28.9 to 32.5
Power steering hose retaining nut	24.5 to 29.4	2.5 to 3.0	18.1 to 21.7
Power steering delivery pipe retaining nut	49.0 to 58.8	5.0 to 6.0	36.2 to 43.4
Front wheel mounting nut	137.3	14.0	101.3
Tie-rod end slotted nut (2WD)	49.0 to 68.6	5.0 to 7.0	36.2 to 50.6
Tie-rod joint	166.7 to 196.1	17.0 to 20.0	123.0 to 144.7
Tie-rod clamp mounting bolt and nut (2WD)	60.8 to 70.6	6.2 to 7.2	44.8 to 52.1
Tie-rod end lock nut (2WD)	166.7 to 196.1	17.0 to 20.0	123.0 to 144.7
Guide assembly	181.1 to 288.9	18.5 to 29.5	133.6 to 213.1
Tie-rod end slotted nut (L3130, L3430, L3830 4WD)	39.2 to 45.1	4.0 to 4.6	28.9 to 33.3
(L4330, L4630, L5030 4WD)	156.9 to 176.5	16.0 to 18.0	115.7 to 130.2
Tie-rod joint lock nut (4WD)	166.7 to 196.1	17.0 to 20.0	123.0 to 144.7
Steering wheel mounting nut	48.1 to 55.9	4.9 to 5.7	35.4 to 41.2

W1012736

4. CHECKING, DISASSEMBLING AND SERVICING

[1] HYDRAULIC PUMP

(1) Checking

(A) Pump Test Using Flow-meter [Manual and Glide Shift Transmission Models]




Preparation

1. Open the bonnet (1).
2. Remove the side skirt RH (2).
3. Remove the fuel tank frame support (3), cover (6) and steering joint shaft (4).
4. Remove the regulator delivery pipe (7).

(When reassembling)

- Install the copper washers firmly.
- Tighten the steering joint shaft bracket mounting screw after adjusting the position of steering joint shaft bracket (5) for smooth rotation of the steering wheel.




Tightening torque	Regulator delivery pipe joint bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft·lbs
-------------------	------------------------------------	---

- | | |
|-----------------------------|----------------------------------|
| (1) Bonnet | (5) Steering Joint Shaft Bracket |
| (2) Side Skirt RH | (6) Cover |
| (3) Fuel Tank Frame Support | (7) Regulator Delivery Pipe |
| (4) Steering Joint Shaft | |

W1012306





Hydraulic Flow Test

■ **IMPORTANT**

- When using a flowmeter other than KUBOTA specified flowmeter, be sure to use the instructions with that flowmeter.
 - Do not close the flowmeter loading valve completely, before testing, because it has no relief valve.
1. Loosen the GST/PTO delivery pipe and install the adaptor 52 to the pump discharge port.
 2. Connect the hydraulic test hose to the adaptor 52 and flowmeter inlet port.
 3. Connect the other hydraulic test hose to the flowmeter outlet port and to transmission fluid filling plug hole.
 4. Open the flowmeter loading valve completely. (Turn counterclockwise.)
 5. Start the engine and set the engine speed at **2000 to 2200 min⁻¹ (rpm)**.
 6. Slowly close the loading valve to generate pressure approx. **9.8 MPa (100 kgf/cm², 1422 psi)**. Hold in this condition until oil temperature reaches approx. 40 °C (104 °F).
 7. Open the loading valve completely.
 8. Set the engine speed. (Refer to **Condition**.)
 9. Read and note the pump delivery at no pressure.
 10. Slowly close the loading valve to increase pressure (Rated pressure). As the load is increased, engine speed drops, therefore, reset the engine speed.
 11. Read and note the pump delivery at rated pressure.
 12. Open the loading valve completely and stop the engine.
 13. If the pump delivery does not reach the allowable limit, check the pump suction line, oil filter or hydraulic pump.

Condition

- Engine Speed.....Approx. 2700 min⁻¹ (rpm) (Except L4330)
Approx. 2600 min⁻¹ (rpm) (L4330)
- Rated pressure

L3130, L3830 2WD	8.0 to 9.0 MPa 81.6 to 91.8 kgf/cm ² 1160 to 1305 psi
L3130, L3430, L3830 4WD	10.7 to 11.7 MPa 109.1 to 119.3 kgf/cm ² 1552 to 1697 psi
L4330, L4630, L5030 4WD	12.7 to 13.7 MPa 129.5 to 139.7 kgf/cm ² 1842 to 1987 psi
- Oil Temperature 40 to 60 °C
104 to 140 °F

W10128770

Hydraulic Flow Test (Continued)

[L3130, L3430, L3830, L4630, L5030]

Hydraulic pump delivery at no pressure	Factory spec.	Above 18.6 L/min. 4.91 U.S.gals./min. 4.09 Imp.gals./min.
Hydraulic pump delivery at rated pressure	Factory spec.	Above 18.2 L/min. 4.81 U.S.gals./min. 4.00 Imp.gals./min.
	Allowable limit	16.2 L/min. 4.28 U.S.gals./min. 3.56 Imp.gals./min.

[L4330]

Hydraulic pump delivery at no pressure	Factory spec.	Above 17.9 L/min. 4.73 U.S.gals./min. 3.94 Imp.gals./min.
Hydraulic pump delivery at rated pressure	Factory spec.	Above 17.5 L/min. 4.62 U.S.gals./min. 3.85 Imp.gals./min.
	Allowable limit	15.6 L/min. 4.12 U.S.gals./min. 3.43 Imp.gals./min.

W1021364

(B) Pump Test Using Flow-meter [Hydrostatic Transmission Models]




Preparation

1. Open the bonnet (1).
2. Remove the side skirt RH (2).
3. Remove the fuel tank frame support (3), cover (6) and steering joint shaft (7).
4. Remove the fuel filter bracket (5) and power steering delivery pipe (4).

(When reassembling)


- Install the copper washers firmly.
- Tighten the steering joint shaft bracket mounting screw after adjusting the position of steering joint shaft bracket (8) for smooth rotation of the steering wheel.



Tightening torque	Power steering delivery pipe joint bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft·lbs
-------------------	---	---

- | | |
|----------------------------------|----------------------------------|
| (1) Bonnet | (5) Fuel Filter Bracket |
| (2) Side Skirt RH | (6) Cover |
| (3) Fuel Tank Frame Support | (7) Steering Joint Shaft |
| (4) Power Steering Delivery Pipe | (8) Steering Joint Shaft Bracket |

W1013423



Hydraulic Flow Test


■ IMPORTANT

- When using a flowmeter other than KUBOTA specified flowmeter, be sure to use the instructions with that flowmeter.
- Do not close the flowmeter loading valve completely, before testing, because it has no relief valve.

1. Install the adaptor 52 to the pump discharge port.
2. Connect the hydraulic test hose to the adaptor 52 and flowmeter inlet port.
3. Connect the other hydraulic test hose to the flowmeter outlet port and to transmission fluid filling plug hole.
4. Open the flowmeter loading valve completely. (Turn counterclockwise.)
5. Start the engine and set the engine speed at **2000 to 2200 min⁻¹ (rpm)**.
6. Slowly close the loading valve to generate pressure approx. **9.8 MPa (100 kgf/cm², 1422 psi)**. Hold in this condition until oil temperature reaches approx. 40 °C (104 °F).
7. Open the loading valve completely.
8. Set the engine speed. (Refer to **Condition**.)
9. Read and note the pump delivery at no pressure.
10. Slowly close the loading valve to increase pressure (Rated pressure). As the load is increased, engine speed drops, therefore, reset the engine speed.
11. Read and note the pump delivery at rated pressure.
12. Open the loading valve completely and stop the engine.
13. If the pump delivery does not reach the allowable limit, check the pump suction line, oil filter or hydraulic pump.

Condition

- Engine Speed.....Approx. 2700 min⁻¹ (rpm) (Except L4330)
Approx. 2600 min⁻¹ (rpm) (L4330)
- Rated pressure
L3130, L3430, L3830 4WD 10.7 to 11.7 MPa
109.1 to 119.3 kgf/cm²
1552 to 1697 psi
L4330, L4630, L5030 4WD 12.7 to 13.7 MPa
129.5 to 139.7 kgf/cm²
1842 to 1987 psi
- Oil Temperature 40 to 60 °C
104 to 140 °F



W10139600

Hydraulic Flow Test (Continued)

[L3130, L3430, L3830, L4630, L5030]

Hydraulic pump delivery at no pressure	Factory spec.	Above 18.6 L/min. 4.91 U.S.gals./min. 4.09 Imp.gals./min.
Hydraulic pump delivery at rated pressure	Factory spec.	Above 18.2 L/min. 4.81 U.S.gals./min. 4.00 Imp.gals./min.
	Allowable limit	16.2 L/min. 4.28 U.S.gals./min. 3.56 Imp.gals./min.

[L4330]

Hydraulic pump delivery at no pressure	Factory spec.	Above 17.9 L/min. 4.73 U.S.gals./min. 3.94 Imp.gals./min.
Hydraulic pump delivery at rated pressure	Factory spec.	Above 17.5 L/min. 4.62 U.S.gals./min. 3.85 Imp.gals./min.
	Allowable limit	15.6 L/min. 4.12 U.S.gals./min. 3.43 Imp.gals./min.


W1021775

(2) Disassembling and Assembling

■ IMPORTANT

- The hydraulic pump is precision machined and assembled : if disassemble once, it may be unable to maintain its original performance. Therefore, when the hydraulic pump fails, replacement should be carried out with the hydraulic pump assembled except when emergency repair is unavoidable.
- When repair is required, follow the disassembly and servicing procedures shown below with utmost care.
- Be sure to test the hydraulic pump with a flowmeter before disassembling.
- After reassembly, be sure to perform break-in operation and ensure that there is nothing abnormal with the hydraulic pump.

(A) Removing Hydraulic Pump Assembly




Bonnet and Side Skirt RH

1. Open the bonnet (1).
2. Remove the side skirt RH (2).

(1) Bonnet

(2) Side Skirt RH

W1014408



Regulator Valve (Manual and Glide Shift Transmission Models)

1. Disconnect the power steering delivery pipe (4) and return hose (3).
2. Disconnect the GST/PTO delivery pipe (5) and regulator delivery pipe (1).
3. Remove the regulator valve (2).


(When reassembling)

- Apply grease to the O-ring and take care not to damage it.
- Install the copper washer firmly.

Tightening torque	Power steering delivery pipe joint bolt	49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 ft-lbs
	GST/PTO delivery pipe joint bolt	34.3 to 39.2 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft-lbs
	Regulator delivery pipe joint bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs
	Regulator valve mounting screw	17.7 to 20.6 N·m 1.8 to 2.1 kgf·m 13.0 to 15.2 ft-lbs

- (1) Regulator Delivery Pipe (4) Power Steering Delivery Pipe
 (2) Regulator Valve (5) GST/PTO Delivery Pipe
 (3) Return Hose

W1014496



Power Steering Delivery Pipe and Oil Cooler Return Pipe (HST Models)

1. Disconnect the power steering delivery pipe (2) and oil cooler return pipe (1).


(When reassembling)

- Install the copper washers firmly.
- Take care not to damage the O-ring.

Tightening torque	Power steering delivery pipe joint bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs
-------------------	---	---

- (1) Oil Cooler Return Pipe (2) Power Steering Delivery Pipe

W1014726



Hydraulic Pump Assembly

1. Disconnect the suction hose (1) and main delivery pipe (3).
2. Remove the hydraulic pump assembly (2).

(When reassembling)


- Apply grease to the O-ring and take care not to damage it.

Tightening torque	Hydraulic pump assembly mounting screw and nut	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft-lbs
-------------------	--	---

- (1) Suction Hose (3) Main Delivery Pipe
 (2) Hydraulic Pump Assembly

W1014977

(B) Disassembling Hydraulic Pump



3TLABAB7P020A

Hydraulic Pump Assembly

1. Remove the pump cover mounting screws (7).
2. Remove the drive gear (6), driven gear (2) and side plate (3) from the casing.

(When reassembling)

- Take care not to damage the gasket.
- Align the hole of the pump cover (4) and casing 2 (5).
- Install the side plate, noting its location and direction.
- Install the gears, noting its direction.

Tightening torque	Pump cover mounting screw	39.2 to 44.1 N·m 4.0 to 4.5 kgf·m 28.9 to 32.5 ft-lbs
-------------------	---------------------------	---

- | | |
|-----------------|----------------|
| (1) Casing 1 | (5) Casing 2 |
| (2) Driven Gear | (6) Drive Gear |
| (3) Side Plate | (7) Screw |
| (4) Pump Cover | |

W10135590

Hydraulic Pump Running-In

After reassembly, perform break-in operation in the following manner, and check the pump for abnormality before use. If the pump temperature should rise noticeably during running-in, recheck should be performed.

1. Install the hydraulic pump to the tractor, and mount the suction pipe and delivery pipe securely.
2. Set the engine speed at 1300 to 1500 min⁻¹ (rpm), and operate the hydraulic pump at no load for about 10 minutes.
3. Set the engine speed at 2000 to 2200 min⁻¹ (rpm), and with the hydraulic pump applied with 2.94 MPa (30 kgf/cm², 427 psi) to 4.90 MPa (50 kgf/cm², 711 psi) pressure, operate it for approx. 15 minutes.
4. With the engine set to maximum speed, fully turn the steering wheel to the left or right, then actuate the relief valve five times for 25 seconds (one time 5 seconds).

W10145360

(3) Servicing



3TLABAB7P021A

Housing Bore (Depth of Scratch)


1. Check for the scratch on the interior surface of the housing caused by the gear.
2. If the scratch reaches more than half the area of the interior surface of the housing, replace at pump assembly.
3. Measure the housing I.D. where the interior surface is not scratched, and measure the housing I.D. where the interior surface is scratched.
4. If the values obtained in the two determinations differ by more than the allowable limit, replace the hydraulic pump as a unit.

Depth of scratch	Allowable limit	0.09 mm 0.0035 in.
------------------	-----------------	-----------------------

(Reference)

- Use a cylinder gauge to measure the housing I.D.

W10146490



3TLABAB7P022A

Clearance between Bushing and Gear Shaft

1. Measure the gear shaft O.D. with an outside micrometer.
2. Measure the bushing I.D. with an inside micrometer or cylinder gauge, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace the gear shaft and the bushings as a unit.

Clearance between bushing and gear shaft	Factory spec.	0.020 to 0.081 mm 0.0008 to 0.0032 in.
	Allowable limit	0.15 mm 0.0059 in.

Gear shaft O.D.	Factory spec.	14.970 to 14.980 mm 0.5894 to 0.5898 in.
	Bushing I.D.	Factory spec.

W1015746



3TLABAB7P023A

Side Plate Thickness

1. Measure the side plate thickness with an outside micrometer.
2. If the thickness is less than the allowable limit, replace it.

Side plate thickness	Factory spec.	2.48 to 2.50 mm 0.0976 to 0.0984 in.
	Allowable limit	2.40 mm 0.0945 in.

W10134960



- Housing Bore (Depth of Scratch)**
1. Check for the scratch on the interior surface of the housing caused by the gear.
 2. If the scratch reaches more than half the area of the interior surface of the housing, replace at pump assembly.
 3. Measure the housing I.D. where the interior surface is not scratched, and measure the housing I.D. where the interior surface is scratched.
 4. If the values obtained in the two determinations differ by more than the allowable limit, replace the hydraulic pump as a unit.

Depth of scratch	Allowable limit	0.08 mm 0.0031 in.
------------------	-----------------	-----------------------


(Reference)

• Use a cylinder gauge to measure the housing I.D.

W1015746

[2] STEERING CONTROLLER

(1) Checking



Relief Valve Setting Pressure Test


1. Disconnect the power steering hose **LT**.
2. Install the power steering tee fitting adaptor to the steering controller and connect the power steering hose **LT**.
3. Install the adaptor **D** to the power steering tee fitting adaptor and set the cable and pressure gauge.
4. Start the engine and set the engine speed at maximum speed.
5. Fully turn the steering wheel to the left and read the pressure when the relief valve functions.
6. Stop the engine.
7. If the pressure is not within the factory specifications, check the pump delivery line or replace the steering controller assembly.

Power steering relief valve setting pressure	Factory spec.	L3130 2WD L3830 2WD	8.0 to 9.0 MPa 81.6 to 91.8 kgf/cm ² 1160 to 1305 psi
		L3130 4WD L3430 4WD L3830 4WD	10.7 to 11.7 MPa 109.1 to 119.3 kgf/cm ² 1552 to 1697 psi
		L4330 4WD L4630 4WD L5030 4WD	12.7 to 13.7 MPa 129.5 to 139.7 kgf/cm ² 1842 to 1987 psi

Tightening torque	Power steering hose retaining nut	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft-lbs
-------------------	-----------------------------------	---

Condition

- Engine speed.....Maximum
- Oil temperature.....40 to 60 °C
104 to 140 °F



W1016736

Steering Controller Assembly

1. Disconnect the power steering delivery pipe (A), steering hoses (B), (C), (D) and return hose (E).
2. Remove the steering controller mounting screw (F) and take out the steering controller assembly (1).
- (When reassembling)
- Reinstall the steering hoses (3), (2) to their original position.

Tightening torque	Steering hose RH and LH retaining nut	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft-lbs
Tightening torque	Power steering delivery pipe retaining nut	48.0 to 58.8 N·m 5.0 to 6.0 kgf·m 36.5 to 43.4 ft-lbs

- (1) Steering Controller
(2) Steering hose RH
(3) Steering hose LH
(4) Power Steering Delivery Pipe
(5) Return hose
(6) Screw

W101529


(2) Disassembling and Assembling

■ IMPORTANT

- Use only the transmission fluid (See page G-7, 8), in no case use mixture of oils of different brands.
- Before disassembling the power steering system hydraulic components, check the performance of hydraulic pump and power steering using a flowmeter.
- After removing or disassembling the power steering hydraulic components, be sure to bleed air.

[Bleeding]

1. Start the engine.
2. Turn the steering wheels slowly in both directions all the way alternately several times, and stop the engine.



Fuel Tank Frame Support, Cover and Steering Joint Shaft 2


1. Remove the fuel tank frame support (1) and cover (2).
2. Remove the steering joint shaft 2 (3).

(When reassembling)

- Tighten the steering joint shaft bracket mounting screw after adjusting the position of steering joint shaft bracket (4) for smooth rotation of the steering wheel.

- | | |
|-----------------------------|----------------------------------|
| (1) Fuel Tank Frame Support | (3) Steering Joint Shaft 2 |
| (2) Cover | (4) Steering Joint Shaft Bracket |

W1017095



Steering Controller Assembly

1. Disconnect the power steering delivery pipe (4), steering hoses (3), (5) and return hose (2).
2. Remove the steering controller mounting screw (6) and take out the steering controller assembly (1).



(When reassembling)

- Reinstall the steering hoses (3), (5) to their original position.

Tightening torque	Power steering delivery pipe retaining nut	49.0 to 58.8 N·m 5.0 to 6.0 kgf·m 36.2 to 43.4 ft·lbs
	Steering hose RH and LH retaining nut	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft·lbs

- | | |
|-------------------------|----------------------------------|
| (1) Steering Controller | (4) Power Steering Delivery Pipe |
| (2) Return Hose | (5) Steering Hose LH |
| (3) Steering Hose RH | (6) Screw |


W1017229



[3] STEERING CYLINDER

(1) Disassembling and Assembling

(A) 2 Wheel Drive



3TLABAB7P028A

Front Wheel, Cylinder Cover and Tie-rod

1. Place a disassembly stand under the front axle frame (4) and support it with a jack.
2. Remove the front wheel and cylinder cover (3).
3. Pull out the cotter pin and remove the tie-rod and slotted nut.
4. Disconnect the tie-rod (2) from knuckle arm (1).

(When reassembling)

- After tightening the tie-rod end slotted nut to the specified torque, install a cotter pin as shown in the figure.




3TMABAB6P017A




Tightening torque	Front wheel mounting nut	137.3 N·m 14.0 kgf·m 101.3 ft-lbs
	Tie-rod end slotted nut	49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 ft-lbs

- (1) Knuckle Arm
(2) Tie-rod

- (3) Cylinder Cover
(4) Front Axle Frame



W1017474



Steering Cylinder

1. Disconnect the power steering hoses (1).
2. Remove the cylinder clamps (2).
3. Take out the steering cylinder (3).
4. Remove the tie-rod joints (4).
5. Carefully clamp the steering cylinder in a vise.
6. Remove the guide assembly (7) and draw out the cylinder rod (8).

(When reassembling)

- Apply transmission fluid to the oil seal and O-ring.
- Apply molybdenum disulfide (Three Bond 1901 or equivalent) on the screw of guide assembly when tighten it.
- After tightening the guide assembly to the specified torque, stake the cylinder firmly.
- Apply liquid lock (Three Bond 1324B or equivalent) to the thread of tie-rod joint (4).

Tightening torque	Power steering hose retaining nut	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft·lbs
	Tie-rod joint	166.7 to 196.1 N·m 17.0 to 20.0 kgf·m 123.0 to 144.7 ft·lbs
	Tie-rod clamp mounting bolt and nut	60.8 to 70.6 N·m 6.2 to 7.2 kgf·m 44.8 to 52.1 ft·lbs
	Tie-rod end lock nut	166.7 to 196.1 N·m 17.0 to 20.0 kgf·m 123.0 to 144.7 ft·lbs
	Guide assembly	181.1 to 288.9 N·m 18.5 to 29.5 kgf·m 133.6 to 213.1 ft·lbs

- | | |
|-------------------------|--------------------|
| (1) Power Steering Hose | (5) Tie-rod Clamp |
| (2) Cylinder Clamp | (6) Lock Nut |
| (3) Steering Cylinder | (7) Guide Assembly |
| (4) Tie-rod Joint | (8) Cylinder Rod |

W1017671

(B) 4 Wheel Drive



Front Wheel, Cylinder Cover and Tie-rod

1. Place a disassembly stand under the engine and support it with a jack.
2. Remove the front wheel and cylinder cover (2).
3. Pull out the cotter pin and remove the tie-rod end slotted nut.
4. Disconnect the tie-rod (1).




(When reassembling)

- After tightening the tie-rod end slotted nut to the specified torque, install a cotter pin as shown in the figure.

Tightening torque	Front wheel mounting nut	137.3 N·m 14.0 kgf·m 101.3 ft·lbs	
	Tie-rod end slotted nut	L3130	39.2 to 45.1 N·m
		L3430	4.0 to 4.6 kgf·m
		L3830	28.9 to 33.3 ft·lbs
	Tie-rod end slotted nut	L4330	156.9 to 176.5 N·m
L4630		16.0 to 18.0 kgf·m	
L5030		115.7 to 130.2 ft·lbs	

- | | |
|-------------|--------------------|
| (1) Tie-rod | (2) Cylinder Cover |
|-------------|--------------------|

W1018390



Steering Cylinder

1. Disconnect the power steering hoses (1), (3) and remove the elbows.
2. Disconnect the tie-rod joint LH (4).
3. Remove the internal snap ring (2).
4. Take out the steering cylinder to the left.
5. Remove the head cover (7) and draw out the cylinder rod (6).

(When reassembling)

- Apply transmission fluid to the oil seal and O-ring.
- Apply liquid lock (Three Bond 1324B or equivalent) to the thread of tie-rod joint (4).

	Power steering hose retaining nut	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft-lbs
Tightening torque	Tie-rod joint	166.7 to 196.1 N·m 17.0 to 20.0 kgf·m 123.0 to 144.7 ft-lbs
	Tie-rod joint lock nut	166.7 to 196.1 N·m 17.0 to 20.0 kgf·m 123.0 to 144.7 ft-lbs

- (1) Power Steering Hose RH
- (2) Internal Snap Ring
- (3) Power Steering Hose LH
- (4) Tie-rod Joint
- (5) Lock Nut
- (6) Cylinder Rod
- (7) Head Cover

W1018590

(2) Servicing



Steering Cylinder I.D.

1. Measure the steering cylinder I.D. with a cylinder gauge.
2. If the cylinder I.D. exceed the allowable limit, replace the cylinder tube.

Factory spec.	2WD	50.000 to 50.062 mm 1.96850 to 1.97094 in.
	4WD	55.000 to 55.074 mm 2.16535 to 2.16827 in.
Allowable limit	2WD	50.100 mm 1.97244 in.
	4WD	55.100 mm 2.16929 in.

W1019033



Clearance between Rod and Bushing


1. Measure the bushing I.D. with a cylinder gauge.
2. Measure the rod O.D. with a outside micrometer, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace as a unit.

Clearance between rod and bushing	Factory spec.	0.009 to 0.127 mm 0.00035 to 0.00500 in.
	Allowable limit	0.135 mm 0.00531 in.

W10182660

[4] STEERING LINKAGE

(1) Disassembling and Assembling



Steering Wheel and Steering Post Covers

1. Remove the steering wheel (1).
2. Remove the steering post covers (2), (3).

(When reassembling)

Tightening torque	Steering wheel mounting nut	48.1 to 55.9 N·m 4.9 to 5.7 kgf·m 35.4 to 41.2 ft·lbs
-------------------	-----------------------------	---

- (1) Steering Wheel
(2) Steering Post Cover 1

(3) Steering Post Cover 2

W1019416




Side Skirt, Fuel Tank Frame Support and Cover

1. Open the bonnet (1).
2. Remove the side skirt RH (2).
3. Remove the fuel tank frame support (3) and cover (4).

- (1) Bonnet
(2) Side Skirt RH

(3) Fuel Tank Frame Support
(4) Cover

W1019511



Steering Joint Shaft 2

1. Remove the screw (3) and steering joint shaft bracket mounting screw.
2. Remove the steering joint shaft 2 (1).



(When reassembling)


- Tighten the steering joint shaft bracket mounting screw after adjusting the position of steering joint shaft bracket (2) for smooth rotation of the steering wheel.

- (1) Steering Joint Shaft 2
(2) Steering Joint Shaft Bracket

(3) Screw

W1019696





Steering Joint Shaft 1 and Steering Post

1. Remove the steering joint shaft 1 (2).
2. Remove the steering post (1).

(1) Steering Joint Shaft 1

(2) Steering Post

W1019851

8 HYDRAULIC SYSTEM


MECHANISM

CONTENTS

1. STRUCTURE	8-M1
[1] MANUAL TRANSMISSION AND GLIDE SHIFT TRANSMISSION.....	8-M1
[2] HYDROSTATIC TRANSMISSION.....	8-M2
2. HYDRAULIC CIRCUIT.....	8-M3
[1] MANUAL TRANSMISSION.....	8-M3
[2] GLIDE SHIFT TRANSMISSION.....	8-M4
[3] HYDROSTATIC TRANSMISSION.....	8-M6
3. HYDRAULIC PUMP.....	8-M8
4. FRONT HYDRAULIC BLOCK.....	8-M9
5. REAR HYDRAULIC BLOCK.....	8-M10
6. POSITION CONTROL VALVE.....	8-M11
7. POSITION CONTROL LINKAGE.....	8-M13
8. LOWERING SPEED ADJUSTING VALVE.....	8-M14
9. HYDRAULIC CYLINDER	8-M15
10. AUXILIARY CONTROL VALVE	8-M16
[1] DOUBLE ACTING TYPE 1	8-M16
[2] DOUBLE ACTING TYPE 2 (FLOATING WITH DETENT)	8-M17


1. STRUCTURE

[1] MANUAL TRANSMISSION AND GLIDE SHIFT TRANSMISSION



- | | | | |
|---------------------------|------------------------------------|-------------------------------|-------------------------|
| (1) Cylinder Safety Valve | (4) Lowering Speed Adjusting Valve | (7) Regulator Valve | (10) Hydraulic Pump 2 |
| (2) Check Valve | (5) Oil Filter | (8) Power Steering Controller | (11) Relief Valve |
| (3) Rear Hydraulic Outlet | (6) Front Hydraulic Block | (9) Hydraulic Pump 1 | (12) Hydraulic Cylinder |

The hydraulic system of manual transmission and glide shift transmission models are composed of two hydraulic pumps, relief valve, position control valve, hydraulic cylinder, oil filter and other components as shown in the figure.


[2] HYDROSTATIC TRANSMISSION

- | | | | |
|---------------------------|------------------------------------|----------------------|--------------------------------|
| (1) Oil Filter (HST) | (5) Lowering Speed Adjusting Valve | (8) Hydraulic Pump 2 | (11) Power Steering Controller |
| (2) Cylinder Safety Valve | (6) Oil Filter | (9) Hydraulic Pump 1 | (12) Relief Valve |
| (3) Check Valve | (7) Front Hydraulic Block | (10) Oil Cooler | (13) Hydraulic Cylinder |
| (4) Rear Hydraulic Outlet | | | |


The hydraulic system of hydrostatic transmission model is composed of two hydraulic pumps, relief valve, position control valve, hydraulic cylinder, oil filters, oil cooler and other components as shown in the figure.

2. HYDRAULIC CIRCUIT

[1] MANUAL TRANSMISSION




- | | | | |
|------------------------------------|---|---|----------------------------|
| (1) Position Control Valve | (5) Auxiliary Control Valve | (8) Regulator Valve (Refer to TRANSMISSION Section) | (11) Oil Filter |
| (2) Lowering Speed Adjusting Valve | (6) Power Steering Controller (Refer to STEERING Section) | (9) Hydraulic Pump 2 | (12) Hydraulic Pump 1 |
| (3) Hydraulic Cylinder | (7) PTO Clutch Valve (Refer to TRANSMISSION Section) | (10) Rear Hydraulic Block | (13) Relief Valve |
| (4) Cylinder Safety Valve | | | (14) Front Hydraulic Block |



- (9) Regulator Valve (Refer to TRANSMISSION Section)
- (10) Hydraulic Pump 2
- (11) Rear Hydraulic Block
- (12) Oil Filter
- (13) Hydraulic Pump 1
- (14) Relief Valve
- (15) Front Hydraulic Block


[3] HYDROSTATIC TRANSMISSION



3TLABAB8P006A


- | | | | |
|------------------------------------|---------------------------|---|---|
| (1) Position Control Valve | (3) Hydraulic Cylinder | (5) Auxiliary Control Valve | (7) Hydraulic Pump 2 |
| (2) Lowering Speed Adjusting Valve | (4) Cylinder Safety Valve | (6) Power Steering Controller (Refer to STEERING Section) | (8) Servo Regulator (Refer to TRANSMISSION Section) |

3. HYDRAULIC PUMP



- (9) PTO Clutch Valve (Refer to TRANSMISSION Section)
- (10) Hydrostatic Transmission (HST) (Refer to TRANSMISSION Section)
- (11) Oil Cooler
- (12) Rear Hydraulic Block
- (13) Oil Filter
- (14) Hydraulic Pump 1
- (15) Relief Valve
- (16) Front Hydraulic Block

3. HYDRAULIC PUMP




The gear type hydraulic pump is adopted for these tractor. This pump is tandem type and it is composed two pair of gears, side plates, bushings and other components as shown in the figure.

The hydraulic pump pressure-fed the oil drawn from the transmission case through oil filter to power steering circuit and main hydraulic circuit.

- (1) Drive Gear 1
- (2) Coupling
- (3) Drive Gear 2
- (4) Driven Gear 1
- (5) Bushing
- (6) Bushing
- (7) Driven Gear 2
- (8) Side Plate


- A : From Power Steering Controller**
- B : From Transmission Case**
- C : To Power Steering Controller**
- D : To Main Hydraulic Circuit**

W1013488



(1) Hydraulic Pump
 (2) Oil Filter
 (3) PTO Control Valve (Refer to TRANSMISSION SECTION)
 (4) Hydraulic Transmission (HST) (Refer to TRANSMISSION SECTION)
 (5) PTO Control Valve (Refer to TRANSMISSION SECTION)
 (6) Oil Cooler
 (7) PTO Hydraulic Block
 (8) Hydraulic Pump
 (9) Oil Filter
 (10) PTO Control Valve (Refer to TRANSMISSION SECTION)
 (11) PTO Hydraulic Block

4. FRONT HYDRAULIC BLOCK




3TLABAB8P009A

- | | | | |
|---------------------------|---|--------------------------------------|--|
| (1) Cap | A : To Implement Control Valve | C : To Position Control Valve | T1 : To Transmission Case |
| (2) Front Hydraulic Block | B : From Implement Control Valve | P : From Hydraulic Pump | T2 : From Implement Control Valve |
| (3) Relief Valve | | | |

The front hydraulic block is provided to take power out from the tractor to operate the hydraulic cylinders on the implement, such as front end loader, front blade and so on.

5. REAR HYDRAULIC BLOCK




3TLABAB8P010A

- | | | | |
|------------------------------------|--|-----------------|--|
| (1) Cylinder Safety Valve | (3) Position Control Valve | (5) Check Valve | A : From Hydraulic Pump |
| (2) Lowering Speed Adjusting Valve | (4) Cover (Rear Hydraulic Outlet Port) | | B : To or From Hydraulic Cylinder |
| | | | C : To or From Hydraulic Cylinder |

The rear hydraulic block is equipped with cylinder safety valve, lowering speed adjusting valve and check valve, etc. besides hydraulic outlet port.

The hydraulic outlet port is located top of the rear hydraulic block to take power out from the tractor to operate the hydraulic cylinders on the implement.

6. POSITION CONTROL VALVE



■ Neutral

Pressurized oil flows at the **P** port, pushes open unload poppet 1 (4) and returns to tank from **T1** port.

The oil in the chamber **A** behind the unload poppet 1 (4) returns to the tank from **T4** port. The oil in the hydraulic cylinder does not flow out because the circuit is cut off by the actions of poppet 2 (1) and check valve in the rear hydraulic block.


This allows the implement to be kept at a steady height.

- (1) Poppet 2
- (2) Spool
- (3) Unload Poppet 2
- (4) Unload Poppet 1

P : Pump Port
C1 : Cylinder Port 1
C2 : Cylinder Port 2
T1 : Tank Port 1
T2 : Tank Port 2
T3 : Tank Port 3
T4 : Tank Port 4

A : Chamber A

W1013891



■ Lifting

When the control lever is moved to "LIFT" position, spool (1) is pushed by the spool operating lever, forming a circuit with the **P** port and chamber **A**.

The pressurized oil thus flows into the chamber **A** and closes unload poppet 1 (2).


The oil from **C1** port flows into hydraulic cylinder through check valve in the rear hydraulic block to lift the implement.

- (1) Spool
- (2) Unload Poppet 1

P : Pump Port
C1 : Cylinder Port 1

A : Chamber A

W1014132




■ Lifting to Neutral (Acting the shockless mechanism)

In returning from **Lifting** to **Neutral**, the spool (1) is pushed back to the arrow-mark direction. When the **Neutral** position comes near, the groove part **D** of the spool (1) makes the pressure difference at the **P** port and **C1** port. Therefore, the check valve in the rear hydraulic block gradually closes, and absorbs any shock at lifting stop. In that case, since oil is remained in the chamber **A** of the unload poppet 1 (2) and closes. However, the unload poppet 2 (3) opens because of low pressure in chamber **B**, and then the oil from the pump returns to the transmission case through **T3** port until unload poppet 1 (2) opens.

- (1) Spool
- (2) Unload Poppet 1
- (3) Unload Poppet 2
- A** : Chamber A
- B** : Chamber B
- D** : Groove

- P** : Pump Port
- C1** : Cylinder Port 1
- T3** : Tank Port 3

W1014273



■ Lowering

When the control lever is moved to "**DOWN**" position, spool (2) moves to arrow-mark direction, and pushes the unload poppet 2 (1). It forms a circuit with the **C2** port and **T2** port.

The oil in the hydraulic cylinder is forced out by the weight of the implement, and returns to the tank through the **C2** port and **T2** port, lowering the implement.

The pressurized oil at the **P** port pushes open unload poppet 1 (3) and returns to tank from **T1** port.

■ Floating

When the control lever is moved all the way to the bottom, spool (2) and unload poppet 2 (1) remain in the position described for "**Lowering**". The oil flows freely between the hydraulic pump, hydraulic cylinder and tank.


- (1) Unload Poppet 2
- (2) Spool
- (3) Unload Poppet 1

A : Chamber A

- P** : Pump Port
- C2** : Cylinder Port 2
- T1** : Tank Port 1
- T2** : Tank Port 2
- T4** : Tank Port 4

W1014640

7. POSITION CONTROL LINKAGE



Position control is a mechanism to raise or lower the implement attached to the tractor in proportion to the movement of the control lever.

The implement can be positioned at any height by moving the position control lever. Fine position adjustment is also easy.

■ Lift

1. When the position control lever is moved to the **LIFT** position, the control arm shaft (2) rotates to the arrow. Therefore, the spool drive lever (3) moves around the fulcrum **P** and push the spool (1) opening the **LIFT** circuit.
2. When the lift arm moves upward, the feedback lever shaft (4) is rotated to the arrow, since the feedback rod is actuated. Therefore, the spool drive lever (3) moves around the fulcrum **Q** and pull the spool (1).
3. The lift arm stops when the spool returns to the neutral position.

■ Down


1. When the position control lever is moved to the **DOWN** position, the control arm shaft (2) rotates to the arrow. Therefore, the spool drive lever (3) moves around the fulcrum **P** and pull the spool (4) opening the **DOWN** circuit.
2. When the lift arm moves downward, the feedback lever shaft (4) is rotated to the arrow, since the feedback rod is actuated. Therefore, the spool drive lever (3) moves around the fulcrum **Q** and pushes the spool (1).
3. The lift arm stops when the spool (1) returns to the neutral position.

- (1) Spool
- (2) Control Arm Shaft
- (3) Spool Drive Lever
- (4) Feedback Lever Shaft

- A** : Neutral
- B** : Lift
- C** : Down

W1014898

8. LOWERING SPEED ADJUSTING VALVE




Turning the rotor shaft (2) clockwise decreases the lowering speed, and counterclockwise increases lowering speed of the three points linkage. When the rotor shaft (2) is completely closed, the three point linkage is held at its position since oil in the hydraulic cylinder is sealed between the hydraulic cylinder and rotor (4).

- | | |
|----------------------------|----------------------------|
| (1) Holder | A : Closed Position |
| (2) Rotor Shaft | B : Open Position |
| (3) Pin | |
| (4) Rotor | C : Cylinder Port |
| (5) Position Control Valve | T : Tank Port |

W1015173

9. HYDRAULIC CYLINDER





The external type hydraulic cylinders are used for three point linkage system. This hydraulic cylinder is single acting type, and it is installed directly between hydraulic lift arm and lower link.

The main components of the hydraulic cylinder are shown in the figure.


- | | |
|-------------------|--|
| (1) Cylinder Tube | (9) Bearing Ring |
| (2) Rod | (10) Backup Ring |
| (3) Wiper | (11) Seal |
| (4) Snap Ring | (12) Piston |
| (5) O-ring | |
| (6) Head | A : To Transmission Case |
| (7) Bushing | B : To or From Position Control Valve |
| (8) Snap Ring | |

W1015282



10. AUXILIARY CONTROL VALVE

[1] DOUBLE ACTING TYPE 1




■ Neutral

Pressure-fed oil from the hydraulic pump is delivered into the **P** port, and flows to the position control valve via **N** port.

- (1) Check Valve
- (2) Spool
- A** : A Port (Implement Cylinder)
- B** : B Port (Implement Cylinder)
- P** : Pump Port
- N** : Neutral Port
- T** : Tank Port

W1015469




■ Lift

When the spool (2) is moved in the direction of the arrow, the pressure-fed oil in the **P** port opens the check valve (1) and flows to the implement cylinder via **B** port.

Return oil from the implement cylinder flows from the **A** port to the transmission case through **T** port.

- (1) Check Valve
- (2) Spool
- A** : A Port (Implement Cylinder)
- B** : B Port (Implement Cylinder)
- P** : Pump Port
- N** : Neutral Port
- T** : Tank Port

W1015571




■ Down

When the spool (2) is moved in the direction of the arrow, the pressure-fed oil in the **P** port opens the check valve (1) and flows to the implement cylinder via **A** port.


Return oil from the implement cylinder flows from the **B** port to the transmission case through **T** port.

- (1) Check Valve
- (2) Spool
- A** : A Port (Implement Cylinder)
- B** : B Port (Implement Cylinder)
- P** : Pump Port
- N** : Neutral Port
- T** : Tank Port

W1015748


[2] DOUBLE ACTING TYPE 2 (FLOATING WITH DETENT)**■ Neutral**

Pressure-fed oil from the hydraulic pump is delivered into the **P** port, and flows to the position control valve via **N** port.

■ Lift

When the spool (1) is moved in the direction of the arrow, the pressure-fed oil in the **P** port opens the check valve (2) and flows to the implement cylinder via **B** port.
Return oil from the implement cylinder flows from the **A** port to the transmission case through **T** port.

■ Down



- (1) Spool
- (2) Check Valve

- A : A Port
(Implement Cylinder)
- B : B Port
(Implement Cylinder)
- P : Pump Port
- N : Neutral Port
- T : Tank Port


W1016237

3TLABAB8P023A

When the spool (1) is moved in the direction of the arrow, the pressure-fed oil in the P port opens the check valve (2) and flows to the implement cylinder via A port.

Return oil from the implement cylinder flows from the B port to the transmission case through T port.

■ Floating



- (1) Spool
- (2) Check Valve
- (3) Detent Ball
- (4) Detent Sleeve

- A : A Port
(Implement Cylinder)
- B : B Port
(Implement Cylinder)
- P : Pump Port
- N : Neutral Port
- T : Tank Port

W1016319

3TLABAB8P024A

When the spool (1) moves to extreme left, the detent ball (3) and detent sleeve (4) hold the spool (1) at the floating position as shown in the figure. The pressure-fed oil from the hydraulic pump flows to position control valve via N port. And, the A port and B port lead to the T port along the notched sections of the spool (1). This result in the attached implement to follow the contour of the terrain.

SERVICING

CONTENTS

1. TROUBLESHOOTING	8-S1
2. SERVICING SPECIFICATIONS	8-S2
3. TIGHTENING TORQUES	8-S4
4. CHECKING, DISASSEMBLING AND SERVICING.....	8-S5
[1] HYRAULIC PUMP.....	8-S5
(1) Checking	8-S5
(2) Disassembling and Assembling	8-S7
(3) Servicing	8-S9
[2] RELIEF VALVE.....	8-S11
(1) Checking and Adjusting	8-S11
(2) Disassembling and Assembling	8-S12
[3] REAR HYDRAULIC BLOCK AND VALVES.....	8-S12
(1) Checking and Adjusting	8-S12
(2) Disassembling and Assembling	8-S13
(3) Servicing	8-S16
[4] LIFT ARM SUPPORT AND HYDRAULIC CYLINDER.....	8-S16
(1) Disassembling and Assembling	8-S16
(2) Servicing	8-S19

1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
Implement Does Not Rise (Not Noise)	<ul style="list-style-type: none"> Control linkage improperly adjusted Control linkage improperly assembled or damaged Position control valve malfunctioning Relief valve spring weaken or broken Hydraulic piston O-ring, cylinder damaged 	Adjust Repair or replace Repair or replace Replace Replace	8-S12 - 8-S14, S15 8-S12 8-S17
	(Noise)	<ul style="list-style-type: none"> Transmission fluid improper or insufficient Oil filter clogged Suction pipe loosen or broken Relief valve setting pressure too low Relief valve spring weaken or damaged Hydraulic pump malfunctioning 	Change or replenish Replace Repair or replace Adjust Replace Repair or replace
Implement Does Not Reach Maximum Height	<ul style="list-style-type: none"> Position control feedback rod improperly adjusted Top link length improperly adjusted Hydraulic arm shaft, lift arm improperly assembled 3 point link improperly set 	Adjust Adjust Adjust Adjust	8-S12 - 8-S18 -
Implement Does Not Lower	<ul style="list-style-type: none"> Position control valve malfunctioning <ul style="list-style-type: none"> Spool damaged Poppet 2, push rod improperly adjusted 	Replace Adjust	8-S15 8-S15
Implement Drops by Weight	<ul style="list-style-type: none"> Hydraulic cylinder worn or damaged Safety valve damaged Hydraulic piston and O-ring worn or damaged Lowering speed adjusting valve damaged Position control valve malfunctioning <ul style="list-style-type: none"> Poppet 2 seat surface damaged Poppet 2 seat sleeve O-ring damaged 	Replace Replace Replace Replace Replace Replace	8-S17 8-S14 8-S17 8-S14 8-S15 8-S15
Implement Hunts (Moves Up and Down)	<ul style="list-style-type: none"> Position control valve malfunctioning <ul style="list-style-type: none"> Poppet 2 seat surface damaged Poppet 2 seat sleeve O-ring damaged Poppet 2, push rod improperly adjusted 	Replace Replace Adjust	8-S15 8-S15 8-S15
Oil Temperature Increases Rapidly	<ul style="list-style-type: none"> Relief valve operating <ul style="list-style-type: none"> Relief valve malfunctioning Hydraulic line is clogged Hydraulic pump leak or damaged Oil leaks from valves 	Adjust or replace Clean or replace Repair or replace Repair or replace	8-S11, S12 - 8-S7 to S10 -

W10143220

2. SERVICING SPECIFICATIONS

HYDRAULIC PUMP

Item	Factory Specification	Allowable Limit
Hydraulic Pump Condition <ul style="list-style-type: none"> Engine Speed : Approx. 2700 min⁻¹ (rpm) (Except L4330) Approx. 2600 min⁻¹ (rpm) (L4330) Rated pressure L3130, L3430, L3830 : 17.1 to 18.1 MPa 174.4 to 184.6 kgf/cm² 2480 to 2625 psi L4330, L4630, L5030 : 18.1 to 19.1 MPa 184.6 to 194.8 kgf/cm² 2625 to 2770 psi Oil Temperature : 40 to 60 °C 104 to 140 °F 	Delivery at No Pressure L3130, L3430, L3830 Above 31.5 L/min. 8.32 U.S.gals./min. 6.93 Imp.gals./min. L4330 Above 35.6 L/min. 9.41 U.S.gals./min. 7.83 Imp.gals./min. L4630, L5030 Above 37.0 L/min. 9.78 U.S.gals./min. 8.14 Imp.gals./min. Delivery at Rated Pressure L3130, L3430, L3830 Above 30.9 L/min. 8.16 U.S.gals./min. 6.80 Imp.gals./min. L4330 Above 34.9 L/min. 9.22 U.S.gals./min. 7.68 Imp.gals./min. L4630, L5030 Above 36.3 L/min. 9.59 U.S.gals./min. 7.99 Imp.gals./min.	 — — — 27.6 L/min. 7.29 U.S.gals./min. 6.07 Imp.gals./min. 31.2 L/min. 8.24 U.S.gals./min. 6.86 Imp.gals./min. 32.4 L/min. 8.56 U.S.gals./min. 7.13 Imp.gals./min.
Housing Bore	Depth of Scratch	0.09 mm 0.0035 in.
Bushing to Gear Shaft	Clearance	0.020 to 0.081 mm 0.0008 to 0.0032 in.
Gear Shaft	O.D.	14.970 to 14.980 mm 0.5894 to 0.5898 in.
Bushing	I.D.	15.000 to 15.051 mm 0.5906 to 0.5926 in.
Side Plate	Thickness	2.48 to 2.50 mm 0.0976 to 0.0984 in.

W10138740

RELIEF VALVE

Item	Factory Specification	Allowable Limit	
Relief Valve Condition • Engine Speed : Maximum • Oil Temperature : 40 to 60 °C 104 to 140 °F	Setting Pressure L3130, L3430, L3830 L4330, L4630, L5030	17.1 to 18.1 MPa 174.4 to 184.4 kgf/cm ² 2480 to 2625 psi 18.1 to 19.1 MPa 184.6 to 194.8 kgf/cm ² 2625 to 2770 psi	— —

W10138740

REAR HYDRAULIC BLOCK AND VALVES

Lift Arm	Free Play (at Maximum Raising Position)	10 to 15 mm 0.39 to 0.59 in.	—
----------	---	---------------------------------	---

W10138740

CYLINDER SAFETY VALVE

Cylinder Safety Valve	Operating Pressure	19.6 to 22.6 MPa 200 to 230 kgf/cm ² 2845 to 3271 psi	—
-----------------------	-----------------------	--	---

W10115520

LIFT ARM SUPPORT AND HYDRAULIC CYLINDER

Hydraulic Cylinder	I.D.	55.000 to 55.074 mm 2.16535 to 2.16827 in.	55.100 mm 2.16929 in.
--------------------	------	---	--------------------------

W10118710

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-9.)

Item	N·m	kgf·m	ft-lbs
Main delivery pipe joint bolt	49.0 to 68.6	5.0 to 7.0	36.2 to 50.6
Power steering delivery pipe joint bolt (Except HST model)	49.0 to 68.6	5.0 to 7.0	36.2 to 50.6
GST/PTO delivery pipe joint bolt	34.3 to 39.2	3.5 to 4.0	25.3 to 28.9
Regulator delivery pipe joint bolt	39.2 to 49.0	4.0 to 5.0	28.9 to 36.2
Regulator valve mounting screw	17.7 to 20.6	1.8 to 2.1	13.0 to 15.2
Power steering delivery pipe joint bolt (HST model)	39.2 to 49.0	4.0 to 5.0	28.9 to 36.2
Hydraulic pump assembly mounting screw and nut	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Pump cover mounting screw	39.2 to 44.1	4.0 to 4.5	28.9 to 32.5
Relief valve plug	49.0 to 68.6	5.0 to 7.0	36.2 to 50.6
Hydraulic cylinder hose	34.3 to 48.1	3.5 to 4.9	25.3 to 35.4
Delivery pipe joint bolt	49.0 to 68.6	5.0 to 7.0	36.2 to 50.6
Cylinder safety valve assembly	39.2 to 49.0	4.0 to 5.0	28.9 to 36.2
Cylinder safety valve lock nut	58.8 to 78.5	6.0 to 8.0	43.4 to 57.9
Unload plug	39.2 to 58.8	4.0 to 6.0	28.9 to 43.4
Plug 2	39.2 to 58.8	4.0 to 6.0	28.9 to 43.4
Plug 1	39.2 to 58.8	4.0 to 6.0	28.9 to 43.4
Lift arm pin mounting nut	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Lift arm pin lock nut	62.8 to 72.6	6.4 to 7.4	46.3 to 53.5
Drawbar frame mounting screw (M14)	166.7 to 196.1	17.0 to 20.0	123.0 to 144.7
(M12)	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5
Top link holder mounting screw	77.5 to 90.2	7.9 to 9.2	57.1 to 66.5

W1012736

4. CHECKING, DISASSEMBLING AND SERVICING

[1] HYRAULIC PUMP

(1) Checking

(A) Pump Test Using Flow-meter




Preparation

1. Open the bonnet (1).
2. Remove the side skirt RH (2).
3. Remove the main delivery pipe (3).

(When reassembling)

- Install the copper washers firmly.


Tightening torque	Main delivery pipe joint bolt	49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 ft·lbs
-------------------	-------------------------------	---



- (1) Bonnet
- (2) Side Skirt RH

(3) Main Delivery Pipe

W1012121



Hydraulic Flow Test

■ IMPORTANT

- When using a flowmeter other than KUBOTA specified flowmeter, be sure to use the instructions with that flowmeter.
 - Do not close the flowmeter loading valve completely, before testing, because it has no relief valve.
1. Install the pump adaptor (see page G-52) with O-ring to the pump discharge port.
 2. Connect the hydraulic test hose to the adaptor and flowmeter inlet port.
 3. Connect the other hydraulic test hose to the flowmeter outlet port and to transmission fluid filling plug hole.
 4. Open the flowmeter loading valve completely. (Turn counterclockwise.)
 5. Start the engine and set the engine speed at **2000 to 2200 min⁻¹ (rpm)**.
 6. Slowly close the loading valve to generate pressure approx. **14.7 MPa (150 kgf/cm², 2133 psi)**. Hold in this condition until oil temperature reached approx. **40 °C (104 °F)**
 7. Open the loading valve completely.
 8. Set the engine speed. (Refer to **Condition**.)
 9. Read and note the pump delivery at no pressure.
 10. Slowly close the loading valve to increase (Rated pressure). As the load is increased, engine speed drops, therefore, reset the engine speed.
 11. Read and note the pump delivery at rated pressure.
 12. Open the loading valve completely and stop the engine.
 13. If the pump delivery does not reach the allowable limit, check the pump suction line, oil filter or hydraulic pump.

Condition

- Engine Speed.....Approx. 2700 min⁻¹ (rpm) (Except L4330)
Approx. 2600 min⁻¹ (rpm) (L4330)
- Rated pressure
L3130, L3430, L3830 17.1 to 18.1 MPa
174.4 to 184.6 kgf/cm²
2480 to 2625 psi
L4330, L4630, L5030 18.1 to 19.1 MPa
184.6 to 194.8 kgf/cm²
2625 to 2770 psi
- Oil Temperature 40 to 60 °C
104 to 140 °F

A : Manual and Glide Shift
Transmission

B : Hydrostatic Transmission

W10187910

Hydraulic Flow Test (Continued)

[L3130, L3430, L3830]

Hydraulic pump delivery at no pressure	Factory spec.	Above 31.5 L/min. 8.32 U.S.gals./min. 6.93 Imp.gals./min.
Hydraulic pump delivery at rated pressure	Factory spec.	Above 30.9 L/min. 8.16 U.S.gals./min. 6.80 Imp.gals./min.
	Allowable limit	27.6 L/min. 7.29 U.S.gals./min. 6.07 Imp.gals./min.

[L4330]

Hydraulic pump delivery at no pressure	Factory spec.	Above 35.6 L/min. 9.41 U.S.gals./min. 7.83 Imp.gals./min.
Hydraulic pump delivery at rated pressure	Factory spec.	Above 34.9 L/min. 9.22 U.S.gals./min. 7.68 Imp.gals./min.
	Allowable limit	31.2 L/min. 8.24 U.S.gals./min. 6.86 Imp.gals./min.

[L4630, L5030]

Hydraulic pump delivery at no pressure	Factory spec.	Above 37.0 L/min. 9.78 U.S.gals./min. 8.14 Imp.gals./min.
Hydraulic pump delivery at rated pressure	Factory spec.	Above 36.3 L/min. 9.59 U.S.gals./min. 7.99 Imp.gals./min.
	Allowable limit	32.4 L/min. 8.56 U.S.gals./min. 7.13 Imp.gals./min.

W1013113

(2) Disassembling and Assembling

■ IMPORTANT

- The hydraulic pump is precision machined and assembled : if disassemble once, it may be unable to maintain its original performance. Therefore, when the hydraulic pump fails, replacement should be carried out with the hydraulic pump assembled except when emergency repair is unavoidable.
- When repair is required, follow the disassembly and servicing procedures shown below with utmost care.
- Be sure to test the hydraulic pump with a flowmeter before disassembling.
- After reassembly, be sure to perform break-in operation and ensure that there is nothing abnormal with the hydraulic pump.

(A) Removing Hydraulic Pump Assembly




Bonnet and Side Skirt RH

1. Open the bonnet (1).
2. Remove the side skirt RH (2).

(1) Bonnet

(2) Side Skirt RH

W1014408



Regulator Valve (Manual and Glide Shift Transmission Models)

1. Disconnect the power steering delivery pipe (4) and return hose (3).
2. Disconnect the GST/PTO delivery pipe (5) and regulator delivery pipe (1).
3. Remove the regulator valve (2).


(When reassembling)

- Apply grease to the O-ring and take care not to damage it.
- Install the copper washers firmly.

Tightening torque	Power steering delivery pipe joint bolt	49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 ft-lbs
	GST/PTO delivery pipe joint bolt	34.3 to 39.2 N·m 3.5 to 4.0 kgf·m 25.3 to 28.9 ft-lbs
	Regulator delivery pipe joint bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs
	Regulator valve mounting screw	17.7 to 20.6 N·m 1.8 to 2.1 kgf·m 13.0 to 15.2 ft-lbs

- (1) Regulator Delivery Pipe (2) Regulator Valve (3) Return Hose (4) Power Steering Delivery Pipe (5) GST/PTO Delivery Pipe

W1014496



Power Steering Delivery Pipe and Oil Cooler Return Pipe (HST Models)

1. Disconnect the power steering delivery pipe (2) and oil cooler return pipe (1).


(When reassembling)

- Install the copper washers firmly.
- Take care not to damage the O-ring.

Tightening torque	Power steering delivery pipe joint bolt	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft-lbs
-------------------	---	---

- (1) Oil Cooler Return Pipe (2) Power Steering Delivery Pipe

W1014726



Hydraulic Pump Assembly

1. Disconnect the suction hose (1) and main delivery pipe (3).
2. Remove the hydraulic pump assembly (2).

(When reassembling)


- Apply grease to the O-ring and take care not to damage it.

Tightening torque	Hydraulic pump assembly mounting screw and nut	23.5 to 27.5 N·m 2.4 to 2.8 kgf·m 17.4 to 20.3 ft-lbs
-------------------	--	---

- (1) Suction Hose (2) Hydraulic Pump Assembly (3) Main Delivery Pipe

W1014977

(B) Disassembling Hydraulic Pump



Hydraulic Pump Assembly

1. Remove the pump cover mounting screws (7).
2. Remove the drive gear (6), driven gear (2) and side plate (3) from the casing.

(When reassembling)

- Take care not to damage the gasket.
- Align the hole of the pump cover (5) and casing 2 (4).
- Install the side plate, noting its location and direction.
- Install the gears, noting its direction.

Tightening torque	Pump cover mounting screw	39.2 to 44.1 N·m 4.0 to 4.5 kgf·m 28.9 to 32.5 ft·lbs
-------------------	---------------------------	---

- | | |
|-----------------|----------------|
| (1) Casing 1 | (5) Pump Cover |
| (2) Driven Gear | (6) Drive Gear |
| (3) Side Plate | (7) Screw |
| (4) Casing 2 | |

W10135590

Hydraulic Pump Running-In

After reassembly, perform break-in operation in the following manner, and check the pump for abnormality before use. If the pump temperature should rise noticeably during running-in, recheck should be performed.

1. Install the hydraulic pump to the tractor, and mount the suction pipe and delivery pipe securely.
2. Set the engine speed at 1300 to 1500 min⁻¹ (rpm), and operate the hydraulic pump at no load for about 10 minutes.
3. Set the engine speed at 2000 to 2200 min⁻¹ (rpm), and with the hydraulic pump applied with 2.94 MPa (30 kgf/cm², 427 psi) to 4.90 MPa (50 kgf/cm², 711 psi) pressure, operate it for approx. 15 minutes.
4. With the engine set to maximum speed, fully turn the steering wheel to the left or right, then actuate the relief valve five times for 25 seconds (one time 5 seconds).

W10145360

(3) Servicing



Housing Bore (Depth of Scratch)


1. Check for the scratch on the interior surface of the housing caused by the gear.
2. If the scratch reaches more than half the area of the interior surface of the housing, replace at pump assembly.
3. Measure the housing I.D. where the interior surface is not scratched, and measure the housing I.D. where the interior surface is scratched.
4. If the values obtained in the two determinations differ by more than the allowable limit, replace the hydraulic pump as a unit.

Depth of scratch	Allowable limit	0.09 mm 0.0035 in.
------------------	-----------------	-----------------------

(Reference)

- Use a cylinder gauge to measure the housing I.D.

W10146490



3TLABAB8P054A


Clearance between Bushing and Gear Shaft

1. Measure the gear shaft O.D. with an outside micrometer.
2. Measure the bushing I.D. with an inside micrometer or cylinder gauge, and calculate the clearance.
3. If the clearance exceeds the allowable limit, replace the gear shaft and the bushings as a unit.

Clearance between bushing and gear shaft	Factory spec.	0.020 to 0.081 mm 0.0008 to 0.0032 in.
	Allowable limit	0.15 mm 0.0059 in.

Gear shaft O.D.	Factory spec.	14.970 to 14.980 mm 0.5894 to 0.5898 in.
	Factory spec.	15.000 to 15.051 mm 0.5906 to 0.5926 in.

W1015746



3TLABAB7P023A

Side Plate Thickness

1. Measure the side plate thickness with an outside micrometer.
2. If the thickness is less than the allowable limit, replace it.

Side plate thickness	Factory spec.	2.48 to 2.50 mm 0.0976 to 0.0984 in.
	Allowable limit	2.40 mm 0.0945 in.

W10134960



- Housing Bore (Depth of Scratch)**
1. Check for the scratch on the interior surface of the housing caused by the gear.
 2. If the scratch reaches more than half the area of the interior surface of the housing, replace at pump assembly.
 3. Measure the housing I.D. where the interior surface is not scratched, and measure the housing I.D. where the interior surface is scratched.
 4. If the values obtained in the two determinations differ by more than the allowable limit, replace the hydraulic pump as a unit.

Depth of scratch	Allowable limit	0.09 mm 0.0035 in.
------------------	-----------------	-----------------------



(Reference)

- Use a cylinder gauge to measure the housing I.D.

W1015746

[2] RELIEF VALVE

(1) Checking and Adjusting



Relief Valve Setting Pressure Test

1. Remove the delivery pipe joint bolt from front hydraulic block.
2. Install the adaptor E. Then connect the cable and pressure gauge to adaptor E.
3. Remove the position control lever stopper (1).
4. Start the engine and set at maximum speed.
5. Move the position control lever all way up to operate the relief valve and read the gauge.
6. If the pressure is not within the factory specifications, remove the relief plug (2) of front hydraulic block (3) and adjust with the adjusting shims (4).
7. After the relief valve setting pressure test, reset the position control lever stopper firmly.

Relief valve setting pressure	Factory spec.	L3130	17.1 to 18.1 MPa
		L3430	174.4 to 184.6 kgf/cm ²
		L3830	2480 to 2625 psi
		L4330	18.1 to 19.1 MPa
		L4630	184.6 to 194.8 kgf/cm ²
		L5030	2625 to 2770 psi

Condition


- Engine speed.....Maximum
- Oil temperature.....40 to 60 °C
104 to 140 °F

(Reference)

- Thickness of shims (4) : 0.1 mm (0.0039 in.)
0.2 mm (0.0079 in.)
0.4 mm (0.0157 in.)
- Pressure change per
0.1 mm (0.0039 in.) shim : Approx. 264.8 kPa
2.7 kgf/cm²
38.4 psi


- (1) Stopper
- (2) Relief Plug
- (3) Front Hydraulic Block

- (4) Adjusting Shim
- (5) Washer



position	maximum raising	Factory spec.	10 to 15 mm 0.39 to 0.59 in.
(1) Position Control Lever			
(2) Stopper			
(3) Position Control Feedback Rod			
(4) Adjusting Shim			
(5) Lock Nut			

(2) Disassembling and Assembling



Relief Valve

1. Remove the plug (9), and draw out the spring (5) and the poppet (4).
2. Take out the valve seat (3).

(When reassembling)

- Take care not to damage the O-ring.

Tightening torque	Relief valve plug	49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 ft-lbs
-------------------	-------------------	---

■ IMPORTANT

- After disassembling and assembling the relief valve, be sure to adjust the relief valve setting pressure.



- (1) Front Hydraulic Block
- (2) Cap
- (3) Valve Seat
- (4) Poppet
- (5) Spring

- (6) Adjusting Shim
- (7) Washer
- (8) O-ring
- (9) Plug

W1015237

[3] REAR HYDRAULIC BLOCK AND VALVES

(1) Checking and Adjusting



Position Control Feedback Rod Adjustment

1. Set the position control lever (1) to the lowest position.
2. Start the engine, and after warming-up, set the engine speed at the idling.
3. Move the position control lever (1) to the uppermost position. [Contact to the position control lever stopper (2).]
4. While pulling the feedback rod to the rear, turn the adjusting nut (4) clockwise until the relief valve begins to be operated.
5. From the relief valve operating position, turn back the adjusting nut (4) counterclockwise by 2 turns.
6. Tighten the lock nut (5).
7. Set the engine speed at the maximum.
8. Move the position control lever (1) to the lowest position and uppermost position to check the relief valve does not operate.
9. Set the position control lever (1) to the uppermost position, then move the lift arm to the upper end by hand and measure the free play.
10. If the measurement is not within the factory specifications, adjust the position control feedback rod setting length.
 - To reduce lift arm free play → Shorten the position control feedback rod setting length.
 - To increase lift arm free play → Lengthen the position control feedback rod setting length.



Lift arm free play at maximum raising position	Factory spec.	10 to 15 mm 0.39 to 0.59 in.
--	---------------	---------------------------------

- (1) Position Control Lever
- (2) Stopper
- (3) Position Control Feedback Rod
- (4) Adjusting Nut
- (5) Lock Nut

W1015610



(2) Disassembling and Assembling



Seat, Seat Bracket and Cover

1. Remove the seat (1).
2. Disconnect the connector (2).
3. Remove the seat bracket (3) together with cover (4).

- (1) Seat
- (2) Connector

- (3) Seat Bracket
- (4) Cover

W1015907

Rear Hydraulic Block

1. Disconnect the position control feedback rod (5) and return hoses (4).
2. Remove the lowering speed adjusting valve joint shaft (8).
3. Disconnect the hydraulic cylinder hose RH (2) and delivery pipe (3).
4. Tap out the spring pin from position control lever (1).
5. Remove the rear hydraulic block mounting screws.
6. Remove the rear hydraulic block (6) and disconnect the position control lever (1) and hydraulic cylinder hose LH (7).


(When reassembling)

- Install the copper washers firmly.
- Visually inspect the gasket, if damaged replace with new one.
- After reassembling, be sure to adjust the position control feedback rod length. (See page 8-S12.)

Tightening torque	Hydraulic cylinder hose	34.3 to 48.1 N·m 3.5 to 4.9 kgf·m 25.3 to 35.4 ft·lbs
	Delivery pipe joint bolt	49.0 to 68.6 N·m 5.0 to 7.0 kgf·m 36.2 to 50.6 ft·lbs

- (1) Position Control Lever
- (2) Hydraulic Cylinder Hose RH
- (3) Delivery Pipe
- (4) Return Hose
- (5) Position Control Feedback Rod
- (6) Rear Hydraulic Block
- (7) Hydraulic Cylinder Hose LH
- (8) Lowering Speed Adjusting Valve Joint Shaft

W1016371



3TLABAB8P036A

Lowering Speed Adjusting Valve


1. Draw out the spring pin (4).
2. Remove the holder (5).
3. Draw out the lowering speed adjusting shaft (3), dowel pin (6) and rotor (2).

(When reassembling)

- Take care not to damage the O-rings.

- | | |
|------------------------------------|----------------|
| (1) Rear Hydraulic Block | (4) Spring Pin |
| (2) Rotor | (5) Holder |
| (3) Lowering Speed Adjusting Shaft | (6) Dowel Pin |

W1016653



3TLABAB8P037A

Check Valves


1. Remove the plug (3).
2. Draw out the spring (2) and poppet (1).

(When reassembling)

- Take care not to damage the O-ring.

- | | |
|------------|----------|
| (1) Poppet | (3) Plug |
| (2) Spring | |

W1016889



3TLABAB8P038A

Cylinder Safety Valve

1. Remove the cylinder safety valve assembly (1).
2. Secure the cylinder safety valve assembly in a vise.
3. Loosen the lock nut (3), and remove the adjust screw (2).
4. Draw out the spring (4), seat (5), and ball (6).

(When reassembling)

- Take care not to damage the O-rings.


Tightening torque	Cylinder safety valve assembly	39.2 to 49.0 N·m 4.0 to 5.0 kgf·m 28.9 to 36.2 ft·lbs
	Cylinder safety valve lock nut	58.8 to 78.5 N·m 6.0 to 8.0 kgf·m 43.4 to 57.9 ft·lbs

■ IMPORTANT

- After disassembling and assembling the cylinder safety valve assembly, be sure to check the operating pressure.

- | | |
|------------------------------------|-------------|
| (1) Cylinder Safety Valve Assembly | (5) Seat |
| (2) Adjusting Screw | (6) Ball |
| (3) Lock Nut | (7) Housing |
| (4) Spring | |

W1017017



3TMABAB8P020B

Position Control Valve


1. Remove the position control valve (1) from rear hydraulic block (2).

(When reassembling)

- Take care not to damage the O-rings.


- | | |
|----------------------------|--------------------------|
| (1) Position Control Valve | (2) Rear Hydraulic Block |
|----------------------------|--------------------------|

W1017276




3TLABAB8P039A

Disassembling Position Control Valve



- (1) Nut
- (2) External Snap Ring
- (3) Unload Plug
- (4) Spring
- (5) Unload Poppet
- (6) Valve Body
- (7) Unload Poppet 2
- (8) Spring
- (9) Plug 2
- (10) Spool
- (11) Spring
- (12) Plain Washer
- (13) External Snap Ring
- (14) Spool Joint
- (15) External Snap Ring
- (16) Plug 1
- (17) Poppet 2
- (18) O-ring
- (19) Backup Ring
- (20) Sleeve
- (21) O-ring
- (22) O-ring
- (23) Dowel Pin
- (24) Spring
- (25) Spring Seat
- (26) Connecting Plate
- (27) Adjusting Screw
- (28) Nut

W1017417



1. Remove the nut (1), and draw out the spool (10).
2. Remove the unload plug (3), and draw out the spring (4), unload poppet (5).
3. Remove the plug 2 (9), and draw out the spring (8), unload poppet 2 (7).
4. Remove the external snap ring (2), spring seat (25) and spring (24).
5. Remove the plug 1 (16), and draw out the poppet 2 (17), sleeve (20).

NOTE

- Do not loosen the adjusting screw (27) unless necessary. If disassembled due to unavoidable reasons, be sure to set the dimension (A) to 0.2 mm (0.0079 in.).


(When reassembling)

- Take care not to damage the backup ring and O-rings.

Tightening torque	Unload plug	39.2 to 58.8 N·m 4.0 to 6.0 kgf·m 28.9 to 43.4 ft-lbs
	Plug 2	39.2 to 58.8 N·m 4.0 to 6.0 kgf·m 28.9 to 43.4 ft-lbs
	Plug 1	39.2 to 58.8 N·m 4.0 to 6.0 kgf·m 28.9 to 43.4 ft-lbs

W1017707

(3) Servicing




Operating Pressure of Cylinder Safety Valve

1. Attach the cylinder safety valve to a injection nozzle tester with a safety valve setting adaptor.
2. Measure the operating pressure of the cylinder safety valve.
3. If the operating pressure is not within the factory specifications, adjust by turning the adjusting screw (1).
4. After adjustment, tighten the lock nut (2) firmly.

NOTE

- Use specified transmission fluid (see page G-7, 8) to test the operating pressure of the cylinder safety valve.




Cylinder safety valve operating pressure	Factory spec.	19.6 to 22.6 MPa 200 to 230 kgf/cm ² 2845 to 3271 psi
Tightening torque	Cylinder safety valve lock nut	58.8 to 78.5 N·m 6.0 to 8.0 kgf·m 43.4 to 57.9 ft·lbs

- | | |
|---------------------|-------------|
| (1) Adjusting Screw | (4) Seat |
| (2) Lock Nut | (5) Ball |
| (3) Spring | (6) Housing |

W10205610

[4] LIFT ARM SUPPORT AND HYDRAULIC CYLINDER

(1) Disassembling and Assembling



Top Link, Lift Rod and PTO Cover


1. Remove the top link (1) and PTO cover (3).
 2. Disconnect the lift rods (2), (4) from lift arm.
- (When reassembling)**

Tightening torque	Lift arm pin mounting nut	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft·lbs
	Lift arm pin lock nut	62.8 to 72.6 N·m 6.4 to 7.4 kgf·m 46.3 to 53.5 ft·lbs

- | | |
|-----------------|-----------------|
| (1) Top Link | (3) PTO Cover |
| (2) Lift Rod RH | (4) Lift Rod LH |

W1018168

7.9 to 9.2 kgf·m 57.1 to 66.5 ft·lbs	Lift arm pin mounting nut	77.5 to 90.2 N·m
6.4 to 7.4 kgf·m 46.3 to 53.5 ft·lbs	Lift arm pin lock nut	62.8 to 72.6 N·m



Top Link Holder and Lift Arm Support

1. Disconnect the position control feedback rod (3).
2. Remove the top link holder (2).
3. Remove the lift arm support (1).

(When reassembling)



- Apply liquid gasket (Three Bond 1208D or equivalent) to joint face of the lift arm support and transmission case after eliminate the water, oil and stuck liquid gasket.
- After reassembling, be sure to adjust the position control feedback rod length. (See page 8-S12.)

Tightening torque	Top link holder mounting screw	77.5 to 90.2 N·m 7.9 to 9.2 kgf·m 57.1 to 66.5 ft·lbs
-------------------	--------------------------------	---

- (1) Lift Arm Support
(2) Top Link Holder

- (3) Position Control Feedback Rod

W1019071



Lift Arm and Lift Arm Shaft

1. Remove the external snap ring (5).
2. Remove the lift arm RH (6).
3. Draw out the lift arm shaft (1) and lift arm LH (7) as a unit.
4. Remove the collar (4) and O-ring (3).


(When reassembling)

- Align the alignment marks (8) of the lift arm shaft and lift arms.
- Apply grease to the right and left bushings of lift arm support and O-rings.
- Take care not to damage the O-rings.



- (1) Lift Arm Shaft
(2) Lift Arm Support
(3) O-ring
(4) Collar

- (5) External Snap Ring
(6) Lift Arm RH
(7) Lift Arm LH
(8) Alignment Mark

W1019375



(2) Servicing



Hydraulic Cylinder Rod Bushing

1. Visually inspect the DX bushings for signs of wear or damage. (The DX bushing tends to show concentrated wear.)
2. If the DX bushing is worn beyond the alloy portion (**A**), replace it.

(Reference)

Hydraulic cylinder rod bushing	Alloy thickness (A)	0.57 mm 0.0224 in.
--------------------------------	---------------------	-----------------------

W1019611



Hydraulic Cylinder I.D.

1. Measure the hydraulic cylinder I.D. with a cylinder gauge.
2. If the cylinder I.D. exceed the allowable limit, replace the cylinder tube.

Hydraulic cylinder I.D.	Factory spec.	55.000 to 55.074 mm 2.16535 to 2.16827 in.
	Allowable limit	55.100 mm 2.16929 in.

W1019902

Lift Arm Support Bushing

1. Visually inspect the DX bushings for signs of wear or damage. (The DX bushing tends to show concentrated wear.)
2. If the DX bushing is worn beyond the alloy portion (**A**), replace it.

(Reference)

Lift arm support bushing	Alloy thickness (A)	0.57 mm 0.0224 in.
--------------------------	---------------------	-----------------------

W1020043




Lift Arm Bushing

1. Visually inspect the DX bushings for signs of wear or damage. (The DX bushing tends to show concentrated wear.)
2. If the DX bushing is worn beyond the alloy portion (A), replace it. (Reference)

Lift arm bushing	Alloy thickness (A)	0.57 mm 0.0224 in.
------------------	---------------------	-----------------------

W1020165



Hydraulic cylinder I.D.	Factory spec	35.800 to 36.076 mm 1.4125 to 1.4203 in.
	Allowance limit	37.190 mm 1.4645 in.

W1020165

- Lift Arm Bushing**
1. Visually inspect the DX bushing for signs of wear or damage. (The DX bushing tends to show concentrated wear.)
 2. If the DX bushing is worn beyond the alloy portion (A), replace it. (Reference)

Lift arm support bushing	Alloy thickness (A)	0.57 mm 0.0224 in.
--------------------------	---------------------	-----------------------

W1020165

9 ELECTRICAL SYSTEM

MECHANISM

CONTENTS

1. WIRING DIAGRAM	9-M1
[1] ROPS TYPE.....	9-M2
(1) Manual Transmission Type.....	9-M2
(2) GST Model.....	9-M4
(3) HST Model.....	9-M6
[2] CABIN TYPE.....	9-M8
(1) GST Model.....	9-M8
(2) HST Model.....	9-M10
(3) Cabin.....	9-M12
2. ELECTRONIC CONTROL PANEL.....	9-M13
[1] SYSTEM OUTLINE AND ELECTRICAL CIRCUIT	9-M13
(1) System Outline.....	9-M13
(2) Control Items.....	9-M14
[2] CONSTRUCTION AND FUNCTION OF COMPONENTS	9-M15
[3] CONTROL SYSTEM.....	9-M23
(1) Basic Control System.....	9-M23
(2) Assistant Control System.....	9-M30
3. STARTING SYSTEM	9-M33
[1] GST-ROPS MODEL.....	9-M33
[2] HST-CABIN MODEL.....	9-M34
[3] OPERATOR PRESENCE CONTROL.....	9-M35
4. CHARGING SYSTEM	9-M36
5. LIGHTING SYSTEM	9-M37
[1] ROPS TYPE.....	9-M37
[2] CABIN TYPE.....	9-M38

1. WIRING DIAGRAM

Color of Wiring

B Black	B/W Black / White	Lg/Y Light Green / Yellow
G Green	B/Y Black / Yellow	Or/W Orange / White
L Blue	Br/B Brown / Black	R/B Red / Black
P Pink	Br/Y Brown / Yellow	R/G Red / Green
R Red	G/B Green / Black	R/L Red / Blue
V Violet	G/L Green / Blue	R/W Red / White
W White	G/R Green / Red	R/Y Red / Yellow
Y Yellow	G/W Green / White	W/B White / Black
Br Brown	G/Y Green / Yellow	W/G White / Green
Lg Light Green	L/B Blue / Black	W/L White / Blue
Or Orange	L/G Blue / Green	W/R White / Red
Sb Sky Blue	L/Or Blue / Orange	W/Y White / Yellow
B/G Black / Green	L/R Blue / Red	Y/B Yellow / Black
B/L Black / Blue	L/W Blue / White	Y/G Yellow / Green
B/P Black / Pink	L/Y Blue / Yellow	Y/L Yellow / Blue
B/Pu Black / Purple	Lg/B Light Green / Blue	Y/R Yellow / Red
B/R Black / Red	Lg/W Light Green / White	


W1019456




A332820AB-JTE

[1] ROPS TYPE


(1) Manual Transmission Type



3TLABAB9P056A




(2) GST Model




[S] CABIN TYPE

[R] GST Model




[2] CABIN TYPE


(1) GST Model




3TLBAB9P062A




(2) HST Model



3TLABAB9P064A



(3) Cabin



2. ELECTRONIC CONTROL PANEL

[1] SYSTEM OUTLINE AND ELECTRICAL CIRCUIT

(1) System Outline



- | | |
|--|-------------------------|
| (1) Combination Switch | (4) Hazard Switch |
| (2) Liquid Crystal Display (LCD) | (5) Travel Speed Switch |
| (3) Electronic Instrument Panel (IntelliPanel) | (6) Display Mode Switch |

W1012906

The Electronic Instrument Panel (IntelliPanel) adopted in the L30 series tractors consists of an 8-bit CPU^{*1}, sensors and input devices, memory devices such as RAM and ROM, and others. The CPU executes multiplex-communication^{*2} with ECU (Electronic Control Unit) and various sensors, switches and other related devices in order to give the functions that accurately and timely provide an operator with various information necessary for tractor operation. The contents include corrective procedure in case of an erroneous operation, precautions, and various alerts. If the tractor gets in trouble, a defective location, for example, is displayed with a message (sign) on the liquid crystal display or indicated with a monitor lamp.

The messages are displayed with segments, which gives approximately 130 patterns.

In the liquid crystal display (LCD)^{*3}, characters appear over reflected illumination, and are always back-lit by a small yellow lamp while the main switch is "ON".

*1 CPU

This Central Processing Unit is the core part of computers that controls the input/output devices to receive data, processes the data, and sends out the computing results.

The CPU comes in different types : 8 bits, 16 bits, 32 bits, etc., according to the number of bits as the unit of internal data processing. In general, the larger the number is, the higher the performance is.

*2 Multiplex communication

In multiplex communication, just one transmission (signal) line is effectively used to send and receive signals for digital transmission. In data communication, the transmission capacity of the line and the capacity of signal transmission/reception are represented by the number of bits that can be transmitted or received for one second. When the capacity of the transmission line is extremely larger than the ability of the transmission/reception performed by a terminal device, signals from plural terminals can be transmitted by means of time-sharing and multiplexing of one transmission path.

The merits of multiplex communication are as follows :

1. It permits high-performance control that allows three units to share information from sensors and information required for control.
2. It provides the smaller number of wire harnesses.
3. It allows each control unit to independently control the connected devices if communication should fail for some reason and become impossible.

*3 Liquid Crystal Display

Liquid crystal display is a displaying device that utilizes the characteristic of liquid crystal, in which the application of voltage triggers the molecules to change their orientations. The principle of indication is that when a voltage is applied on a liquid crystal sandwiched between two glass plates, the direction of molecules changes, with the resultant variation of the oscillatory direction of light that penetrates the liquid crystal. The set-up of a polarizing plate makes light go through or get blocked according to a change in voltage. Since the use of only the polarizing plate results in peculiar color, the film to counteract colored light is superimposed. However, the liquid crystal itself does not generate light, so it is back-lit by a fluorescent tube, for example, which makes the display easy to read in a dark space.

(2) Control Items

For HST models and manual transmission models, the electronic instrument panel (IntelliPanel) functions to receive data from sensors and switches, and displays them on the meter. For GST models, the electronic instrument panel also receives data also from the GST control ECU (Electric Control Unit) through multiplex communication, and displays them on the panel. Further, the GST control ECU receives model data and sensor data from electronic instrument panel to determine the control status.

In addition, the electronic instrument panel controls the following items.

1. Various Information Display Function

- Normal Display
Receive various data from each sensor, and display the hour meter, the traveling speed, the PTO speed, the fuel level, and the coolant temperature, etc. on the LCD which are basic information necessary for the tractor operation.
- Attention Display (at engine starting)
Display the operator's guidance of levers and pedals at the engine starting on the LCD.
- Service Interval Display
Display and alert the service interval periodically on the LCD and panel.
- Warning Display
Display the fuel level warning and overheat warning on the LCD and panel.
- Error Display
Display the occurrence of trouble with the sign on the LCD by the self-diagnosis function.

2. Lamp Control Function

Control the lighting and blinking of the warning lamp and the monitor lamp for operation.

3. Self-diagnosis Function


4. Fail-safe Function

It is a function that the entire system operates safely when the part of system gets in trouble.


5. Glow Control Function

6. Data Input, Fine-adjustment and Test Function

The function such as an input of various data, fine-adjustment of GST, and a testing of each sensor, etc. can be done by using LCD and switch operation.



[2] CONSTRUCTION AND FUNCTION OF COMPONENTS



3TLBAB9P069A

- | | | | |
|---|-----------------------------------|---|---|
| (1) Glow Relay | (10) Hazard Unit | (18) Engine Tachometer Sensor | (25) Electric Control Unit (ECU) |
| (2) Engine Oil Pressure Switch | (11) Combination Switch | (19) Traveling Speed Sensor | (26) GST Valve (Solenoid Valve and Proportional Reducing Valve) |
| (3) Coolant Temperature Sensor | (12) Main Switch | (20) Shuttle Switch | (27) Battery |
| (4) Fuel Sensor | (13) Cruise Switch | (21) GST Lever Sensor | |
| (5) Mid PTO Switch (Option) | (14) HST Range Shift Lever Sensor | (22) Oil Pressure Switch | |
| (6) PTO Switch | (15) HST Pedal Neutral Switch | (23) Oil Temperature Sensor | |
| (7) Parking Brake Switch | (16) Clutch Pedal Switch | (24) Electronic Instrument Panel (IntelliPanel) | |
| (8) Display Mode Switch and Travel Speed Switch | (17) Alternator | | |
| (9) Hazard Switch | | | |
- [A] For HST Model**
[B] For GST Model




■ **Electronic Instrument Panel (IntelliPanel)**

An 8 bit CPU is incorporated into the electronic instrument panel, and outputs the status of the tractor to the liquid crystal display, monitor lamp, tachometer, and buzzer. The built-in buzzer starts sounding, interlocked with alert/failure indications as well as with indication switching, and permits to make sure of the operational status of each part.

- (1) Electronic Instrument Panel (IntelliPanel)

W1013947



■ **Main Switch**

The main switch (1) transmits a main switch "ON" signal and an "ST" signal at the time of engine start to the electronic instrument panel. When each lever switch and the associated are in the neutral position, the computer in the electronic instrument panel detects the signals and determines whether the engine can be started safely.

- (1) Main Switch

W1014104



■ **Combination Switch**

The illumination lamp within the electronic instrument panel lights up by the operation of the headlight switch (1), interlocked with the light-up of the headlight. When the high beam headlight is used, the monitor lamp at the panel lights up.

The pilot lamp at the panel lights up by the operation of turn signal switch (2), interlocked with the turn signal lamp flashing through the hazard unit.

- (1) Headlight Switch
- (2) Turn Signal Switch

W1014167




■ **Hazard Switch**

The pilot lamp at the panel lights up by the operation of hazard switch (1), interlocked with the hazard lamp flashing through the hazard unit.

- (1) Hazard Switch

W1014047




■ Display Mode Switch and Travel Speed Switch

These switches are located at the right of the electronic instrument panel and both are of tact type. Usually, the display mode switch (1) is used at the switching of display indication, and the traveling speed switch (2) is used to switching to the traveling speed display as well as at data input and fine adjustment.

- (1) Display Mode Switch (2) Traveling Speed Switch

W1014375




■ Parking Brake Switch

This switch (1) is turned on and off interlocked with the parking brake lever (2). It is switched on when the parking brake is applied, thereby sending a signal to light up the pilot lamp at the electronic instrument panel.

- (1) Parking Brake Switch (2) Parking Brake Lever

W1014449



■ PTO Switch

This switch (1) is mounted on the PTO shift lever (2), and sends a 12 V signal to light up the lamp at the electronic instrument panel when PTO is used. It also serves as a safety switch when the engine is started.

- (1) PTO Switch (2) PTO Shift Lever

W1014516




■ Mid PTO Switch (Option)

This switch (1) is turned on by lever operation, sends a signal to change the LCD indication from rear PTO speed to mid PTO speed, and simultaneously sends a signal to light up the monitor lamp at the electronic instrument panel.

- (1) Mid PTO Switch (2) Mid PTO Shift Lever

W1014252




■ Fuel Sensor

This sensor (1) is designed to detect the fuel level in the fuel tank. It detects the position of the float that moves according to the quantity of fuel through the variation in resistance of the variable resistor, in order to indicate the fuel level on the LCD. It also sends a signal to light up the monitor lamp at the electronic instrument panel when fuel becomes less than 5 L (1.32 U.S.gals.).

(1) Fuel Sensor

W1014733




■ Coolant Temperature Sensor

This sensor (1) is designed to detect the temperature of coolant. It employs a thermistor, and detects the variation in resistance due to a change in temperature to indicate the temperature on the LCD. It also sends a signal to light up the alarm lamp in case of overheat, and indicate an alert message.

(1) Coolant Temperature Sensor

W1014804




■ Engine Oil Pressure Switch

This switch (1) is turned on when the main switch is turned on and the engine oil pressure becomes lower than 49 kPa (0.5 kgf/cm², 7.1 psi), and sends a signal to light up the alarm lamp.

(1) Engine Oil Pressure Switch

W1014871




■ Alternator

The terminal L of this alternator detects a signal from the battery charge. The alternator sends a signal for making the alarm lamp at the electronic instrument panel to light up if the electricity charge system becomes abnormal. In the ECU, if the engine tachometer sensor is defective, the terminal L of this alternator also detects an engine speed, thereby permitting ECU control as much as needed.

(1) Alternator

W1014934




■ Engine Tachometer Sensor

This sensor (1) is mounted at the right side of the engine gear case, and generates pulses proportional to the rotation of the fuel camshaft and the number of the cam gear teeth. The engine speed is calculated from the frequency of the pulse. The tachometer of the electronic instrument panel is of cross coil type, and analogically indicates by and after converting the frequency of the engine tachometer sensor. The PTO speed is calculated by means of using the frequency detected by this sensor and operational coefficient preset from model to model.

(1) Engine Tachometer Sensor

W1015004




■ Traveling Speed Sensor

This sensor (1) is mounted at the right bottom of the transmission case, and generates pulses proportional to the rotating speed and the number of teeth of the front-wheel drive gear on the PTO drive shaft. The speed of the tractor is calculated by means of using the frequency of the pulse and the operational coefficient preset for the model and tire size in question.

(1) Traveling Speed Sensor

W1015075




■ Glow Relay

This tractor has a system in which glow control is performed through the electronic instrument panel, and controls the coil current that starts or stops the preheating circuit through the electronic meter. The time required for preheating is adjusted by means of the water temperature sensor.

(1) Glow Relay

W1015142




■ Electric Control Unit (ECU) : for GST Model

The ECU (1) functions to operate GST in accordance with information coming from various sensors.

It has the role of controlling all the components while sharing sensor information necessary for control and control information with the electronic instrument panel, and consists of 16 bit CPU and interface that corresponds to the signal inlet and outlet.

(1) Electric Control Unit (ECU)

W1015355




3TLABAB3P030B

■ GST Valve (Solenoid Valves and Proportional Reducing Valve) : for GST Model

This valve (1) includes the sensors and switches and the associated necessary for GST control, solenoid that actuates GST, shift pin, proportional reducing valve, and others. It sends information from sensors and the associated to ECU, and then a signal from ECU actuates each solenoid valve.

- (1) GST Valve Assembly (2) Proportional Reducing Valve

W1015434



3TLABAB3P018A


■ Shuttle Switch : for Manual Transmission and GST Model

This switch (1) is mounted at the bottom of the shuttle lever shaft (2) and is turned on when the position of **F**, **N**, or **R** is detected through the movement of the sensor lever, thereby outputting a 12 V signal to the electronic instrument panel and ECU.

It also serves as a safety switch when the engine is started.

- (1) Shuttle Switch (2) Shuttle Lever Shaft

W1015505




3TLABAB3P017A

■ GST Lever Sensor : for GST Model

This sensor (1) is designed to detect the position at which the GST lever changes speed, and is mounted at the bottom of the GST lever (2). It has the variable resistor of revolution angle type, the maximum resistance value is 2 k Ω , and the electrically effective angle is 140 degrees. It also outputs the position of the lever from **N** to 12th speed stage in the range of approximately 0.5 to 3.5 V, and then sends a signal to the electronic instrument panel and ECU.

- (1) GST Lever Sensor (2) GST Lever

W1015572




3TLABAB3P030C

■ Oil Pressure Switch : for GST Model

This switch (1) is designed detect that the gear shift completion of GST and pressurizing of GST clutch pressure, and is mounted at the side of GST valve. It is turned on when the pilot pressure has become higher than 0.49 MPa (5 kgf/cm², 71 psi) and is turned off when the pressure has become lower than 0.34 MPa (3.5 kgf/cm², 50 psi).

- (1) Oil Pressure Switch

W1015635




■ Oil Temperature Sensor : for GST Model

This sensor (1) is designed to detect the temperature of transmission oil and is mounted at the side of GST valve. It is provided in order to compensate the operating time and electric current of the proportional reducing valve within GST valve, according to the transmission oil temperature.

The sensor employs the thermistor in which a rise in oil temperature causes smaller resistance and a fall in the temperature causes larger one.

(1) Oil Temperature Sensor

W1015709



■ HST Range Gear Shift Lever Sensor : for HST Model

This sensor (1) is designed to detect the position at which the HST range gear shift lever changes the speed, and is mounted at the bottom of the lever.

It has the variable resistor of revolution angle type, and the maximum resistance value is 5.4 k Ω . It outputs the lever position of L, M, N or H in the range of approximately 1.0 to 4.0 V.

(1) HST Range Gear Shift Lever Sensor

W1015780



■ HST Pedal Neutral Switch : for HST Model

This switch (1) is mounted on the HST pedal link, and is turned on when the HST pedal is in the neutral position. It serves as a safety switch when the engine is started.

(1) HST Pedal Neutral Switch

W1015847



■ Cruise Control Switch : for HST Model

This switch (1) is mounted at the bottom of the cruise lever assembly, and is turned on when the lever is operated, thereby sending a signal to light up the pilot lamp at the electronic instrument panel.

(1) Cruise Control Switch

W1015910




■ **Clutch Pedal Switch : for HST Model**

This switch (1) is mounted close to the fulcrum of the clutch pedal, and is turned on when the pedal is depressed (clutch "OFF"). It serves as a safety switch when the engine is started.

- (1) Clutch Pedal Switch
- (2) Clutch Pedal

W1014615



■ **Emergency Connector : for GST Model**

This is a device which compulsorily operates the shift solenoid when the tractor does not move due to the trouble of the GST system and moves the tractor.

(Situation for necessity of emergency connector)

- The defect in ECU
- The tractor does not move at all even if the shuttle lever and GST lever are operated though the trouble is repaired.

(Use of emergency connector)

1. Stop the engine.
2. Disconnect the ECU connector (3).
3. Remove the each cap from connectors (1), (2).
4. Connect the connector A and B.
5. Start the engine and move the tractor.

■ **NOTE**

- **When connecting the emergency connectors, the GST valve is set at 1st speed position even if the GST lever is at any position. And the stop and the start of the tractor is operated by shuttle lever.**

■ **IMPORTANT**

- **Be sure to disconnect the ECU connector when using the emergency connector.**

- (1) Emergency Connector A
- (2) Emergency Connector B
- (3) ECU Connector

W1031207




■ **Cruise Control Switch : for HST Model**
 This switch (1) is mounted at the bottom of the cruise lever assembly, and is turned on when the lever is operated, thereby sending a signal to light up the lamp at the electronic instrument panel.
 (1) Cruise Control Switch

W1031207

[3] CONTROL SYSTEM

(1) Basic Control System

(A) Normal Display



The normal display is a message indicated in the liquid crystal display (LCD) while the main switch is turned **ON** or the engine is starting.

The fuel gauge and coolant temperature gauge are always displayed on a right edge of LCD, and the position of gear shifting is displayed on a left edge for GST and HST model.

By pushing the display mode switch (3), it is switched to five kinds of displays shown in the table below.

- (1) IntelliPanel (Electronic Instrument Panel)
- (2) Liquid Crystal Display (LCD)
- (3) Display Mode Switch
- (4) Travel Speed Switch
- (5) Periodic Service Required
- (6) Fuel Gauge
- (7) Selected Speed Indication (HST and GST Model Only)
- (8) Message Display
- (9) Unit Indication
- (10) Coolant Temperature Gauge Readout

W1017233

Display Item	Manual Transmission Model	GST Model	HST Model
Normal Display 1 Hour Meter (Multiplication hours)	5678 h	12 5678 h	M 5678 h
Normal Display 2 Trip Meter (Unit hours)	TR 1234 h	8TR 1234 h	HTR 1234 h
Normal Display 3 Traveling Speed (mph)	16 mph	12 16 mph	H 16 mph
Normal Display 4 Traveling Speed (km/h)	25 km/h	4 25 km/h	L 25 km/h
Normal Display 5 PTO Speed (PTO OFF) (PTO ON) (Mid PTO ON)	PTO OFF	N PTO OFF	N PTO OFF
	REAR 540	SREAR 540	MREAR 540
	MID 2200	8MID 2200	HMID 2200

■ NOTE

- Trip meter can be reset to 0.0 h by pushing and holding the display mode switch for about two seconds with trip meter displayed.

W1015278

(B) Attention Display (At Engine Starting)


If neither of the levers or pedals are in neutral positions when the main switch is turned to the "START" position, the engine cannot be started. The electronic instrument panel displays a message for the operator to correct the situation by placing the appropriate lever or pedal in the neutral position.

■ **Manual Transmission and GST Model**

The safety switch for engine starting is adapted for the shuttle lever and the PTO shift lever in these models.

(Reference)


- As for the manual transmission model, selected speed displayed on left edge is not indicated.



■ **When the shuttle lever is not set at a Neutral position**

Shift the shuttle lever to **Neutral** position.


W1017623



■ **When the PTO shift lever is not set at a Neutral Position**

Shift the PTO shift lever to **Neutral** position.

W1017667







■ **When both the shuttle lever and the PTO shift lever are not set at a Neutral position**

Shift both shuttle lever and PTO shift lever to **Neutral** position.

W1017711

■ **HST Model**

The safety switch for engine starting is adapted for HST pedal, PTO shift lever and clutch pedal in this model.



■ **When the HST pedal is not set at a Neutral position**

Release the HST pedal to set the **Neutral** Position.
W1017819

■ **When the PTO shift lever is not set at a Neutral position**


Shift the PTO shift lever to **Neutral** position.
W1017869

■ **When the clutch pedal is not depressed**

Depress the clutch pedal.
W1017913

■ **When the HST pedal and PTO shift lever are not set a Neutral position**


Release the HST pedal and shift the PTO shift lever to set the **Neutral** position.
W1017957



■ When the HST pedal is not set at a **Neutral position** and the **clutch pedal is not depressed**

Release the HST pedal to set **Neutral** position and depress the clutch pedal.


W1018012



■ When the **PTO shift lever is not set a Neutral position** and the **clutch pedal is not depressed**

Shift the PTO shift lever to **Neutral** position and depress the clutch pedal.

W1018064




■ When the **HST pedal and PTO shift lever are not set a Neutral position**, and **clutch pedal is not depressed**

Release the HST pedal and shift the PTO shift lever to set a **Neutral** position, and depress the clutch pedal.

W1017516



(C) Service Interval Alert



The electronic instrument panel display will alert the operator when the scheduled service is required.

■ IMPORTANT

- This display, **SERVICE INSPECT**, informs the operator that periodic maintenance service is due. It does not indicate system or product malfunction.

“SERVICE INSPECT” (1), is displayed in the ICD and the service indicator lamp (2) illuminates every 50 hours. This service alert indicator remains illuminated until the clearing operation is completed after the periodic maintenance is performed.

(Reference)

- It is possible to change to other standard display by pushing the display mode switch (3).


Clearing Operation :

- Keep pushing both switches (3), (4) for two seconds or more while displaying the hour meter (Normal Display 1).

- | | |
|---------------------------------------|-------------------------------|
| (1) Periodic Service Required Readout | (a) GST and HST Model |
| (2) Service Indicator Lamp | (b) Manual Transmission Model |
| (3) Display Mode Switch | |
| (4) Travel Speed Switch | |

W1018218

(D) Warning Display or Warning Information




■ Fuel Level Warning

If the fuel in the tank goes below the prescribed level (less than 5 L, 1.3 U.S.gals.), “FUEL” is displayed on the LCD (1) and the warning lamp (2) in the panel will come on. If this should happen during operation, refuel as soon as possible.

It is possible to return to Normal Display by pushing the display mode switch even if “FUEL” is displayed.

- | | |
|----------------------------------|-----------------------------|
| (1) Liquid Crystal Display (LCD) | (2) Fuel Level Warning Lamp |
|----------------------------------|-----------------------------|

W1018698



■ Overheating Warning

The electronic instrument panel perceives the rise of coolant temperature, and has the function to display the overheat warning on the LCD.

When the coolant temperature becomes 125 °C (257 °F) or more, "OVERHEAT" (1) and "Eng SLOW" (2) are alternately displayed. Therefore, when these are displayed, lower the engine speed at once according to the message.


When the coolant temperature becomes 110 °C (230 °F) or less, "Eng STOP" (3) and "Check" (4) are alternately displayed. Therefore, when these are displayed, stop the engine and check the related place.

When the coolant temperature becomes 100 °C (212 °F) or less, Normal Display is displayed.

The warning lamp (6) comes on when the overheat display-1 (1) is displayed, and it keeps being on until water temperature is becoming 100 °C (212 °F) or less.

- (1) Overheat Display-1
- (2) Overheat Display-2
- (3) Overheat Display-3
- (4) Overheat Display-4
- (5) Normal Display
- (6) Overheat Warning Lamp
- (7) Liquid Crystal Display (LCD)

W1018762



■ Engine Oil Pressure and Electric Charging Warning


If the engine oil pressure goes below the 0.49 MPa (5 kgf/cm², 71 psi), the warning lamp (1) will come on. If this should happen during operation, and it does not go off when the engine is accelerated to more than 700 min⁻¹ (rpm), check level of engine oil.

If the alternator is not charging the battery, warning lamp (2) will come on. If this should happen during operation, check the charging system.

At above-mentioned two warnings, the buzzer rings for five seconds at the same time as the warning lamp's lighting, and it informs warning.

- (1) Engine Oil Pressure Warning Lamp
- (2) Electric Charging Warning Lamp

W1018641

(E) Lamp Control

In this electronic instrument panel, the control of various monitor lamps shown in figure are equipped in addition to warning lamps.

(1) Parking Brake Lamp

If the parking brake is applied, parking brake switch is turned on and monitor lamp will come on.

(2) GST Warning Indicator Lamp (GST Model Only)

If there have electrically problem in GST system, the GST warning indicator lamp will come on.

(3) Glow Indicator Lamp

If the main switch is turned to "ON" position, the glow indicator lamp comes on, and goes off automatically when preheating is completed.

(4) Rear PTO Lamp

If the PTO shift lever is "ON" position, PTO switch is turned on, and monitor lamp will come on.

(5) High Beam Indicator Lamp

If the head light switch is turned to High beam position, the indicator lamp comes on.

(6) Mid PTO Lamp

If the mid PTO shift lever is "ON" position while engaging the PTO, mid PTO lamp will come on.

(7) Shuttle Neutral Lamp**(Manual and GST Model Only)**

If the shuttle lever is set a **Neutral** position, this monitor lamp will come on.

(8) Cruise Lamp (HST Model Only)

If the cruise control lever is at speed set position, the cruise lamp will come on.

W1019091


(2) Assistant Control System

(A) Fail-safe Function

If a sensor or solenoid valve of the system gets in trouble during operation, an error message appears in the LCD screen of the electronic instrument panel. The entire system adjusts itself on the safer side and keeps itself from getting into another trouble.

What's more, if the shift solenoid valve of the GST valve gets in trouble, the system adjusts itself to an accessible shift position or the neutral position no matter which position the shift lever stays in.

(B) Self-diagnosis Function



If any of the following troubles occurs, its related error code gets displayed flashing in the panel's LCD screen as shown in figure. With the repair finished, the error code disappears. The error information will be, however, put in the memory device of the electronic instrument panel and can be reviewed in the Error Information Display Mode (see page 9-S18). Such error information can also be deleted out of the error history by operating of Error Information Reset Mode (see page 9-S15).

(Error Messages)

■ For All Models

ERROR-00 : Electronic meter in trouble

ERROR-20 : Communication error (For GST model)
GST-specified meter wrongly installed
on HST or Manual Transmission Model

■ For GST Model Only

ERROR-30 : ECU in trouble

ERROR-40 : Power supply of sensor from ECU in
trouble

ERROR-50 : GST lever sensor in trouble

ERROR-60 : Proportional reducing valve in trouble

ERROR-61 : Shift solenoid 1 in trouble

ERROR-62 : Shift solenoid 2 in trouble

ERROR-63 : Shift solenoid 3 in trouble

ERROR-64 : Shift solenoid 4 in trouble

ERROR-65 : Shift solenoid 6 in trouble

ERROR-66 : Shift solenoid 5 in trouble


■ NOTE

- See page 9-S4 about a detailed content of the error messages and their action method.

(A) The error message is
displayed here.

W1019431

(C) Testing, Setting and Adjusting Function



It can do various settings, adjustments and testing by using the electronic instrument panel.

When the main switch is turned to **ON** or **START** position while pushing both the display mode switch (2) and the travel speed switch (3), the mode selection display as shown in figure is indicated. And then, a target mode is selected, the data input and the fine adjustment, etc. can be done.

The following table shows the content of each mode display by the alphabet.

Sign	Mode Name	Contents
A	Test Mode	For checking the sensors, battery voltage and engine revolution
B	Traveling Speed Coefficient Input Mode	For inputting operation coefficient of traveling speed
C	PTO Coefficient Number Input Mode	For inputting operation coefficient number of PTO
D	Error Information Reset Mode	For deleting the error information
E	GST Lever Sensor Fine-adjustment Mode	For setting the Neutral position of GST lever sensor
F	GST Valve Fine-adjustment Mode	For setting the function of proportional reducing valve
G	GST Shift Shock Fine-adjustment Mode	For adjusting the clutch engaging interval
H	Error Information Display Mode	For reviewing error information (history)
I	Transmission Model Input Mode	For inputting the transmission model
J	Speed Unit Input Mode	For inputting the unit of traveling speeds

- (1) LCD
- (2) Display Mode Switch
- (3) Travel Speed Switch

- (A) Mode Selection Display for HST and Manual Transmission Model
- (B) Mode Selection Display for GST Model

W1019768

(D) Glow Control

The electronic meter incorporates the glow control which was external single parts so far, and controls it with CPU. When the main switch is turned **ON**, the temperature of the coolant is detected with the coolant temperature sensor, and the time to supply current to the glow plug and the glow indicator lamp is controlled by CPU according to the detected temperature. And the supply current to the glow plug is stopped automatically when the preheating time is completed, and monitor lamp on the electronic meter panel is turned off. (Refer to **"STARTING SYSTEM"**.)

The following table shows the content of each mode display by the display.

Mode Name	Content
1. Speed Unit Input Mode	For setting the unit of traveled speeds
2. Transmission Model Input Mode	For lighting the transmission model
3. Error Information Display Mode	For reversing error information (warning)
4. GST Shift Stroke Fine Adjustment Mode	For adjusting the clutch engaging interval
5. GST Valve Fine Adjustment Mode	For setting the function of proportional reversing valve
6. GST Level Sensor Fine Adjustment Mode	For setting the neutral position of GST level sensor
7. Error Information Input Mode	For changing the error information
8. PTO Coefficient Input Mode	For inputting coefficient of PTO
9. Traveling Speed Coefficient Input Mode	For inputting coefficient of traveling speed
10. Fuel Mode	For setting the sensor battery voltage and engine level (min)




(A) Mode Selection Display for HST and Manual Transmission Model
 (B) Travel Speed Switch
 (C) Testing, Setting and Adjusting Function

W010728


3. STARTING SYSTEM

[1] GST-ROPS MODEL



- | | | | |
|-----------------------------|------------------------|---------------------|---|
| (1) Battery | (8) Fuse (5 A) | (15) PTO Switch | (21) Fuse |
| (2) Slow Blow Fuse (50 A) | (9) Fuse (5 A) | (16) Mid PTO Switch | (22) Electronic Instrument Panel (IntelliPanel) |
| (3) Slow Blow Fuse (40 A) | (10) Fuse (30 A) | (17) Shuttle Switch | (23) Glow Relay |
| (4) Main Switch | (11) Fuse (10 A) | (18) OPC Timer | (24) Glow Plug |
| (5) Slow Blow Fuse (50 A) | (12) Fuse (5 A) | (19) Starter Relay | (25) Electric Control Unit (ECU) |
| (6) Slow Blow Fuse (30 A) | (13) Seat Switch | (20) Starter | |
| (7) Key Stop Solenoid Relay | (14) Key Stop Solenoid | | |




[2] HST-CABIN MODEL



3TLBAB9P122A

- | | | | |
|---------------------------|-----------------------------|-------------------------|----------------------------------|
| (1) Battery | (7) Key Stop Solenoid Relay | (13) HST Pedal Switch | (19) Starter Relay |
| (2) Slow Blow Fuse (60 A) | (8) Key Stop Solenoid | (14) Seat Switch | (20) Starter |
| (3) Slow Blow Fuse (50 A) | (9) Fuse (5 A) | (15) Mid PTO Switch | (21) Fuse (7.5 A) |
| (4) Main Switch | (10) Fuse (5 A) | (16) Main Clutch Switch | (22) Glow Relay |
| (5) Slow Blow Fuse (60 A) | (11) Fuse (30 A) | (17) Cruise Switch | (23) Electronic Instrument Panel |
| (6) Slow Blow Fuse (30 A) | (12) PTO Switch | (18) OPC Timer | (IntelliPanel) |

[3] OPERATOR PRESENCE CONTROL



The L30 series tractor equips operator presence control (OPC) system which automatically stops the engine when operator stands from the seat while shifting the PTO lever, shuttle lever or HST pedal.

This system is controlled by the seat switch (3), OPC timer (6), key stop solenoid relay (7), key stop solenoid (8), PTO switch (4) and shuttle switch or HST pedal switch (5).

■ Electric Circuit

1. When sitting on the seat in the state of main switch **ON**, the battery voltage passes the seat switch (3) and the OPC timer (6), and maintain the key stop solenoid relay (7).
2. When standing from the operators seat, the circuit from the seat switch (3) to the OPC timer is cut. However, if the levers (or pedal) are set at a **neutral** position, the circuit from the battery to the key stop solenoid relay (7) is formed with the lever (or pedal) switches (4), (5).
3. When standing from the seat while shifting the levers, the circuit from the battery to the key stop solenoid relay is cut, and the engine is stopped by function of key stop solenoid (8).

■ OPC Timer

After the current supply cuts, the OPC timer (6) adopted for this system has maintained the state of **ON** position for about one second.

■ Seat Switch

The seat switch (3) has two **ON** positions. One is sitting condition, and another is condition of seat lifting.


Therefore, if the engine is started, levers (or pedal) are shifted to neutral, it gets off from the tractor, and the seat is tilted forward, the PTO operation etc. become possible.

- | | |
|---|-----------------------|
| (1) Battery | (8) Key Stop Solenoid |
| (2) Main Switch | (9) Sensor Bar |
| (3) Seat Switch | |
| (4) PTO Switch | |
| (5) Shuttle Switch (for Manual and GST Model)
HST Pedal Switch (HST Model) | |
| (6) OPC Timer | |
| (7) Key Stop Solenoid Relay | |

- a : Sitting on the seat**
b : Lifting the seat
A : Seat Switch is ON
B : Seat Switch is OFF
C : Seat Switch is ON
D : Seat Suspension Plate Line



W1029338

4. CHARGING SYSTEM




3TLABAB9P125A

- (1) Battery
- (2) Slow Blow Fuse (ROPS : 50 A, Cabin : 60 A)
- (3) Main Switch (for ROPS)
- (4) Main Switch (for Cabin)
- (5) Engine Tachometer Sensor
- (6) Electronic Instrument Panel (IntelliPanel)
- (7) ECU (GST Model Only)
- (8) Alternator



5. LIGHTING SYSTEM


[1] ROPS TYPE



3TLABAB9P126A

- (1) Battery
- (2) Main Switch
- (3) Fuse (7.5 A)
- (4) Fuse (7.5 A)
- (5) Working Light (Option)
- (6) Fuse (5 A)
- (7) Fuse (15 A)
- (8) Fuse (7.5 A)
- (9) Head Light Switch
- (10) Turn Signal Switch
- (11) Hazard Switch
- (12) Flasher Unit
- (13) Head Light
- (14) Turn Signal Light, RH
- (15) Rear Combination Lamp, RH
- (16) Turn Signal Light, LH
- (17) Rear Combination Lamp, LH
- (18) Electronic Instrument Panel (IntelliPanel)

[2] CABIN TYPE



3TLABAB9P127A

- | | | | |
|-----------------------|-------------------------|---------------------------------|---|
| (1) Battery | (10) Head Light Switch | (18) Rear Combination Lamp, RH | (26) Door Switch |
| (2) Main Switch | (11) Horn Switch | (19) Rear Combination Lamp, LH | (27) Fuse (15 A) |
| (3) Fuse (7.5 A) | (12) Turn Signal Switch | (20) Front Combination Lamp, RH | (28) Working Light Switch, Front |
| (4) Fuse (5 A) | (13) Flasher Unit | (21) Front Combination Lamp, LH | (29) Working Light Switch, Rear |
| (5) Fuse (20 A) | (14) Fuse (20 A) | (22) Rear Upper Lamp, RH | (30) Working Light, Front |
| (6) Patrol Lamp | (15) Hazard Switch | (23) Rear Upper Lamp, LH | (31) Working Light, Rear |
| (7) Fuse (15 A) | (16) Head Light | (24) Fuse (10 A) | (32) Electronic Instrument Panel (IntelliPanel) |
| (8) Fuse (15 A) | (17) Horn | | |
| (9) Brake Lamp Switch | | | |

SERVICING

CONTENTS

1. TROUBLESHOOTING	9-S1
2. SERVICING SPECIFICATIONS	9-S8
3. TIGHTENING TORQUES	9-S9
4. CHECKING, DISASSEMBLING AND SERVICING.....	9-S10
[1] BATTERY.....	9-S10
(1) Checking	9-S10
[2] ELECTRONIC INSTRUMENT PANEL (INTELLIPANEL)	9-S12
(1) Testing, Setting and Adjusting by Electronic Instrument Panel (Intellipanel)	9-S12
(2) Checking Electrical Control System	9-S20
(3) Checking GST Electric Control System (GST Model Only)	9-S27
[3] STARTING SYSTEM	9-S33
(1) Checking	9-S33
(2) Disassembling and Assembling	9-S42
(3) Servicing	9-S42
[4] CHARGING SYSTEM	9-S45
(1) Checking	9-S45
(2) Disassembling and Assembling	9-S46
(3) Servicing	9-S48
[5] LIGHTING SYSTEM	9-S50
(1) Checking	9-S50
[6] WARNING LAMPS.....	9-S53
(1) Checking	9-S53
[7] MONITOR LAMP	9-S54
(1) Checking	9-S54
[8] GAUGES.....	9-S56
(1) Checking	9-S56

1. TROUBLESHOOTING

Symptom	Probable Cause	Solution	Reference Page
All Electrical Equipment Do Not Operate	• Battery discharged or defective	Recharge or replace	G-23
	• Battery positive cable disconnected or improperly connected	Repair or replace	—
	• Battery negative cable disconnected or improperly connected	Repair or replace	—
	• Slow blow fuse blown	Replace	G-34
Fuse Blown Frequently	• Short-circuited	Repair or replace	—

W10143220

BATTERY

Battery Discharges Too Quickly	• Battery defective	Replace	—
	• Alternator defective	Repair or replace	9-S45
	• IC Regulator defective	Replace	9-S45
	• Wiring harness disconnected or improperly connected (between battery positive terminal and regulator B terminal)	Repair or replace	—
	• Cooling fan belt slipping	Adjust tension	G-21

W10137180

STARTING SYSTEM

Starter Motor Does Not Operate	• Battery discharged or defective	Recharge or replace	G-23
	• Slow blow fuse blown	Replace	G-34
	• Safety switch improperly adjusted or defective	Repair or replace	9-S35
	• Wiring harness disconnected or improperly connected (between main switch terminal and safety switches, between safety switches and starter motor, between battery positive terminal and starter motor)	Repair or replace	—
	• Starter motor defective	Repair or replace	9-S42
	• Main switch defective	Replace	9-S33
	• Seat switch defective	Replace	9-S38
	• OPC timer defective	Replace	9-S38
	• Connector A for electronic instrument panel disconnected or improperly connected	Repair or replace	9-S23
	• Electronic instrument panel defective	Replace	9-S23
Glow Lamp Does Not Light	• Coolant temperature sensor defective	Replace	9-S56
	• Bulb blown	Replace	G-35
	• Main switch defective	Replace	9-S33
	• Circuit in panel defective	Replace	—
	• Wiring harness disconnected or improperly connected (between main switch terminal and panel, between panel and glow relay, between glow relay and ground)	Repair or replace	—
	• Electronic instrument panel defective	Replace	9-S23

W10137180

CHARGING SYSTEM

Symptom	Probable Cause	Solution	Reference Page
Charging Lamp Does Not Light when Main Switch is Turned ON	• Wiring harness disconnected or improperly connected (between main switch terminal and panel, between panel and alternator)	Repair or replace	—
	• Alternator defective	Repair or replace	9-S45
Charging Lamp Does Not Go Off When Engine is Running	• Wiring harness disconnected or improperly connected (between main switch terminal and alternator, between panel and alternator)	Replace	—
		Repair or replace	—
	• Alternator defective	Repair or replace	9-S45

W10135800

LIGHTING SYSTEM

Head Light Does Not Light	• Fuse blown	Replace	9-S20
	• Bulb blown	Replace	G-35
	• Wiring harness disconnected or improperly connected (between main switch terminal and combination switch B1 terminal, between combination switch 1 terminal and head light, between combination switch 2 terminal and head light)	Repair or replace	—
Hazard Light Does Not Light	• Fuse blown	Replace	9-S20
	• Bulb blown	Replace	G-35
	• Wiring harness disconnected or improperly connected	Repair or replace	—
	• Flasher unit defective	Replace	9-S53
	• Hazard switch defective	Replace	9-S52

W10137180

EASY CHECKER

Engine Oil Pressure Lamp Lights Up When Engine Is Running	• Engine oil pressure too low	Repair engine	—
	• Engine oil insufficient	Replenish	G-7, 8
	• Engine oil pressure switch defective	Replace	9-S53
	• Short circuit between engine oil pressure switch lead and chassis	Repair	—
	• Circuit in panel defective	Replace	9-S23
Engine Oil Pressure Lamp Does Not Light When Main Switch Is Turned ON and Engine Is Not Running	• Bulb blown	Replace	G-35
	• Engine oil pressure switch defective	Replace	9-S53
	• Wiring harness disconnected or improperly connected (between panel and engine oil pressure switch)	Repair or replace	—
	• Circuit in panel defective	Replace	9-S23

W10137180

GAUGES

Symptom	Probable Cause	Solution	Reference Page
Fuel Gauge Does Not Function	<ul style="list-style-type: none"> Fuel unit (tank unit) defective Wiring harness disconnected or improperly connected (between panel and fuel level sensor) 	Replace Repair or replace	9-S56 -
	<ul style="list-style-type: none"> Circuit in panel defective 	Replace	9-S23
Coolant Temperature Gauge Does Not Function	<ul style="list-style-type: none"> Coolant temperature sensor defective Wiring harness disconnected or improperly connected (between panel and coolant temperature sensor) 	Replace Repair or replace	9-S56 -
	<ul style="list-style-type: none"> Circuit in panel defective 	Replace	9-S23

W10137180

ELECTRONIC INSTRUMENT PANEL (INTELLIPANEL)

Nothing is Displayed in LCD	<ul style="list-style-type: none"> Battery discharged or defective (Battery voltage is below 7 V) 	Recharge or replace	G-23 9-S10
	<ul style="list-style-type: none"> Slow blow fuse blown 	Replace	-
	<ul style="list-style-type: none"> Electronic instrument panel connector disconnect Electronic instrument panel defective 	Connect Replace	9-S23 9-S23
Indication on LCD Does Not Change When Pushing the Display Mode Switch	<ul style="list-style-type: none"> Display mode switch defective Wiring harness disconnected 	Replace Repair	9-S26 -
Traveling Speed is Not Indicating	<ul style="list-style-type: none"> Wiring harness disconnected Traveling speed sensor defective 	Repair Replace	- 9-S25
PTO Speed is Not Indicating	<ul style="list-style-type: none"> Wiring harness disconnected Engine tachometer sensor defective 	Repair Replace	- 9-S25
Fuel Gauge is Indicating Always E	<ul style="list-style-type: none"> Wiring harness (GND) disconnected Fuel unit defective 	Repair or replace	- 9-S56
Fuel Gauge is Indicating Always F	<ul style="list-style-type: none"> Wiring harness short-circuited Fuel unit defective 	Repair or replace Replace	- 9-S56
Position of Range Gear Shift Lever Is Not Indicated (for HST Model)	<ul style="list-style-type: none"> Wiring harness disconnected Range gear shift lever sensor defective 	Repair or replace Replace	- 9-S24

W10233580

■ Error Display









→ Error message is displayed here

Display on LCD Screen	Trouble Item (Affected Model)	Probable Cause	Solution	Reference Page
ERROR-00	Electronic instrument panel memory device has failed (All model)	<ul style="list-style-type: none"> Electronic instrument panel memory device failure 	<ul style="list-style-type: none"> Replace electronic instrument panel 	9-S23
ERROR-10 Selected Travel Speed Is Not Displayed on LCD	HST range gear shift lever sensor failure (HST model)	<ul style="list-style-type: none"> Lever sensor output terminal is out of adjustment Lever sensor wire connector is broken or short-circuited Lever sensor defective <p>NOTE: ERROR-10 : is not automatically displayed in the LCD, but it is memorized in the electronic instrument panel as error information</p>	<ul style="list-style-type: none"> Check lever sensor wire connector Check sensor voltage by Test mode (Mode A) Check sensor voltage by connector Check sensor resistance Replace lever sensor 	9-S24 9-S13 9-S24 9-S26 9-S26
ERROR-20	Wrong setting of electric instrument panel (Manual Transmission and HST model)	<ul style="list-style-type: none"> GST specified electronic instrument panel installed wrong on HST or Manual transmission model 	<ul style="list-style-type: none"> Input appropriate transmission model by Transmission model Input Mode (Model I) 	9-S19
	Communication error between ECU and electronic instrument panel (GST model)	<ul style="list-style-type: none"> Fuse blown out Communication line between ECU and electronic instrument panel is broken or short-circuited No signals from ECU for longer than 5 seconds (error cleared if signal sent and received later) ECU defective 	<ul style="list-style-type: none"> Check fuse Check ECU connector Check communication line between ECU and electronic instrument panel at ECU connector Replace ECU 	9-S27 9-S27 9-S31 9-S28
ERROR-30	ECU memory device has failed (GST model)	<ul style="list-style-type: none"> ECU memory device failure 	<ul style="list-style-type: none"> Replace ECU 	9-S28






W1013580

Display on LCD Screen	Trouble Item (Affected Model)	Probable Cause	Solution	Reference Page
ERROR-40	Input voltage to lever sensor from ECU is failed (GST model)	<ul style="list-style-type: none"> Lever sensor input voltage drop below 2.6 V for 0.1 second or more Ground wire of lever sensor short-circuited 	<ul style="list-style-type: none"> Check ground wire Check input voltage at ECU connector Check sensor connector 	9-S27 9-S29 -
ERROR-50	GST lever sensor is failed (GST model)	<ul style="list-style-type: none"> Lever sensor output terminal is out of adjustment Lever sensor output wire terminal broken or short-circuited Input line broken Lever sensor defective 	<ul style="list-style-type: none"> It is possible to run at its selected speed position until engine is stopped. Check sensor connector Check sensor voltage by Test mode (Mode A) Check lever sensor wire connector (voltage) or check sensor resistance Replace lever sensor 	- - 9-S13 9-S29, S31 9-M20
ERROR-60	Proportional reducing valve failure (GST model)	<ul style="list-style-type: none"> Output voltage of proportional reducing valve terminal or return current is out of specification Valve wire broken or short-circuited Proportional reducing valve defective 	<ul style="list-style-type: none"> Check connector of proportional reducing valve Check proportional reducing valve resistance at valve or ECU connector Check grounding wire Connect emergency connector and move 	- 9-S30, S32 9-S27 9-M22

W1053954

Display on LCD Screen	Trouble Item (Affected Model)	Probable Cause	Solution	Reference Page
	Solenoid 1 failure (At forward or neutral) (GST model)	<ul style="list-style-type: none"> • Solenoid output terminal's voltage is out of specification • Solenoid broken or short-circuited • Wiring harness broken or short-circuited • Grounding plate of solenoid is poor contact with chassis 	<ul style="list-style-type: none"> • Able to travel at speeds other than 1, 7 and 8 (Forward) or 1 and 5 (Reverse) • Check the wiring connector of solenoid • Check a resistance between solenoid and GND • Replace GST valve 	—
	Solenoid 1 failure (At reverse) (GST model)			9-S30, S32 3-S82
	Solenoid 2 failure (At forward or neutral) (GST model)			—
	Solenoid 2 failure (At reverse) (GST model)			9-S30, S32 9-S82
	Solenoid 3 failure (At forward or neutral) (GST model)			—
	Solenoid 3 failure (At reverse) (GST model)			9-S30, S32 3-S82

W1011845

Display on LCD Screen	Trouble Item (Affected Model)	Probable Cause	Solution	Reference Page
	Solenoid 4 failure (At forward or neutral) (GST model)	<ul style="list-style-type: none"> • Solenoid output terminal's voltage is out of specification • Solenoid broken or short-circuited • Wiring harness broken or short-circuited • Grounding plate of solenoid is poor contact with chassis 	<ul style="list-style-type: none"> • Able to travel at speeds other than 5, 6 and 12 (Forward) or 4 and 8 (Reverse) • Check the wiring connector of solenoid • Check a resistance between solenoid and GND • Replace GST valve 	–
	Solenoid 4 failure (At reverse) (GST model)			9-S30, S32
	Solenoid 6 (Main range gear shift) failure (At forward or neutral) (GST model)			–
	Solenoid 6 (Main range gear shift) failure (At reverse) (GST model)			9-S30, S32
	Solenoid 5 (Sub-range gear shift) failure (GST model)			–
			<ul style="list-style-type: none"> • Able to travel at speeds other than 3, 5, 7 and 9 (Forward) • Check the wiring connector of solenoid • Check a resistance between solenoid and GND • Replace GST valve 	9-S30, S32
			• Replace GST valve	3-S82

W1024766

2. SERVICING SPECIFICATIONS

Item	Factory Specification	Allowable Limit
Starter		
Commutator	O.D. 30.0 mm 1.181 in.	29.0 mm 1.142 in.
Mica	Under Cut 0.50 to 0.80 mm 0.0197 to 0.0315 in.	0.20 mm 0.0079 in.
Brush	Length 15.0 mm 0.591 in.	11.0 mm 0.433 in.
Brush Holder and Holder Support	Resistance Infinity	—
Glow Plug	Resistance Approx. 0.9 Ω	—
Fuel Level Sensor		
Float at Upper-most Position	Resistance 1.0 to 5.0 Ω	—
Float at Lower-most Position	Resistance 103 to 117 Ω	—
Coolant Temperature Sensor		
at 130 °C (266 °F)	Resistance Approx. 12.2 Ω	—
at 105 °C (221 °F)	Resistance Approx. 23.6 Ω	—
at 80 °C (176 °F)	Resistance Approx. 51.9 Ω	—
at 50 °C (122 °F)	Resistance Approx. 153.9 Ω	—
Alternator		
No-load voltage	More than 14 V	—
Stator	Resistance Less than 1.0 Ω	—
Rotor	Resistance 2.9 Ω	—
Slip Ring	O.D. 14.4 mm 0.567 in.	12.8 mm 0.504 in.
Brush	Length 10.5 mm 0.413 in.	8.4 mm 0.331 in.
GST Proportional Reducint Valve	Resistance Approx. 8 to 9 Ω	—
Shift Solenoid Valve	Resistance Approx. 11 to 15 Ω	—

W10138740

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
 (For general use screws, bolts and nuts : See page G-9.)

Item	N·m	kgf·m	ft-lbs
Alternator pulley nut	58.3 to 78.9	5.95 to 8.05	43.0 to 58.2
Starter terminal nut	5.9 to 11.8	0.6 to 1.2	4.3 to 8.7

W10127360


- Keep open sparks and flames away from the battery at all times. Hydrogen gas mixed with oxygen becomes very explosive.
- IMPORTANT
- If the machine is to be operated for a short time without battery (using a slave battery for starting), use additional current (lights) while engine is running and insulate terminal of battery. If this advice is disregarded, damage to alternator and regulator may result.

(1) BATTERY (1) Checking

- Battery Voltage**
1. Stop the engine and turn the main switch off.
 2. Connect the COM (-) lead of the voltmeter to the battery's negative terminal post and the (+) lead to the positive terminal post, and measure the battery voltage.
 3. If the battery voltage is less than the factory specification, check the battery specific gravity and recharge the battery.

Battery voltage	Reference value
More than 12 V	


W10125020



- Battery Terminal Connection**
1. Turn the main switch on, and turn on the head light.
 2. Measure the voltage across the battery's positive terminal post and the cable terminal, and the voltage across the battery's negative terminal post and the chassis.
 3. If the measurement exceeds the factory specification, clean the battery terminal posts and cable clamps, and tighten them firmly.

Terminal difference	Reference value
Less than 0.1 V	

W10125030



4. CHECKING, DISASSEMBLING AND SERVICING

⚠ CAUTION


- To avoid accidental short circuit, be sure to attach the positive cable to the positive terminal before the negative cable is attached to the negative terminal.
- Never remove the battery cap while the engine is running.
- Keep electrolyte away from eyes, hands and clothes. If you are spattered with it, wash it away completely with water immediately.
- Keep open sparks and flames away from the battery at all times. Hydrogen gas mixed with oxygen becomes very explosive.

■ IMPORTANT

- If the machine is to be operated for a short time without battery (using a slave battery for starting), use additional current (lights) while engine is running and insulate terminal of battery. If this advice is disregarded, damage to alternator and regulator may result.

[1] BATTERY

(1) Checking




Battery Voltage

1. Stop the engine and turn the main switch off.
2. Connect the COM (-) lead of the voltmeter to the battery's negative terminal post and the (+) lead to the positive terminal post, and measure the battery voltage.
3. If the battery voltage is less than the factory specification, check the battery specific gravity and recharge the battery.

Battery voltage	Reference value	More than 12 V
-----------------	-----------------	----------------

W10125620





Battery Terminal Connection

1. Turn the main switch on, and turn on the head light.
2. Measure the voltage across the battery's positive terminal post and the cable terminal, and the voltage across the battery's negative terminal post and the chassis.
3. If the measurement exceeds the factory specification, clean the battery terminal posts and cable clamps, and tighten them firmly.

Potential difference	Reference value	Less than 0.1 V
----------------------	-----------------	-----------------

W10126630



Battery Specific Gravity

1. Check the specific gravity of the electrolyte in each cell with a hydrometer.
2. When the electrolyte temperature differs from that at which the hydrometer was calibrated, correct the specific gravity reading following the formula mentioned in (Reference).
3. If the specific gravity is less than 1.215 (after it is corrected for temperature), charge or replace the battery.
4. If the specific gravity differs between any two cells by more than 0.05, replace the battery.

■ **NOTE**

- Hold the hydrometer tube vertical without removing it from the electrolyte.
- Do not suck too much electrolyte into the tube.
- Allow the float to move freely and hold the hydrometer at eye level.
- The hydrometer reading must be taken at the highest electrolyte level.

(Reference)

- Specific gravity slightly varies with temperature. To be exact, the specific gravity decreases by 0.0007 with an increase of 1 °C (0.0004 with an increase of 1 °F) in temperature, and increases by 0.0007 with a decreases of 1 °C (0.0004 with a decrease of 1 °F).

Therefore, using 20 °C (68 °F) as a reference, the specific gravity reading must be corrected by the following formula :

- Specific gravity at 20 °C = Measured value + 0.0007 × (electrolyte temperature : 20 °C)
- Specific gravity at 68 °F = Measured value + 0.0004 × (electrolyte temperature : 68 °C)

Specific Gravity	State of Charge
1.260 Sp. Gr.	100 % Charged
1.230 Sp. Gr.	75 % Charged
1.200 Sp. Gr.	50 % Charged
1.170 Sp. Gr.	25 % Charged
1.140 Sp. Gr.	Very Little Useful Capacity
1.110 Sp. Gr.	Discharged

At an electrolyte temperature of 20 °C (68 °F)

W10127630

[2] ELECTRONIC INSTRUMENT PANEL (INTELLIPANEL)

(1) Testing, Setting and Adjusting by Electronic Instrument Panel (Intellipanel)

The following settings, adjustments and testing can be done by using the electronic instrument panel.

- Testing : Check a voltage of various sensor or rotation of engine.
- Setting or Adjusting : Input the various data to electronic instrument panel or ECU.
- Error Information : Confirm or clear the error information.

⚠ CAUTION

- To perform the testing of the electronic instrument panel the operator must be seated on the tractor.



■ Mode Selection

Select a corresponded mode by the following procedure, and do the test, the adjustment, the setting, and the confirmation respectively.

1. While holding down both the display mode switch and the travel speed switch at once, turn the main switch to ON or START position.
2. Mode selection display is indicated on the LCD.
3. Press the display mode switch (2) and the flashing part moves.
4. Hold down the display mode switch (2) for more than 2 seconds, and the buzzer rings and flashing symbol is selected.

■ NOTE

- To save entire and review the conditions, usually hold down the Display Mode switch until the buzzer rings.
- When a setting has been saved or an adjustment mode in any mode, be sure to turn off the main switch to end the procedure.




Symbol	Mode
A	Test Mode
B	Traveling Speed Coefficient Input Mode
C	PTO Coefficient Number Input Mode
D	Error Information Reset Mode
E	GST Lever Sensor Fine-adjustment Mode
F	GST Valve Fine-adjustment Mode
G	GST SHift Shock Fine-adjustment Mode
H	Error Information Display Mode
I	Transmission Model Selection Mode
J	Speed Unit Selection Mode

- (1) Liquid Crystal Display (LCD)
- (2) Display Mode Switch
- (3) Travel Speed Switch

(A) Mode Selection Display for HST and Manual Transmission Model

(B) Mode Selection Display for GST Model

W1010725



■ Test Mode (Mode "A")

1. While holding down the both switches at once, turn the main switch to **ON** or **START** position.
2. Select the mode "A".
3. "T1" is displayed (b).
4. Each time the display mode switch is pressed, the symbol changes from "T1" to "T7" with the buzzer sound.
5. Turn off the main switch to end the test mode.

(a) Mode Selection Display

(b) Testing Display

W1011155


Symbol	Contents	Condition	Value (unit)	Availability*		
				M	G	H
T1	Engine revolution	Idling to Max.	700 to Max. (n/min.)	☆	☆	☆
T2	Coolant temperature sensor voltage	0 to 60 °C (32 to 140 °F)	2.86 to 0.29 (V)	☆	☆	☆
T3	Fuel sensor voltage	F to E	3.62 to 0.13 (V)	☆	☆	☆
T4	Battery Voltage		More than 12 (V)	☆	☆	☆
T5	HST range gear shift lever sensor voltage	L → N → M → N → H	4.0 → 3.4 → 2.5 → 1.6 → 1.0 (V)			☆
T6	GST shift lever sensor voltage	N · 8 th · 12 th	0.71 · 3.07 · 4.21 (V)		☆	
T7	Oil temperature sensor voltage	0 to 60 °C (32 to 140 °F)	4.7 to 0.4 (V)		☆	

*M : Manual Transmission Model

G : GST Model

H : HST Model

W1012736



■ **Traveling Speed Coefficient Input Mode (Mode “B”)**

(Input the 4 digit tire code for correct travel speed to the electronic instrument panel memory panel)

■ **NOTE**

• When the tire size is changed or electronic instrument panel is replaced, this operation is required.

1. While holding down the both switches at once, turn on the main switch.
2. Select the mode “B”.
3. “0000” or the existing 4-digit numerical setting is displayed (b).
4. To change the code, select the appropriate code, referring to the tractor model and tire size.

(Numeric modification)

- Each time the display mode switch is pressed, the flashing number shifts. Press the travel speed switch to change the number.
5. Hold down the display mode switch for more than 2 seconds to preserve the code in the panel's memory.
 6. “OK” is displayed (c) : The code has been input correctly.
 7. “NG” is displayed (d) : Incorrect input. Repeat the procedure.


Availability	Value (mm)
H	700 to Max. (mm)
G	5.86 to 0.58 (V)
M	0.85 to 0.13 (V)
	More than 15 (V)
	0.1 to 0.2 (V)
	0.7 to 0.4 (V)

Tractor Model	Rear wheel tire size	Operation Coefficient
L3130 L3430	12.4 – 24 R1	2358
	355/80D – 20 R3	2178
	44 × 18 – 20 R3	2311
	41/18LL × 16.1 R3	2113
L3830	420/70 – 24 R4	2404
	14.9 – 24 R1	2505
	355/80D – 20 R3	2178
	41/18LL × 16.1 R3	2112
L4330 L4630	44 × 18 – 20 R3	2311
	17.5L – 24 R4	2550
	14.9 – 24 R1	2290
L5030	41/18LL × 16.1 R3	1930
	44 × 18 – 20 R3	2112
	17.5L – 24 R4	2330
	14.9 – 26 R1	2463
	13.6 – 28 R1	2470
	41/18LL × 16.1 R3	1945
	44 × 18 – 20 R3	2121
	17.5L – 24 R4	2351

(a) Mode Selection Display
(b) Input Display

(c) Correct Preserving Display
(d) Incorrect Preserving Display

W1012066



■ **PTO Coefficient Number Input Mode (Mode "C")**
 (Input the numeric code number for PTO speed into the electronic instrument panel)

■ **NOTE**


- **When the electronic instrument panel is replaced, this operation is required.**
- 1. While holding down the both switches at once, turn on the main switch.
- 2. Select the mode "C".
- 3. "1234" is displayed (b). The existing numerical code setting will flash.
- 4. To change the setting, select an appropriate input coefficient number, referring to the tractor model
(Numeric modification)
 - Each time display mode switch is pressed, the flashing number shifts.
- 5. Hold down the display mode switch for more than 2 seconds with the correct code number flashing. (Preserve the data to electronic instrument panel)
- 6. "OK" is displayed (c) : The code number has been input correctly.
- 7. "NG" is displayed (d) : The code number has not been input correctly. Repeat the procedure.

Operation Coefficient No.	Tractor model	Transmission model
1	L3130, L3430, L3830, L4330, L4630, L5030	Manual transmission GST
2	L3130, L3430, L3830, L4630	HST
3	L4330	HST
4	L5030	HST

(a) Mode Selection Display
 (b) Input Display

(c) Correct Preserving Display
 (d) Incorrect Preserving Display

W1013003




■ **Error Information Reset Mode (Mode "D")**
 (Delete the error information from the electronic instrument panel)

1. While holding down the both switches at once, turn on the main switch.
2. Select the mode "D".
3. "CLEAR" is displayed (b) and "PUSH SW" is displayed (c) for two seconds.
4. Hold down the display mode switch for more than 2 seconds, and the error information is deleted.
5. "OK" is displayed (d) : The electronic instrument panel memory has been reset correctly.
6. "NG" is displayed (e) : The resetting process has failed. Repeat the procedure.

(a) Mode Selection Display
 (b) Information Display
 (c) Resetting Display

(d) Correct Operation Display
 (e) Incorrect Operation Display

W1013628



■ **GST Lever Sensor Fine-adjustment (Mode "E")**
(Setting the GST lever's neutral position with its sensor)

■ **IMPORTANT**

- As for this fine-adjustment, be sure to set it correctly because the set state becomes the standard of the control thereafter.

■ **NOTE**

- When the GST lever sensor, the ECU or the electronic instrument panel is replaced, this adjustment is required.


1. Set the GST shift lever to **Neutral** position.
2. While holding down the both switches at once, turn on the main switch.
3. Select mode "E".
4. "LEVER" is displayed (b) and "PUSH SW" is displayed (c) for five seconds.
5. Hold down the display mode switch for more than 2 seconds. (This preserve the adjusted value to the ECU.)
6. "OK" is displayed (d) on LCD screen to tell that preserving to ECU has been made correctly. Turn off the main switch to end the mode.
7. If "NG" is displayed (f), it means the preserving has not been made correctly (4). Turn off the main switch and repeat the procedure.
8. If "LEVER" is displayed (b) first and then "ERROR-70" shows up (e), it means the lever sensor voltage is out of specification. In this case;

- Check to see that GST lever is at the **Neutral** position.
- Check the lever sensor voltage in the Test Mode (Mode "A") (see page 9-S13). If out of specification, replace the sensor itself.

- (1) Liquid Crystal Display (LCD)
- (2) Display Mode Switch
- (3) Travel Speed Switch

- (a) Mode Selection Display
- (b) Information Display
- (c) Adjusting Display
- (d) Correct Preserving Display
- (e) Error Display
- (f) Incorrect Preserving Display





■ GST Valve Fine-adjustment Mode (Mode "F") (Setting the function of proportional reducing valve)

■ NOTE

- When the ECU or GST valve is replaced, this adjustment is required.

1. While holding down the both switches at once, start the engine.
2. Select mode "F".
3. "P-VALVE" is displayed (b) and STEP-01 (c) is displayed the three seconds after.

■ NOTE

- To make this adjustment, follow these steps in the exact order described. (Otherwise the switch does not work to go to next step. At "STEP-01" and "STEP-03", however, the next step can be moved without their settings.)
- Push the display mode switch to move to the next step.

4. STEP-01 (c) : Release parking brake.
5. STEP-02 (d) : Set the engine speed at 1000 to 1400 min⁻¹ (rpm).
6. STEP-03 (e) : Set front tires straight ahead.
7. STEP-04 (f) : Operate the speed selection lever (GST lever) as follows ; disengaged the clutch, select "forward" with the shuttle lever, and shift the GST lever from 1 thru 12 several times. Set the GST lever at the positions other than neutral.
8. STEP-05 (g) : Set the GST lever to **Neutral** position.
9. STEP-06 (h) : Set shuttle lever to forward and engage clutch.
10. PUSH SW (i) : Push the display mode switch for more than three seconds.
11. STEP-07 (j) : To perform this function the operator must be seated on the tractor. After a short delay the tractor will begin to move slowly. And then, after it moves a little, the tractor stops automatically. (Fine-adjustment is being executed.)
12. OK is displayed (k) : The setting has been preserved correctly to the ECU.
13. NG is displayed (l) : The setting has not been correctly saved in the ECU. Repeat the entire procedure.

(a) Mode Selection Display

(b) Information Display

(c) Setting Display-1

(d) Setting Display-2

(e) Setting Display-3

(f) Setting Display-4

(g) Setting Display-5

(h) Setting Display-6

(i) Adjusting Display

(j) Setting Display-7

(k) Correct Preserving Display

(l) Incorrect Preserving Display

W1020355



■ **GST Shift Shock Fine-adjustment Mode (Mode "G")**
(Adjusting the clutch engaging interval)

■ **NOTE**

• **When the sense of shifting shock is not suitable, shifting shock can be changed by this adjustment.**

1. While holding down the both switches at once, start the engine.
2. Select mode "G".
3. "SHOCK" is displayed (b) first and then the numerical code setting is displayed (c).
The number "-9" through "+9" can be displayed. This has been factory-adjusted to "0".


4. Setting;
 - For lighter shifting shock;
Press the display mode switch to reduce the number.
 - For higher shifting shock;
Press the travel speed switch to increase the number.
5. Move the tractor to confirm the shifting shock.
6. Turn off the key. Then setting will be put in memory.

■ **NOTE**

• **If the shift shock has been adjusted but no remarkable effect can be felt, keep the setting at "0".**

- (a) Mode Selection Display (c) Setting Number Display
(b) Information Display

W1020862




■ **Error Information Display Mode (Mode "H")**
(Confirming or Reviewing the Error Information)

1. While holding down the both switches at once, turn on the main switch.
2. Select mode "H".
3. If there is not error information in memory, "NO ERROR" is displayed (b).
4. If there is error information in memory, its information is displayed.
5. If there are two or more error information readouts, presses the display mode switch and the stored information can be reviewed one by one.
6. Even if a problem has been corrected or repaired, the information is displayed until it is deleted.
7. Refer to "Error Information Reset Mode (Mode "D")" for deleting the error information.

- (a) Mode Selection Display (b) Information Display

W1014747



■ Transmission Model Input Mode (Mode "I") (Input the transmission model into electronic instrument panel)

■ NOTE

- When the electronic instrument panel is replaced, this operation is required.
- On the HST models, the range gear shift lever sensor must be adjusted at the same time.

1. While holding down the both switches at once, turn on the main switch.
2. Select mode "I".
3. "MHG" is displayed (b), and the existing symbol setting is flashing.

(Reference)


- "M" : Manual Transmission Model
- "G" : GST Model
- "H" : HST Model

4. To change the setting, select either "G" or "M", and input to the electronic instrument panel. Each time display mode switch is pressed, the flashing symbol shifts. And then, hold down switch for more than 2 seconds with the symbol flashing.
5. "OK" is displayed (c) : The tractor model has been input correctly.
6. If "NG" is displayed (d) : The tractor model has not been input correctly. Repeat the procedure.

- (a) Mode Selection Display
(b) Input Display

- (c) Correct Preserving Display
(d) Incorrect Preserving Display

W1014885



■ Adjustment of HST range gear shift lever sensor (for HST Model)

■ NOTE

- When the electronic instrument panel or range gear shift sensor was replaced, this adjustment is required.

1. Set the range gear shift lever to the **M** position.
2. Select mode "I" and then select "H" of the HST model according to above procedure.
3. "OK" is displayed (c) : Lever sensor voltage is as specified.
4. "ERROR 71" is displayed (d) : Lever sensor voltage is not specified.


In this case;

- Check to see that the range gear shift lever is at **M** position.
- Check the lever sensor voltage in the Test Mode (Mode "A") (see page 9-S13). If out of specification, replace the sensor.

- (a) Mode Selection Display
(b) Information Display

- (c) Correct Preserving Display
(d) Error Display

W1021589



■ Speed Unit Selection Mode (Mode "J")

(Input the traveling speed unit to the electronic instrument panel)

1. While holding down the both switches at once, turn on the main switch.
2. Select mode "J".
3. "12" is displayed (b), and existing number is flashing. (Reference)
 - "1" : Traveling speed unit is "km/h"
 - "2" : Traveling speed unit is "mph"
4. To change the setting, select an appropriate number, and input to the electronic instrument panel. Each time display mode switch is pressed, the flashing number shifts. And then, hold down switch for more than 2 seconds with the number flashing.
5. "OK" is displayed (c) : The code number has been input correctly.
6. "NG" is displayed (d) : The code number has not been input correctly. Repeat the procedure.

(a) Mode Selection Display
(b) Input Display

(c) Correct Preserving Display
(d) Incorrect Preserving Display

W1015386

(2) Checking Electrical Control System

⚠ CAUTION

- For checking of electric circuit, use the circuit tester and test function of electronic instrument panel (See page 9-S#)
- As for the checking of sensors, switches and solenoid, do the following order; check the battery, fuse and grounding line first, check by the test function of electronic instrument panel next, and check the connectors of panel or electronic control unit. If any defect is found there, check individual sensors, switches or solenoids to see whether the defect exists at the sensor, switch and solenoid side or at the wire harness side.
- When the normal function is restored as the result of replacement of the part which is suspected to see that the trouble is regenerated.

■ IMPORTANT

- When connecting or disconnecting the connector for the purpose of checking, be sure to turn OFF the main switch before hand. Moreover, pay attention not to allow the terminal to come in contact with other terminal or chassis while checking.
- When applying the test pin of the tester to the connector terminals, use care not to damage to the connector terminal.

(A) Check the Fuse and Connector





Checking Fuse

1. Check the fuse.
2. If any of the fuses is blown, replace it with the one having same capacity. (Refer to page G-34.)

■ IMPORTANT

- If a fuse is blown, check the cause and be sure to replace it with the one having same capacity.

W1034998



Checking Grounding Wire

1. Check the whether the grounding wire (1) is connected securely to the tractor chassis.
2. If the grounding wire is broken or disconnected, replace it.

(1) Grounding Wire

(A) Located at Left Side of Front Axle Frame

(B) Located at Left Side of Transmission Case

W1035073

Checking Panel Connector

1. Disconnect the connectors (1), (2) and check their terminals for contamination and deformation.
2. Check to see that cable does not broken or terminals are not shelled off.
3. If any defective parts are found, repair or replace them.

IMPORTANT

- Connect connectors surely after checked.


(1) Connector B (16P)

(2) Connector A (20P)

W1035253

No.	Color of wiring	Terminal Name
1	Red	Power supply 12 V (from battery)
2	Black	GND (for circuit line)
3	Black / Yellow	GND (for sensor)
4	Brown / White	Check connector
5	Brown	Check connector
6	Yellow	Check connector
7	White	Check connector
8	Yellow / Blue	Check connector
9	Red / Blue	Check connector
10	Red / Yellow	Check connector
11	Black	Check connector
12	Green / Red	Check connector
13		Check connector
14	Orange	Check connector
15	Light Green	Check connector
16	Green / Red	Check connector

No.	Color of wiring	Terminal Name
1	Red	Power supply 12 V (from battery)
2	Black	GND (for circuit line)
3	Black / Yellow	GND (for sensor)
4	Brown / White	Check connector
5	Brown	Check connector
6	Yellow	Check connector
7	White	Check connector
8	Yellow / Blue	Check connector
9	Red / Blue	Check connector
10	Red / Yellow	Check connector
11	Black	Check connector
12	Green / Red	Check connector
13		Check connector
14	Orange	Check connector
15	Light Green	Check connector
16	Green / Red	Check connector

(B) Checking by Electronic Instrument Panel Connector**(A) Connector A (20P Connector) of Wire Harness Side**

No.	Color of wiring	Terminal Name		
		Manual Transmission	GST	HST
1				
2	Light green / Black		Display mode switch	
3	Blue		Travel speed switch	
4	Brown / Yellow		Hi-beam	
5	Red / White	Main switch ON		
	Black / Yellow			HST pedal neutral switch
6	Black / Red		PTO switch output	
7	Black / Yellow		PTO switch input	
8	Black / Yellow	Shuttle switch		Clutch switch
9	Green / White		Mid PTO switch	
10				
11	Blue		Oil switch	
12				
13	White / Red		Charge	
14				
15	Violet / White			Cruise switch
16				
17	Black / White		Main switch ST	
18	Black / White		Turn signal switch RH	
19	Green / Blue		Turn signal switch LH	
20	Black / Red		Glow relay	

(B) Connector B (16P Connector) of Wire Harness Side

No.	Color of wiring	Terminal Name		
		Manual Transmission	GST	HST
1	Red		Power supply 12 V (From battery)	
2	Black		GND (for circuit line)	
3	Black / Yellow		GND (for sensor)	
4	Brown / White	Check connector	Communication line to ECU+	Check connector
5	Brown	Check connector	Communication line to ECU-	Check connector
6	Yellow			HST lever sensor
7	White		Coolant temperature sensor	
8	Yellow / Blue		Fuel unit	
9	Red / Blue		Main switch ON	
10	Red / Yellow			+5 V (for HST lever sensor)
11	Black		GND	
12	Green / Red		Parking brake switch	
13				
14	Orange		Traveling speed sensor	
15	Light Green		Engine tachometer sensor	
16	Green / Red		Lighting	



Disconnecting Electronic Instrument Panel Connector

1. Remove the combination switch (2).
2. Remove the panel cover (1).
3. Disconnect the panel connectors (5), (6).
4. Remove the electronic instrument panel (3) from panel frame (4).

- (1) Panel Cover
- (2) Combination Switch
- (3) Electronic Instrument Panel (IntelliPanel)
- (4) Panel Frame
- (5) Connector A (20P)
- (6) Connector B (16P)

W1036395



Connector Voltage


■ **Main Voltage**

1. Measure the voltage between the terminal 1 (+) and terminal 11 (-).
2. If the voltage differs from the battery voltage (11 to 14 V), the wiring harness or battery is faulty.

Voltage	Terminal 1 to 11	Approx. battery voltage
---------	------------------	-------------------------

A : Connector B (16P) of Wire Harness Side


W1036564



Voltage	Terminal 1 to Terminal 11	Approx. battery voltage
---------	---------------------------	-------------------------

A : Connector B (16P) of Wire Harness Side

W1036395



Checking HST Range Gear Shift Lever Sensor (HST model)

■ Connector Voltage

1. Turn on the main switch.
2. Measure the voltage between the terminal **10 (+)** and terminal **3 (-)** of the connector **B**.
3. If the voltage is not indicated as table below, wire harness or fuse is faulty.

Voltage	Terminal 10 to terminal 3	Approx. 5 V
---------	---------------------------	-------------


■ Sensor Voltage

1. Turn on the main switch.
2. Measure the voltage between the terminal **6 (+)** and terminal **3** of the connector **B** while shifting the range gear shift lever.
3. If the voltage is not indicated as table below, wire harness or lever sensor is faulty.

Lever position	Measuring terminal	Voltage
L	Terminal 6 to terminal 3	Approx. 4.0 V
N		Approx. 3.4 V
M		Approx. 2.5 V
N		Approx. 1.6 V
H		Approx. 1.0 V

A : Connector B (16P) of Wire Harness Side

W1045520




Checking Fuel Unit

1. Turn on the main switch.
2. Measure the voltage between the terminal **8 (+)** and terminal **3 (-)** of the connector **B**.
3. If the voltage is not indicated as table below, wire harness or fuel unit is faulty.

Voltage	Terminal 8 to terminal 3	0.13 to 3.62 V (E to F)
---------	--------------------------	-------------------------

A : Connector B (16P) of Wire Harness Side

W1046153




Checking Coolant Temperature Sensor

1. Turn on the main switch.
2. Measure the voltage between the terminal **7 (+)** and terminal **3 (-)** of the connector **B**.
3. If the voltage is not indicated as table below, wire harness or coolant temperature sensor is faulty.

Voltage	Terminal 7 to terminal 3	0.29 to 2.86 V (60 to 0°C, 140 to 32°F)
---------	--------------------------	---

A : Connector B (16P) of Wire Harness Side

W1046594



Checking Display mode Switch and Travel Speed Switch

(Display Mode Switch)

1. Turn on the main switch. (Do not start engine.)
2. Measure the voltage between the terminal 2 (+) of connector A and chassis.
3. It is OK if the battery voltage (12 V) is indicated while pushing the display mode switch.


(Travel Speed Switch)

1. Turn on the main switch. (Do not start engine.)
2. Measure the voltage with voltmeter between terminal 3 (+) of connector A and chassis.
3. It is OK if the battery voltage (12 V) is indicated while pushing the travel speed switch.

Voltage with switch pushing	Terminal 2 to chassis	12 V
	Terminal 3 to chassis	

A : Connector A (20P) of wire harness Side

W1046806




Checking Engine Tachometer Sensor

1. Connect the panel connector A (20P) to the electronic instrument panel.
2. Start the engine.
3. Measure the AC voltage between terminal 15 and terminal 3 of connector B.
4. If the voltage is not indicated as table below, wire harness or engine tachometer is faulty.

Voltage	Terminal 15 to terminal 3	Approx. AC 2.0 V
---------	---------------------------	------------------

A : Connector B (16P) of Wire Harness Side

W1047444



Checking Traveling Speed Sensor


1. Connect the panel connector A (20P) to the electronic instrument panel.
2. Jack up front and rear wheels or jack up rear wheels. Be sure to shift the front wheel drive lever to 2WD position
3. Start the engine and shift the shift lever or pedal so that the rear wheels can be turn.
4. Measure the AC voltage between terminal 14 and terminal 3 of connector B.
5. If the voltage is not indicated as table below, wire harness or traveling speed sensor is faulty.

Voltage	Terminal 14 to terminal 3	Approx. AC 2.0 V
---------	---------------------------	------------------

A : Connector B (16P) of Wire Harness Side

W1048327

(C) Unit Checking




Display Mode Switch and Travel Speed Switch

1. Check the resistance between terminal **a** and terminal **c** while pushing the display mode switch (1).
2. It is OK if 0 ohm is indicated.
3. Check the resistance between terminal **b** and terminal **c** while pushing the travel speed switch (2).

(1) Display Mode Switch

(2) Travel Speed Switch

W1048960



HST Range Gear Shift Lever Sensor Resistance



1. Measure the resistance between **A** and **B** while shifting the range gear shift lever.
2. It is OK if the resistance is smoothly changing.

(Reference)

- The maximum resistance value is 4.32 to 6.48 kΩ.

(1) Range Gear Shift Lever Sensor

W1080989




Voltage	Terminal 14 to Terminal 3	Approx. AC 5.0 V
---------	---------------------------	------------------

A : Connector B (12P) of Wire Harness Side

W1048960

(3) Checking GST Electric Control System (GST Model Only)

(A) Checking Fuse and Connector




Checking Fuse

1. Check the fuse.
2. If any of the fuses is blown, replace it with the one having same capacity. (Refer to page G-34.)

■ IMPORTANT

- If a fuse is blown, check the cause and be sure to replace it with the one having same capacity.

W1058136




Checking Grounding Wire

1. Check the whether the grounding wire (1) is connected securely to the tractor chassis.
2. If the grounding wire is broken or disconnected, replace it.

(1) Grounding Wire

W1058245



Checking ECU Connector

1. Disconnect the connector (1), and check their terminals for contamination and deformation.
2. Check to see that cable does not broken or terminals are not shelled off.
3. If any defective parts are found, repair or replace them.

■ IMPORTANT


- Connect connectors surely after checked.

(1) ECU Connector (44P)

W1037538





32	Pink	TXD (for check connector)	44	Violet	FXD (for check connector)
31	Brown / White	Communication line to Panel (-)	43	Brown	Communication line to Panel (+)
30	White / Yellow	Oil temperature sensor	42	White / Green	GST level sensor
19	White / Yellow	Oil temperature sensor	41	Light Green	Engine tachometer sensor
17	Orange	Traveling speed sensor	39	Light Green	Engine tachometer sensor
16	Orange	Traveling speed sensor	38	Light Green	Engine tachometer sensor
15	Orange	Traveling speed sensor	37	Red / Green	Shuttle switch (Reverse)
14	Black / Yellow	Shuttle switch (Neutral)	36	Yellow / Orange	Shuttle switch (Forward)
12	Black / White	Black / White	35	Yellow / Orange	Shuttle switch (Forward)
11	Black / White	Black / White	34	Yellow / Orange	Shuttle switch (Forward)
10	Black / White	Black / White	33	Yellow / Orange	Shuttle switch (Forward)
9	Black / White	Black / White	32	Yellow / Orange	Shuttle switch (Forward)
8	Black / White	Black / White	31	Yellow / Orange	Shuttle switch (Forward)
7	Black / White	Black / White	30	Yellow / Orange	Shuttle switch (Forward)
6	Black / White	Black / White	29	Yellow / Orange	Shuttle switch (Forward)
5	Black / White	Black / White	28	Yellow / Orange	Shuttle switch (Forward)
4	Red	Red	27	Yellow / Orange	Shuttle switch (Forward)
3	Red	Red	26	Yellow / Orange	Shuttle switch (Forward)
2	Red / Yellow	Red / Yellow	25	Yellow / Orange	Shuttle switch (Forward)
1	Red / Yellow	Red / Yellow	24	Yellow / Orange	Shuttle switch (Forward)

A : ECU Connector or Wire Harness Side

(B) Checking by Electric Control Unit (ECU)

No.	Color of wiring	Terminal Name	No.	Color of wiring	Terminal Name
1			23	Green / White	Output terminal for proportional reducing valve
2	Red / Yellow	Output voltage 12 V (for pressure switch)	24		
3			25	Brown / Blue	Output terminal for sub-range shift solenoid
4	Red	Output voltage 12 V (for Check connector)	26	Brown / Yellow	Output terminal for main range shift solenoid
5			27	Brown / Black	Output terminal for 1st shift solenoid
6			28	Brown / White	Output terminal for 2nd shift solenoid
7	Black	GND (ground for circuit line)	29	Brown / Red	Output terminal for 3rd shift solenoid
8	Red / Yellow	+12 V (power source from main switch)	30	Brown / Green	Output terminal for 4th shift solenoid
9			31	Red	+12 V (power source from battery)
10	Black / White	GND (ground for oil temp. sensor)	32	Blue / Red	Return line terminal for proportional reducing valve
11	Black / White	GND (ground for check connector)	33	Black / White	GND (ground for sensor)
12			34	Red / White	+5 V (power source for sensor)
13			35	Yellow / White	Pressure switch
14	Black / Yellow	Shuttle switch (Neutral)	36	Yellow / Orange	Shuttle switch (Forward)
15			37	Red / Green	Shuttle switch (Reverse)
16			38		
17	Orange	Traveling speed sensor	39	Light green	Engine tachometer sensor
18			40		
19	White / Yellow	Oil temperature sensor	41		
20			42	White / Green	GST lever sensor
21	Brown / White	Communication line to Panel (-)	43	Brown	Communication line to Panel (+)
22	Pink	TXD (for check connector)	44	Violet	RXD (for check connector)

A : ECU Connector of Wire Harness Side



ECU Connector

1. Remove the seat.
2. Disconnect the seat switch connector (2) and remove the seat bracket (1) with seat suspension (3) as a unit.
3. Disconnect the ECU connector (5).

- (1) Seat Bracket
- (2) Seat Switch Connector
- (3) Seat Suspension

- (4) ECU (Electric Control Unit)
- (5) ECU Connector

W1039817

Connector Voltage (Main Circuit)

1. Turn ON the main switch. (Do not start engine.)
2. Measure the voltage between terminal 31 (+) and terminal 7 (-).
3. It is OK if the voltage equals to the battery voltage.

(Sensor Voltage)

1. Turn ON the main switch. (Do not start engine.)
2. Measure the voltage between terminal 34 (+) and terminal 33 (-).
3. It is OK if the voltage is approx. 5 V.

Voltage	Terminal 31 to 7	Approx. battery voltage
	Terminal 34 to 33	Approx. 5 V

A : Connector of wire harness side

W1039947


GST Lever Sensor Voltage

1. Start the engine. (Do not start engine.)
2. Measure the voltage between terminal 42 (+) and terminal 34 (-).
3. It is OK if the voltage comes to show in the table below.

Voltage between terminal 42 to 34	GST lever at Neutral	Approx. 0.7 V
	GST lever at 8th	Approx. 3.07 V
	GST lever at 12th	Approx. 4.21 V

A : Connector of wire harness side

W1040168




Pressure Switch Voltage

1. Connect the 44P connector to ECU.
2. Connect the tester positive cable to terminal 35 of wire harness side connector and negative cable to terminal 7.
3. Start the engine and depress the clutch, and shift the shuttle lever to Forward position.
4. Measure the voltage when the GST lever is in neutral and the voltage when GST lever is shifting.
5. It is OK if the voltage comes to show in the table below.

Voltage between terminal 35 to 7	GST lever at Neutral	0 V
	GST lever at Shifting	Above 12 V

A : Connector of wire harness side

W1040692




Oil Temperature Sensor Voltage

1. Measure the voltage between terminal 19 (+) and terminal 33 (-).
2. It is OK if the voltage value approximates to the value shown in the table below.

Voltage between terminal 19 to 33	Reference value	Approx. 4.7 V at -30°C (-22°F)
		Approx. 3.8 V at 0°C (32°F)
		Approx. 2.3 V at 30°C (86°F)
		Approx. 1.0 V at 60°C (140°F)
		Approx. 0.4 V at 100°C (212°F)

A : Connector of wire harness side

W1040859





Proportional Reducing Valve Solenoid Valve Resistance

1. Measure the resistance between each valve terminal and terminal 32.
2. It is OK if the resistance value approximates to the value shown in the table below.

Item	Measuring terminal	Resistance
Proportional Reducing valve	Terminal 23 and 32	Approx. 8 to 9 Ω
Solenoid 1	Terminal 27 and 32	Approx. 11 to 15 Ω
Solenoid 2	Terminal 28 and 32	
Solenoid 3	Terminal 29 and 32	
Solenoid 4	Terminal 30 and 32	
Solenoid 5 (Sub-range)	Terminal 25 and 32	
Solenoid 6 (Main range)	Terminal 26 and 32	

W1041158






Electronic Instrument Panel and ECU Continuity

1. Disconnect the connector **B** (16P) from electronic instrument panel. (See page 9-S23.)
2. Measure the resistance between terminal 4 of panel connector and terminal 21 of ECU connector, and between terminal 5 of panel connector and terminal 43.
3. If 0 ohm is not indicated, the wiring harness is faulty.

Resistance	Terminal 4 of panel connector -Terminal 21 of ECU connector	0 Ω
	Terminal 5 of panel connector -Terminal 43 of ECU connector	




A : Panel Connector B of Wire Harness Side

B : ECU Connector B of Wire Harness Side

W1041490

(C) Checking Sensor and Switch



GST Lever Sensor Resistance

1. Measure the resistance between terminal **A** and **C**.
2. Then, check resistance between terminal **A** and **B** while slowly turning the sensor shaft.
3. It is OK if the resistance value approximates to the value shown in the table below.

(Reference)

- The change of resistance can be checking easily when an analog tester is employed.

Resistance	Terminal A - Terminal C	1.6 to 2.4 kΩ
	Terminal A - Terminal B	Resistance is normal if smoothly changing

W1041711



Pressure Switch Resistance

1. Disconnect the pressure switch connector (1).
2. Connect the circuit tester pins to each terminal of pressure switch (2).
3. Start the engine and depress the clutch pedal.
4. Check the resistance at time when shuttle lever or GST lever is shifted.
5. It is OK if the resistance comes to have shown in the table below.

CAUTION


- Be sure to depress the clutch pedal so that the tractor should not move while shifting each lever.

Resistance between terminals	When the shuttle lever or GST lever is shifted	Continuity exists
	Both levers are at Neutral	0 Ω

(1) Pressure Switch Connector

(2) Pressure Switch

W1042028




Oil Temperature Sensor Resistance

1. Measure the resistance between the sensor terminals.
2. It is OK if the resistance value approximates to the value shown in the table below.
3. If there exists a large difference, replace the sensor.

Resistance	Reference value
	16.4 to 21.1 kΩ at -20°C (-4°F)
	1.04 to 1.23 kΩ at 40°C (104°F)
	0.15 to 0.16 kΩ at 100°C (212°F)

(1) Oil Temperature Sensor

W1042316




Proportional Reducing Valve Resistance

1. Measure the resistance between the valve terminals.
2. It is OK if the resistance comes to have shown in the table below.

Resistance	Reference value
	8 to 9 Ω

W1042539




Shift Solenoid Resistance

1. Measure the resistance between each connector terminal and each valve body.
2. It is OK if the resistance comes to have shown in the table below.

Measuring point		Resistance
Solenoid	Connector terminal	
(1) Solenoid 1	1	11 to 15 Ω
(2) Solenoid 2	2	
(3) Solenoid 3	3	
(4) Solenoid 4	4	
(5) Solenoid 5 (Sub-range)	5	
(6) Solenoid 6 (Main range)	6	

A : Connector of Solenoid Side

W1042693



CAUTION ⚠

Be sure to depress the clutch pedal so that the tractor should not move while shifting each lever.

Procedure	Result
1) Pressure Switch Connector	OK
2) Pressure Switch	OK
3) Pressure Switch	OK
4) Pressure Switch	OK
5) Pressure Switch	OK
6) Pressure Switch	OK

W1042528

[3] STARTING SYSTEM

(1) Checking

(A) Main Switch (ROPS Type)



3TLABAB5P004B


Remove the Main Switch

1. Remove the combination switch.
2. Remove the panel cover.
3. Disconnect the main switch connector (2).
4. Perform the following checking.

(1) Main Switch

(2) Main Switch Connector

W1013848



3TLABAB9P027A


Connector Voltage

1. Measure the voltage across the connector **B** terminal and chassis.
2. If the voltage differs from the battery voltage (11 to 14 V), the wiring harness is faulty.

Voltage	Connector B terminal – Chassis	Approx. battery voltage
---------	---------------------------------------	-------------------------

A : Wire Harness Side Connector 4C

W1014366



3TLABAB9P027B


Main Switch at ON Position

1. Turn the main switch **ON** position.
2. Measure the resistance across the **B** terminal and the **AC** terminal.
3. If 0 ohm is not indicated, renew the main switch.

Resistance	B terminal – AC terminal	0 Ω
------------	--	-----

A : Main Switch Side Connector 4C

W1014494



3TLABAB9P027B

Main Switch at START Position


1. Turn and hold the main switch at the **START** position.
2. Measure the resistances across the **B** terminal and the **AC** terminal, and across the **B** terminal, and the **ST** terminal.
3. If 0 ohm is not indicated, renew the main switch.

Resistance	B terminal – AC terminal	0 Ω
	B terminal – ST terminal	0 Ω

A : Main Switch Side Connector 4C

W1014907

(B) Main Switch (CABIN Type)




Connector Voltage

1. Measure the voltage across the connector **B** terminal and chassis.
2. If the voltage differs from the battery voltage (11 to 14 V), the wiring harness is faulty.

Voltage	Connector B terminal – Chassis	Approx. battery voltage
---------	--	-------------------------

A : Wire Harness Side Connector 6G

W1014732




Main Switch at ACC Position

1. Turn the main switch **ACC** position.
2. Measure the resistance across the **B** terminal and the **ACC** terminal.
3. If 0 ohm is not indicated, renew the main switch.

Resistance	B terminal – ACC terminal	0 Ω
------------	--	-----

A : Main Switch Side Connector 6G

W1014824




Main Switch at Key ON Position

1. Turn and hold the main switch at the **ON** position.
2. Measure the resistances across the **B** terminal and the **ACC** terminal, across **B** terminal and **IG1** terminal and **B** terminal and **IG2** terminal.
3. If 0 ohm is not indicated, renew the main switch.

Resistance	B terminal – ACC terminal	0 Ω
	B terminal – IG1 terminal	0 Ω
	B terminal – IG2 terminal	0 Ω

A : Main Switch Side Connector 6G

W1014641



Main Switch at START Position




1. Turn and hold the main switch at the **START** position.
2. Measure the resistances across the **B** terminal and the **IG1** terminal, and across the **B** terminal, and the **ST** terminal.
3. If 0 ohm is not indicated, renew the main switch.

Resistance	B terminal – IG1 terminal	0 Ω
	B terminal – ST terminal	0 Ω

A : Main Switch Side Connector 6G

W1015222

(C) Safety Switch




PTO Switch Continuity

1. Disconnect the PTO switch connector (1).
2. Measure the resistance between connector terminal as shown in table below.
3. If the switch is defective, replace it.

Resistance between connector terminal	When switch spring is pushed (Neutral)	0 Ω
	When switch spring is Released	Infinity

- (1) PTO Switch Connector
(2) PTO Switch



Shuttle Switch Continuity (For Manual Transmission and GST Model)

(Shuttle Switch)

1. Remove the steering post under cover.
2. Disconnected the shuttle switch connector (1).
3. Measure the resistance across four terminal referring to the table below.

Shuttle lever position	Connector terminal						Resistance
	a	b	c	d	e	f	
Forward	●				●		0 Ω
Neutral		●	●		●	●	
Reverse				●	●		

4. If 0 ohm is not indicated, the shuttle switch is faulty.

(Reference)

- There are no terminal **c** and **f** for manual transmission model.

- (1) Shuttle Switch (2) Connector of Switch Side

W1044817



HST Pedal Switch (For HST Model)


1. Disconnect the HST neutral switch connector.
2. Remove the HST neutral switch (1).
3. Push the switch and measure the resistance between terminal 1 and 2, and between terminal 3 and 4.
4. If 0 ohm is not indicated, switch is faulty.

Resistance while pushing the switch	Terminal 1 - 2	0 Ω
	Terminal 3 - 4	

(1) HST Neutral Switch

(2) Switch Connector

W1045046




Clutch Pedal Switch (For HST Model)


1. Remove the panel cover.
2. Disconnect the clutch pedal switch connector (2).
3. Measure the resistance between connector terminals while pushing the clutch pedal switch.
4. If 0 ohm is not indicated, switch is faulty.

(1) Clutch Pedal Switch

(2) Clutch Pedal Switch Connector

W1045306



(D) Operators Pressure Control**Checking System****(Manual Transmission and GST Model)****■ Test 1**

1. Shift the all shifting lever to neutral position and apply parking brake.
2. Sit on the operator's seat and start engine.
3. Shift the shuttle lever to F or R and stand up from the seat.
4. Confirm the engine stops after one second.

■ Test 2

1. Start the engine according to procedure 1 and 2 of Test 1.
2. Shift the PTO lever to **ON** position and stand up from the seat.
3. Confirm the engine stops after one second.

■ Test 3

1. Start the engine according to procedure 1 and 2 of Test 1.
2. Keep the all shift levers are at neutral.
3. Get off the tractor, tilt the operator's seat forward, and shift the PTO lever to **ON** (engage) position.
4. Confirm the engine does not stop and the PTO shaft rotates.
If any defective is found in Test 1, 2 and 3, check the seat switch, OPC timer or safety switches.

(HST Model)**■ Test 1**

1. Shift the PTO lever and range gear shift lever to neutral, and set the HST pedal in neutral.
2. Depress the clutch pedal and start the engine.
3. Depress the HST pedal and stand up from the seat.
4. Confirm the engine stops after one second.

■ Test 2

1. Start the engine according to procedure 1 and 2 of Test 1.
2. Shift the PTO lever to **ON** position and stand up from the seat.
3. Confirm the engine stops after one second.

■ Test 3


1. Start the engine according to procedure 1 and 2 of Test 1.
2. Keep the levers and pedal are neutral.
3. Get off the tractor, tilt the operator's seat forward, and shift the PTO lever to **ON** (engage) position.
4. Confirm the engine does not stop and the PTO shaft rotates.
If any defective is found in Test 1, 2 and 3, check the seat switch, OPC timer or safety switches.

(1) Seat


(2) Seat Switch

(3) PTO Lever


W1049518




3TLABAB9P036A



3TLABAB8P034C



3TLABAB9P037A



3TLABAB9P038A

Checking Seat Switch

1. Remove the seat.
2. Disconnect the seat switch connector (3).
3. Change the sensor bar angle (1) and measure the resistance between connector terminals, referring to the table below.
4. If the measurement does not between as table, switch is faulty.

Sensor bar angle	Measuring terminal	Resistance
Approx. 18 ° (Angle A)	a - c	0 Ω
	a - b, b - c	infinity
Approx. 25 ° (Angle B)	a - b, a - c, b - c	infinity
Approx. 5 ° (Angle C)	b - c	0 Ω
	a - b, a - c	infinity

- (1) Sensor Bar
- (2) Seat Switch
- (3) Seat Switch Connector

D : Reference Line (Seat Suspension Plate Line)

W1050159

Checking OPC Timer

1. Remove the timer. (OPC timer is located behind the panel)
2. Connect jumper leads across the battery positive terminal and the timer 3 terminal, and across the battery positive terminal and the timer 4 terminal.
3. Connect jumper leads across the battery negative terminal and the timer 2 terminal, and across the battery negative terminal and the bulb terminal.
4. Connect jumper lead across the timer 1 terminal and the bulb terminal.
5. The bulb lights up when disconnecting a jumper lead from the 3 terminal 0.7 to 1.3 seconds late, the timer is proper.

- (1) OPC Timer
- (2) Load (Lamp)
- (3) Battery (12 V)

A : OPC Timer Relay Side Connector
4A

W1020537

(E) Starter and Starter Relay




3TLABAB9P055A

Starter Motor B Terminal Voltage

1. Measure the voltage across the **B** terminal and chassis.
2. If the voltage differs from the battery voltage, check the battery's cable.

Voltage	Factory spec.	Approx. battery voltage
---------	---------------	-------------------------

W1016256



3TMABAB9P007A

Motor Test




- **Secure the starter to prevent it from jumping up and down while testing the motor.**
1. Disconnect the battery negative cable from the battery.
 2. Disconnect the battery positive cable and the leads from the starter.
 3. Remove the starter from the engine.
 4. Disconnect the connecting lead (2) from the starter **C** terminal (1).
 5. Connect a jumper lead from the connecting lead (2) to the battery positive terminal post.
 6. Connect a jumper lead momentarily between the starter motor housing and the battery negative terminal post.
 7. If the motor does not run, check the motor.

(1) C Terminal

(2) Connecting Lead

W10142670



3TMABAB9P008A

Magnet Switch Test (Pull-in, Holding Coils)

1. Remove the motor from the starter housing.
2. Prepare a 6 V battery for the test.
3. Connect jumper leads from the battery negative terminal to the housing and the starter **C** terminal.
4. The plunger should be attached and the pinion gear should pop out when a jumper lead is connected from the battery positive terminal to the **S** terminal. It's a correct.
5. Disconnect the jumper lead to the starter **C** terminal. Then the pinion gear should remain popped out. It's a correct.


IMPORTANT

- **Testing time must be 3 to 5 sec..**

(a) To Negative Terminal

(b) To Positive Terminal

W10146900



3TMABAB9P010B


Checking Starter Relay

1. Remove the panel cover and meter panel. (See page 9-S23.)
2. Remove the starter relay.
3. Apply battery voltage across terminals **3** and **4**, and check for continuity across terminals **1** and **2**.
4. If continuity is not established, renew the starter relay.

A : Connector of Starter Relay

W1026991

(F) Glow Control System



Glow Plug Lead Terminal Voltage


1. Disconnect the wiring lead (1) from the glow plug (2) after turning the main switch off.
2. Turn the main switch key to the **"PREHEAT"** position, and measure the voltage between the lead terminal and the chassis.
3. Turn the main switch key to the **"START"** position, and measure the voltage between the lead terminal and the chassis.
4. If the voltage at either position differs from the battery voltage, the wiring harness or main switch is faulty.

Voltage (Lead terminal – Chassis)	Main switch key at "PREHEAT"	Approx. battery voltage
	Main switch key at "START"	Approx. battery voltage

(1) Wiring Lead (Positive)

(2) Glow Plug

W10149130




Glow Plug Continuity

1. Disconnect the lead from the glow plugs.
2. Measure the resistance between the glow plug terminal and the chassis.
3. If 0 ohm is indicated, the screw at the tip of the glow plug and the housing are short-circuited.
4. If the factory specification is not indicated, the glow plug is faulty.

Glow plug resistance	Factory spec.	Approx. 0.9 Ω
----------------------	---------------	---------------

W10151150



Glow Relay

1) Connector Voltage


1. Turn the main switch off.
2. Disconnect the **4P** connector from glow relay.
3. Measure the voltage across the terminal **3** (Positive) and chassis (Negative).
4. If the voltage differs from the battery voltage, the wiring harness is faulty.
5. Turn the main switch on.
6. Measure the voltage across the terminal **1** (Positive) and chassis (Negative).
7. If the voltage differs from the battery voltage, the wiring harness is faulty.

2) Glow Relay Test

1. Remove the glow relay.
2. Apply battery voltage across terminals **3** and **4**, and check for continuity across terminals **1** and **2**.
3. If continuity is not established across terminal **1** and **2**, replace the glow relay.


A : Connector of Wire Harness Side

B : Connector of Glow Relay



W1014050

(G) Engine Stop Solenoid



Connector Voltage


1. Disconnect the **2P** connector from engine stop solenoid.
2. Turn the main switch key to the "ON" position.
3. Measure the voltage between the terminal 1, terminal 2 and body.
4. If the voltage differs from the battery voltage, the wiring harness or main switch is faulty.

Voltage	Terminal 1 – Body	Approx. battery voltage
	Terminal 2 – Body	

(1) Terminal 1

(2) Terminal 2

W1015556



Stop Solenoid Coil


1. Disconnect the **2P** connector from engine stop solenoid.
2. Measure the resistance between the terminal 1, terminal 2 and body.
3. If resistance differs from the factory specification, the coil is faulty.

Resistance	Terminal 1 – Body	Approx. 0.375 Ω
	Terminal 2 – Body	Approx. 15.6 Ω

(1) Terminal 1 (Pulling Coil)

(2) Terminal 2 (Holding Coil)


W1015848



Engine Stop Solenoid Relay

1) Connector Voltage


1. Turn the main switch off.
2. Disconnect the **4P** connector from glow relay.
3. Measure the voltage across the terminal 3 (Positive) and chassis (Negative).
4. If the voltage differs from the battery voltage, the wiring harness is faulty.
5. Turn the main switch on.
6. Measure the voltage across the terminal 1 (Positive) and chassis (Negative).
7. If the voltage differs from the battery voltage, the wiring harness is faulty.



2) Engine Stop Solenoid Relay


1. Remove the engine stop solenoid relay.
2. Apply battery voltage across terminals 3 and 4, and check for continuity across terminals 1 and 2.
3. If continuity is not established across terminal 1 and 2, replace the engine stop solenoid relay.

A : Connector of Wire Harness Side **B :** Connector of Engine Stop Solenoid Relay



(2) Disassembling and Assembling

(A) Starter



Disassembling Motor

1. Disconnect the connecting lead (9) from the magnet switch (8).
2. Remove the screws (6), and then separate the end frame (4), yoke (2) and armature (1).
3. Remove the two screws (5), and then take out the brush holder (3) from the end frame (4).


(When reassembling)

- Apply grease to the spline teeth (A) of the armature (1).

Tightening torque	Nut (7)	5.9 to 11.8 N·m 0.6 to 1.2 kgf·m 4.3 to 8.7 ft·lbs
-------------------	---------	--

- | | |
|------------------|-------------------------|
| (1) Armature | (7) Nut |
| (2) Yoke | (8) Magnet Switch |
| (3) Brush Holder | (9) Connecting Lead |
| (4) End Frame | |
| (5) Screw | A : Spline Teeth |
| (6) Screw | |

W10162880



Disassembling Magnet Switch


1. Remove the drive end frame (1) mounting screws.
2. Take out the overrunning clutch (2), ball (3), spring (4), gears (5), rollers (6) and retainer (7).

(When reassembling)

- Apply grease to the gear teeth of the gears (5) and overrunning clutch (2), and ball (3).

- | | |
|------------------------|--------------|
| (1) Drive End Frame | (5) Gear |
| (2) Overrunning Clutch | (6) Roller |
| (3) Ball | (7) Retainer |
| (4) Spring | |

W10167280




Plunger

1. Remove the end cover (1).
2. Take out the plunger (2).

- | | |
|---------------|-------------|
| (1) End Cover | (2) Plunger |
|---------------|-------------|

W10168830






(3) Servicing



Overrunning Clutch

1. Inspect the pinion for wear or damage.
2. If there is any defect, replace the overrunning clutch assembly.
3. Check that the pinion turns freely and smoothly in the overrunning direction and does not slip in the cranking direction.
4. If the pinion slips or does not rotate in the both directions, replace the overrunning clutch assembly.

W10169900



Commutator and Mica

1. Check the contact face of the commutator for wear, and grind the commutator with emery paper if it is slightly worn.
2. Measure the commutator O.D. with an outside micrometer at several points.
3. If the minimum O.D. is less than the allowable limit, replace the armature.
4. If the difference of the O.D.'s exceeds the allowable limit, correct the commutator on a lathe to the factory specification.
5. Measure the mica undercut.
6. If the undercut is less than the allowable limit, correct it with a saw blade and chamfer the segment edges.

Commutator O.D.	Factory spec.	30.0 mm 1.181 in.
	Allowable limit	29.0 mm 1.142 in.

Difference of O.D.'s	Factory spec.	Less than 0.02 mm 0.0008 in.
	Allowable limit	0.05 mm 0.0020 in.

Mica undercut	Factory spec.	0.50 to 0.80 mm 0.0197 to 0.0315 in.
	Allowable limit	0.20 mm 0.0079 in.

- (1) Segment
- (2) Undercut
- (3) Mica

- (a) Correct
- (b) Incorrect

W10170920

Brush Wear

1. If the contact face of the brush is dirty or dusty, clean it with emery paper.
2. Measure the brush length (A) with vernier calipers.
3. If the length is less than the allowable limit, replace the yoke assembly and brush holder.

Brush length (A)	Factory spec.	15.0 mm 0.591 in.
	Allowable limit	11.0 mm 0.433 in.




W10175440

Brush Holder

1. Check the continuity across the brush holder and the holder support with an ohmmeter.
2. If it conducts, replace the brush holder.

Resistance	Brush holder – Holder support	Infinity
------------	----------------------------------	----------

W10176720



Armature Coil

1. Check the continuity across the commutator and armature coil core with an ohmmeter.
2. If it conducts, replace the armature.
3. Check the continuity across the segments of the commutator with an ohmmeter.
4. If it does not conduct, replace the armature.

W10177670

Field Coil

1. Check the continuity across the lead (1) and brush (2) with an ohmmeter.
2. If it does not conduct, replace the yoke assembly.
3. Check the continuity across the brush (2) and yoke (3) with an ohmmeter.
4. If it conducts, replace the yoke assembly.

- (1) Lead
- (2) Brush

(3) Yoke

W10180150

Brush Holder


1. Check the continuity across the brush holder and the holder support with an ohmmeter.
2. If it conducts, replace the brush holder.

Resistance	Brush holder - holder support	Infinity
------------	-------------------------------	----------

W10178150

[4] CHARGING SYSTEM

(1) Checking




Alternator

1. Disconnect the 2P connector (3) from alternator after turning the main switch **OFF**.
2. Perform the following checkings.

- (1) B Terminal
- (2) Alternator

(3) 2P Connector

W10181750



Connector Voltage


1. Turn the main switch **OFF**. Measure the voltage between the **B** terminal (1) and the chassis.
2. Turn the main switch **ON**. Measure the voltage between the **IG** terminal (3) and the chassis.

Voltage (Main switch at OFF)	B terminal – Chassis	Approx. battery voltage
Voltage (Main switch at ON)	IG terminal – Chassis	Approx. battery voltage

- (1) B Terminal
- (2) Alternator

- (3) IG Terminal
- (4) L Terminal

W10182790



No-Load Test

1. Connect the 2P connector (6) to previous positions of the alternator after turning the main switch **OFF**.
2. Connect the jumper lead (3) between **IG** terminal (4) and **B** terminal (2).
3. Start the engine and then set at idling speed.
4. Disconnect the negative cable from the battery.
5. Measure the voltage between the **B** terminal (2) and the chassis.
6. If the measurement is less than the factory specification, disassemble the alternator and check the IC regulator.

Voltage	Factory spec.	More than 14 V
---------	---------------	----------------


(Reference)

- Once the engine has started, the alternator temperature rises quickly up to an ambient temperature of 70 to 90 °C (158 to 194 °F). As the temperature goes higher than 50 °C (122 °F), the alternator voltage slowly drops; at higher than 100 °C (212 °F), it drops by about 1 V.

- (1) Voltmeter
- (2) B Terminal
- (3) Jumper Lead

- (4) IG Terminal
- (5) L Terminal
- (6) 2P Terminal

W10184780

(2) Disassembling and Assembling

3TMABAB9P019A


Pulley

1. Secure the hexagonal end of the pulley shaft with a double-ended ratchet wrench as shown in the figure, loosen the pulley nut with a socket wrench and remove it.

(When reassembling)

Tightening torque	Pulley nut	58.3 to 78.9 N·m 5.95 to 8.05 kgf·m 43.0 to 58.2 ft·lbs
-------------------	------------	---

W10187280




3TMABAB9P020A

Rear End Cover

1. Unscrew the three rear end cover screws and the B terminal nut, and remove the rear end cover.

W10189820




3TMABAB9P021A

Brush Holder

1. Unscrew the two screws holding the brush holder, and remove the brush holder (1).

(1) Brush Holder

W10190540




3TMABAB9P022A

IC Regulator

1. Unscrew the three screws holding the IC regulator, and remove the IC regulator (1).

(1) IC Regulator

W10191230




3TMABAB9P023A

Rectifier

1. Remove the four screws holding the rectifier and the stator lead wires.
2. Remove the rectifier (1).

(1) Rectifier

W10191920




3TMABAB9P024A

Rear End Frame

1. Unscrew the two nuts and two screws holding the drive end frame and the rear end frame.
2. Remove the rear end frame (1).

(1) Rear End Frame

W10192740



3TMABAB9P025A

Rotor

1. Press out the rotor (1) from drive end frame (3).


■ IMPORTANT

- Take special care not to drop the rotor and damage the slip ring or fan, etc..

(1) Rotor
(2) Block

(3) Drive End Frame

W10194380




3TMABAB9P026A

Retainer Plate

1. Unscrew the four screws holding the retainer plate, and remove the retainer plate (1).

(1) Retainer Plate

W10195420



3TMABAB9P027A


Bearing on Drive End Side

1. Press out the bearing from drive end frame (3) with a press and jig (1).

(1) Jig
(2) Block

(3) Drive End Frame

W10196110



3TMABAB9P028A

Bearing at Slip Ring Side


1. Lightly secure the rotor (1) with a vise to prevent damage, and remove the bearing (2) with a puller (3).

(1) Rotor
(2) Bearing

(3) Puller

W10197010

(3) Servicing




3EEABAB1P192A

Bearing

1. Check the bearing for smooth rotation.
2. If it does not rotate smoothly, replace it.

W10197900




3EEABAB1P193A

Stator

1. Measure the resistance across each lead of the stator coil with an ohmmeter.
2. If the measurement is not within factory specification, replace it.
3. Check the continuity across each stator coil lead and core with an ohmmeter.
4. If infinity is not indicated, replace it.

Resistance	Factory spec.	Less than 1.0 Ω
------------	---------------	-----------------

W10199640




3EEABAB1P194A

Rotor

1. Measure the resistance across the slip rings with an ohmmeter.
2. If the resistance is not the factory specification, replace it.
3. Check the continuity across the slip ring and core with an ohmmeter.
4. If infinity is not indicated, replace it.

Resistance	Factory spec.	2.9 Ω
------------	---------------	-------

W10200940




3EEABAB1P195A

Slip Ring

1. Check the slip ring for score.
2. If scored, correct with an emery paper or on a lathe.
3. Measure the O.D. of slip ring with vernier calipers.
4. If the measurement is less than the allowable limit, replace it.

Slip ring O.D.	Factory spec.	14.4 mm 0.567 in.
	Allowable limit	12.8 mm 0.504 in.

W10202080




3EEABAB1P196A

Brush Wear

1. Measure the brush length with vernier calipers.
2. If the measurement is less than allowable limit, replace it.
3. Make sure that the brush moves smoothly.
4. If the brush is defective, replace it.

Brush length	Factory spec.	10.5 mm 0.413 in.
	Allowable limit	8.4 mm 0.331 in.

W10203290



Rectifier

1. Check the continuity across each diode of rectifier with an analog ohmmeter. Conduct the test in the (R × 1) setting.
2. The rectifier is normal if the diode in the rectifier conducts in one direction and does not conduct in the reverse direction.


■ **IMPORTANT**

- Do not use a 500 V megger for measuring because it will destroy the rectifier.

■ **NOTE**

- Do not use an auto digital multimeter. Because it's very hard to check the continuity of rectifier by using it.

W10204520



IC Regulator

1. Check the continuity across the **B** terminal and the **F** terminal of IC regulator with an analog ohmmeter. Conduct the test in the (R × 1) setting.
2. The IC regulator is normal if the IC regulator conducts in one direction and does not conduct in the reverse direction.

■ **IMPORTANT**

- Do not use a 500 V megger for measuring because it will destroy the IC regulator.

■ **NOTE**



- Do not use an auto digital multimeter. Because it's very hard to check the continuity of IC regulator by using it.

W10206450

4. If infinity is not indicated, the head light switch is faulty.
5. Measure the resistance across the B₁ terminal to the T terminal, the B₁ terminal to the terminal 1 and the B₁ terminal to the terminal 2.
6. Set the light switch to the OFF position.
7. Disconnect the combination switch connector.
8. Light Switch Continuity when Setting Switch at OFF Position

Resistance (Switch at OFF position)	B ₁ terminal - 2 terminal	Infinity
	B ₁ terminal - 1 terminal	Infinity
	B ₁ terminal - T terminal	Infinity

W1042584



[5] LIGHTING SYSTEM

(1) Checking

(A) Combination Switch



Remove the Combination Switch

1. Remove the panel cover, and disconnect the combination switch connector (2) after turning the main switch **OFF** position.
2. Perform the following checkings.

(1) Combination Switch

(2) Combination Switch Connector

W10207990





1) Connector Voltage

1. Disconnect the **8P** connector from the combination switch.
2. Measure the voltage across the connector **B1** terminal to chassis and the **B2** terminal to chassis when the main switch is "**OFF**" position.
3. If the voltage differs from the battery voltage, the wiring harness is faulty.

Voltage	Main switch at " OFF " position	B1 terminal – Chassis	Battery voltage
		B2 terminal – Chassis	

W1073019




2) Light Switch Continuity when Setting Switch at OFF Position

1. Disconnect the combination switch connector.
2. Set the light switch to the **OFF** position.
3. Measure the resistance across the **B1** terminal to the **T** terminal, the **B1** terminal to the terminal **1** and the **B1** terminal to the terminal **2**.
4. If infinity is not indicated, the head light switch is faulty.

Resistance (Switch at OFF position)	B1 terminal – T terminal	Infinity
	B1 terminal – 1 terminal	
	B1 terminal – 2 terminal	

W1042584




3) Light Switch Continuity when Setting Switch at HIGH-BEAM Position

1. Measure the resistance across the **B1** terminal to the **T** terminal and the **B1** terminal to the terminal **1**.
2. If 0 ohm is not indicated, the head light switch is faulty.

Resistance (Switch at HIGH-BEAM position)	B1 terminal – T terminal	0 Ω
	B1 terminal – 1 terminal	

W1043473




4) Light Switch Continuity when Setting Switch at LOW-BEAM Position

1. Measure the resistance across the **B1** terminal to the **T** terminal and the **B1** terminal to the terminal **2**.
2. If 0 ohm is not indicated, the head light switch is faulty.

Resistance (Switch at LOW-BEAM position)	B1 terminal – T terminal	0 Ω
	B1 terminal – 2 terminal	

W1044119




5) Turn Signal Light Switch when Setting Switch Knob at OFF Position

1. Set the turn signal light switch to the **OFF** position.
2. Measure the resistance across the **B2** terminal to the **R** terminal and the **B2** terminal to the **L** terminal.
3. If infinity is not indicated, the turn signal light switch is faulty.

Resistance (Switch at OFF position)	B2 terminal – R terminal	Infinity
	B2 terminal – L terminal	

W1044501




6) Turn Signal Light Switch when Setting Switch Knob at R Position

1. Set the turn signal light switch to the **R** position.
2. Measure the resistance across the **B2** terminal to the **R** terminal.
3. If 0 ohm is not indicated, the turn signal light switch is faulty.

Resistance (Switch at R position)	B2 terminal – R terminal	0 Ω
-----------------------------------	--------------------------	-----

W1044955




7) Turn Signal Light Switch when Setting Switch Knob at L Position

1. Set the turn signal light switch to the **L** position.
2. Measure the resistance across the **B2** terminal to the **L** terminal.
3. If 0 ohm is not indicated, the turn signal light switch is faulty.

Resistance (Switch at L position)	B2 terminal – L terminal	0 Ω
-----------------------------------	--------------------------	-----

W1045932



8) Horn Switch (If equipped)

1. Measure the resistance across the **B1** terminal to the **H** terminal.
2. If 0 ohm is not indicated, the horn switch is faulty.

Resistance (Horn switch is pushed)	B1 terminal – H terminal	0 Ω
------------------------------------	--	-----

W1074245




Hazard Switch (If equipped)

1. Remove the meter panel and disconnect the **4P** connector from hazard switch (1) after disconnect the battery negative code.
2. Remove the hazard switch (1).
3. Perform the following checking.

(1) Hazard Switch

W1046485




1) Connector Voltage

1. Connect the battery negative code, then measure the voltage across the terminal **a** and chassis.
2. If the voltage differ from the battery voltage, the wiring harness is faulty.

Voltage	Terminal a – Chassis	Approx. battery voltage
---------	-----------------------------	-------------------------

(1) 4P Connector

W1046902



2) Hazard Switch Continuity


1. Measure the resistance with ohmmeter across the terminal **a** and terminal **c**, and across the terminal **d** and terminal **e**.
2. If the measurement is not following below, the hazard switch or the bulb are faulty.

Resistance (Switch at OFF)	Terminal a – Terminal c	Infinity
Resistance (Switch at ON)	Terminal a – Terminal c	0 Ω
Resistance (Bulb)	Terminal d – Terminal e	Approx. 13 Ω

- (1) Hazard Switch Connector
- (2) Terminal **a**
- (3) Terminal **d**

- (4) Terminal **c**
- (5) Terminal **e**






Flasher Unit

1. Disconnect the connector from the flasher unit.
2. Measure the voltage across the terminal **h** and chassis.
3. If the voltage differ from the battery voltage, the wiring harness is faulty.

Voltage	Terminal h – Chassis	Approx. battery voltage
---------	----------------------	-------------------------

W1047788



Flasher Unit Actuation Test


1. Set the hazard switch to the **ON** position, and make sure the hazard light gives 60 to 85 flashes for a minute.
2. With the main switch and the hazard switch at the **ON** positions, respectively, move the turn signal switch to the left. Make sure that the right-hand light stays on and the left-hand light gives flashes earlier (by about 20 flashes) than when the hazard lamp is activated. Then move the turn signal switch to the right and make sure the corresponding actions take place.
3. Now set the main switch to the **ON** position and move the turn signal switch alone. Make sure the same actions as above result.
4. If both the hazard switch and the turn signal switch function but the above actions do not take place, replace the flasher unit with new one.

- (1) Hazard Switch
- (2) Turn Signal Switch
- (3) Flasher Unit

W1048275

[6] WARNING LAMPS

(1) Checking






Engine Oil Pressure Switch Panel Board and Wiring Harness

1. Disconnect the lead (2) from the engine oil pressure switch after turning the main switch **OFF**.
2. Turn the main switch **ON** and connect a jumper lead from the lead to the chassis.
3. If the engine oil pressure indicator lamp does not light, the panel circuit or the wiring harness is faulty.

- (1) Engine Oil Pressure Switch
- (2) Switch Lead
- (a) From Oil Pressure Lamp

W10259540






Engine Oil Pressure Switch Continuity

1. Measure the resistance across the switch terminal and the chassis.
2. If 0 ohm is not indicated in the normal state, the switch is faulty.
3. If infinity is not indicated at pressure over 4.9 kPa (0.5 kgf/cm², 7 psi), the switch is faulty.

Resistance (Switch terminal – Chassis)	In normal state	0 Ω
	At pressure over approx. 4.9 kPa (0.5 kgf/cm ² , 7 psi)	Infinity

(1) Engine Oil Pressure Switch

W10260840



Charging Circuit (Panel Board and Wiring Harness)

1. Disconnect the 2P connector from the alternator after turning the main switch **OFF**.
2. Turn the main switch **ON** and connect a jumper lead from the wiring harness connector terminal (WR) to the chassis.
3. If the charge lamp does not light, the panel board circuit, alternator, wiring harness, or fuse is fault.

(1) Alternator

(a) From Charge Lamp

W10262530

[7] MONITOR LAMP

(1) Checking



Parking Brake Switch Continuity




1. Disconnect the connector from the parking brake switch (1) after turning the main switch **OFF**.
2. Measure the resistance across the two terminals.
3. If infinity is not indicated, the switch is faulty.


Resistance (Across switch terminals)	In normal state	Infinity
---	-----------------	----------

(1) Parking Brake Switch

(2) Connector of Parking Brake Switch

W1026390






Parking Brake Switch Panel and Wiring Harness

1. Disconnect the connector from the parking brake switch after turning the main switch **OFF**.
2. Turn the main switch **ON** and connect a jumper lead between the connector terminals of wiring harness.
3. If the parking brake indicator lamp does not light, the panel circuit or wiring harness is faulty.

(1) Connector of Parking Brake Switch (2) Connector of Wiring Harness

W1026754






Cruise Switch Continuity

1. Disconnect the connector (1) from the cruise switch after turning the main switch **OFF**.
2. Measure the resistance across the two terminals.
3. If infinity is not indicated, the switch is faulty.

Resistance (Across switch terminals)	In normal state	Infinity
--------------------------------------	-----------------	----------

(1) Cruise Switch Connector



Cruise Switch Panel and Wiring Harness

1. Disconnect the connector from the cruise switch after turning the main switch **OFF**.
2. Turn the main switch **ON** and connect a jumper lead between the connector terminals of wiring harness.
3. If the cruise indicator lamp does not light, the panel circuit or wiring harness is faulty.


(1) Connector of Cruise Switch (2) Connector of Wiring Harness

W1076155

[8] GAUGES

(1) Checking

(A) Fuel Level Sensor



3TLABAB9P053A

Fuel Level Sensor


1) Sensor Continuity

1. Remove the fuel level sensor from the fuel tank.
2. Measure the resistance across the sensor terminal and its body.
3. If the reference value are not indicated, the sensor is faulty.

Resistance (Sensor terminal – its body)	Reference value	Float at upper-most position	1 to 5 Ω
		Float at lower-most position	103 to 117 Ω

W10248650

(B) Coolant Temperature Sensor




3TMABAB9P042A

Coolant Temperature Sensor Continuity

1. Measure the resistance across the sensor terminal and the chassis.
2. If the measurement is not indicated, the sensor is faulty.

Resistance (Sensor terminal – Chassis)	Factory spec.	Approx. 16 Ω at 120 °C (248 °F) Approx. 50 Ω at 80 °C (176 °F) Approx. 149 Ω at 50 °C (122 °F)
--	------------------	---

(1) Coolant Temperature Sensor



W1022725

10 CABIN


MECHANISM

CONTENTS

1. AIR CONDITIONER SYSTEM	10-M1
[1] OUTLINE OF AIR CONDITIONING SYSTEM	10-M1
[2] SYSTEM CONTROL.....	10-M3
[3] ELECTRICAL SYSTEM	10-M4
(1) Electrical Citcuit	10-M4
(2) Air Conditioner Relay, Blower Relays and Compressor Relay	10-M5
(3) Air Conditioner Blower Switch.....	10-M6

1. AIR CONDITIONER SYSTEM

[1] OUTLINE OF AIR CONDITIONING SYSTEM



- (1) Heater Hose (Out Side)
- (2) Heater Hose (In Side)
- (3) Control Panel
- (4) Water Valve

- (5) Outside Air Filter
- (6) Inner Roof
- (7) Inside Air Filter
- (8) Side Air Outlet

- (9) Front Air Outlet
- (10) High Pressure Pipe
- (11) Low Pressure Pipe
- (12) Pressure Switch

- (13) Air Conditioner Unit
- (14) Compressor
- (15) Receiver
- (16) Condensor

The machine is equipped with a thin large-capacity air conditioner with outside air intake. Through the inside air filter (7) as well as the outside air filter (5), the inner roof (6) and reaches the air conditioner unit (13). The air is then cooled and defumidified by this unit.

The resulting air is heated to a comfortable level. In this way, the air being blown via the blow port can be kept at comfortable temperature and humidity.

The front air outlet (9) can be opened and closed using the center knob of each port. The side air outlet (8) are opened and closed using the mode lever on the control panel (3). With these ports open or closed, you can feel your head cool and your feet warm.

Capacity (Cooling)	Factory spec.	2.7 to 3.3 kW
Capacity (Warming)	Factory spec.	3.85 to 4.71 kW
Kinds of refrigerant (Charge amount)	Factory spec.	R134a 0.95 to 1.05 kg 2.09 to 2.31 lbs
Pressure sensor (Low)	Factory spec.	0.196 MPa 2.0 kg/cm ² 28.4 psi
Pressure sensor (High)	Factory spec.	3.14 MPa 32.0 kg/cm ² 455 psi

W1014918

■ NOTE

- As for the mechanism and function of each component part, refer to Workshop Manual of "MECHANISM".

■ Compressor Oil


The compressor oil dissolves in the refrigerant, circulates through the air-conditioning cycle, and functions to lubricate the compressor. But the conventional compressor oil for R12 doesn't dissolve in R134a, so it doesn't circulate through the cycle, and the lifespan of the compressor is considerably shortened.

It is still essential to ensure that the correct refrigerant oil is used. R12 systems were lubricated with mineral oil, which is totally unsuitable for R134a systems. The letter require PAG oil, which mixes very well with the refrigerant and provides ideal lubrication throughout the system.

Quantity (Total)	Brand Name
50 to 70 cm ³ 3.1 to 4.3 cu.in.	ND-OIL 8 <PAG* oil>

*PAG : Polyalkyleneglycol (Synthetic oil)

[2] SYSTEM CONTROL



3TLABABWP083A

- | | | | |
|-------------------------------|---|-------------------------------------|---------------------------------------|
| (1) Air Mode Lever | (7) Recirculated Air | (12) Air Outlet Door D3 (Mode Door) | (A) Control Plate |
| (2) Blow Switch | (8) Blower | (13) DEFOGGER | (B) Air Selection Lever |
| (3) Air Conditioner Switch | (9) Evaporator | (14) FACE | (C) Block Diagram of Air Flow Passage |
| (4) Temperature Control Lever | (10) Temperature Door D2 (Air Mixed Door) | (15) DEF and FACE | O1 :Front air outlet |
| (5) Fresh Air | (11) Heater | (16) Air Selection Lever | O2 :Side air outlet |
| (6) Air Intake Door D1 | | | |

1) Selection of recirculated air (7) or fresh air (5) is done with door D1.

■ RECIRC

By setting the air selection lever (16) in rear control panel to **RECIRC** position, door **D1** (6) shuts the fresh air inlet port. Air inside the cabin is recirculated.

■ FRESH

By moving the air selection lever (16) to **FRESH** position, door **D1** opens the fresh air inlet port. Outside air comes into cabin.

2) Temperature control of outlet air is done with door D2.

■ COOL

By setting the temperature control lever (4) in control panel to **COOL** position, door **D2** (10) is moved to close water valve. The air flows to door **D3** (12) side without passing the heater core.

■ WARM

By moving the temperature lever to **WARM** position door **D2** is moved to open water valve. The air flows to door **D3** (12) side passing through the heater core.

3) Outlet air flow is controlled by door D3.

Moving the air mode lever (1) opens and shuts door **D3** and establishes the air passage according to the lever position.

■ DEF + FACE


By moving the mode lever to **DEF + FACE** position, the door **D3** is moved to establish the air passages to outlets **O1** and **O2**. Air comes out from both outlets.

■ DEF

Moving the mode lever to **DEF** position, door **D3** is moved to set up the air passage to outlet **O1**. Air comes out from outlet **O1**.

[3] ELECTRICAL SYSTEM

(1) Electrical Circuit



3TLBABWP084A

- | | | | |
|--------------------|----------------------|------------------------|--------------------------|
| (1) Battery | (5) Joint Connector | (9) Thermostat | (12) A/C Blower Relay |
| (2) Slow Blow Fuse | (6) Compressor Relay | (10) A/C Blower Switch | (13) A/C Blower Motor |
| (3) Main Switch | (7) Compressor | (11) Diode | (14) A/C Blower Resistor |
| (4) Diode | (8) Pressure Switch | | |

The process of magnetic clutch being engaged is shown below.

Main Switch (3) **ON** → A/C Switch (10) **ON** → Blower Switch (10) **ON** (Low, medium or High) → Compressor Relay Contact (6) → Thermo Switch (7) **ON** (the thermostat temperature is more than 4 °C (39.2 °F)) → Pressure Switch (8) **ON** (if refrigerant pressure is between 0.21 MPa (2.1 kgf/cm², 30 psi) and 265 MPa (27 kgf/cm², 384 psi) → Magnetic Clutch of Compressor (7) Engaged.


(2) Air Conditioner Relay, Blower Relays and Compressor Relay



Remove the outer roof and the relays are visible at the ceiling center of the cabin : blower relay (1) and compressor relay (2). When the blower fan is adjusted for the air flow rate, the blower relay (1) is activated by a signal from the fan switch on the control panel.

Among the air conditioner components, current flows to the blower motor (7) and magnetic clutch. If all of these current were to be passed through the main switch (5) and supplied, the current would be too large for the main switch contact. If the current were to be passed directly from the battery (3), forgetting to turn off the blower motor (7) could result in a discharged battery (3).

To protect against such trouble, relays have been provided. These relays have been made so that when current flows through its coil, the contact close to supply the power from the battery (3). By employing these relays, the current flowing through the main switch (5) has been decreased as only a small current is required to actuate the relay. Thus there will be no danger of burning out the switch contact, and when the main switch (5) is opened, the relay contact will open at the same time. This action stops the current flow in the air conditioner circuit so that there will also be no chance of the battery discharging.



- | | |
|----------------------|-------------------------|
| (1) A/C Blower Relay | (5) Main Switch |
| (2) Compressor Relay | (6) A/C Blower Switch |
| (3) Battery | (7) A/C Blower Motor |
| (4) Slow Blow Fuse | (8) A/C Blower Resistor |


W1013825

When the main switch is turned ON the current flows from battery to A/C blower relay coil and A/C relay is turned ON. As the A/C relay is turned ON the current from battery flows to A/C blower switch through the A/C blower motor as follows:

● (High) Position
 Battery (1) → Slow Blow Fuse (2) → Main Switch (5) → Fuse → A/C Blower Relay Contact (15) → Blower Motor (7) → Blower Resistor (14) → A/C Blower Switch HI Position (10) → Ground

● (Medium) Position
 Battery (1) → Slow Blow Fuse (2) → Main Switch (5) → Fuse → A/C Blower Relay Contact (15) → Blower Motor (7) → Blower Resistor (14) → A/C Blower Switch ME Position (10) → Ground

● (Low) Position
 Battery (1) → Slow Blow Fuse (2) → Main Switch (5) → Fuse → A/C Blower Relay Contact (15) → Blower Motor (7) → Blower Resistor (14) → A/C Blower Switch LO Position (10) → Ground

(3) Air Conditioner Blower Switch**■ When Blower Switch is in (Low), (Medium) or (High) Position**

- | | | | |
|--------------------|----------------------|------------------------|--------------------------|
| (1) Battery | (5) Joint Connector | (9) Thermostat | (12) A/C Blower Relay |
| (2) Slow Blow Fuse | (6) Compressor Relay | (10) A/C Blower Switch | (13) A/C Blower Motor |
| (3) Main Switch | (7) Compressor | (11) Diode | (14) A/C Blower Resistor |
| (4) Diode | (8) Pressure Switch | | |

When the main switch is turned **ON**, the current flows from battery to A/C blower relay coil and A/C relay is turned **ON**. As the A/C relay is turned **ON**, the current from battery flows to A/C blower switch through the A/C blower motors as follows.

“(Low) Position

Battery (1) → Slow Blow Fuse (2) → Main Switch (3) → Fuse → A/C Blower Relay Contact (12) → Blower Motor (13) → Blower Resistor (14) → A/C Blower Switch LO Position (10) → Ground.

“(Medium) Position

Battery (1) → Slow Blow Fuse (2) → Main Switch (3) → Fuse → A/C Blower Relay Contact (12) → Blower Motor (13) → Blower Resistor (14) → A/C Blower Switch ME Position (10) → Ground.

“(High) Position

Battery (1) → Slow Blow Fuse (2) → Main Switch (3) → Fuse → A/C Blower Relay Contact (12) → A/C Blower Motor (13) → A/C Blower Switch HI Position (10) → Ground.

SERVICING

CONTENTS

1.	TROUBLESHOOTING	10-S1
2.	SERVICING SPECIFICATIONS	10-S6
3.	TIGHTENING TORQUES	10-S7
4.	PRECAUTIONS AT REPAIRING REFRIGERANT CYCLE	10-S8
	[1] HANDLING OF SERVICE TOOLS.....	10-S9
	(1) Manifold Gauge Set	10-S9
	(2) Refrigerant Charging Hose	10-S10
	(3) Vacuum Pump Adaptor.....	10-S11
	(4) Electric Gas Leak Tester.....	10-S11
	(5) Can Tap Valve	10-S11
	(6) T-joint	10-S12
	(7) R134a Refrigerant Recovery and Recycling Machine	10-S12
5.	CHECKING AND CHARGING REFRIGERANT CYCLE.....	10-S13
	[1] CHECKING WITH MANIFOLD GAUGE	10-S13
	[2] DISCHARGING EVACUATING AND CHARGING	10-S17
	(1) Discharging the System	10-S17
	(2) Evacuating the System	10-S17
	(3) Charging the System	10-S19
	(4) Checking Charge Refrigerant Amount	10-S21
6.	CHECKING, DISASSEMBLING AND SERVICING.....	10-S22
	[1] SEPARATING CABIN FROM TRACTOR BODY.....	10-S22
	[2] COMPRESSOR	10-S27
	(1) Checking	10-S27
	(2) Disassembling and Assembling	10-S27
	(3) Servicing	10-S30
	[3] AIR CONDITIONER SYSTEM AND FRONT WINDSHIELD WIPER	10-S30
	(1) Checking	10-S30
	(2) Disassembling and Assembling	10-S36
	(3) Servicing	10-S43
	[4] LIGHTING SYSTEM	10-S44
	(1) Checking	10-S44
	[5] OTHERS	10-S45
	(1) Disassembling and Assembling	10-S45

1. TROUBLESHOOTING

COMPRESSOR

Symptom	Probable Cause	Solution	Reference Page
Noisy (Compressor ON)	• Bearing of compressor worn or damaged	Replace	10-S28
	• Valves in compressor damaged	Replace	10-S28
	• Belt slipping	Adjust or replace	G-28
	• Compressor bracket mounting screws loosen	Tighten	–
	• Piping resonant	Tighten or add clamp	–
(Compressor OFF)	• Blower defective	Repair or replace	10-S37
	• Bearings of magnetic clutch, idle pulley or crank pulley worn or damaged	Replace	–

W1013580

AIR CONDITIONING SYSTEM

Does Not Cool (No Air Flow)	• Fuse blown	Replace	G-34
	• A/C main relay defective	Repair or replace	10-S30
	• Blower relay defective	Replace	10-S30
	• Blower motor defective	Replace	10-S32
	• Blower switch defective	Replace	10-S32
	• Wiring harness disconnected or improperly connected	Repair	–
(Compressor Does Not Rotate)	• Fuse blown	Replace	G-34
	• Magnetic clutch defective	Repair or replace	10-S27
	• A/C switch defective	Replace	10-S32
	• Pressure switch defective	Replace	10-S34
(Others)	• Belt slipping	Adjust or replace	G-28
	• Insufficient refrigerant	Check with manifold gauge	10-S13
	• Expansion valve defective	Replace	–
	• Compressor defective	Replace	10-S28
Insufficient Cooling (Insufficient Air Flow)	• Air filter clogged	Clean or replace	G-29
	• Evaporator frosted	Clean or replace thermo switch	10-S43
(Many Bubbles in Sight Glass)	• Blower motor defective	Replace	10-S32
	• Insufficient refrigerant	Check with manifold gauge	10-S13
	• Gas leaking from some place in refrigerating cycle	Repair and charge refrigerant	10-S11
	• Air mixed in	Check with manifold gauge	10-S14
(No Bubbles in Sight Glass)	• Too much refrigerant	Check with manifold gauge	10-S14


W1013718

AIR CONDITIONING SYSTEM (Continued)


Symptom	Probable Cause	Solution	Reference Page
Insufficient Cooling (Compressor Does Not Rotate Properly) (Others)	• Belt slipping	Adjust or replace	G-28
	• Magnetic clutch defective	Repair or replace	10-S27
	• Compressor defective	Replace	10-S28
	• Thermostat defective	Replace	-
	• Water valve defective	Replace	-
	• Condenser fin clogged with dust	Clean	G-29
	• Expansion valve defective	Replace	-
Insufficient Heating	• Water valve defective	Replace	-
	• Air mix door malfunctioning	Adjust control cable	10-S37
	• Insufficient coolant	Replenish	G-7, 8
Insufficient Cooling (Compressor Does Not Rotate Properly) (Others)	• Belt slipping	Adjust or replace	G-28
	• Magnetic clutch defective	Repair or replace	10-S27
	• Compressor defective	Replace	10-S28
	• Condenser fin clogged with dust	Clean	G-29
	• Expansion valve defective	Replace	-

W1013580

AIR CONDITIONING SYSTEM (Continued)



3TLABABWP001A



WINDSHIELD WIPER

Symptom	Probable Cause	Solution	Reference Page
Windshield Wiper Does Not Operate	<ul style="list-style-type: none"> • Wiring defective • Fuse blown (Short-circuit, burnt component inside motor or other part for operation) • Wiper motor defective (Broken armature, worn motor brush or seized motor shaft) • Wiper switch defective • Foreign material interrupts movement of link mechanism • Wiper arm seized or rusted 	Check and repair Correct cause and replace Replace Replace Repair Lubricate or replace	– G-34 10-S40 10-S35 10-S37, S38 10-S40
Windshield Wiper Operating Speed Is Too Low	<ul style="list-style-type: none"> • Wiper motor defective (Short-circuit of motor armature, worn motor brush or seized motor shaft) • Low battery voltage • Humming occurs on motor in arm operating cycle due to seized arm shaft • Wiper switch contact improper 	Replace Recharge or replace Lubricate or replace Replace	10-S40 G-24 – 10-S35
Windshield Wiper Does Not Stop Correctly	<ul style="list-style-type: none"> • Wiper motor defective (Contaminated auto-return contacts or improper contact due to foreign matter) 	Replace	10-S40

W1066515

WASHER MOTOR

Washer Motor Does Not Operate	<ul style="list-style-type: none"> • Fuse blown • Washer switch defective • Washer motor defective • Wiring defective 	Correct cause and replace Replace Replace Repair	– 10-S36 – –
Washer Motor Operate but Washer Fluid Is Not Ejected	<ul style="list-style-type: none"> • No washer fluid • Clogged washer nozzle 	Replenish Clean or replace	– –

W1011118

2. SERVICING SPECIFICATIONS

Item		Factory Specification	Allowable Limit
Air-gap of A/C Compressor Magnet Clutch	Air-gap	0.20 to 0.45 mm 0.008 to 0.018 in.	—
Refrigerating Cycle (Refrigerating Cycle is Normal Operating) Condition <ul style="list-style-type: none"> • Engine Speed : Approx. 1500 min⁻¹ (rpm) • Ambient Temperature : 30 to 35 °C 86 to 95 °F • Blower Switch : PURGE Position 	Pressure (LO Pressure Side)	0.15 to 0.20 MPa 1.5 to 2.0 kgf/cm ² 21 to 28 psi	—
	Pressure (HI Pressure Side)	1.27 to 1.66 MPa 13 to 17 kgf/cm ² 185 to 242 psi	—
Pressure Switch (Dual Type) (When pressure switch is turned OFF)	Setting Pressure (LO Pressure Side)	Less than approx. 0.196 MPa 2.0 kgf/cm ² 28.4 psi	—
	Setting Pressure (HI Pressure Side)	More than approx. 3.14 MPa 32 kgf/cm ² 455 psi	—
Air Conditioner Drive Belt	Tension	10 to 12 mm (0.39 to 0.47 in.) deflection at 98 N (10 kgf, 22 lbs) of force	—
Proper Clutch Pedal	Free Travel	35 to 45 mm 1.38 to 1.77 in.	—
Proper Brake Pedal	Free Travel	40 to 45 mm 1.57 to 1.77 in.	—
Shift Rod	Length	Approx. 275 mm 10.8 in.	—
Hydraulic Control Rod Position and Draft Rod	Length	Approx. 362 mm 14.25 in.	—

W1013874

3. TIGHTENING TORQUES

Tightening torques of screws, bolts and nuts on the table below are especially specified.
(For general use screws, bolts and nuts : See page G-9.)

Item	N·m	kgf·m	ft·lbs
Cabin mounting screws and nuts	124 to 147	12.6 to 15.0	91.1 to 108
Muffler mounting screw	31.4 to 37.2	3.2 to 3.8	23.1 to 27.5
Compressor mounting screws	24.5 to 29.4	2.5 to 3.0	18.1 to 21.7
Compressor bracket mounting screws			
Screws to inlet manifold	23.5 to 27.5	2.4 to 2.8	17.4 to 20.3
Screws to water flange	17.7 to 20.6	1.8 to 2.1	13.0 to 15.2
Clutch mounting nut (swash plate type compressor)	14.7 to 24.5	1.5 to 2.5	10.8 to 18.1
Clutch mounting screw (scroll type compressor)	10.8 to 16.2	1.10 to 1.65	8.0 to 11.9
High pressure pipe screw and retainer nut between compressor and condenser (High pressure pipe 1)			
screw	7.8 to 11.8	0.8 to 1.2	5.8 to 8.7
retaining nut	19.6 to 24.5	2.0 to 2.5	14.5 to 18.1
between condenser and receiver			
screw	3.9 to 6.9	0.4 to 0.7	2.9 to 5.1
retaining nut	11.8 to 14.7	1.2 to 1.5	8.7 to 10.8
between receiver and A/C unit (High pressure pipe 2)			
retaining nut	11.8 to 14.7	1.2 to 1.5	8.7 to 10.8
Low pressure pipe between A/C unit and compressor			
screw	7.8 to 11.8	0.8 to 1.2	5.8 to 8.7
retaining nut	29.4 to 34.3	3.0 to 3.5	21.7 to 25.3
Front wiper arm mounting nut	6.37 to 9.32	0.65 to 0.95	4.7 to 6.9
Rear wiper arm mounting nut	7.8 to 9.3	0.8 to 0.95	5.79 to 6.87
Rear wiper motor mounting bolt	7.8 to 9.3	0.8 to 0.95	5.79 to 6.87
Main delivery hose retaining nut	47.1 to 51.0	4.8 to 5.2	34.7 to 37.6
Turning delivery hose retaining nut	24.5 to 29.4	2.5 to 3.0	18.1 to 21.7
A/C unit mounting screws (M6)	3.9 to 6.9	0.4 to 0.7	2.89 to 5.06
A/C unit mounting screws (M8)	9.8 to 15.7	1.0 to 1.6	7.23 to 11.6

W1012736

4. PRECAUTIONS AT REPAIRING REFRIGERANT CYCLE

When checking or repairing the air conditioning system, the following precautions and rules must be observed. And it is of first importance that no other personnel than a well-trained serviceman should be allowed to handle the refrigerant.

CAUTION


- Since direct contact of the liquid refrigerant with your skin will cause frostbite, always be careful when handling the refrigerant. Always wear goggles to protect your eyes when working around the system.
- The refrigerant service container has a safe strength. However, if handled incorrectly, it will explode. Therefore, always follow the instructions on the label. In particular, never heat the refrigerant container above 40 °C (104 °F) or drop it from a high height.
- Do not steam clean on the system, especially condenser since excessively high pressure will build up in the system, resulting in explosion of the system.
- If you improperly connect the hose between the service valve of compressor and gauge manifold, or incorrectly handle the valves, the refrigerant service container or charging hose will explode. When connecting the hose or handling the valve, be sure to check the high pressure side or low pressure side.
- In case the refrigerant is charged while the compressor is operated, do not open the high pressure valve of the gauge manifold.
- Beware of the toxicity of the gas. The gas is harmless and nontoxic in its original state, however it produces a toxic substance when it comes in contact with high temperature parts and decomposes.
- Do not heat the service can unless necessary. When it has to be heated, use warm water of 40 °C (104 °F) or lower. Do not heat using boiling water.

■ IMPORTANT

- If the refrigerant, O-rings, etc. for R12 are used in the R134a air conditioner system, problems such as refrigerant leakage or cloudiness in the sight glass may occur. Therefore, in order to prevent charging of refrigerant or erroneous connections, the shapes of the piping joint as well as the shapes of the service valve and the service tools have been changed.
- Always keep the working place clean and dry and free from dirt and dust. Wipe off water from the line fittings with a clean cloth before disconnecting.
- Use only for R134a refrigerant service tool.
- Use for R134a refrigerant recovery and recycling machine when discharging the refrigerant.
- Before attaching the charging hose to the can tap valve of the refrigerant container, check each packing for clogging.
- When disconnecting the charging hose from the charging valve of compressor and receiver, remove it as quick as possible so that gas leakage can be minimized.
- Be sure to charge the specified amount of refrigerant, but not excessively. Over-charging of the refrigerant in particular may cause insufficient cooling, etc..
- Since the charging hose can be connected to can tap valve by hand, do not use a pliers for tightening it.
- Keep refrigerant containers in a cool and dark place avoiding such place which are subject to strong sunlight or high temperature.
- R134a compressor oil absorbs moisture easily, so that be sure to seal after disconnecting the each parts.
- Do not use old-type refrigerant R12a or compressor oil for old-type refrigerant.
- When replacing the condenser, evaporator and receiver, etc., replenish the compressor oil to compressor according to the table below.

[1] HANDLING OF SERVICE TOOLS


(1) Manifold Gauge Set



The hand valves on the manifold gauge set are used to open and close the valve. The hand valve inscribed **LO** is for the low pressure side valve (3) and **HI** is for the high pressure side valve (4). By opening or closing the high and low pressure hand valves, the following circuits are established.

- (1) LO Pressure Gauge
- (2) HI Pressure Gauge
- (3) LO Pressure Side Valve
- (4) HI Pressure Side Valve
- (5) Schrader Valve

W1013107




■ When LO Pressure Side Valve and HI Pressure Side Valve are Closed

Two circuits are established.
 Port (C) → LO pressure gauge (1)
 Port (A) → HI pressure gauge (2)

■ NOTE

- Schrader valve (D) must be opened.

W1013376




■ When LO Valve is Opened and HI Valve is Closed

Two circuits are established.
 Port (C) → LO pressure gauge (1)
 → Port (B)
 → Port (D)
 Port (A) → HI pressure gauge (2)

■ NOTE

- Schrader valve (D) must be opened.

W1013454




■ When LO Valve is Closed and HI Valve is Opened

Two circuits are established.
 Port (C) → HI pressure gauge (2)
 → Port (B)
 → Port (D) (Schrader valve must be opened)
 Port (A) → LO pressure gauge (1)

■ NOTE

- Schrader valve (D) must be opened.

W1013304



■ When LO and HI Valve are Opened





Circuits are established.
 Port (A) → HI pressure gauge (2)
 → LO pressure gauge (1)
 → Port (B)
 → Port (C)
 → Port (D) (Schrader valve must be opened)

■ NOTE

- Schrader valve (D) must be opened.

W1013864

(2) Refrigerant Charging Hose



The charging hoses are classified into three colors. Each charging hose must be handled as follows :

- The air conditioner manufacture recommends that the blue hose (3) is used for the **LO** pressure side (suction side), the green hose (5) for refrigeration side (center connecting port) and the red hose (4) for **HI** pressure side (discharged side).

(When connecting)

- Push the quick disconnect adaptor (6) into the charging valve, and push on part **A** until a click is heard.

■ NOTE

- When connecting, push carefully so the pipe doesn't bend.
- When connecting the quick disconnect connector, should the sleeve (7) move before the quick link connector can be connected to the charging valve, move the quick sleeve to its original position and try again.
- When some refrigerant remains in the charging hose at the time of connections, it may be difficult to connect the quick link connector. In this case, perform the operation after removing any residual pressure in the hose. (Remove the residual pressure by pushing the pusher (8).)

(When reassembling)

- While holding on to part **A** of the quick disconnect adaptor, slide part **B** up.

■ NOTE

- After removing the adaptor, ensure to cap the quick disconnect adaptor service valve.



- (1) LO Pressure Side Valve
- (2) HI Pressure Side Valve
- (3) Blue Hose
- (4) Red Hose
- (5) Green Hose
- (6) Quick Disconnect Adaptor

- (7) Sleeve
- (8) Pusher
- (9) Sleeve

a : CLICK

W1014039

(3) Vacuum Pump Adaptor




Objective of the Vacuum Pump Adaptor

1. After vacuum has been created in the air conditioning cycle, when the vacuum pump is stopped, since there is vacuum in hoses within the gauge manifold, the vacuum pump oil flows back into the charging hose. If the refrigerant is refilled with the system still in this state, the vacuum pump oil left in the charging hose enters the air conditioner cycle together with the refrigerant. Vacuum pump adaptor with a solenoid valve is used to prevent this back-flow of oil from the vacuum pump. The role of the solenoid valve is that when the current passes through the solenoid valve, the valve closes to keep out the outside air and allow the vacuum to build up, but when the current stops, the valve opens to allow in air and end the vacuum.
2. Attaching this adaptor to the R12 vacuum pump currently being used allows the pump to be used with both R134a and R12.

- | | |
|-------------------------|---------------|
| (1) Vacuum Pump Adaptor | (6) For R134a |
| (2) Vacuum Pump | (7) For R12 |
| (3) Magnetic Valve | |
| (4) Blind Cap | |
| (5) Air | |

W1014539

(4) Electric Gas Leak Tester



The current R12 gas leak tester has poor sensitivity for R134a and cannot be used. Therefore, a new electric gas leak tester with greater sensitivity has been designed and can be used with both R134a and R12.

(Reference)


Leak tester with halide torch

- Since the reaction with chlorine within the refrigerant is used to detect gas leaks, R134a, which contains no chlorine, cannot be detected.

- (1) Electric Gas Leak Tester

W1014905

(5) Can Tap Valve




The can tap valve that is used to charge the refrigerant into the air conditioning system, should be used as follows :

1. Before putting the can tap valve on the refrigerant container, turn the handle (1) counterclockwise till the valve needle is fully retracted.
2. Turn the plate nut (disc) (4) counterclockwise till it reaches its highest position, then screw down the can tap valve into the sealed tap.
3. Turn the plate nut clockwise fully, and fix the center charging hose to the valve.
4. Tighten the plate nut firmly by hand.
5. Turn the handle (1) clockwise, thus making a hole in the sealed tap.
6. To charge the refrigerant into the system, turn the handle (1) counterclockwise. To stop charging, turn it clockwise.

- | | |
|----------------------|------------|
| (1) Butterfly Handle | (3) Needle |
| (2) Connection | (4) Disc |

W1015014

(6) T-joint



T-joint (2) is used to increase efficiency of gas charging using two refrigerant containers (4) at a time.

1. Install two refrigerant container service valves to T-joint (2) sides and connect the charging hose (1) to it.

- (1) Charging Hose (Green)
- (2) T-joint
- (3) Can Tap Valve
- (4) Refrigerant Container


W1015169

(7) R134a Refrigerant Recovery and Recycling Machine

When there is necessity of discharging the refrigerant on repairing the tractor, it should use recovery and recycling machine. (Don't release the refrigerant into the atmosphere.)

■ IMPORTANT

- Use only R134a refrigerant recovery and recycling machine, eliminate mixing R134a equipment, refrigerant and refrigerant oils with R12 systems to prevent compressor damage.



W1015488



(3) Can Tap Valve



5. CHECKING AND CHARGING REFRIGERANT CYCLE



[1] CHECKING WITH MANIFOLD GAUGE

■ IMPORTANT

- The gauge indications described in the following testing are those taken under the same condition, so it should be noted that the gauge readings will differ somewhat with the ambient conditions.

Condition

- Ambient temperature : 30 to 35 °C (86 to 95 °F)
- Engine speed : Approx. 1500 min⁻¹ (rpm)
- Temperature control lever : **Maximum cooling position**
- Air-Conditioner switch : **ON**
- Blower switch : **HI position**



Manifold Gauge Connecting and Test Preparation

- Close the manifold gauge **HI** and **LO** pressure side valve (7), (6) tightly.
- Connect the charging hose (1) (red) to the **HI** pressure side charging valve (2) and connect the charging hose (4) (blue) to the **LO** pressure side charging valve (3).

■ NOTE

- Be sure to drive out the air in the charging hoses at the manifold gauge connection end by utilizing the refrigerant pressure in the refrigerating cycle.
- Start the engine and set at approx. 1500 min⁻¹ (rpm).
 - Turn on the A/C switch and set the temperature control lever to **maximum cooling position**.
 - Set the blower switch to **HI position**.

- | | |
|-------------------------------------|----------------------------|
| (1) Charging Hose (Red) | (5) Manifold Gauge |
| (2) HI Pressure Side Charging Valve | (6) HI Pressure Side Valve |
| (3) LO Pressure Side Charging Valve | (7) LO Pressure Side Valve |
| (4) Charging Hose (Blue) | |

W1015662

Normal Operating


If the refrigerating cycle is operating normally, the reading at the **LO** pressure side (1) should be generally by around 0.15 to 0.2 MPa (1.5 to 2.0 kgf/cm², 21 to 28 psi) and that at the **HI** pressure side (2) around 1.27 to 1.66 MPa (13 to 17 kgf/cm², 185 to 242 psi).

Gas pressure	Factory spec.	Low pressure side	0.15 to 0.20 MPa 1.5 to 2.0 kgf/cm ² 21 to 28 psi
		High pressure side	1.27 to 1.66 MPa 13 to 17 kgf/cm ² 185 to 242 psi

(1) LO Pressure Side

(2) HI Pressure Side

W1015870




Insufficient Refrigerant

- Symptoms seen in refrigerating cycle
 - Both **LO** and **HI** pressure side (1), (2) pressures too low.
 - LO** pressure side (1) : 0.05 to 0.1 MPa
(0.5 to 1.0 kgf/cm², 7.1 to 14.2 psi)
 - HI** pressure side (2) : 0.69 to 0.98 MPa
(7 to 10 kgf/cm², 99.6 to 142.2 psi)
 - Bubbles seen in sight glass.
 - Air discharged from air conditioner slightly cold.
- Probable cause
 - Gas leaking from some place in refrigerant cycle.
- Solution
 - Check for leakage with electric gas leak tester (see page 10-S11) and repair.
 - Recharge refrigerant to the proper level. (See page 10-S21.)

(1) **LO** Pressure Side(2) **HI** Pressure Side

W1016070



Excessive Refrigerant or Insufficient Condenser Cooling


- Symptoms seen in refrigerating cycle
 - Both **LO** and **HI** pressure side (1), (2) pressures too high.
 - LO** pressure side (1) : 0.2 to 0.35 MPa
(2.0 to 3.5 kgf/cm², 28 to 49.8 psi)
 - HI** pressure side (2) : 1.96 to 2.45 MPa
(20 to 25 kgf/cm², 284.5 to 355.6 psi)
- Probable cause
 - Overcharging refrigerant into cycle.
 - Condenser cooling faulty.
- Solution
 - Clean condenser. (See page G-29.)
 - Adjust air conditioner belt to proper tension. (See page G-28.)
 - If the above two items are in normal condition, check refrigerant quantity. (See page 10-S21.)

NOTE

- If excessive refrigerant is to be discharged, loosen manifold gauge **LO** pressure side valve and vent out slowly.

(1) **LO** Pressure Side(2) **HI** Pressure Side

W1016402



Air Entered in the Cycle


- Symptoms seen in refrigerating cycle
 - Both **LO** and **HI** pressure side (1), (2) pressures too high.
 - LO** pressure side (1) : 0.2 to 0.35 MPa
(2.0 to 3.5 kgf/cm², 28 to 49.8 psi)
 - HI** pressure side (2) : 1.96 to 2.45 MPa
(20 to 25 kgf/cm², 284.5 to 355.6 psi)
 - LO** pressure side (1) piping not cold when touched.
- Probable cause
 - Air entered in refrigerating cycle.
- Solution
 - Replace receiver.
 - Check compressor oil contamination and quantity.
 - Evacuate and recharge new refrigerant. (See page 10-S18, S19.)

NOTE

- The above cycle can be seen when the cycle is charged without evacuation.

(1) **LO** Pressure Side(2) **HI** Pressure Side

W1016771




Moisture Entered in the Cycle

1. Symptoms seen in refrigerating cycle
 - The air conditioner operates normally at the beginning, but over time, **LO** pressure side (1) pressure is **vacuum** and **HI** pressure side (2) is low pressure.
 - LO** pressure side (1) : Vacuum
 - HI** pressure side (2) : 0.69 to 0.98 MPa
(7 to 10 kgf/cm², 99.6 to 142.2 psi)
2. Probable cause
 - The moisture in the refrigerating cycle freezes in the expansion valve orifice and causes temporary blocking. After a time, the ice melts and condition returns to normal.
3. Solution
 - Replace receiver.
 - Remove moisture in cycle by means of repeated evacuation. (See page 10-S17.)
 - Recharge new refrigerant to the proper level. (See page 10-S19.)

(1) LO Pressure Side

(2) HI Pressure Side

W1017013




Refrigerant Fails to Circulate

1. Symptoms seen in refrigerating cycle
 - **LO** pressure side (1) pressure is **vacuum** and, **HI** pressure side (2) is **low** pressure.
 - LO** pressure side (1) : Vacuum
 - HI** pressure side (2) : 0.49 to 0.59 MPa
(5 to 6 kgf/cm², 71.2 to 85.3 psi)
 - Frost or dew formed on piping at front and rear sides of expansion valve or receiver.
2. Probable cause
 - Refrigerant flow obstructed by moisture or dirt in the refrigerating cycle freezing or sticking on the expansion valve orifice.
3. Solution
 - Allow to stand for same time and then resume operation to decide whether the plugging is due to moisture or dirt.
 - If caused by moisture, correct by referring to instructions in previous.
 - If caused by dirt, remove the expansion valve and blow out the dirt with compressed air.
 - If unable to remove the dirt, replace the expansion valve.
 - Replace the receiver. Evacuate and charge in proper amount of new refrigerant. (See page 10-S17 to S19.)
 - If caused by gas leakage in heat sensitizing tube, replace the expansion valve.

(1) LO Pressure Side

(2) HI Pressure Side

W1017346




Expansion Valve Opens Too Far or Improper Installation of Heat Sensitizing Tube

1. Symptoms seen in refrigerating cycle
 - Both **LO** and **HI** pressure side (1), (2) pressures too high.
 - LO** pressure side (1) : 0.29 to 0.39 MPa
(3.0 to 4.0 kgf/cm², 42.71 to 56.9 psi)
 - HI** pressure side (2) : 1.96 to 2.45 MPa
(20 to 25 kgf/cm², 284.5 to 355.6 psi)
 - Frost or heavy dew on low pressure side piping.
2. Probable cause
 - Expansion valve trouble or heat sensitizing tube improperly installed.
 - Flow adjustment not properly done.
3. Solution
 - Check installed condition of heat sensitizing tube.
 - If installation of heat sensitizing tube is correct, replace the expansion valve.

(1) LO Pressure Side

(2) HI Pressure Side

W1017612



Faulty Compression of Compressor

1. Symptoms seen in refrigerating cycle
 - **LO** pressure side (1) pressure too high : 0.39 to 0.59 MPa (4 to 6 kgf/cm², 56.9 to 85.3 psi)
 - **HI** pressure side (2) pressure too low : 0.69 to 0.98 MPa (7 to 10 kgf/cm², 99.6 to 142.2 psi)
 2. Probable cause
 - Leak in compressor.
 3. Solution
 - Replace compressor. (See page 10-S39.)
- **NOTE**
- **Manifold gauge indications (left side figure) at faulty compressing by compressor.**

(1) LO Pressure Side

(2) HI Pressure Side


W1017960

[2] DISCHARGING EVACUATING AND CHARGING

■ IMPORTANT

- When discharging, evacuating or charging the refrigerating system, be sure to observe the "PRECAUTION AT REPAIRING REFRIGERANT CYCLE". (See page 10-S8.)

(1) Discharging the System



Prepare for the R134a refrigerant recovery and recycling machine.

1. Connect low pressure side hose (blue) from the recovery and recycling machine to **LO** pressure side charging valve (3) on the compressor (1). Connect high pressure side hose (red) to **HI** pressure side charging valve (2) on the compressor (1).
2. Follow the manufacturers instructions and discharge the system.

■ IMPORTANT

- Use only R134a refrigerant recovery and recycling machine. Eliminate mixing R134a equipment, refrigerant, and refrigerant oils with R12 systems to prevent compressor damage.


⚠ CAUTION


- Protect fingers with cloth against frostbite by refrigerant when disconnecting the hose to the charging valve.

- (1) Compressor (2) HI Pressure Side Charging Valve (3) LO Pressure Side Charging Valve

W1018328

(2) Evacuating the System





Evacuating the System



1. Discharge refrigerant from the system by R134a refrigerant recovery and recycling machine. (Refer to "Discharging the system".)
2. Connect the charging hose (7) (red) to the **HI** pressure side charging valve and connect the charging hose (9) (blue) to the **LO** pressure side charging valve.
3. Connect the center charging hose (8) (green) to a vacuum pump inlet.
4. Open both valves (6), (10) of manifold gauge fully. Then run the vacuum pump (1) to evacuate the refrigerant cycle. (For approx. **15 minutes.**)
5. When **LO** pressure gauge (10) reading is more than **750 mmHg (299 in.Hg)**, stop the vacuum pump (8) and close both valves (6), (10) of manifold gauge fully.
6. Wait for over 5 minutes with the **HI** and **LO** pressure side valves (6), (10) of gauge manifold closed, and then check that gauge indicator does not return to 0.
7. If the gauge indicator is going to approach to 0, check whether there is a leaking point and repair if it is, and then evacuate it again.

- | | |
|------------------------------|--|
| (1) Vacuum Pump (Running) | (6) HI Pressure Side Valve (Open) |
| (2) Vacuum Pump Adaptor | (7) Red Hose |
| (3) LO Pressure Gauge | (8) Green Hose |
| (4) HI Pressure Gauge | (9) Blue Hose |
| (5) Compressor | (10) LO Pressure Side Valve (Close) |

W1018495



(3) Charging the System



Charging an Empty System (Liquid)

This procedure is for charging an empty system through the HI pressure side with the refrigerant in the liquid state.

⚠ CAUTION

- Never run the engine when charging the system through the HI pressure side.
- Do not open the LO pressure valve when refrigerant R134a is being charged in the liquid state (refrigerant container is placed upside-down).

■ IMPORTANT

- After charging the refrigerant in the liquid state with approx. 500 g (1.1 lbs) through the HI pressure side, be sure to recharge the refrigerant in the vapor state to specified amount through the LO pressure side.


1. Close the HI and LO pressure side valves (5), (6) of manifold gauge after the system is evacuated completely.
2. Connect the center charging hose (2) to the can tap valve (7) fitting, and then loosen the center charging hose at the center fitting of manifold gauge until hiss can be heard. Allow the air to escape for few seconds and tighten the nut.
3. Open the HI pressure side valve (5) fully, and keep the container upside-down to charge the refrigerant in the liquid state from the HI pressure side.
4. Charge the refrigerant in the liquid state with approx. 500 g (1.1 lbs) from the HI pressure side.

■ NOTE

- If LO pressure gauge does not show a reading, the system is clogged and must be repaired.
5. Close the HI pressure side valve (5) of manifold gauge and can tap valve of refrigerant container.

- | | |
|------------------------------------|-----------------------------------|
| (1) Refrigerant Container (R134a) | (7) Can Tap Valve (Open) |
| (2) Green Hose | (8) Compressor |
| (3) Red Hose | |
| (4) Blue Hose | |
| (5) HI Pressure Side Valve (Open) | A : Air Purge |
| (6) LO Pressure Side Valve (Close) | B : Loosen the Nut |
| | C : Open the Can Tap Valve |

W1018931



Charging an Empty or Partially Charged System (Vapor)

This procedure is to charge the system through the **LO** pressure side with refrigerant in the vapor state. When the refrigerant container is placed right side up, refrigerant will enter the system as a vapor.

⚠ CAUTION

- Never open the **HI** pressure valve of manifold gauge while the engine is running.

■ NOTE

- Do not turn the refrigerant container upside-down when charging the system by running the engine.
- Put refrigerant container into a pan of warm water (maximum temperature 40 °C (104 °F)) to keep the vapor pressure in the container slightly higher than vapor pressure in the system.

1. Check that the **HI** pressure valve (5) is closed.
2. Start the engine and set an approx. 1500 min⁻¹ (rpm).
3. Turn on the A/C switch.
Set the temperature control lever to **maximum cooling** position and the blower switch to **HI** position.
4. Open the **LO** pressure valve (6) of manifold gauge and the can tap valve (1) on refrigerant container and charge the refrigerant until air bubbles in the sight glass of the receiver vanish.
5. After charging the specified amount of refrigerant into the system, close the **LO** pressure valve (6) of manifold gauge and can tap valve (1), then stop the engine.
6. Check for gas leak with an electric gas leak tester (see page 10-S11).

(Reference)

- Specified amount of refrigerant (total) :
900 to 1000 g (2.0 to 2.2 lbs) [Refrigerant R134a]
- Manifold gauge indication at fully charged system (at ambient temperature : 30 °C (86 °F))



HI pressure side : 1.27 to 1.66 MPa
13 to 17 kgf/cm²
185 to 242 psi

LO pressure side : 0.15 to 0.20 MPa
1.5 to 2.0 kgf/cm²
21 to 28 psi

- | | |
|------------------------------|--------------------------------------|
| (1) Can Tap Valve | (4) Compressor (Running) |
| (2) LO Pressure Gauge | (5) HI Pressure Valve (Close) |
| (3) HI Pressure Gauge | (6) LO Pressure Valve (Open) |

W1019245

(4) Checking Charge Refrigerant Amount



After charging the refrigerant, check for amount of charging refrigerant as follows.

■ NOTE

• The pressure on the following checking are the gauge indications at ambient temperature 30 °C (86 °F), so it should be noted that the pressure will differ some what with the ambient temperature.

1. Disconnect the 2P connector (4) of magnetic clutch.
2. Start the engine and set a approx. 1500 min⁻¹ (rpm).
3. Connect the 2P connector (4) of magnetic clutch to battery directly, and then set the blower switch to HI position.
4. Leave the system for approx. 5 minutes until the refrigerant cycle becomes stable, keeping pressure on the HI pressure side from 1.27 to 1.66 MPa (13 to 17 kgf/cm², 185 to 242 psi).
5. When the refrigerant cycle is stabilizer, turn off the blower switch and let the compressor alone to run. Then pressure on the LO pressure side gradually drops. At this time, if pressure on the HI pressure side is maintained from 1.27 to 1.66 MPa (13 to 17 kgf/cm², 185 to 242 psi), air bubbles which pass through the sight glass becomes as stated below depending on refrigerant charged amount.

A : Insufficient refrigerant charge

Air bubbles pass continuously the sight glass when pressure on the LO pressure side is over 99.0 kPa (1.01 kgf/cm², 14.4 psi). In this case, charge the refrigerant from the LO pressure side.

B : Properly refrigerant charge

Air bubbles pass through the sight glass continuously when pressure on the LO pressure side is within 59 to 98 kPa (0.6 to 1.0 kgf/cm², 9 to 14 psi).

If the charge refrigerant amount is proper, no air bubble is observed on the sight glass at pressure on the LO pressure side over 99.0 kPa (1.01 kgf/cm², 14.4 psi) when the blower switch is turned on. When the blower switch is turned off, bubbles pass through the sight glass in case pressure on the LO pressure side is within 59 to 98 kPa (0.6 to 1.0 kgf/cm², 9 to 14 psi).

C : Excessive refrigerant charge

Air bubbles pass through the sight glass time to time or no air bubble is observed when pressure on the LO pressure side is under 59 kPa (0.6 kgf/cm², 9 psi).

In this case, discharge excessive refrigerant gradually from the LO pressure side.



- (1) LO Pressure Gauge
- (2) To Battery
- (3) Compressor (Running)
- (4) 2P Connector

- (5) HI Pressure Gauge
- (6) HI Pressure Valve (Close)
- (7) LO Pressure Valve (Close)

W1019604

6. CHECKING, DISASSEMBLING AND SERVICING

[1] SEPARATING CABIN FROM TRACTOR BODY



Draining Coolant

⚠ CAUTION

- Never remove the radiator cap until coolant temperature is well below its boiling point. Then loosen cap slightly to the stop to relieve any excess pressure before removing cap completely.

1. Stop the engine and let cool down.
2. Loosen the drain plug (2) to drain the coolant.
3. Remove the radiator cap to completely drain the coolant.
4. After all coolant is drained, retighten the drain plug (2).

(When refilling)

- Fill the coolant between the "FULL" and "LOW" marks of recovery tank (1).

Coolant capacity (with recovery tank)	L3430	7.2 L 7.6 U.S.qts. 6.3 Imp.qts.
	L4330 L4630	8.7 L 9.2 U.S.qts. 7.7 Imp.qts.
	L5030	9.2 L 9.7 U.S.qts. 8.1 Imp.qts.

- (1) Recovery Tank
(2) Drain Plug

A : FULL
B : LOW

W10590830



Battery, Front Grill, Skirt and Bonnet

1. Open the bonnet and disconnect the battery negative cable.
2. Disconnect the head light connector and remove the front grill (4).
3. Remove the left and right side skirts (3).
4. Disconnect window washer hoses (2).
5. Remove the bonnet (1).






■ NOTE

- When disconnecting the battery cords, disconnect the negative cord first, when connecting, positive cord first.

- (1) Bonnet
(2) Window Washer Hose

(3) Skirt
(4) Front Grill

W1059877



Steering Joint, Brake Pedal Rod and Electric Wiring

1. Remove the tank frame support (2).
2. Remove the universal joint bolt (10) and steering joint support (6), and then remove the steering joint (1).
3. Disconnect the hand accelerator wire and foot accelerator wire (7). (A foot accelerator is not equipped in HST model.)
4. Disconnect the wiring connectors for engine stop solenoid (8), engine tachometer sensor (9) and glow plug.
5. Disconnect the heater hoses (3), and then reconnect their hoses to make loop.

NOTE

- Put a mark to the each heater hose before disconnecting.
6. Disconnect the wiring connector for window washer tank (4) and compressor 1P connector (5).
 7. Disconnect the brake pedal rod.

(When reassembling)

- When accelerator wire is installed, adjust the wiring length as hit both the idling speed adjusting bolt and the maximum speed adjusting bolt by lever within the stroke of the accelerator lever.
- Set the steering joint (1) by the joint support (6) so that the steering wheel is turned lightly.
- Be sure to check and adjust the brake pedal free travel. (See page G-16.)

- (1) Steering Joint
 (2) Tank Frame Support
 (3) Heater Hose
 (4) Window Washer Tank
 (5) 1P Connector

- (6) Steering Joint Support
 (7) Accelerator Wire
 (8) Engine Stop Solenoid
 (9) Engine Tachometer Sensor
 (10) Universal Joint Bolt

W1060784

Clutch Rod, Brake Pedal Rod and Electric Wiring

1. Disconnect the brake pedal rod (6) and clutch rod (4).
2. Disconnect the wiring connectors for alternator (1), coolant temperature sensor (9), oil pressure switch (2), fuel unit (3), starter motor (7) and battery.
3. Remove the clamps and ground earth of wiring harness and collect wiring harness to the step or cabin.
4. Remove the clamps (8) of A/C hoses (5).






(When reassembling)

- Be sure to check and adjust the clutch and brake pedal free travel. (See page G-16, 22.)

- (1) Alternator
 (2) Oil Pressure Switch
 (3) Fuel Unit
 (4) Clutch Rod
 (5) A/C Hoses

- (6) Brake Pedal Rod
 (7) Starter Motor
 (8) Clamps
 (9) Coolant Temperature Sensor

W1061143



Seat, Seat Bracket and Lever Grips

1. Remove the seat.
2. Disconnect the seat switch connector (3) and remove the seat bracket (1) with seat suspension (7).
3. Remove the front wheel drive lever (6).

(GST Model)

4. Remove the lever grip for position control lever (2) and creep shift lever (4).

(HST Model)

4. Remove the lever grip for position control lever (2), range gear shift lever (8) and cruise control lever (9).

- (1) Seat Bracket
- (2) Position Control Lever
- (3) Seat Switch Connector
- (4) Creep Shift Lever
- (5) GST Lever
- (6) Front Wheel Drive Lever

- (7) Seat Suspension
- (8) Range Gear Shift Lever
- (9) Cruise Control Lever

A : GST Model
B : HST Model

W1061319

Differential Lock Rod and Lowering Speed Adjusting Knob (GST Model)

1. Disconnect the differential lock rod (1).
2. Remove the lowering speed adjusting knob (2).

- (1) Differential Lock Rod
- (2) Lowering Speed Adjusting Knob


W1061980

Electric Connector for GST

1. Disconnect the ECU connector (1).
2. Disconnect the GST lever sensor connector (2).
3. Remove the GST valve cover.
4. Disconnect the pressure switch connector (4), proportional reducing valve connector (5), solenoid valve connector (6), oil temperature sensor connector (8) and ground cables (7).

- (1) ECU Connector
- (2) GST Lever Sensor Connector
- (3) Wiring Harness of GST Lever Sensor
- (4) Pressure Switch Connector
- (5) Proportional Reducing Valve Connector
- (6) Solenoid Valve Connector
- (7) Ground Cable
- (8) Oil Temperature Sensor Connector


W1062110




Electric Connector for HST

1. Remove the lowering speed adjusting knob (4).
2. Disconnect the differential lock rod (2).
3. Disconnect the range gear shift lever sensor connector (3).
4. Disconnect the cruise switch connector (1).
5. Disconnect the HST pedal neutral switch connector (5).
6. Disconnect the ground earth (a).

- | | |
|---|--|
| (1) Cruise Switch Connector | (4) Lowering Speed Adjusting Knob |
| (2) Differential Lock Pedal | (5) HST Pedal Neutral Switch Connector |
| (3) Range Gear Shift Lever Sensor Connector | (a) Ground earth is connected here |



W1062242



PTO Shift Wire and Electric Connector


1. Disconnect the PTO shift wire (2) at the PTO clutch valve lever (4).
2. Disconnect the traveling speed sensor connector (1).

(When reassembling)

- When connecting the PTO shift wire (2) to the lever (4), be sure to adjust the length of wire as follows.
1. Set the PTO shift lever to **OFF (Neutral)** position.
 2. Loosen the lock nut (3) of wire, and connect wire to the clutch valve lever (4), and then place the wire to the hook.
 3. Tighten the lock nut (3) clockwise (pull the wire), and lock the nut just before the lever moves.

- | | |
|--------------------------------------|----------------------------|
| (1) Traveling Speed Sensor Connector | (3) Lock Nut |
| (2) PTO Shift Wire | (4) PTO Clutch Valve Lever |

W1062504



Shuttle Switch Connector (GST Model)

1. Remove the panel cover and steering post cover.
2. Disconnect the shuttle switch connector (1).

- (1) Shuttle Switch Connector

W1062664



Cruise Control Release Wire (HST Model)





1. Disconnect the cruise control release wire (1).

(When reassembling)

- Be sure to adjust the cruise control release wire (1). (See page 3-S95.)

- (1) Cruise Control Release Wire

W1062741



Air Conditioner Parts

1. Remove the muffler (2).
2. Remove the air conditioner belt (4) and remove the compressor (1) mounting screw.
3. Remove the recovery tank (6) and window washer tank (7).
4. Disconnect the air cleaner hose (8).
5. Disconnect the recovery tank hose (5).
6. Disconnect the radiator upper hose (3).
7. Remove the oil cooler mounting screw. (HST model only)
8. Remove the battery (10).
9. Remove the battery stay mounting bolt.
10. Take out the compressor (1), condenser (11), receiver (12), hoses (13), battery stay (9) and etc. as a unit.

(When reassembling)

- After reassembling the compressor, be sure to adjust the air conditioner belt tension. (See page G-28.)

Tightening torque	Compressor mounting screw	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft·lbs
	Muffler mounting screw	31.4 to 37.2 N·m 3.2 to 3.8 kgf·m 23.1 to 27.5 ft·lbs

- (1) Compressor
- (2) Muffler
- (3) Radiator Upper Hose
- (4) Air Conditioner Belt
- (5) Recovery Tank Hose
- (6) Recovery Tank
- (7) Window Washer Tank

- (8) Air Cleaner Hose
- (9) Battery Stay
- (10) Battery
- (11) Condenser
- (12) Receiver
- (13) Air Conditioner Hose

W1063451

Cabin Assembly

1. Remove the outer roof of cabin.
2. Support the cabin with nylon straps (1) and hoists.
3. Loosen and remove the cabin mounting bolts (2) and nuts (9).
4. Dismounting the cabin from tractor body.

NOTE

- Lift the cabin while making sure it does not catch on anything.

(When reassembling)

- Be sure to install the washers and mount rubbers, etc. in their original positions.
- Before mounting the cabin, be sure to set both the shuttle lever rod and the shuttle arm to the neutral position, and then connect the shuttle lever rod securely. (GST model)

Tightening torque	Cabin mounting bolt and nut	124 to 147 N·m 12.6 to 15.0 kgf·m 91.1 to 108 ft·lbs
-------------------	-----------------------------	--

- (1) Nylon Straps
- (2) Bolt
- (3) Plate
- (4) Mount Rubber
- (5) Collar
- (6) Plain Washer (M14)

- (7) Washer
- (8) Spring Washer
- (9) Nut

F : Front Side
R : Rear Side

W1063848

[2] COMPRESSOR

(1) Checking



3TLABABWP032A

Operation of Magnetic Clutch

1. Start the engine.
2. Check whether abrasion or abnormal noise is heard when only the magnetic clutch pulley is running while the A/C switch is pushed **OFF**.
3. Check that the magnetic clutch (1) does not slip when the A/C switch and blower switch are turned **ON** (when the air conditioner is in operation).
4. If anything abnormal is found, repair or replace.

(1) Magnetic Clutch

W1014211



3TLABABWP033A

Stator Coil

1. Measure the resistance of the stator coil with an ohmmeter across the **2P** connector.
2. If the measurement is not within the factory specifications, replace the stator coil.

Stator coil resistance	Factory spec.	3.0 to 3.4 Ω
------------------------	---------------	--------------

W1014331

(2) Disassembling and Assembling



3TLABAB3P167A

Battery, Front Grill, Skirt and Bonnet

1. Open the bonnet and disconnect the battery negative cable.
2. Disconnect the head light connector and remove the front grill (4).
3. Remove the left and right side skirts (3).
4. Disconnect window washer hoses (2).
5. Remove the bonnet (1).

■ NOTE



- When disconnecting the battery cords, disconnect the negative cord first, when connecting, positive cord first.

- (1) Bonnet
(2) Window Washer Hose

- (3) Skirt
(4) Front Grill

W1064077

10.8 to 18 N·m 1.10 to 1.65 kgf·m 8.9 to 13.5 ft·lb	Clutch mounting screw	Tightening torque
---	-----------------------	-------------------



Compressor

1. Discharge the refrigerant from the system. (Refer to "Discharging the System" : See page 10-S17.)
2. Disconnect the low pressure pipe (suction) (2) and high pressure pipe (discharge) (1) from the compressor, then cap the open fittings immediately to keep moisture out of the system.
3. Disconnect the 2P connector (3) of magnetic clutch.
4. Remove the air conditioner belt (4) and remove the compressor (5).

(When reassembling)

- After reassembling the compressor, be sure to adjust the air conditioner belt tension (see page G-28) and recharge the refrigerant to the system. (Refer to "Charging the System" : See page 10-S19.)
- Apply compressor oil (**NIPPONDENSO ND-OIL8** or equivalent) to the O-rings and take care not to damage them.



(When replacing compressor)

- When replacing the compressor with a new one, meet the oil amount with old one.

Tightening torque	High pressure pipe and low pressure pipe mounting screw	7.9 to 11.8 N·m 0.81 to 1.20 kgf·m 5.8 to 8.7 ft·lbs
	Compressor mounting screws	24.5 to 29.4 N·m 2.5 to 3.0 kgf·m 18.1 to 21.7 ft·lbs

- | | |
|--------------------------|---------------------------------|
| (1) High Pressure Pipe | (5) Compressor |
| (2) Low Pressure Pipe | (6) New Compressor |
| (3) 2P Connector | (7) Old Compressor |
| (4) Air-conditioner Belt | (8) Remove the Excess Oil (A-B) |

W1014469



Hub Plate

1. Three stopper bolts (1) are set in stopper magnet clutch (2) at the position corresponding to the shape of compressor. (See page G-50.)
2. The stopper magnet clutch (2) is hung on hub plate (3) and it is fixed that the compressor rotates.
3. Remove the magnet clutch mounting screw or nut.
4. Remove the hub plate (3).
- Compressor is used remover magnet clutch (4). (See page G-51.)
5. Remove the shims.





(When reassembling)

- Do not apply grease or oil on the hub plate facing.
- Do not use the screw or nut again.
- It is confirmed to turn rotor by hand after assembling and not contact with stator.
- Check and adjust the air gap before tight the magnet clutch mounting screw or nut to the specified torque.

Tightening torque	Clutch mounting screw	10.8 to 16.2 N·m 1.10 to 1.65 kgf·m 8.0 to 11.9 ft·lbs
-------------------	-----------------------	--

- | | |
|---------------------------|---------------------------|
| (1) Stopper Bolt | (3) Hub Plate |
| (2) Stopper Magnet Clutch | (4) Remover Magnet Clutch |

W1059166



Rotor

1. Remove the cir-clip (1).
2. Remove the rotor (3).

(When reassembling)

- Do not use the cir-clip again.
- Assemble the cir-clip for the tapered side to become outside of rotor.
- The width of expanding of cir-clip is set in boss of shaft as a minimum.

(Reference)

Type of compressor	Code No. for circlip
Scroll type	T1065-87450

- (1) Cir-Clip (3) Rotor
 (2) Shim

W1059753

Stator

1. Remove the lead wire from compressor body.
2. Remove the external circlip (1).
3. Remove the stator (2).

(When reassembling)


- Do not use the cir-clip again.
- Assemble the cir-clip for the tapered side to become outside of front housing.
- The width of expanding of cir-clip is set is boss of shaft as a minimum.
- Match and assemble the concave part (3) of the front housing (5) and the pin (4) of stator.

- (1) External Circlip (4) Pin
 (2) Stator (5) Front Housing
 (3) Concave Part

W1059953



(3) Servicing



Adjustment of Air-gap

1. Measure the air-gap with a feeler gauge.
2. When the measurement value comes off from factory specification, adjustment shim is added or deleted.

Air-gap	Factory spec.	0.20 to 0.45 mm 0.008 to 0.018 in.
---------	---------------	---------------------------------------

(Reference)

	Adjustment shim
0.10 mm (0.0039 in.)	T1065-87340
0.15 mm (0.0059 in.)	T1065-87350
0.40 mm (0.016 in.)	T1065-87360
0.60 mm (0.024 in.)	T1065-87370
1.0 mm (0.0394 in.)	T1065-87380

(1) Shim

A : Air-Gap

W1060178

[3] AIR CONDITIONER SYSTEM AND FRONT WINDSHIELD WIPER

(1) Checking

(A) Air Conditioner Unit




A/C Blower Relay and Compressor Relay

1. Remove the outer roof of cabin, and disconnect the relay connectors.
2. Perform the following checkings 1) and 2).

(1) A/C Blower Relay

(2) Compressor Relay

W1016913



1) Connector Voltage

a) A/C Blower Relay

1. The voltage across the 4 terminal and chassis should be approx. battery voltage.
2. When turning the main switch **ON** and A/C blower switch to **LO** position, the voltage across the 2 terminal and chassis should be approx. battery voltage.

b) Compressor Relay


1. The voltage across the 4 terminal and chassis should be approx. battery voltage.
2. When turning the main switch **ON**, A/C blower switch to **LO** and A/C switch **ON**, the voltage across the terminal 2 and chassis should be approx. battery voltage.

(1) A/C Blower Relay

(3) Connector Side

(2) Compressor Relay

W1017012



2) Relay Test

1. Remove the relay (1).
2. Connect the battery (2) and bulb (3) with the relay (1) as shown in the left figure.
3. In this condition, the bulb should light on if the relay is proper.
4. If the bulb light off when disconnecting the jumper lead from the relay 4 terminal, the relay is proper.

(1) Relay
(2) Battery

(3) Bulb

W1017314




A/C Switch

1. Remove the outer roof and disconnect the A/C blower switch connector (1).
2. Perform the following checkings 1) and 2).

(1) A/C Blower Switch Connector

W1017559



1) Connector Voltage

1. Turn the main switch ON.
2. Measure the voltage with a voltmeter across the connector 4 terminal and 3 terminal.
3. If the voltage differs from the battery voltage, the wiring harness, A/C relay, fuse or main switch is faulty.

Voltage	4 terminal – 3 terminal	Approx. battery voltage
---------	-------------------------	-------------------------

2) A/C Blower Switch

1. Check the continuity through the switch with an ohmmeter.
2. If the continuity specified below are not indicated, the switch is faulty.

		Terminal			
		3	4	1	2
A/C blower switch	OFF	●			
	● (Low)	●	●		
	● (Medium)	●	●	●	
	● (High)	●	●	●	●

(1) A/C Blower Switch

(2) A/C Blower Switch Connector



W1017851



A/C Blower Motor Test

1. Remove the outer roof.
2. Turn the blower motor (2) by hand and check whether it turns smoothly.
3. Disconnect the connector (1) of blower motor (2).
4. Connect a jumper lead from battery (3) positive terminal to connector **B** terminal.
5. Connect a jumper lead from battery negative terminal to connector **E** terminal momentarily.
6. If the blower motor does not run, check the motor.

- (1) Blower Motor Connector (3) Battery (12 V)
 (2) Blower Motor




A/C Blower Resistor

1. Remove the outer roof.
2. Disconnect the **4P** connector (1) for A/C blower resistor (2).
3. Measure the resistance with an ohmmeter across the **R1** terminal and **E** terminal, and across the **R2** terminal and **E** terminal.
4. If the factory specifications are not indicated, A/C blower resistor is faulty.

Resistance	Factory spec.	R1 terminal – E terminal	Approx. 0.9 Ω
		R2 terminal – E terminal	Approx. 1.8 Ω

- (1) A/C Blower Resistor Connector (2) A/C Blower Resistor

W1019107




A/C Switch

1. Remove the outer roof, and disconnect the A/C switch connector (2).
2. Perform the following checkings **1)** and **2)**.

- (1) A/C Switch (2) A/C Switch Connector

W1019584



1) Connector Voltage

1. Turn the main switch **ON**.
2. Measure the voltage with a voltmeter across the connector 7 terminal and 6 terminal.
3. If the voltage differs from the battery voltage, the wiring harness, A/C relay or fuse is faulty.

2) A/C Switch

1. Check the continuity through the switch with an ohmmeter.
2. If the continuity specified below is not indicated, the switch is faulty.

Terminal		7	6	5
		Position		
A/C switch	OFF *2			
	ON *1	●	●	

*1 : Push the A/C switch button to **ON** position.

*2 : Push again the A/C switch button to **OFF** position.

(1) A/C Switch

(2) A/C Switch Connector

W1019763

Setting pressure	Factory spec.	Pressure switch GPP	More than approx. 2.14 MPa (30 kg/cm ²)
------------------	---------------	---------------------	---

2) LO Pressure Side

1. Disconnect 2P connector of pressure switch.
2. Measure the resistance with an ohmmeter across the connector terminals.
3. If 0 ohm is not indicated at normal condition there is no refrigerant in the refrigerating cycle because gas leak or pressure switch is defective.

(Reference)

Setting pressure	Factory spec.	Pressure switch GPP	Less than approx. 0.186 MPa (2.0 kg/cm ²)
------------------	---------------	---------------------	---

* The resistance of pressure switch is 0 ohm in normal running, but is becomes infinity if the pressure is abnormal (out of factory spec.). Because the pressure switch starts to work.

- (1) Charging Hose (Red)
- (2) HI (High Pressure Side) Charging Valve
- (3) Manifold Gauge
- (4) LO (Low Pressure Side) Charging Valve
- (5) Air Conditioner Unit
- (6) Pressure Switch
- (7) Charging Hose (Blue)

W105050



Defogger Switch

1. Remove the outer tool and disconnect the defogger switch connector (1).
2. Perform the following checkings (1) and (2).

- (1) Defogger Switch Connector
- (2) Defogger Switch

W101288





Pressure Switch

1) HI Pressure Side

1. Connect the manifold gauge (6) to compressor as following procedure.

Close the **HI** and **LO** pressure valves (5), (7) of manifold gauge tightly, and connect the charging hoses (red and blue) (1), (4) to the respective compressor service valves. (Refer to **HANDLING OF SERVICE TOOLS** : See page 10-S9.)

NOTE

• Be sure to drive out the air in the charging hoses at the manifold gauge connection end by utilizing the refrigerant pressure in the refrigerant cycle.

2. Start the engine and set at approx. 1500 min⁻¹ (rpm). Turn on the A/C switch, then set the blower switch to **HI** position.

3. Raise pressure on the **HI** pressure side of the refrigerant cycle by covering the condenser front with a corrugated cardboard, and the pressure switch (9) is activated and the compressor magnetic clutch is turned off. At this time, read the **HI** pressure gauge of the manifold gauge. If this pressure reading differs largely with the setting pressure, replace the pressure switch with a new one.

Setting pressure	Factory spec.	Pressure switch OFF	More than approx. 3.14 MPa 32 kg/cm ² 455 psi
------------------	---------------	-------------------------------	---

2) LO Pressure Side

1. Disconnect **2P** connector of pressure switch.

2. Measure the resistance with an ohmmeter across the connector terminals.

3. If 0 ohm is not indicated at normal condition, there is no refrigerant in the refrigerating cycle because gas leaks or pressure switch is defective.

(Reference)

Setting pressure	Factory spec.	Pressure switch OFF	Less than approx. 0.196 MPa 2.0 kg/cm ² 28.4 psi
------------------	---------------	-------------------------------	--

• The resistance of pressure switch is 0 ohm in normal running, but is becomes infinity if the pressure is abnormal (out of factory spec.). Because the pressure switch starts to work.

- (1) Charging Hose (Red)
- (2) **HI** (High Pressure Side) Charging Valve
- (3) **LO** (Low Pressure Side) Charging Valve
- (4) Charging Hose (Blue)
- (5) **HI** Pressure Valve
- (6) Manifold Gauge
- (7) **LO** Pressure Valve
- (8) Air Conditioner Unit
- (9) Pressure Switch

W1020509


Defogger Switch


1. Remove the outer roof and disconnect the defogger switch connector (1).

2. Perform the following checkings **1)** and **2)**.

- (1) Defogger Switch Connector
- (2) Defogger Switch

W1015868





1) Connector Voltage

1. Turn the main switch **ON**.
2. Measure the voltage with a voltmeter across the connector **B** terminal and chassis.
3. If the voltage differs from the battery voltage, the wiring harness, fuse or main switch is faulty.

Voltage	B terminal – Chassis	Approx. battery voltage
---------	----------------------	-------------------------

2) Defogger Switch

1. Check the continuity through the switch with an ohmmeter.
2. If the continuity specified below are not indicated, the switch is faulty.


	T	B	R	E
P				
ON		●	●	●
OFF			●	●

(1) Defogger Switch Side

(2) Connector Side

W1015953

(B) Front Windshield Wiper




Front Wiper Switch

1. Remove the outer roof, and disconnect the front wiper switch connector (1).
2. Perform the following checkings 1) and 2).

(1) Front Wiper Switch Connector

(2) Front Wiper Switch

W1021780



1) Connector Voltage

1. Turn the main switch **ON**.
2. Measure the voltage with a voltmeter across the connector **W** terminal and chassis.
3. If the voltage differs from the battery voltage, the wiring harness, fuse or main switch is faulty.

Voltage	W terminal – Chassis	Approx. battery voltage
---------	----------------------	-------------------------

2) Front Wiper Switch

1. Check the continuity through the switch with an ohmmeter.
2. If continuity specified below is not indicated, the switch is faulty.

	Terminal	S1	S2	B	W	E	PL
Front wiper switch	WASH I				●	●	
	OFF	●	●				
	ON		●	●			●
	WASH II		●	●	●	●	●

(Reference)

- **WASH I : OFF** side of the wiper switch remains pushed in.
- **WASH II : ON** side remains pushed in after the wiper switch is switched **ON** and remains switched **ON**.


(1) Front Wiper Switch

(2) Front Wiper Switch Connector (Switch Side)

(3) Front Wiper Switch Connector (Wiring Harness Side)

a : From Main Switch AC Terminal

W1021874



Front Wiper Motor

1. Raise up the front wiper arm (2).
2. Turn the main switch **ON**.
3. Push the front wiper switch to **ON** position.
4. Count the number of wiper arm rocking per minutes.
5. If the number differs from the factory specifications, replace the wiper motor assembly.

No load rotating speed	Factory spec.	33 to 43 min ⁻¹ (rpm)
------------------------	---------------	----------------------------------



(1) Wiper Blade

(2) Wiper Arm

W1022632

(2) Disassembling and Assembling

(A) Removing Air Conditioner Unit and Front Wiper Motor



Draining Coolant

CAUTION

- **Never remove the radiator cap until coolant temperature is well below its boiling point. Then loosen cap slightly to the stop to relieve any excess pressure before removing cap completely.**
1. Stop the engine and let cool down.
 2. Loosen the drain plug (2) to drain the coolant.
 3. Remove the radiator cap to completely drain the coolant.
 4. After all coolant is drained, retighten the drain plug (2).

(When refilling)

- Fill the coolant between the **“FULL”** and **“LOW”** marks of recovery tank (1).

Coolant capacity (with recovery tank)	L3430	7.2 L 7.6 U.S.qts. 6.3 Imp.qts.
	L4330 L4630	8.7 L 9.2 U.S.qts. 7.7 Imp.qts.
	L5030	9.2 L 9.7 U.S.qts. 8.1 Imp.qts.

- (1) Recovery Tank
- (2) Drain Plug

A : FULL
B : LOW

W10646580

Discharging Refrigerant

1. Refer to **“Discharging the System”**. (See page 10-S17.)

W1023185





Blower Motor and Blower Resistor

1. Remove the outer roof.
2. Disconnect the battery negative cable.
3. Disconnect the A/C blower motor connector (1).
4. Disconnect the 4P connector for A/C blower resistor (3).

- (1) A/C Blower Motor Connector
- (2) A/C Blower Resistor Connector
- (3) A/C Blower Resistor

W1023280



Air Mixing Door Control Cable (Blue Tape)

1. Disconnect the air mixing door control cable (3) from the damper lever (1) of air conditioner control panel side.

(When reassembling)


- Set the damper lever (1) of the air conditioner unit at **MAX HOT** position. Reconnect the cable.
- Move the control to **MAX HOT** position. Fit the inner cable in position, and press and fix the outer cable by the cable clip (2) in the direction of arrow (A) as shown at left.
- Move the temperature control lever several times and finally set it to **MAX HOT** position to make sure the damper lever is at **HOT** position too.





- (1) Damper Lever
- (2) Cable Clip
- (3) Air Mixing Door Control Cable

a : 5 to 10 mm (0.20 to 0.40 in.)

A : Direction of Pulling Outer Cable

W1023417





A/C Mode Door Control Cable (Yellow Tape)

1. Disconnect the air conditioner mode door control cable (3) from the defrosting (**DEF**) position control lever (1) of A/C control panel side.

(When reassembling)

- Set the air conditioner unit to **DEF** mode position and reconnect the cable (3).
- Set the control at **DEF** position. Fit the inner cable in position, and press and fix the outer cable by the cable clip (2) in the direction of arrow (**A**) as shown at left.
- Move the mode lever several times and finally set it to **DEF** position to make sure to air conditioner unit is at defrosting (**DEF**) mode position.
- Lay and fix the mode door control cable over the water valve cable.

- (1) DEF. Control Lever
- (2) Cable Clip
- (3) Mode Door Control Cable

a : 5 to 10 mm (0.20 to 0.40 in.)

A : Direction of Pulling Outer Cable

W1023759

Water Valve Control Cable (White Tape)

1. When disconnecting the water valve cable (1), follow the next reassembly procedure.

(When reassembling)



- Fully close the water valve (3) and reconnect the cable (1).
- Set the control at **MAX COOL** position. Fit the inner cable in position, and press and fix the outer cable by the cable clip (2) in the direction of arrow (**A**) as shown at left.
- Move the temperature control lever several times to make sure the water valve is fully closed at **MAX COOL** position.
- Do not allow the water valve cable to bend just away from the control, nor to get caught by the outer roof.

- (1) Water Valve Control Cable
- (2) Cable Clip
- (3) Water Valve

a : 5 to 10 mm (0.20 to 0.40 in.)

A : Direction of Pulling Outer Cable

W1023983



Air Conditioning Unit

1. Remove the unit cover (1).
2. Disconnect the heater hoses (5).
3. Disconnect the cooler pipe (liquid) (6) and cooler pipe (suction side) (7).
4. Remove the screws and take off the unit.
5. Remove the duct hoses.

(When reassembling)



- When reconnecting the cooler pipes with the unit, apply compressor oil (NIPPONDENSO OIL8 or equivalent) to O-rings.
- When remounting the unit, tighten five screws by hand and finally retighten them after aligning the inner roof duct with the unit duct.
- When connecting the heater hose with A/C unit, hose should be put into the A/C unit pipe more than 30 mm (1.2 in.)

Tightening torque	A/C unit mounting screw (M6)	3.92 to 6.86 N·m 0.40 to 0.70 kgf·m 2.89 to 5.06 ft·lbs
	A/C unit mounting screw (M8)	9.8 to 11.68 N·m 1.00 to 1.19 kgf·m 7.23 to 8.6 ft·lbs
	Low pressure pipe (Cooler pipe (suction)) retaining nut	29.4 to 34.3 N·m 3.0 to 3.5 kgf·m 21.7 to 25.3 ft·lbs
	High pressure pipe (Cooler pipe (liquid)) retaining nut	11.8 to 14.7 N·m 1.2 to 1.5 kgf·m 8.7 to 10.8 ft·lbs

- | | |
|--|---|
| <ul style="list-style-type: none"> (1) Unit Cover (2) Expansion Valve (3) Evaporator (4) Heater Core (5) Heater Hoses | <ul style="list-style-type: none"> (6) High Pressure Pipe (Cooler Pipe (Liquid)) (7) Low Pressure Pipe (Cooler Pipe (Suction Side)) |
|--|---|

W1025169





Front Wiper Motor

1. Remove the steering post covers and steering post under cover.
2. Remove the meter panel.
3. Remove the panel under cover.
4. Disconnect the front wiper motor 4P connector (5).
5. Remove the wiper arm mounting nut (7) and wiper arm (1).
6. Remove the wiper link cap (6).
7. Remove the front wiper motor (3).

(When reassembling)

- When attaching the wiper arm (1) to the wiper motor (3), assemble so that the dimensions are as given in the photo on the left. After doing so, check if the wiper wipes symmetrically on the left and right (bilateral symmetry).


Tightening torque	Wiper arm mounting nut (7)	6.37 to 9.32 N·m 0.65 to 0.95 kgf·m 4.7 to 6.9 ft·lbs
	Wiper motor mounting nut (4)	2.5 to 3.4 N·m 0.25 to 0.35 kgf·m 1.9 to 2.5 ft·lbs

Distance "A"	Factory spec.	90 to 110 mm 3.5 to 4.3 in.
--------------	---------------	--------------------------------

- | | |
|--|---|
| <ul style="list-style-type: none"> (1) Wiper Arm (2) Wiper Blade (3) Front Wiper Motor (4) Nut | <ul style="list-style-type: none"> (5) Front Wiper Motor Connector (4P) (6) Wiper Link Cap (7) Nut |
|--|---|

W1025464

(B) Removing Air Conditioner Pipes



Discharging Refrigerant

1. Refer to "Discharging the System". (See page 10-S17.)

W1026331

Battery, Front Grill, Skirt and Bonnet

1. Open the bonnet and disconnect the battery negative cable.
2. Disconnect the head light connector and remove the front grill (4).
3. Remove the left and right side skirts (3).
4. Disconnect window washer hoses (2).
5. Remove the bonnet (1).

NOTE

- When disconnecting the battery cords, disconnect the negative cord first, when connecting, positive cord first.

- | | |
|--|--|
| <ul style="list-style-type: none"> (1) Bonnet (2) Window Washer Hose | <ul style="list-style-type: none"> (3) Skirt (4) Front Grill |
|--|--|

W1064975



High Pressure Pipe 1

1. Disconnect the high pressure pipe 1 (2) from the compressor (1) and condenser (3), then cap the open fittings immediately to keep moisture out of the system.


(When reassembling)

- Apply compressor oil (NIPPONDENSO ND-OIL 8 or equivalent) to the O-rings and take care not to damage them.

Tightening torque	High pressure pipe 1 mounting screw (Compressor side)	7.8 to 11.8 N·m 0.81 to 1.20 kgf·m 5.8 to 8.7 ft-lbs
	High pressure side 1 retaining nut (Condenser side)	19.6 to 24.5 N·m 2.0 to 2.5 kgf·m 14.5 to 18.1 ft-lbs

- (1) Compressor (3) Condenser
(2) High Pressure Pipe 1

W1026502



Hose Clamp

1. Remove the hose clamp (4).
2. Disconnect the high pressure pipe 1 (5) from the receiver (1) and low pressure pipe (3) from the compressor, then cap the open fittings immediately to keep moisture out of the system.


(When reassembling)

- Apply compressor oil (NIPPONDENSO ND-OIL 8 or equivalent) to the O-rings and take care not to damage them.

Tightening torque	High pressure pipe 2 retaining nut (Receiver side)	11.8 to 14.7 N·m 1.2 to 1.5 kgf·m 8.7 to 10.8 ft-lbs
	Low pressure pipe mounting screw (Compressor side)	7.9 to 11.8 N·m 0.81 to 1.20 kgf·m 5.8 to 8.7 ft-lbs

- (1) Receiver (4) Hose Clamp
(2) High Pressure Pipe 2 (5) High Pressure Pipe 1
(3) Low Pressure Pipe

W1026689



High Pressure and Low Pressure Pipes


1. Remove the outer roof.
2. Disconnect the pressure switch (2) connector.
3. Disconnect the high pressure pipe 2 (3), then cap the open fitting immediately to keep moisture out of the system.
4. Remove the rubber (4) and disconnect the low pressure pipe (1), then cap the open fittings immediately to keep moisture out of the system.
5. Remove the inner covers (5).

(When reassembling)

- Replace the rubber (4) with a new one.
- Apply compressor oil (NIPPONDENSO ND-OIL 8 or equivalent) to the O-rings and take care not to damage them.



Tightening torque	High pressure pipe 2 retaining nut	11.8 to 14.7 N·m 1.2 to 1.5 kgf·m 8.7 to 10.8 ft-lbs
	Low pressure pipe retaining nut	29.4 to 34.3 N·m 3.0 to 3.5 kgf·m 21.7 to 25.3 ft-lbs

- (1) Low Pressure Pipe (4) Rubber
(2) Pressure Switch (5) Inner Cover
(3) High Pressure Pipe 2



W1026890

(C) Removing Heater Hoses



Draining Coolant

CAUTION

• Never remove the radiator cap until coolant temperature is well below its boiling point. Then loosen cap slightly to the stop to relieve any excess pressure before removing cap completely.

1. Stop the engine and let cool down.
2. Loosen the drain plug (2) to drain the coolant.
3. Remove the radiator cap to completely drain the coolant.
4. After all coolant is drained, retighten the drain plug (2).

(When refilling)

• Fill the coolant between the “FULL” and “LOW” marks of recovery tank (1).

Coolant capacity (with recovery tank)	L3430	7.2 L 7.6 U.S.qts. 6.3 Imp.qts.
	L4330 L4630	8.7 L 9.2 U.S.qts. 7.7 Imp.qts.
	L5030	9.2 L 9.7 U.S.qts. 8.1 Imp.qts.

- (1) Recovery Tank
- (2) Drain Plug

A : FULL
B : LOW

W10652320



Battery, Front Grill, Skirt and Bonnet


1. Open the bonnet and disconnect the battery negative cable.
2. Disconnect the head light connector and remove the front grill (4).
3. Remove the left and right side skirts (3).
4. Disconnect window washer hoses (2).
5. Remove the bonnet (1).

NOTE

• When disconnecting the battery cords, disconnect the negative cord first, when connecting, positive cord first.

- (1) Bonnet
- (2) Window Washer Hose
- (3) Skirt
- (4) Front Grill

W1065454



Hose Clamp

1. Remove the hose bands (1).
2. Remove the hose clamp (2).

NOTE

• Before disconnecting the heater hoses (3), put the parting marks on the hoses for marking proper reconnecting.



3. Disconnect the heater hoses (3), then take out them under the cabin.

(When reassembling)

• Connecting the heater hoses at their original position.

- (1) Hose Band
- (2) Hose Clamps
- (3) Heater Hoses

W1027385



(3) Servicing

(A) Air Conditioner Unit



Heater Hoses

1. Remove the outer roof.


■ NOTE

- Before disconnecting the heater hoses (2), put the parting marks on the hoses for marking proper reconnecting.
2. Disconnect the heater hoses (2) from the hose pipes (1).
 3. Remove the inner covers (3).
 4. Pull out the heater hoses (2) from the bottom of the cabin.
 5. Take out the heater hoses (2).

(When reassembling)

- Connect the heater hoses at their original positions.
- In assembling the heater hose (2) to the pipe (1), connect the heater hose with identification mark (white paint) to upper side of the hose pipe.
- When connecting the heater hose with A/C unit, hose should be put into the A/C unit pipe more than 30 mm (1.2 in.).

- (1) Heater Pipe
(2) Heater Hose



Evaporator

1. Check whether white powder or dust is attached to the evaporator (1). If they are attached, wash them off with warm water and blow them off with compressed air.

■ NOTE

- In case the evaporator is cleaned with warm water, cap the evaporator pipe ends so that water does not enter it.


- (1) Evaporator

W1027811

[4] LIGHTING SYSTEM

(1) Checking

(A) Working Light




Working Light Switch

1. Remove the outer roof, and disconnect the working light switch connector (2) from the working light switch (1).
2. Perform the following checkings 1) and 2).

(1) Working Light Switch

(2) Working Light Switch Connector

W1027926



1) Connector Voltage

1. Turn the main switch **ON**.
2. Measure the voltage with a voltmeter across the connector 5 terminal and chassis.
3. If the voltage differs from the battery voltage, the wiring harness, fuse or main switch is faulty.

Voltage	5 terminal – Chassis	Approx. battery voltage
---------	----------------------	-------------------------

2) Working Light Switch

1. Check the continuity through the switch with an ohmmeter.
2. If continuity specified below is not indicated.

		Terminal				
		5	6	3	1	2
Working light switch	OFF					
	ON	●	●	●	●	●

(1) Working Light Switch

(2) Working Light Switch Connector
(Switch Side)

(3) Working Light Switch Connector
(Wiring Harness Side)

W1028024

[5] OTHERS

(1) Disassembling and Assembling

(A) Cabin Windshields

Preparation


1. Prepare the followings.

- Cutter knife 1 piece
- Scraper 1 piece
- Gun for coating 1 piece
- Sika Tack-Ultrafast or equivalent
- Gummed tape
- Sika-Activator
- Sika primer 209
- Shin Etsu silicon KE45

■ NOTE

- Sika product are made by Sika Corporation.
- Shin Etsu silicon KE45 is made by Shin Etsu Polymer Corporation.
- These materials can't be provided by Kubota Corporation.
- Therefore, please find the local made equivalent materials in your country and use them when you need.

W1053361



3TLABABWP073A

Before Replacing Windshields (1)

[In case of using piano wire (When glass is cracked)]

1. Thread the piano wire from the inside of cabin. Tie its both ends to a wooden blocks or the like. (See the left figure.)
2. Pull the piano wire inward/outward alternately to cut the adhered part.

■ NOTE

- Do not let the piano wire make sliding contact with the edge of glass plate forcibly.

[In case of using cutter knife (When glass is totally crushed finely)]

1. Insert the knife (3) into the adhered part.
2. Keep the edge of knife blade square to the glass edge at the part (a). Slide the knife blade along the glass surface and the edge. Pull the part (b) in the direction parallel to the glass edge to cut them off.


■ NOTE

- Find a wider gap between the glass and body.
- Take care of handling the cutter knife not to damage your hand.

- (1) Piano Wire
(2) Wood Peace

- (3) Cutter Knife
(4) Pulling

W1035600



3TLABABWP074A


Before Replacing Windshields (2)

1. When the Sika Tack-Ultrafast or equivalent attached to the cabin frame and the glass are reused, remove the bond clearly.
2. Clean the frame surface with Sika-Activator.

■ NOTE

- Remove the bond completely.

W1035852



Before Replacing Windshields (3)

1. Check that the glasses are not damaged and cracked.
2. Turn over the glass and clean this surface of the glass by Sika-Activator.
3. The cleaning area of the rear surface is indicated "A" in the figure left.


■ **NOTE**

- **If not cleaning the glass, it may result in adhesive failure.**

- (1) Upper Windshield
- (2) Lower Windshield (Left)
- (3) Lower Windshield (Right)

A : 18 to 22 mm (0.71 to 0.87 in.)

W1035931



Rear Windshield

1. Apply a Sika primer 209 on the cabin frame.
2. Apply a Sika-Activator (3) on the rear windshield shown in figure.
3. Apply a Sika Tack-Ultrafast (2) (or equivalent) on the rear windshield (1) as shown in figure.
4. Install the rear windshield (1) to the cabin and fix it with a gummed tape.
5. Leave it for one hour.




■ **NOTE**






- **Apply the Sika Tack-Ultrafast (or equivalent) with the jig having the specified tip shape as shown in the figure left.**
- **Apply it with a uniform speed to minimize unevenness.**
- **Follow the instruction manual of Sika Tack-Ultrafast.**
- **When the gummed tape is removed the rear windshield may be displaced. In this case fix it again.**
- **Remove the gummed tape (adhesive tape) little by little to confirm the bonding condition.**

- (1) Rear Windshield
- (2) Sika Tack-Ultrafast
- (3) Sika-Activator
- (4) Jig

A : 8 mm dia. (0.31 in. dia.)
B : 12 mm (0.47 in.)

W1054050





Front Windshield

■ **NOTE**

- Apply the Sika Tack-Ultrafast (or equivalent) with the jig having the specified tip shape as shown in the figure left.
- Apply it with a uniform speed to minimize unevenness.
- Follow the instruction manual of Sika Tack-Ultrafast.

1. Apply the Sika Primer 209 on the cabin frame A and B in the figure.
2. Apply the Sika-Activator (5) on the windshield A and B in the figure.
3. Apply the Sika Tack-Ultrafast (4) on the windshield A and B in the figure.
4. Install the lower (left or right) windshield to the cabin and fix it with a gummed tape.
5. Set the upper windshield to the cabin and fix it with a gummed tape.

■ **NOTE**

- Use a jig (8) shown in the figure to create even clearance E [approx. 5 mm (0.2 in.)] between the lower and upper windshield.

- The level unevenness between the upper and lower windshields should be -1 to +1 mm (-0.04 to +0.04 in.) or less at the windshield surface.

6. Leave it for one hour.
7. Remove the jig (8).
8. Install the H rubber (7) between the lower and upper windshield (2), (3).
9. Apply the Shin Etsu silicon KE45 in H rubber (7).
10. Apply the Shin Etsu silicon KE45 on the edge of H rubber (7).

■ **NOTE**

- When the gummed tape is removed, the glass may be displaced. In this case fix it again.
- Remove the gummed tape (adhesive tape) little by little to confirm the bonding condition.

(1) Upper Windshield	A : 10 mm (0.39 in.)
(2) Lower Windshield (Right)	B : 12 mm (0.47 in.)
(3) Lower Windshield (Left)	C : 8 mm dia. (0.31 in. dia.)
(4) Sika Tack-Ultrafast	D : 12 mm (0.47 in.)
(5) Sika Activator	E : 5 mm (0.2 in.)
(6) Jig	F : -1.0 to +1.0 mm (-0.04 to +0.04 in.)
(7) H Rubber	G : 300 mm (11.8 in.)
(8) Jig	H : 20 mm (0.8 in.)
	I : 5 mm (0.2 in.)

W1054287

Kubota®

KUBOTA TRACTOR CORPORATION

CORPORATE OFFICE: 3401 DEL AMO BOULEVARD, TORRANCE, CA 90503

WESTERN DIVISION: 1175 S. Guild Ave., Lodi, CA 95240 • (209) 334-9910

CENTRAL DIVISION: 14855 F.A.A. Blvd., Fort Worth, TX 76155 • (817) 871-0900

NORTHERN DIVISION: One Kubota Way, Groveport, OH 43125 • (614) 835-1100

SOUTHEAST DIVISION: 1025 Northbrook Parkway, Suwanee, GA 30024 • (770) 995-8855



REPRINTED IN U.S.A.
July 2007
Code No. 97897-13000



