



## Service Course Manual

---

### G - PLEX WD, ZV & DP SERIES



**WARNING:** If incorrectly used this machine can cause severe injury. Those who use and maintain this machine should be trained in its proper use, warned of its dangers and should read the entire manual before attempting to set up, operate, adjust or service the machine.



# SECTION 1 SPECIFICATIONS

1

## ENGINE SPECIFICATION

TYPE:TYPE: Kubota 15.5KW @ 3600 RPM,  
3 cylinder Dies el engine, 4  
stroke, water cooled, 719cc  
with 12V electric start.  
Model: D722-E  
Maximum Speed: 3400 RPM (No load)  
Idle Speed: 1500 RPM  
Oil Sump Capacity:3.2 litres  
Firing Order: 1, 3, 4, 2.  
Fuel: No. 2-D Diesel fuel (ASTM D975)

Brakes, Service: Positive hydrostatic braking.  
Parking: 152 mm Caliper Disk

Capacities:  
Cooling System: 3.8 litres

Fuel Tank: 31 litres

Hydraulic Tank: 18.2 litres  
Total System 25.7 litres

Battery: 12 volt, Type 093

Alternator Diesel 40amp  
Gasoline 15amp

## ENGINE SPECIFICATION

TYPE:TYPE: Briggs & Stratton 13.5KW @  
3600 RPM, V twin gasoline  
engine, 4 stroke, air cooled,  
719cc with 12V electric start.  
Model: Vanguard 350447 Type 1294  
Maximum Speed: 3400 RPM (No load)  
Idle Speed: 1500 RPM  
Oil Sump Capacity:1.4 litres  
Fuel: Unleaded Gasoline Minimum 85  
octane

## CUTTING UNIT

Type: Three 559mm wide steerable  
floating head.  
Reel: 127mm diameter, 7 / 9 / 11  
knife.  
Rolls: S smooth rear roll, s smooth or  
grooved front/rear rolls optional.  
Bedknife to reel  
adjustment: Opposed set screw.  
Height of cut  
adjustment: Micro-adjusters on front roll.  
height of cut: 2.5mm to 16mm S tandard blade  
2mm to 16mm Tournament  
blade.

## MACHINE SPECIFICATION

Frame construction:  
Heavy duty fabricated steel  
chassis.  
Transmission:  
Variable displacement  
hydrostatic pump with high  
speed low torque wheel motors.

Cutting unit drive:  
Direct drive hydrostatic and reel  
drive pumps, bi-directional  
hydraulic gear motor with reel  
control valve and backlap control  
valve.

Speeds:  
Cutting: 6 km/h  
Transport: 12 kp/h  
Reverse: 3 kp/h  
Steering: Rear Wheel S teering. Power  
S teering, 2.5 turns lock to lock  
330mm dia. S teering Wheel

Ground pressure: 1.0 kg/cm

## DIMENSIONS

Width of cut: 1.57 metres  
Overall width with reels: 1.9 metres  
Overall height: 1.3 metres  
Overall length with reels: 2.1 metres  
Overall length with catchers: 2.5 metres  
Overall weight of machine  
With Reels

Diesel: 630kg  
Gasoline: 574kg

Without Reels

Diesel: 535kg  
Gasoline: 478kg

Wheel Track: 1.2 metres  
Wheel Base: 1.3 metres

## TYRE PRESSURES

| Product    | Front Wheel    |                   |                |          | Rear Wheel       |                   |                |          |
|------------|----------------|-------------------|----------------|----------|------------------|-------------------|----------------|----------|
|            | Tyre Size      | Tyre Typ          | e Tyre Pressur | e        | Tyre Siz         | Tyre Typ          | e Tyre Pressur | e        |
| G-Plex III | 20 x 1000 - 12 | Titan S mooth 2pr | i 9 ps         | 0.62 bar | 20 x 10.00 - 120 | Titan S mooth 2pr | i 9 ps         | 0.62 bar |

## VIBRATION LEVEL

The machine was tested for whole body and hand/arm vibration levels. The operator was seated in the normal operating position with both hands on the steering mechanism. The engine was running and the cutting device was rotating with the machine stationary.

Standard ISO 5349: 1986 Mechanical vibration. Guidelines for the measurement and the assessment of human exposure to hand-transmitted vibration.

| Machine Name<br>Series##<br>Hand / Arm Acceleration<br>level | Max LH or RH<br>Accelerations m/s <sup>2</sup> |       |       |
|--------------------------------------------------------------|------------------------------------------------|-------|-------|
|                                                              | X Aeq                                          | Y Aeq | Z Aeq |
|                                                              | 3.2                                            | 2.44  | 1.26  |
| Dominant Value                                               | 3.2                                            |       |       |

Standard ISO 2631-1: 1985 Evaluation of human exposure to whole body vibration -- Part 1: General requirements.

| Machine Name<br>Series##<br>Whole Body<br>Acceleration<br>level | Floor Location<br>Accelerations m/s <sup>2</sup> |        |       | Seat Location<br>Accelerations m/s <sup>2</sup> |        |        |
|-----------------------------------------------------------------|--------------------------------------------------|--------|-------|-------------------------------------------------|--------|--------|
|                                                                 | x                                                | y      | z     | x                                               | y      | z      |
| Mean                                                            | 0.0234                                           | 0.0499 | 0.109 | 0.0050                                          | 0.0255 | 0.0161 |

## SLOPES

DO NOT USE ON SLOPES GREATER THAN 15°  
The slope 15° was calculated using static stability measurements according to the requirements of EN 836.

## RECOMMENDED LUBRICANTS

Engine oil:

Diesel: S should be to MIL-L-2104C  
or to A.P.I. Classification CD  
Gasoline: A.P.I. Classification SE/SF

| TEMPERATURE        | OIL VISCOSITY      |
|--------------------|--------------------|
| ABOVE 4°C (39°F) 0 | SAE 3              |
| BELOW 4°C (39°F) 0 | SAE 5W-30 or 10W-3 |

Hydraulic Oil: GreensCare 68

Grease: Lithium based.

## CUTTING PERFORMANCE

Cutting Frequency

7-knife reel - 7.4mm at 6km/h  
9-knife reel - 5.7mm at 6km/h  
11-knife reel - 4.7mm at 6km/h

## SECTION 2 CONTROLS




Figure 11

1. Voltmeter
2. Hour Meter
3. Headlight Switch
4. Engine Oil Warning Light
5. Ignition Switch
6. Throttle
7. Turf Protection System (optional)
8. Pre-Heat Switch and Glow Plug Light
9. Temperature Gauge And Warning Light
10. Reel Enable Switch

**Voltmeter** - indicates battery condition.

**Headlight Switch** - turns the headlights on and off.

**Engine Oil Warning Light** - will come on when the engine oil pressure is too low for operation.

**Ignition Switch** - has four positions:

- OFF - prevents all electrical functions from operating. Switch must be in the OFF position to remove the key.
- ON - for normal operation.
- START - engages the starter. Release the key after engine starts (the switch automatically returns to ON).
- ACC. - has no function on this unit.

### NOTICE

- If the engine fails to start, or if it "dies" for any reason, the ignition switch must be returned to the OFF position before restarting is attempted. This feature prevents damage to the starter and flywheel teeth that can occur if the

starter is engaged while the engine is running.  
Wait 30 seconds before restarting engine.



#### WARNING

- When the ignition is switched on, if the units are in the lowered position they will raise. It should be ensured that operators/ bystanders are clear of all moving parts before the ignition switch is switched on.

**Throttle** - Push all the way forward for normal engine operating speed, and all the way back for idle.

**Hour Meter** - records the number of hours the engine has run. Use the hour meter to manage a good scheduled maintenance program (refer to the Maintenance Guide).

**Pre-Heat Switch and Glow Plug Light** - With key switch ON, push up/forward and hold the pre-heat switch until the glow plug light goes out.

**Temperature Gauge and Warning Light** - gauge indicates coolant temperature and light warns of overheat situation.

**Turf Protection System** - can be installed as an option to warn the operator if a leak in the hydraulic system is detected.

**Reel Enable Switch** - This switch must be in the on position (1) in order for the reels to rotate. The switch must be in the off position (0) for the unit to be started.

#### CONTROL PEDALS

The **Direction/Speed Pedal** (See Fig. 12) controls speed and direction. Depress front of pedal to go forward, depress back of pedal to go backward. Increased movement of the pedal will increase speed. To slow and stop the unit, release the pedal completely. Proper braking is provided by hydrostatic pressure. If more braking is required, press on the brake pedal.



#### WARNING

- DO NOT attempt to force the direction control pedal to the neutral (stop) position or to change directions before coming to a complete stop. Abrupt stops or changes in direction may cause injury.




Figure 12

1. Direction/Speed Pedal
2. Brake Pedal

#### NOTICE

- To reduce fatigue during normal forward operation, the operator's heel should rest on the floorboard next to the pedal (**not on the lower part of the pedal**).

#### PARKING BRAKE PEDAL

The **Parking Brake** can be engaged by depressing the brake pedal until the unit is at a complete stop. Once the unit is stopped, push the parking brake latch forward to hold the brake pedal. Disengage the parking brake by depressing and releasing the brake pedal.




Figure 13

1. Brake Pedal
2. Park Brake Latch

#### PADDLE/FOOTSWITCH MOW/LIFT

The **Mow/Lift Paddle/Footswitch** lowers and raises the cutting heads. To **Lower the Heads**: Depress the footswitch or operate the paddle. If reel enable switch is on, reel rotation starts when the heads are lowered. To **Raise the Heads**: Depress the footswitch or operate the paddle. Reel rotation stops when the heads are raised.

## ZX Models Only.

### NOTICE

- The paddle/footswitch will not operate if the rear unit has not completed its raise/lower cycle.




Figure 14

1. Paddle Control (Mow/Raise)
2. Footswitch Control (Mow/Raise)
3. Illustration of Paddle/Footswitch Operation



### STATEMENTS WARNING

Adjustment procedures must be performed as specified by properly trained service personnel **ONLY**. If assistance is needed, contact your local Jacobsen Textron Dealer.

To avoid the possibility of serious injury, switch the reel enable switch to the off position, lower the heads, stop the engine, remove the key and set the parking brake **BEFORE** making any adjustment.

The rear swing out arm is to allow you easy access to the rear cutting head. The cutting heads **MUST BE** in the raised position. **DO NOT** swing the arm out with the cutting heads in the lowered position.

**NEVER** rotate the cutting reel by pushing it with your hands or fingers. Fingers can become caught between the reel and the frame resulting in serious injury. Use a ratchet with a 9/16" socket on the end of the cutting head shaft to rotate the reel during adjustment and testing (See Fig. 15).




Figure 15

1. Rotate Cutting Reel with this Screw Head

### BEDKNIFE ADJUSTMENT

For this adjustment, the backlap valve control lever must be in the center "**neutral**" position so that the reel:



### WARNING

To avoid the possibility of serious injury, **NEVER** attempt any cutting head adjustment while the engine is running.

Any adjustment to the clearance between the reel blades and the bedknife should be done at the leading end of the reel first (the end at which each individual blade first crosses the bedknife). Then at the opposite end of the reel.

1. Loosen the **lower** adjustment screws at each end by turning them approximately 1/4 turn counterclockwise (See Figure 16).
2. While rotating the reel backwards, turn the **upper** adjustment screws (leading end first) until there is approximately (.025mm-.075mm) clearance. After adjusting both ends, recheck the leading end.

### NOTICE

- **Too much clearance** between the bedknife and the blades will result in **poor cutting quality**. **Too little clearance** will cause **excessive wear** to the cutting edges and may cause damage to the bedknife, reel blades or other components.




Figure 16

1. Upper Adjustment Screw
2. Lower Adjustment Screw

3. Rotate the reel forward. **The reel must turn freely** and you should just be able to hear the reel blades making slight contact with the bedknife.
4. After the bedknife is properly adjusted, tighten the **lower** adjustment screw at each end.
5. Test the cutting head by holding two strips of newsprint perpendicular to the bedknife. Rotate the reel with a wrench. The reel **must turn freely** and each blade on the reel should cut one of the two strips of paper.

### HEIGHT OF CUT

#### NOTICE

- All three cutting heads **MUST** be accurately set at the same height of cut to insure an even cut.
  - Bedknife adjustment must be made before setting the height of cut.
1. Set the height of cut on the gauge block by turning the wingnut until the distance between the bottom of the screw head and the top of the gauge block equals the desired height of cut (See Fig. 18).
  2. Loosen the locking nut on **one** of the front roller adjusting brackets just enough to allow adjustment (See Fig. 17).




Figure 17

1. Loosen Locking Nut
3. Hold the gauge block across the bottom of both the front and rear rollers near the roller adjustment bracket and adjust the front roller until the cutting edge of the bedknife comes up to touch the bottom of the gauge screw head (See Fig. 18).




Figure 18

### Height of Cut Adjustment

4. Tighten the locking nut and repeat the procedure at the other end. After adjustment has been made at both ends, go back and recheck both ends.
5. Make sure all three cutting heads are set without changing the height of the gauge screw.

### SEAT ADJUSTMENT LEVER

Pull out on the adjustment lever located under the left side of the seat. Slide the seat to the desired position and release the lever.




Figure 19

### 1. Seat Adjustment Lever

## CONTROL ARM ADJUSTMENT

Support the control arm to avoid a sudden drop while adjusting its height. Loosen the **Locking Lever** to allow the steering wheel and control arm to be adjusted up or down. Tighten the locking lever when steering wheel is at the desired position.




Figure 21

1. Control Arm Height Locking Lever



### WARNING

- *DO NOT* attempt to adjust the control arm position while the unit is moving. Operator may lose control, causing possible injury to themselves or bystanders.

## HYDRAULIC PUMP BYPASS VALVE

The **Bypass Valve** allows the unit to be pushed or towed. Turn the handle on the bottom of the pump counterclockwise (as viewed from the bottom of the pump) to open the valve. After moving the unit, close the valve by turning the handle clockwise.





Figure 22

1. Bypass Valve Handle

### NOTICE

- The bypass valve must be tightly closed for normal operation or a significant loss of speed will occur and



Read and familiarize yourself with the following warnings **before** operating the unit.



### WARNING

- This is heavy equipment. Improper use, or operating the unit in areas that may cause it to overturn, could cause serious injury or death of you the operator or bystanders.
- *READ* and *understand* the operator's manual before attempting to operate this unit. Allow *ONLY* trained and authorized persons to operate this unit. *NEVER* allow children to operate this unit. Local regulations may restrict the age of the operator.
- Never operate the unit while people, especially children, or pets are nearby.
- Keep in mind that the operator or user is responsible for accidents or hazards occurring to other people or property.
- *BEFORE* using the unit, always inspect it for problems. If something is wrong, *DO NOT USE IT*. Fix the problem before using the unit to prevent possible injury.
- *WHILE* using the unit, if something is found to be wrong, *STOP* using it. Fix the problem before the unit is used again.
- Run the engine *ONLY* where there is enough fresh air to prevent the buildup of carbon monoxide fumes. Carbon monoxide is colorless, odorless and deadly. *NEVER* run the unit in an enclosed space where exhaust fumes will collect.
- *NEVER* use the unit in or near an area where there may be explosive dust or fumes. The electrical and exhaust systems of this unit will make sparks that can ignite explosive materials.
- *ALWAYS* use good judgement when operating on or near hills or slopes. *NEVER* start or stop suddenly, you may cause unstable operating conditions. *NEVER* change directions abruptly or make sharp turns on slopes. *ALWAYS* drive straight up and down the face of slopes, *NEVER* across the face.
- When refueling, *ALWAYS* stop the engine and do not allow sparks or open flames anywhere near the unit. *DO NOT* overfill the fuel tank. Fuel is extremely flammable and highly explosive under certain conditions. Clean up any spilled fuel and allow the vapors to dissipate before operating the unit. Store fuel in containers specifically



## SECTION 3 ENGINE

### STARTING THE ENGINE

When starting a diesel engine for the first time, after prolonged storage or if the fuel tank is allowed to run dry, the fuel system must be bled before attempting to start the engine. Refer to Bleeding The Fuel System in the maintenance and parts manual.

After bleeding the system *(if required)*:

1. Operator must be properly seated in the operator's seat.
2. Make sure foot is off direction/speed control pedal. The reel enable switch must be in the off position before the engine will start.
3. Push hand throttle lever forward to a **"MIDDLE"** position.
4. Insert key in ignition switch and turn to **ON** position.
5. Push and hold the pre-heat switch forward. The red indicator light will come on. When the light goes out, release the pre-heat switch and start the engine (If the engine has been running and is already warm, there should be no need to pre heat the glow plugs).
6. After the engine starts, allow it to warm up for at least one minute.

### NOTICE

- The starter motor should never be run for more than 10 seconds. If the engine does not start after operating the starter for 10 seconds, stop the starter. Wait for 30 seconds and repeat the start sequence.
  - Do not use ether or starter fluid; severe engine damage may occur.
7. After the engine starts, check the following:
    - Make sure the oil pressure light goes off
    - The exhaust should be colorless or slightly dark when engine is under load

### NOTICE

- If the oil light or water temperature light and buzzer come on during operation, stop the engine immediately. To avoid serious engine damage, find and fix the problem before restarting.

### ENGINE BREAK-IN

All new engines require a break-in period. The service life of your engine is dependent upon how your engine is operated during the first 50 hours of operation.

1. **ALWAYS** idle and warm up your engine for at least one minute. In cold weather, allow the engine to warm up completely before operating the unit.
2. **NEVER** overload the engine.
3. Change engine oil after the first 50 hours:  
With the engine stopped and warm, drain the crankcase and remove oil filter. Install a new oil filter and refill the crankcase with proper oil.



### WARNING

- This oil change must be performed as specified and only by properly trained service personnel.
4. Refer to the Maintenance Guide for future service intervals.

## ENGINE ACCESS

The rear section of the unit can be raised for better access to the engine. Loosen the two handknobs above the rear fork. Raise the fuel tank frame. Support it by pivoting the rod beneath the fuel tank down and securing it in the cup next to the fork pivot (See Fig. 23).



### WARNING

- **DO NOT** remove the fuel tank cap while the tank is in the raised position.



Figure 23  
Rear Section of Unit Raised

## DAILY SERVICE GUIDE

## ENGINE OIL LEVEL

Damage to engines due to improper maintenance or use of incorrect oil quality and/or viscosity is not covered by the engine warranty (refer to the engine operator's manual for crankcase capacity and recommended oil grade and weight). Unit must be on a level surface to obtain an accurate oil level reading. The oil level must be kept between the two marks on the dipstick.

### NOTICE

- **DO NOT** overfill. Engine overheating and damage may result.

Figure 26  
1. Dipstick




Figure 27  
1. Oil Filler Port

### IMPORTANT!

WE RECOMMEND THAT THE FILTER ELEMENT BE REPLACED BEFORE ENGINE PERFORMANCE IS AFFECTED. THIS MAY OCCUR AT 250 HOURS OF SERVICE UNDER VERY DUSTY CONDITIONS OR AT 500 HOURS UNDER NORMAL OPERATING CONDITIONS. WE DO NOT RECOMMEND CLEANING THE FILTER ELEMENT BECAUSE OF THE POSSIBILITY OF DAMAGING IT.

### CHECKING THE ELEMENT

To check for damage, pin holes, etc. shine a light source into the end of the element. If light **CANNOT** be seen through the paper, a new element should be installed. Likewise, if pinholes of bright light appear in the paper, the element should be replaced.

### INSTALLING ELEMENT

1. Clean the dust from inside the filter housing with a damp cloth. Make sure that dust does not enter the engine air intake.
2. Check the soft gasket material at both ends of the element to be sure it is not damaged.
3. Insert the open end of the element into the housing and press it onto the air intake pipe at the back of the housing. Make sure the filter element fits over the pipe snugly and is pushed all the way on to prevent any dust from getting past the filter.
4. Install the air cleaner cover over the element with the dust collector pointing **DOWN** (dust collector empties automatically when properly installed). Secure the cover with the two wire bails (See Fig. 29).




Figure 29

1. Cover
2. Dust Collector
3. Wire Bails

## BLEEDING THE FUEL SYSTEM



### WARNING

- This procedure must be performed as specified and only by properly trained service personnel.

The fuel system must be bled when:

- Starting the engine for the first time
- The fuel tank becomes completely empty
- The engine has not been used for an extended period of time
- The fuel filter and/or fuel lines have been loosened, removed or replaced.

Primary fuel filter PN 825619  
Secondary fuel filter element (See Fig. 25)

1. Fill the fuel tank.
2. Open the air vent on top of the fuel filter (See Fig. 25).
3. Without preheating the glow plugs, turn the ignition switch to START to operate the fuel pump. Allow the starter to run the pump until a steady stream of fuel is coming out of the fuel filter air vent. Stop the starter and close the air vent.

PN 840161




Figure 25

1. Fuel Filter Air Vent
2. Secondary fuel filter

4. Open the air vent on top of the injection pump, open air vent only when engine is NOT running (See Fig. 26).




Figure 26

1. Injection Pump Air Vent

5. Without preheating the glow plugs, turn the ignition switch to START to operate the fuel pump. Allow the starter to run the pump until a steady stream of fuel is coming out of the injection pump air vent. Stop the starter and close the air vent.



### WARNING

- Catch fuel and dispose of properly.
- To avoid a fire hazard, clean up any spilled fuel.

## **SECTION 4 DRIVE TRAIN**

**THIS SECTION INTENTIONALLY LEFT BLANK**




## SECTION 5 BRAKE SYSTEM

### PARKING BRAKE PEDAL

The **Parking Brake** can be engaged by depressing the brake pedal until the unit is at a complete stop. Once the unit is stopped, push the parking brake latch forward to hold the brake pedal. Disengage the parking brake by depressing and releasing the brake pedal.

It is important to note on the ZX series machines and machines that have been updated using kit LMAB 973, the parking brake must be depressed to enable the machine to start.



1. Brake Pedal
2. Park Brake Latch



## **SECTION 6 STEERING**

**THIS SECTION INTENTIONALLY LEFT BLANK**



## SECTION 7

# WHEELS AND TYRES

### TYRE PRESSURE



CAUTION

- Caution must be used when inflating a low tyre to recommended pressure. Check pressure with a low pressure tire gauge before connecting an air hose to a partly inflated tire.



CAUTION

- Due to the low air volume requirements of a small tyre, over inflation may be reached in a matter of a few seconds, which could cause the tire to explode.

| COLD INFLATION PRESSURE |                  |
|-------------------------|------------------|
| All Tires               | 9 PSI (60.3 kPa) |

### NOTICE

- Improper inflation will reduce tire life considerably



## SECTION 8 HYDRAULICS FOR WB SERIES

|     |                                           |       |
|-----|-------------------------------------------|-------|
| 8A. | Repair, Service Tools and Materials ..... | 8A-3  |
| 8B. | Steering and Lift Hydraulic Circuit ..... | 8B-5  |
|     | Specifications .....                      | 8B-5  |
|     | Hydraulic Circuit (Master) .....          | 8B-6  |
|     | All Drives In Neutral .....               | 8B-7  |
|     | Steering To One side .....                | 8B-8  |
|     | Front Units Raises .....                  | 8B-9  |
|     | Centre Units Raise .....                  | 8B-10 |
|     | Front Units Lower .....                   | 8B-11 |
| 8C. | Cutting Circuit .....                     | 8C-13 |
|     | Specifications .....                      | 8C-13 |
|     | Circuit Description .....                 | 8C-13 |
|     | Reels Engaged Forward .....               | 8C-14 |
|     | Backlap .....                             | 8C-15 |
| 8D. | Transmission Circuit .....                | 8D-17 |
|     | Specifications .....                      | 8D-17 |
|     | Circuit Description .....                 | 8D-17 |
|     | Transmission Forward .....                | 8D-18 |
|     | Transmission Forward 3WD .....            | 8D-19 |
|     | Transmission Reverse .....                | 8D-20 |
|     | All Drives in Neural .....                | 8D-21 |



## SECTION 8A. REPAIR, SERVICE TOOLS AND MATERIALS

**Tools required:** Standard automotive hand tools, including torque wrench, seal drivers, circlip pliers and bearing driver.

**Tachometer** (Photo/Mechanical)  
Obtain from local supplier or,  
Graham and White Instruments  
135 Hatfield Road  
St. Albans  
Herts.  
AL1 4LZ  
United Kingdom  
Tel: 01727 841692

| <u>Part number</u> | <u>Description</u>                                                                                                                           |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| A810957            | <b>Hydraulic Flow meter</b> equipped with loading valve.                                                                                     |
| A808947            | <b>Fittings kit</b> (7/8" JIC to assorted ORFS sizes)                                                                                        |
| A810938            | <b>Pressure Gauge test kit.</b> 1 x 0-6000psi gauge, 1 x 0-600psi gauge, 2 x rubber covers for gauges and 1 x micro-bore connector hose.     |
| A810954            | <b>0-600psi pressure gauge</b>                                                                                                               |
| A810955            | <b>0-6000psi pressure gauge</b>                                                                                                              |
| A810939            | <b>Micro-bore connector hose</b> for pressure gauges                                                                                         |
| 2695493            | <b>Flushing Filter.</b> Flow capacity 230 ltrs/min, pressure capacity 6085psi (414 Bar), filtration 10 micron and condition indicator gauge. |
| 2695483            | <b>Replacement element</b> for flushing filter                                                                                               |
| A810953            | <b>Belt tension tester</b>                                                                                                                   |

**Cleaning Materials:** Stoddard or equivalent solvent  
Detergent and water  
Loctite " Locquic" Primer " T"

**Lubricants:** See section 11

**Other service items:** Seal and repair kits (available from Textron distributors)  
Liquid gasket  
Loctite 242 Blue



## SECTION 8B. STEERING AND LIFT CIRCUIT

## SPECIFICATIONS

|                        |                                                                                                                |
|------------------------|----------------------------------------------------------------------------------------------------------------|
| Pump:                  | Charge pump of the Sundstrand Series 15 Transmission pump. 5.4 cc/rev 18.3 litres/min at 3400rpm engine speed. |
| Steering valve:        | Eaton five port valve.                                                                                         |
| Steering Relief Valve: | Implement valve fitted to the Sundstrand Series 15 Transmission pump.<br>69 bar (1000psi)                      |
| Speed restrictors:     | 1.27mm (0.050") in both lines to centre unit ram, one being located in the Sequence valve.                     |

## CIRCUIT DESCRIPTION

NOTE: All hydraulic pump outputs and pressures are given with the engine at maximum rpm and with the oil at working temperature.

Oil is drawn into the charge pump from the hydraulic reservoir (**Shell Tellus 46** grade or equivalent) via the 25 micron suction filter. The oil is displaced by the (5.4cc) gerotor pump at a rate of **18.3 litres/min**, at an engine speed of **3400 rpm**.

From the pump the oil flows to the “P” port of the Eaton steering valve. When turning the steering wheel oil is fed from the valve to the double acting ram at the rear of the machine. Oil displaced from the other side of the ram returns to the hydraulic reservoir via port “T” of the steering valve. The maximum pressure available for steering is **1000psi**. An implement valve located in the Transmission pump controls this pressure.

If the steering wheel is not being turned then the oil flows out of steering valve from the “PB” port to the “P” port of the lift valve. If the lift levers are not being used oil flows past the spools out of the “T” port of the lift valve to the oil cooler and then on to the hydraulic reservoir.

When raising units the rear of the foot pedal is pressed which energises the lift valve solenoid thus moving the spools to feed oil out of the “A” port opening the check valve as it does so. The oil then goes to the front rams, which extend and raise the units. The flow combiner/divider ensures that the front rams lift at equal speed by controlling the rate that oil is displaced from the rams. The oil also goes to the centre ram but as the sequence valve is closed it prevents oil within the ram from being displaced so the unit cannot lift.

After a short delay the sequence valve opens allowing the centre unit to raise. The oil flow to the centre unit ram and from the sequence valve is restricted to slow the raise speed. Oil displaced by the rams goes through valve port “B” before returning to the oil cooler and reservoir.

If the Operator continues to press the foot pedal the pressure would build until the **1000psi** implement relief blows. When the pedal is released the oil is trapped between the rams and the check valve preventing the units from dropping.

Pressing the front of the foot pedal energises the lower solenoid on the lift valve moving the spool and allowing oil to flow out of port “B”. At the same time the check valve in port “A” is lifted off its seat via a pilot line. Oil flows to the front rams via the flow combiner/divider ensuring the units lower at the same rate. Oil also flows to the sequence valve but this is closed initially.


After a short delay the sequence valve opens and the centre unit lowers, it’s speed controlled by the restriction created by the orifice in the line to the valve and another fitted in the line from the ram. Oil displaced from the rams has to pass through the open check valve in port “A” before returning to the oil cooler and reservoir.

Flotation of the units whilst cutting is not restricted in any way by the rams as they locate in slots in the unit arms allowing full articulation.


IMPORTANT NOTE: When turning the steering wheel on a continuous full lock the implement valve will blow and this will prevent the lift circuit from working. This is a characteristic of the circuit that should not present a problem when the machine is used as intended.

# HYDRAULICS

## SECTION 8B. STEERING AND LIFT CIRCUIT




SECTION 8B. STEERING AND LIFT CIRCUIT




# HYDRAULICS

## SECTION 8B. STEERING AND LIFT CIRCUIT




SECTION 8B. STEERING AND LIFT CIRCUIT




8B

# HYDRAULICS

## SECTION 8B. STEERING AND LIFT CIRCUIT




## SECTION 8B. STEERING AND LIFT CIRCUIT



# HYDRAULICS

## SECTION 8B. STEERING AND LIFT CIRCUIT



SECTION 8C. CUTTING CIRCUIT

---

## SPECIFICATIONS

Pump: Haldex Barnes Corporation W900 8cc/rev 27.2litres/min @ 3400rpm engine speed.  
Cutter Relief valve: 207bar (3000psi)  
Motors: Haldex Barnes Corporation W600 12cc Bi-directional 2190rpm @ 3400rpm engine speed.

## CIRCUIT DESCRIPTION

*NOTE: All hydraulic pump outputs and pressures are given with the engine at maximum rpm and with the oil at working temperature.*

Oil is drawn into the cutting pump from the hydraulic reservoir (**Shell Tellus 46** grade or equivalent) via the 25 micron suction filter. This oil is displaced by the twin gear pump (8cc) at a rate of **27.2 ltrs/min**, at an engine speed of **3400rpm**.


From the pump the oil flows to the **“P”** port of the Reel drive valve. If reel drive is not enabled the oil passes through the solenoid valve and returns to the hydraulic reservoir from the **“T”** port via the cooler.

If the Reel drive is enabled (and the units lowered) the solenoid valve closes and the oil then flows from **“M”** port to the Reel motors via the back-lap valve. If forward drive has been selected the oil goes to the front right hand unit, the front left hand unit and then to the centre unit before returning to the back-lap valve, the cooler and the reservoir.


Within the Reel drive valve is a variable speed control that comprises a needle valve and a pilot operated spool valve. Rotating the knurled head of the needle valve allows a proportion of the oil to return to the reservoir reducing reel speed. The pilot operated pressure compensating spool valve ensures that the selected speed is maintained regardless of changes in loading.

If one of the Reels becomes jammed by a shoe spike or tee peg then the pressure within the circuit will quickly increase until it reaches **207bar (3000psi)** at which point the relief valve will open allowing oil to return to the reservoir via the cooler. All reels will then stop rotating.

**SAFETY NOTE:** To avoid the possibility of serious injury, switch the reel enable switch to off, stop the engine, remove the key and set the parking brake before attempting to release the obstruction. Never rotate the reel by pushing with your hands or fingers as energy can be released suddenly resulting in serious injury. Instead use a suitable length of softwood to ease the obstruction free.



## SECTION 8C. CUTTING CIRCUIT





**SPECIFICATIONS**

|                      |                                                                                              |
|----------------------|----------------------------------------------------------------------------------------------|
| Pump:                | Sundstrand 15 series, 15 cc/rev. maximum, <b>51 litres/min @ 3400rpm</b> engine speed.       |
| Charge (boost) pump: | Integral part of transmission pump. 5.4cc/rev, <b>18.3litres/min @ 3400rpm</b> engine speed. |
| Charge relief valve: | <b>10.3 bar (150psi)</b>                                                                     |
| Wheel motors:        | Parker Ross ME10 169cc                                                                       |
| Optional 3WD:        | Parker Ross ME21 338cc                                                                       |


**CIRCUIT DESCRIPTION**


*NOTE: All hydraulic pump outputs and pressures are given with the engine at maximum rpm and with the oil at working temperature.*


The foot pedal mounted on the right hand side of the platform is linked to the Transmission pump by cable. A simple spring return system is provided to ensure the pump returns to a neutral position. Movement of the pedal results directly in a corresponding movement of the transmission pump's swash-plate. The transmission system is not protected by any form of shock or relief valve. This is considered unnecessary, as overloading the system will result in spinning the slick tyres.


Oil from the pump goes to a tee, which supplies both front motors before returning to the pump. The front right hand motor has an oil shuttle that sets up an exchange of oil at a rate of **4 litres/minute** joining that going to the steering and lift circuit. This oil is replaced within the transmission pump by cooler, filtered oil by the charge pump. This works whether forward or reverse drive is selected.

Third wheel drive is available as an optional accessory. A rear wheel motor of twice the capacity of the front motors is connected in what is the return line to the pump in forward drive. As the oil has already driven the front wheels in parallel this larger motor rotates at the same speed. A check valve ensures that the rear motor can freewheel during severe hydrostatic braking on steep descents or when reversing.












## **SECTION 8**

# **HYDRAULICS FOR ZV SERIES**

Master Hydraulic Schematic Diagrams

ZV Series machines fitted with pressure switch and variable needle valve.

## Hydraulic Circuit (Master)




## **SECTION 8**

# **HYDRAULICS FOR DP SERIES**


### Hydraulic Schematic Diagrams

DP Series machines fitted with Bi-directional relief valve (no pressure switch, as used with the new timed lift/lower pic module).


# Hydraulic Circuit (Master)




# All drives in neutral




# Steering to one side




# Lift Units




# Lower Units




# Reels Engage Forward



# Transmission Forward



# Transmission Reverse





## **SECTION 8**


# **HYDRAULICS - FN & FJ SERIES**

Hydraulic Schematic Diagrams


FN & FJ Series machines fitted with new cutting and lift circuit (Plus 1 Controller)




# Hydraulic Circuit (Master)




All Drives in Neutral




Transmission Forward







# Steering to One Side





# Lower Units






# Lift Units






# 3WD Circuit (Forward)

- Pressure
- Return
- Case
- Charge
- Suction



# 3WD Circuit (Reverse)

- Pressure
- Return
- Case
- Charge
- Suction





# SECTION 10

## ELECTRICAL SYSTEM

### US (WD) Series

|                                                                      |        |
|----------------------------------------------------------------------|--------|
| <b>10A.</b> Repair, Service Tools and Materials .....                | 10A-3  |
| <b>10C.</b> Schematic diagrams .....                                 | 10C-5  |
| Engine management and mow system ( <b>USA. Specification</b> ) ..... | 10C-5  |
| Off Position .....                                                   | 10C-6  |
| Pre Heat Switch Pressed -1st 5 Seconds .....                         | 10C-7  |
| Pre Heat Switch Pressed -After 5 Seconds .....                       | 10C-8  |
| Start Engine Crank .....                                             | 10C-9  |
| Engine Running .....                                                 | 10C-10 |
| Sit In seat Drive Machine To Green .....                             | 10C-11 |
| Engage Reel Enable Switch .....                                      | 10C-12 |
| Depress LowerEngage Reel Enable Switch .....                         | 10C-13 |
| Centre units Lowers .....                                            | 10C-14 |
| Rear unit lowered Reels Engaged .....                                | 10C-15 |
| Depress Raise Pedal-F/Units Start To Raise .....                     | 10C-16 |
| Rear Units Start To Raise-Reels Stop .....                           | 10C-17 |
| Rear Units Fully Raise Position .....                                | 10C-18 |
| Off Position-Initial 3 Seconds .....                                 | 10C-19 |




**Tools required:** Digital Multimeter  
Jumper wires  
60 amp Ammeter  
Battery Tester

**Cleaning Materials:** Baking soda and water  
Water repellent (WD40)

**Other service items:** Electrical insulation compound




Greensplex II - Electric circuit



## SECTION 10C. USA. ELECTRIC SCHEMATIC DIAGRAMS






## SECTION 10C. USA. ELECTRIC SCHEMATIC DIAGRAMS




## Start engine (Crank)




# ELECTRICAL SYSTEM

## SECTION 10C. USA. ELECTRIC SCHEMATIC DIAGRAMS

### Engine running




## Sit in seat - drive machine to green




# ELECTRICAL SYSTEM

## SECTION 10C. USA. ELECTRIC SCHEMATIC DIAGRAMS

### Engage reel enable switch



Depress lower pedal (lower switch)




**10C**


# ELECTRICAL SYSTEM

## SECTION 10C. USA. ELECTRIC SCHEMATIC DIAGRAMS

### Centre unit lowers



Rear unit lowered, reels engaged




10C

## SECTION 10C. USA. ELECTRIC SCHEMATIC DIAGRAMS



## Rear unit starts to raise - reels stop



## SECTION 10C. USA. ELECTRIC SCHEMATIC DIAGRAMS


The diagram illustrates the electrical system of a vehicle, featuring a battery, alternator, and various control components. The wiring is color-coded and labeled with wire types (e.g., W/R, W/B, W/Y) and gauges (e.g., 30 amp, 20 amp). Key components include:

- Battery:** Connected to the main power line.
- Alternator:** Provides charging power, connected via an ammeter.
- Starter Motor:** Controlled by a solenoid and starter relay.
- Fuel System:** Includes a fuel pump, fuel solenoid, and various sensors (TP S oil temp sender, TPS oil level sender).
- Lighting:** Includes headlights, pre-heat lamp, and water temp lamp.
- Controls:** Includes a key switch, sequence relay, sequence sol, and various limit switches (Rear Up limit, Rear down limit).
- Sensors:** Includes an oil pressure switch, water temp gauge, and water temp sender.

**Key Switch Legend:**

| Key Switch | Bat | AC | St | Ign |
|------------|-----|----|----|-----|
| Off        | ◇   | ◇  | ◇  | ◇   |
| Start      | ◇   | ◇  | ◇  | ◇   |
| On         | ◇   | ◇  | ◇  | ◇   |
| Acc        | ◇   | ◇  | ◇  | ◇   |

Off position - Initial 3 seconds






# SECTION 10

## ELECTRICAL SYSTEM


### WD Series with Paddle Control

11/11/2011


# GreensPlex 2 Electric Circuit version 2 Pic module




# GreensPlex 2 Electric Circuit version 2 Pic module



# GreensPlex 2 Electric Circuit version 2 Pic module




# GreensPlex 2 Electric Circuit version 2 Pic module




Run, PTO on, reels lower using paddle lever

# GreensPlex 2 Electric Circuit version 2 Pic module



Run, PTO on, reels lowering, rear unit lowering


# GreensPlex 2 Electric Circuit version 2 Pic module




Key Switch

Run, PTO on, all reels lowered


# GreensPlex 2 Electric Circuit version 2 Pic m module



# GreensPlex 2 Electric Circuit version 2 Pic module



# GreensPlex 2 Electric Circuit version 2 Pic module



Run, PTO on, all units raised


# SECTION 10

## ELECTRICAL SYSTEM

### ZV Series with Paddle Control


|                                                             |  |
|-------------------------------------------------------------|--|
| Schematic diagrams .....                                    |  |
| Off Position .....                                          |  |
| Pre Heat Switch .....                                       |  |
| Start Engine Crank .....                                    |  |
| Engine Running, brake applied, PTO off .....                |  |
| Engine Running, sit in seat, release brake, in drive .....  |  |
| Engine running, PTO on, lower units using foot switch ..... |  |
| Activate pressure switch .....                              |  |
| Engine running,PTO on, raise using paddle .....             |  |
| Activate pressure switch .....                              |  |

# GreensPlex II Electric Circuit - V3 PIC Module




Ignition Key Off


# Ignition Key Off




# Ignition Key Off, Pre Heat Switch On




# Ignition Key Start




# Engine Running, Brake Applied, & PTO Switch Off




# Sit in seat, release brake,& drive machine



# Lower Cutting Units Using Foot Switch, Reels Engage




# Activate L/L Stop Pressure Switch




Reels Engaged (Mowing)


# Reels Engaged (Mowing)



# Raise Cutting Units Using Paddle Switch, Reels Engaged



# Activate L/L Stop Pressure Switch



Key Switch

End

**SECTION 10**  
**ELECTRICAL SYSTEM**  
**DP Series with Paddle Control**

Schematic diagrams .....

Hot.....

Ignition.....

Start Engine.....


Engine Running, Brake Applied.....

Drive to Green, PTO Switch ON.....

Lower Units (Paddle) onto Green PTO ON.....

Raise Units (Foot) PTO ON.....





With the 2 pole plug connected the time for raise will be 2 seconds. With plug removed the time will revert to 5 seconds raise duration.


ALTERNATOR


Hot 2 of 2

SPLIT TO  
INST PNL #1

SPLIT TO  
INST PNL #2

SPLIT TO  
INST PNL #3






## Ignition 1 of 2


## Ignition 2 of 2

SPLIT TO  
INST PNL #1

SPLIT TO  
INST PNL #2

SPLIT TO  
INST PNL #3






Start Engine 1 of 2


With the 2 pole plug connected the time for raise will be 2 seconds. With plug removed the time will revert to 5 seconds raise duration.

## Start Engine 2 of 2



SPLIT TO  
INST PNL #1




SPLIT TO  
INST PNL #2




SPLIT TO  
INST PNL #3






Engine Running & Brake Applied 1 of 2

Engine Running & Brake Applied 2 of 2







Drive to Green, PTO Switch ON 1 of 2

## Drive to Green, PTO Switch ON 2 of 2


SPLIT TO  
INST PNL #1






SPLIT TO  
INST PNL #2




SPLIT TO  
INST PNL #3





ALTERNATOR






Lower Units (Paddle) onto Green PTO ON 2 of 2





**Raise Units (Foot) PTO ON 1 of 2**

Raise Units (Foot) PTO ON 2 of 2












**SECTION 10**  
**ELECTRICAL SYSTEM**  
**FH Series - Diesel Engine**

Schematic diagrams .....






G-PLEX III  
FN SERIES  
DIESEL POWERED




Wire Colour Chart

|    |   |             |
|----|---|-------------|
| B  | - | Black       |
| G  | - | Green       |
| K  | - | Pink        |
| LG | - | Light Green |
| N  | - | Brown       |
| O  | - | Orange      |
| R  | - | Red         |
| S  | - | Slate/Gray  |
| U  | - | Blue        |
| V  | - | Violet      |
| W  | - | White       |




G-PLEX III  
FN SERIES  
DIESEL POWERED




Wire Colour Chart

|    |   |             |
|----|---|-------------|
| B  | - | Black       |
| G  | - | Green       |
| K  | - | Pink        |
| LG | - | Light Green |
| N  | - | Brown       |
| O  | - | Orange      |
| R  | - | Red         |
| S  | - | Slate/Gray  |
| U  | - | Blue        |
| V  | - | Violet      |
| W  | - | White       |




G-PLEX III  
FN SERIES  
DIESEL POWERED




G-PLEX III  
FN SERIES  
DIESEL POWERED

Seat Switch ON  
Park Brake ON  
Reel (PTO) Switch OFF


ELECTRIC DIAGRAM  
IGNITION ON



Wire Colour Chart  
B - Black  
G - Green  
K - Pink  
LG - Light Green  
N - Brown  
O - Orange  
R - Red  
S - Slate/Gray  
U - Blue  
V - Violet  
W - White



G-PLEX III  
FN SERIES  
DIESEL POWERED




Seat Switch ON  
Park Brake ON  
Reel (PTO) Switch OFF

## ELECTRIC DIAGRAM CRANKING ENGINE

G-PLEX III  
FN SERIES  
DIESEL POWERED


Seat Switch ON  
Park Brake ON  
Reel (PTO) Switch OFF

ELECTRIC DIAGRAM  
CRANKING ENGINE




Wire Colour Chart

|    |   |             |
|----|---|-------------|
| B  | - | Black       |
| G  | - | Green       |
| K  | - | Pink        |
| LG | - | Light Green |
| N  | - | Brown       |
| O  | - | Orange      |
| R  | - | Red         |
| S  | - | Slate/Gray  |
| U  | - | Blue        |
| V  | - | Violet      |
| W  | - | White       |




G-PLEX III  
FN SERIES  
DIESEL POWERED




G-PLEX III  
FN SERIES  
DIESEL POWERED

Seat Switch ON  
Park Brake OFF  
Reel (PTO) Switch OFF


ELECTRIC DIAGRAM  
ENGINE RUNNING  
DRIVE TO GREEN  
2 of 2



Wire Colour Chart  
B - Black  
G - Green  
K - Pink  
LG - Light Green  
N - Brown  
O - Orange  
R - Red  
S - Slate/Gray  
U - Blue  
V - Violet  
W - White



G-PLEX III  
FN SERIES  
DIESEL POWERED




Seat Switch ON  
Park Brake OFF  
Reel (PTO) Switch ON

ELECTRIC DIAGRAM  
MOWING - LOWER UNITS  
USING PADDLE  
1 of 2

G-PLEX III  
FN SERIES  
DIESEL POWERED


Seat Switch ON  
Park Brake OFF  
Reel (PTO) Switch ON

ELECTRIC DIAGRAM  
MOWING - LOWER UNITS  
USING PADDLE




Wire Colour Chart

|    |   |             |
|----|---|-------------|
| B  | - | Black       |
| G  | - | Green       |
| K  | - | Pink        |
| LG | - | Light Green |
| N  | - | Brown       |
| O  | - | Orange      |
| R  | - | Red         |
| S  | - | Slate/Gray  |
| U  | - | Blue        |
| V  | - | Violet      |
| W  | - | White       |




Heat Switch ON  
Park Brake OFF  
Wheel (PTO) Switch ON



G-PLEX III  
FN SERIES  
DIESEL POWERED


Seat Switch ON  
Park Brake OFF  
Reel (PTO) Switch ON

ELECTRIC DIAGRAM  
MOWING - RAISE UNITS  
USING FOOT




Wire Colour Chart

|    |   |             |
|----|---|-------------|
| B  | - | Black       |
| G  | - | Green       |
| K  | - | Pink        |
| LG | - | Light Green |
| N  | - | Brown       |
| O  | - | Orange      |
| R  | - | Red         |
| S  | - | Slate/Gray  |
| U  | - | Blue        |
| V  | - | Violet      |
| W  | - | White       |






G-PLEX III  
FN SERIES  
DIESEL POWERED



NOTE:  
When the Shutdown Timer gives an output to the Fuel Solenoid for 7 sec (approx), it shuts off the fuel supply.

Wire Colour Chart

|    |   |             |
|----|---|-------------|
| B  | - | Black       |
| G  | - | Green       |
| K  | - | Pink        |
| LG | - | Light Green |
| N  | - | Brown       |
| O  | - | Orange      |
| R  | - | Red         |
| S  | - | Slate/Gray  |
| U  | - | Blue        |
| V  | - | Violet      |
| W  | - | White       |








**SECTION 10**  
**ELECTRICAL SYSTEM**  
**FJ Series - Petrol Engine**

Schematic diagrams .....








G-PLEX III  
FN SERIES  
PETROL POWERED




G-PLEX III  
FN SERIES  
PETROL POWERED



G-PLEX III  
FN SERIES  
PETROL POWERED



G-PLEX III  
FN SERIES  
PETROL POWERED





Seat Switch ON  
Park Brake OFF  
Reel (PTO) Switch OFF

ELECTRIC DIAGRAM  
IGNITION ON

G-PLEX III  
FN SERIES  
PETROL POWERED

Seat Switch ON  
Park Brake OFF  
Reel (PTO) Switch OFF


ELECTRIC DIAGRAM  
IGNITION ON



Wire Colour Chart

|    |   |             |
|----|---|-------------|
| B  | - | Black       |
| G  | - | Green       |
| K  | - | Pink        |
| LG | - | Light Green |
| N  | - | Brown       |
| O  | - | Orange      |
| R  | - | Red         |
| S  | - | Slate/Gray  |
| U  | - | Blue        |
| V  | - | Violet      |
| W  | - | White       |

G-PLEX III  
FN SERIES  
PETROL POWERED





Seat Switch ON  
Park Brake ON  
Reel (PTO) Switch OFF

ELECTRIC DIAGRAM  
CRANK ENGINE


G-PLEX III  
FN SERIES  
PETROL POWERED

Seat Switch ON  
Park Brake ON  
Reel (PTO) Switch OFF

ELECTRIC DIAGRAM  
CRANK ENGINE







G-PLEX III  
FN SERIES  
PETROL POWERED



Seat Switch ON  
Park Brake OFF  
Reel (PTO) Switch OFF

ELECTRIC DIAGRAM  
ENGINE RUNNING  
DRIVE TO GREEN  
1 of 2

G-PLEX III  
FN SERIES  
PETROL POWERED




**Wire Colour Chart**

|           |   |                    |
|-----------|---|--------------------|
| <i>B</i>  | - | <i>Black</i>       |
| <i>G</i>  | - | <i>Green</i>       |
| <i>K</i>  | - | <i>Pink</i>        |
| <i>LG</i> | - | <i>Light Green</i> |
| <i>N</i>  | - | <i>Brown</i>       |
| <i>O</i>  | - | <i>Orange</i>      |
| <i>R</i>  | - | <i>Red</i>         |
| <i>S</i>  | - | <i>Slate/Gray</i>  |
| <i>U</i>  | - | <i>Blue</i>        |
| <i>V</i>  | - | <i>Violet</i>      |
| <i>W</i>  | - | <i>White</i>       |

ELECTRIC DIAGRAM  
ENGINE RUNNING  
DRIVE TO GREEN  
2 of 2

G-PLEX III  
FN SERIES  
PETROL POWERED





Seat Switch ON  
Park Brake OFF  
Reel (PTO) Switch ON

G-PLEX III  
FN SERIES  
PETROL POWERED

Seat Switch ON  
Park Brake OFF  
Reel (PTO) Switch ON


ELECTRIC DIAGRAM  
MOWING - LOWER UNITS  
USING PADDLE  
2 of 2



Wire Colour Chart

|    |               |
|----|---------------|
| B  | - Black       |
| G  | - Green       |
| K  | - Pink        |
| LG | - Light Green |
| N  | - Brown       |
| O  | - Orange      |
| R  | - Red         |
| S  | - Slate/Gray  |
| U  | - Blue        |
| V  | - Violet      |
| W  | - White       |

G-PLEX III  
FN SERIES  
PETROL POWERED





Seat Switch ON  
Park Brake OFF  
Reel (PTO) Switch ON

ELECTRIC DIAGRAM  
MOWING - RAISE UNITS  
USING FOOT  
1 of 2

G-PLEX III  
FN SERIES  
PETROL POWERED

Seat Switch ON  
Park Brake OFF  
Reel (PTO) Switch ON

ELECTRIC DIAGRAM  
MOWING - RAISE UNITS  
USING FOOT  
2 of 2



Wire Colour Chart  
B - Black  
G - Green  
K - Pink  
LG - Light Green  
N - Brown  
O - Orange  
R - Red  
S - Slate/Gray  
U - Blue  
V - Violet  
W - White




# SECTION 11

## PREVENTATIVE MAINTENANCE

### LUBE CHART

NOTICE

Lubricate sparingly with a lithium based lubricant. Excess lubrication may drop from unit and cause turf damage.





## SECTION 15 NOTES

[illegible]



[illegible]



[illegible]



[illegible]



[illegible]



## NOTES

[illegible]



[illegible]



[illegible]

## Material Up-date Sheet

[illegible]