



Toro Valve Bank Seal Installer

11/12/01



This is a trick I learned working at the local Toro Distributors. It's using these two bushings to help install the seals in the valve bank.



The bushings are Toro part numbers 256-185 and 256-237. They fit together great.



Remove the valve cover and clean out the old seal.



Start installing the new seal. This is about the point where you normally get your little pick and screwdriver.



Instead, slide the larger bushing over the seal. Sometimes I have to start with the seal inside the bushing.



Next, slide in the smaller bushing and use it to push in the seal. The larger bushing keeps the lip from catching.



I found the gentleman who came up with this. Bill Berdnick of Wesco Turf in Sarasota, Florida. Pretty outstanding